

# LPC-NG Installation Guide



# This document must be used for training purposes only.

No part of this manual may be reproduced in any form, by any means, without the prior written permission of Airbus SAS.




1, rond-point Maurice Bellonte 31707 Blagnac Cedex FRANCE

© AIRBUS S.A.S 2015. All rights reserved.



« Please consider your environmental responsibility before printing this document »





# **REVISION STATUS**

ISSUE	ISSUER	DATE	REASON FOR REVISION
01	Guy IZARD	02/04/2014	Document creation
02	Albéric BERNARD	20/02/2015	Include EFB event panel, Patch and
			associated installation guide
03	Stephane	08/01/2016	Update the document with the new media
	SENNEGON		name.
04	Stephane	15/05/2017	Update the document remove the
	SENNEGON		EventPanel installation chapter



## **TABLE OF CONTENT**

#### **PAGE**

1.	PRE-INSTALLATION OPERATION	. 2
2.	INSTALLATION	. 4
3	I AUNCH THE LPC-NG	6





This installation must be done with an account that has administrator rights.

No supported with Windows 10.

# 1. Pre-Installation operation




This operation should be already done if you have previously installed another version of LPC-NG.


Delete the old directory "LPC-NG5.1.4-XWB-ME" with right click and delete. In this case you can ignore this chapter and continue to the installation Chapter.

- Airbus folder creation
   On C:\ create a folder Airbus
- 2) Give rights to the Airbus folder

Right click on C:\Airbus folder and Select Properties.








3) From the Installation media Copy jre16017 folder under C:\Airbus (if not present).

**DATE: May 2017** 




# 2. Installation

### Step 1: From the "FSA XWB Me" media run: LPC-NG5.1.4-XWB-ME\lpcng-setup.exe




**DATE:** May 2017










Note: On the Desktop delete the LPC-NG-GROUND.exe Shortcut in: "C:\ProgramData\Microsoft\Windows\Start Menu\Programs\Airbus\LPC-NG\ LPC-NG5.1.4-XWB-ME"

# 3. LAUNCH the LPC-NG

Step 1: Run C:\Airbus\LPC-NG5.1.4-XWB-ME\LPC-NG.exe





Be patient, this operation can take several minutes.

Select A350:





When LPC-NG is available, click on EFB, then go down in order to select EXIT SESSION



#### Confirm by clicking on **OK**

