Hardware Locality (hwloc) 1.11.0rc2

Generated by Doxygen 1.8.9.1

Sun Jun 14 2015 21:56:30

Contents

4 Environment Variables

1	Hard	ware Locality	1
	1.1	Introduction	1
	1.2	Installation	2
	1.3	CLI Examples	3
	1.4	Programming Interface	6
		1.4.1 Portability	6
		1.4.2 API Example	10
	1.5	Questions and Bugs	13
	1.6	History / Credits	13
	1.7	Further Reading	13
_			
2	Term	ns and Definitions	15
3	Com	mand-Line Tools	19
	3.1	Istopo and Istopo-no-graphics	19
	3.2	hwloc-bind	19
	3.3	hwloc-calc	19
	3.4	hwloc-info	20
	3.5	hwloc-distrib	20
	3.6	hwloc-ps	20
	3.7	hwloc-gather-topology	20
	3.8	hwloc-distances	20
	3.9	hwloc-annotate	20
	3.10	hwloc-diff and hwloc-patch	20
	3.11	hwloc-compress-dir	21
	3.12	hwloc-assembler	21
	3.13	hwloc-assembler-remote	21

23

iv CONTENTS

5	CPU	and Memory Binding Overview	25	
6	I/O Devices			
	6.1	Enabling and requirements	27	
	6.2	I/O object hierarchy	27	
	6.3	Software devices	28	
	6.4	Consulting I/O devices and binding	28	
	6.5	Examples	29	
7	Misc	rellaneous objects	31	
	7.1	Misc objects added by hwloc	31	
	7.2	Annotating topologies with Misc objects	31	
8	Multi	i-node Topologies	33	
	8.1	Multi-node Objects Specifities	33	
	8.2	Assembling topologies with command-line tools	34	
	8.3	Assembling topologies with the programming interface	34	
	8.4	Example of assembly with the programming interface	34	
9	Obje	oct attributes	37	
	9.1	Normal attributes	37	
	9.2	Custom string infos	37	
10	Impo	orting and exporting topologies from/to XML files	41	
	10.1	libxml2 and minimalistic XML backends	41	
	10.2	XML import error management	42	
11 Synthetic topologies		hetic topologies	43	
	11.1	Synthetic description string	43	
	11.2	Loading a synthetic topology	44	
	11.3	Exporting a topology as a synthetic string	44	
12	Inter	operability With Other Software	45	
13	Thre	ad Safety	47	
14	Com	ponents and plugins	49	
	14.1	Components enabled by default	49	
	14.2	Selecting which components to use	50	
	14.3	Loading components from plugins	50	
	14.4	Adding new discovery components and plugins	50	

CONTENTS

	14.4.2 Registering a new discovery component	 51
	14.5 Existing components and plugins	 51
15	i Embedding hwloc in Other Software	53
	15.1 Using hwloc's M4 Embedding Capabilities	 53
	15.2 Example Embedding hwloc	 55
16	Frequently Asked Questions	57
	16.1 I do not want hwloc to rediscover my enormous machine topology every time I rerun a process	 57
	16.2 How many topologies may I use in my program?	 57
	16.3 How to avoid memory waste when manipulating multiple similar topologies?	 57
	16.4 Why is Istopo slow?	 58
	16.5 What should I do when hwloc reports "operating system" warnings?	 58
	16.6 Does hwloc require privileged access?	 58
	16.7 hwloc only has a one-dimensional view of the architecture, it ignores distances	 59
	16.8 What happens to my topology if I disable symmetric multithreading, hyper-threading, etc. ?	 59
	16.9 How may I ignore symmetric multithreading, hyper-threading, etc. ?	 59
	16.10What happens if my topology is asymmetric?	 60
	16.11 How do I annotate the topology with private notes?	 61
	16.12Why does Valgrind complain about hwloc memory leaks?	 61
	16.13How do I handle ABI breaks and API upgrades?	 61
	16.14How do I build hwloc for BlueGene/Q?	 62
	16.15How to get useful topology information on NetBSD?	 62
	16.16How do I build for Intel Xeon Phi coprocessor?	 62
17	Module Index	63
	17.1 Modules	 63
18	B Data Structure Index	65
	18.1 Data Structures	 65
19	Module Documentation	67
	19.1 API version	 67
	19.1.1 Detailed Description	 67
	19.1.2 Macro Definition Documentation	 67
	19.1.2.1 HWLOC_API_VERSION	 67
	19.1.2.2 HWLOC_COMPONENT_ABI	 67
	19.1.3 Function Documentation	 67

vi CONTENTS

		19.1.3.1 hwloc_get_api_version	. 67
19.2	Object	Sets (hwloc_cpuset_t and hwloc_nodeset_t)	. 68
	19.2.1	Detailed Description	. 68
	19.2.2	Typedef Documentation	. 68
		19.2.2.1 hwloc_const_cpuset_t	. 68
		19.2.2.2 hwloc_const_nodeset_t	. 68
		19.2.2.3 hwloc_cpuset_t	. 68
		19.2.2.4 hwloc_nodeset_t	. 68
19.3	Object	Types	. 69
	19.3.1	Detailed Description	. 69
	19.3.2	Typedef Documentation	. 69
		19.3.2.1 hwloc_obj_bridge_type_t	. 69
		19.3.2.2 hwloc_obj_cache_type_t	. 69
		19.3.2.3 hwloc_obj_osdev_type_t	. 69
	19.3.3	Enumeration Type Documentation	. 70
		19.3.3.1 hwloc_compare_types_e	. 70
		19.3.3.2 hwloc_obj_bridge_type_e	. 70
		19.3.3.3 hwloc_obj_cache_type_e	. 70
		19.3.3.4 hwloc_obj_osdev_type_e	. 70
		19.3.3.5 hwloc_obj_type_t	. 71
	19.3.4	Function Documentation	. 71
		19.3.4.1 hwloc_compare_types	. 71
19.4	Object	Structure and Attributes	. 73
	19.4.1	Detailed Description	. 73
	19.4.2	Typedef Documentation	. 73
		19.4.2.1 hwloc_obj_t	. 73
19.5	Topolog	gy Creation and Destruction	. 74
	19.5.1	Detailed Description	. 74
	19.5.2	Typedef Documentation	. 74
		19.5.2.1 hwloc_topology_t	. 74
	19.5.3	Function Documentation	. 74
		19.5.3.1 hwloc_topology_check	. 74
		19.5.3.2 hwloc_topology_destroy	. 74
		19.5.3.3 hwloc_topology_dup	. 75
		19.5.3.4 hwloc_topology_init	. 75
		19.5.3.5 hwloc_topology_load	. 75
19.6	Topolog	gy Detection Configuration and Query	. 76

CONTENTS vii

	19.6.1	Detailed Description	6
	19.6.2	Enumeration Type Documentation	7
		19.6.2.1 hwloc_topology_flags_e	7
	19.6.3	Function Documentation	7
		19.6.3.1 hwloc_topology_get_flags	7
		19.6.3.2 hwloc_topology_get_support	7
		19.6.3.3 hwloc_topology_get_userdata	'8
		19.6.3.4 hwloc_topology_ignore_all_keep_structure	'8
		19.6.3.5 hwloc_topology_ignore_type	'8
		19.6.3.6 hwloc_topology_ignore_type_keep_structure	'8
		19.6.3.7 hwloc_topology_is_thissystem	'8
		19.6.3.8 hwloc_topology_set_custom	'8
		19.6.3.9 hwloc_topology_set_distance_matrix	'9
		19.6.3.10 hwloc_topology_set_flags	'9
		19.6.3.11 hwloc_topology_set_fsroot	'9
		19.6.3.12 hwloc_topology_set_pid	'9
		19.6.3.13 hwloc_topology_set_synthetic	0
		19.6.3.14 hwloc_topology_set_userdata	0
		19.6.3.15 hwloc_topology_set_xml	0
		19.6.3.16 hwloc_topology_set_xmlbuffer	1
19.7	Object	levels, depths and types	2
	19.7.1	Detailed Description	2
	19.7.2	Enumeration Type Documentation	
		19.7.2.1 hwloc_get_type_depth_e	12
	19.7.3	Function Documentation	12
		19.7.3.1 hwloc_get_depth_type	32
		19.7.3.2 hwloc_get_nbobjs_by_depth	
		19.7.3.3 hwloc_get_nbobjs_by_type	
		19.7.3.4 hwloc_get_next_obj_by_depth	
		19.7.3.5 hwloc_get_next_obj_by_type	
		19.7.3.6 hwloc_get_obj_by_depth	3
		19.7.3.7 hwloc_get_obj_by_type	
		19.7.3.8 hwloc_get_root_obj	3
		19.7.3.9 hwloc_get_type_depth	4
		19.7.3.10 hwloc_get_type_or_above_depth	4
		19.7.3.11 hwloc_get_type_or_below_depth	
		19.7.3.12 hwloc_topology_get_depth	4

viii CONTENTS

19.8 Manipulating Object Type, Sets and Attributes as Strings
19.8.1 Detailed Description
19.8.2 Function Documentation
19.8.2.1 hwloc_obj_add_info
19.8.2.2 hwloc_obj_attr_snprintf
19.8.2.3 hwloc_obj_cpuset_snprintf
19.8.2.4 hwloc_obj_get_info_by_name
19.8.2.5 hwloc_obj_type_snprintf
19.8.2.6 hwloc_obj_type_sscanf
19.8.2.7 hwloc_obj_type_string
19.9 CPU binding
19.9.1 Detailed Description
19.9.2 Enumeration Type Documentation
19.9.2.1 hwloc_cpubind_flags_t
19.9.3 Function Documentation
19.9.3.1 hwloc_get_cpubind
19.9.3.2 hwloc_get_last_cpu_location
19.9.3.3 hwloc_get_proc_cpubind
19.9.3.4 hwloc_get_proc_last_cpu_location
19.9.3.5 hwloc_get_thread_cpubind
19.9.3.6 hwloc_set_cpubind
19.9.3.7 hwloc_set_proc_cpubind
19.9.3.8 hwloc_set_thread_cpubind
19.10Memory binding
19.10.1 Detailed Description
19.10.2 Enumeration Type Documentation
19.10.2.1 hwloc_membind_flags_t
19.10.2.2 hwloc_membind_policy_t
19.10.3 Function Documentation
19.10.3.1 hwloc_alloc
19.10.3.2 hwloc_alloc_membind
19.10.3.3 hwloc_alloc_membind_nodeset
19.10.3.4 hwloc_alloc_membind_policy
19.10.3.5 hwloc_alloc_membind_policy_nodeset
19.10.3.6 hwloc_free
19.10.3.7 hwloc_get_area_membind
19.10.3.8 hwloc_get_area_membind_nodeset

CONTENTS ix

CONTENTS

CONTENTS xi

xii CONTENTS

CONTENTS xiii

19.25.4.19hw	wloc_bitmap_isequal	133
19.25.4.20hw	wloc_bitmap_isfull	133
19.25.4.21hw	wloc_bitmap_isincluded	133
19.25.4.22hw	wloc_bitmap_isset	133
19.25.4.23hw	wloc_bitmap_iszero	133
19.25.4.24hw	wloc_bitmap_last	133
19.25.4.2 5 hw	wloc_bitmap_list_asprintf	133
19.25.4.26hw	wloc_bitmap_list_snprintf	134
19.25.4.27hw	wloc_bitmap_list_sscanf	134
19.25.4.28hw	wloc_bitmap_next	134
19.25.4.29hw	wloc_bitmap_not	134
19.25.4.30hw	wloc_bitmap_only	134
19.25.4.31hw	wloc_bitmap_or	134
19.25.4.32hw	wloc_bitmap_set	134
19.25.4.33hw	wloc_bitmap_set_ith_ulong	135
19.25.4.34hw	wloc_bitmap_set_range	135
19.25.4.35hw	wloc_bitmap_singlify	135
19.25.4.36hw	wloc_bitmap_snprintf	135
19.25.4.37hw	wloc_bitmap_sscanf	135
19.25.4.38hw	wloc_bitmap_taskset_asprintf	135
19.25.4.39hw	wloc_bitmap_taskset_snprintf	135
19.25.4.40hw	wloc_bitmap_taskset_sscanf	136
19.25.4.41hw	wloc_bitmap_to_ith_ulong	136
19.25.4.42hw	wloc_bitmap_to_ulong	136
19.25.4.43hw	wloc_bitmap_weight	136
19.25.4.44hw	wloc_bitmap_xor	136
19.25.4.45hw	wloc_bitmap_zero	136
19.26Topology differences	3	137
19.26.1 Detailed Des	scription	137
19.26.2 Typedef Doci	cumentation	138
19.26.2.1 hw	wloc_topology_diff_obj_attr_type_t	138
19.26.2.2 hw	wloc_topology_diff_t	138
19.26.2.3 hw	wloc_topology_diff_type_t	138
19.26.3 Enumeration	Type Documentation	138
19.26.3.1 hw	wloc_topology_diff_apply_flags_e	138
19.26.3.2 hw	wloc_topology_diff_obj_attr_type_e	138
19.26.3.3 hw	wloc_topology_diff_type_e	139

xiv CONTENTS

CONTENTS xv

19.30.3.4 hwloc_hide_errors
19.30.3.5 hwloc_insert_object_by_cpuset
19.30.3.6 hwloc_insert_object_by_parent
19.30.3.7 hwloc_plugin_check_namespace
19.30.3.8 hwloc_report_os_error
19.31Components and Plugins: PCI functions to be used by components
19.31.1 Detailed Description
19.31.2 Function Documentation
19.31.2.1 hwloc_insert_pci_device_list
19.31.2.2 hwloc_pci_find_cap
19.31.2.3 hwloc_pci_find_linkspeed
19.31.2.4 hwloc_pci_prepare_bridge
19.32Linux-specific helpers
19.32.1 Detailed Description
19.32.2 Function Documentation
19.32.2.1 hwloc_linux_get_tid_cpubind149
19.32.2.2 hwloc_linux_get_tid_last_cpu_location
19.32.2.3 hwloc_linux_parse_cpumap_file
19.32.2.4 hwloc_linux_set_tid_cpubind
19.33 Interoperability with Linux libnuma unsigned long masks
19.33.1 Detailed Description
19.33.2 Function Documentation
19.33.2.1 hwloc_cpuset_from_linux_libnuma_ulongs
19.33.2.2 hwloc_cpuset_to_linux_libnuma_ulongs
19.33.2.3 hwloc_nodeset_from_linux_libnuma_ulongs
19.33.2.4 hwloc_nodeset_to_linux_libnuma_ulongs
19.34Interoperability with Linux libnuma bitmask
19.34.1 Detailed Description
19.34.2 Function Documentation
19.34.2.1 hwloc_cpuset_from_linux_libnuma_bitmask
19.34.2.2 hwloc_cpuset_to_linux_libnuma_bitmask
19.34.2.3 hwloc_nodeset_from_linux_libnuma_bitmask
19.34.2.4 hwloc_nodeset_to_linux_libnuma_bitmask
19.35Interoperability with glibc sched affinity
19.35.1 Detailed Description
19.35.2 Function Documentation
19.35.2.1 hwloc_cpuset_from_glibc_sched_affinity

xvi CONTENTS

19.35.2.2 hwloc_cpuset_to_glibc_sched_affinity
19.36Interoperability with OpenCL
19.36.1 Detailed Description
19.36.2 Function Documentation
19.36.2.1 hwloc_opencl_get_device_cpuset
19.36.2.2 hwloc_opencl_get_device_osdev
19.36.2.3 hwloc_opencl_get_device_osdev_by_index
19.37Interoperability with the CUDA Driver API
19.37.1 Detailed Description
19.37.2 Function Documentation
19.37.2.1 hwloc_cuda_get_device_cpuset
19.37.2.2 hwloc_cuda_get_device_osdev
19.37.2.3 hwloc_cuda_get_device_osdev_by_index
19.37.2.4 hwloc_cuda_get_device_pci_ids
19.37.2.5 hwloc_cuda_get_device_pcidev
19.38Interoperability with the CUDA Runtime API
19.38.1 Detailed Description
19.38.2 Function Documentation
19.38.2.1 hwloc_cudart_get_device_cpuset
19.38.2.2 hwloc_cudart_get_device_osdev_by_index
19.38.2.3 hwloc_cudart_get_device_pci_ids
19.38.2.4 hwloc_cudart_get_device_pcidev
19.39Interoperability with the NVIDIA Management Library
19.39.1 Detailed Description
19.39.2 Function Documentation
19.39.2.1 hwloc_nvml_get_device_cpuset
19.39.2.2 hwloc_nvml_get_device_osdev
19.39.2.3 hwloc_nvml_get_device_osdev_by_index
19.40 Interoperability with OpenGL displays
19.40.1 Detailed Description
19.40.2 Function Documentation
19.40.2.1 hwloc_gl_get_display_by_osdev
19.40.2.2 hwloc_gl_get_display_osdev_by_name
19.40.2.3 hwloc_gl_get_display_osdev_by_port_device
19.41 Interoperability with Intel Xeon Phi (MIC)
19.41.1 Detailed Description
19.41.2 Function Documentation

CONTENTS xvii

			19.41.2.1	hwloc_intel_mic_get_device_cpuset	10	35
			19.41.2.2	hwloc_intel_mic_get_device_osdev_by_index	10	35
	19.42	2Interop	erability w	ith OpenFabrics	10	36
		19.42.1	Detailed	Description	10	36
		19.42.2	2 Function	Documentation	10	36
			19.42.2.1	hwloc_ibv_get_device_cpuset	10	36
			19.42.2.2	? hwloc_ibv_get_device_osdev	10	36
			19.42.2.3	B hwloc_ibv_get_device_osdev_by_name	10	36
	19.43	3Interop	erability w	ith Myrinet Express	10	38
		19.43.1	Detailed	Description	10	38
		19.43.2	2 Function	Documentation	10	38
			19.43.2.1	hwloc_mx_board_get_device_cpuset	10	38
			19.43.2.2	Phwloc_mx_endpoint_get_device_cpuset	10	38
20	Data	Structu	ire Docum	nentation	10	69
				Struct Reference		
		_		Description		
				cumentation		
			20.1.2.1			
			20.1.2.2	discover	1	70
			20.1.2.3	flags	1	70
			20.1.2.4	get_obj_cpuset	1	70
			20.1.2.5	is_custom	1	70
			20.1.2.6	is_thissystem	1	70
			20.1.2.7	notify_new_object	1	70
			20.1.2.8	private_data	1	70
	20.2	hwloc_	obj_attr_u	::hwloc_bridge_attr_s Struct Reference	1	70
		20.2.1	Detailed	Description	1	71
		20.2.2	Field Doo	cumentation	1	71
			20.2.2.1	depth	1	71
			20.2.2.2	domain	1	71
			20.2.2.3	downstream	1	71
			20.2.2.4	downstream_type	1	71
			20.2.2.5	pci	1	71
			20.2.2.6	pci	1	71
			20.2.2.7	secondary_bus	1	71
			20.2.2.8	subordinate_bus	1	71

xviii CONTENTS

	20.2.2.9 upstream	71
	20.2.2.10 upstream_type	71
20.3 hwlo	c_obj_attr_u::hwloc_cache_attr_s Struct Reference	71
20.3	1 Detailed Description	72
20.3	2 Field Documentation	72
	20.3.2.1 associativity	72
	20.3.2.2 depth	72
	20.3.2.3 linesize	72
	20.3.2.4 size	72
	20.3.2.5 type	72
20.4 hwlo	c_component Struct Reference	72
20.4.	1 Detailed Description	73
20.4.	2 Field Documentation	73
	20.4.2.1 abi	73
	20.4.2.2 data	73
	20.4.2.3 finalize	
	20.4.2.4 flags	73
	20.4.2.5 init	
	20.4.2.6 type	74
	c_disc_component Struct Reference	
20.5.	1 Detailed Description	74
20.5.	2 Field Documentation	
	20.5.2.1 excludes	
	20.5.2.2 instantiate	
	20.5.2.3 name	
	20.5.2.4 priority	
	20.5.2.5 type	
20.6 hwlo	c_distances_s Struct Reference	75
20.6.	1 Detailed Description	75
20.6.	2 Field Documentation	75
	20.6.2.1 latency	75
	20.6.2.2 latency_base	
	20.6.2.3 latency_max	
	20.6.2.4 nbobjs	
	20.6.2.5 relative_depth	
20.7 hwlo	c_obj_attr_u::hwloc_group_attr_s	76
20.7.	1 Detailed Description	76

CONTENTS xix

	20.7.2	Field Doc	cun	me	ntat	ion					 	 	 		 	 		 		. 176
		20.7.2.1	d	qeb	th .							 	 		 	 		 		. 176
20.8	hwloc_	obj Struct	Re	efe	renc	ce .						 	 		 	 		 		. 176
	20.8.1	Detailed I	De	esc	ripti	on						 	 		 	 		 		. 177
	20.8.2	Field Doc	cur	me	ntat	ion						 	 		 	 		 		. 177
		20.8.2.1	a	allov	wed	l_cp	use	et				 	 		 	 		 		. 177
		20.8.2.2	a	allo	wed	l_no	des	set				 	 		 	 		 		. 178
		20.8.2.3	a	arity	<i>,</i> .							 	 		 	 		 		. 178
		20.8.2.4	a	attr								 	 		 	 		 		. 178
		20.8.2.5	С	chile	drer	١						 	 		 	 		 		. 178
		20.8.2.6	C	com	ıple	te_c	pus	set				 	 		 	 		 		. 178
		20.8.2.7	C	com	nple	te_r	node	ese	et .			 	 		 	 		 		. 178
		20.8.2.8		•																
		20.8.2.9	d	qeb	th .							 	 		 	 		 		. 179
		20.8.2.10) d	dist	ance	es .						 	 		 	 		 		. 179
		20.8.2.11																		
		20.8.2.12	2 fi	irst	_chi	ild .						 	 	٠.	 	 		 		. 179
		20.8.2.13	3 ir	nfo	s .							 	 	٠.	 	 		 		. 179
		20.8.2.14	4 ir	nfo	s_c	oun	t					 	 		 	 		 		. 179
		20.8.2.15	5 la	ast	_chi	ild .						 	 		 	 		 		. 179
		20.8.2.16		•																
		20.8.2.17	7 m	ner	nory	y .						 	 		 	 		 		. 179
		20.8.2.18																		
		20.8.2.19			_															
		20.8.2.20) n	next	t_sit	bling	g .					 	 		 	 		 		. 180
		20.8.2.21																		
		20.8.2.22																		
		20.8.2.23	3 o	os_	inde	ЭХ .						 	 		 	 		 		. 180
		20.8.2.24																		
		20.8.2.25	5 p	oare	ent							 	 		 	 	 •	 		. 181
		20.8.2.26	6 p	orev	/_cc	ousii	n .					 	 		 	 	 •	 		. 181
		20.8.2.27	7 p	orev	/_sil	bling	g .					 	 		 	 	 •	 		. 181
		20.8.2.28	3 si	sibli	ng_	ranl	k .					 	 		 	 		 		. 181
		20.8.2.29																		
		20.8.2.30) ty	ype								 	 		 	 		 		. 181
		20.8.2.31	1 u	use	rdat	a.						 	 		 	 		 		. 181
20.9	hwloc_	obj_attr_u	ı Uı	Jnio	n R	lefer	enc	е				 	 		 	 		 		. 181

XX CONTENTS

20.9.1 Detailed Description	182
20.9.2 Field Documentation	182
20.9.2.1 bridge	182
20.9.2.2 cache	182
20.9.2.3 group	182
20.9.2.4 osdev	182
20.9.2.5 pcidev	182
20.10hwloc_obj_info_s Struct Reference	182
20.10.1 Detailed Description	182
20.10.2 Field Documentation	182
20.10.2.1 name	182
20.10.2.2 value	183
20.11hwloc_obj_memory_s::hwloc_obj_memory_page_type_s Struct Reference	183
20.11.1 Detailed Description	183
20.11.2 Field Documentation	183
20.11.2.1 count	183
20.11.2.2 size	183
20.12hwloc_obj_memory_s Struct Reference	183
20.12.1 Detailed Description	184
20.12.2 Field Documentation	184
20.12.2.1 local_memory	184
20.12.2.2 page_types	184
20.12.2.3 page_types_len	184
20.12.2.4 total_memory	184
20.13hwloc_obj_attr_u::hwloc_osdev_attr_s Struct Reference	184
20.13.1 Detailed Description	184
20.13.2 Field Documentation	185
20.13.2.1 type	185
20.14hwloc_obj_attr_u::hwloc_pcidev_attr_s Struct Reference	185
20.14.1 Detailed Description	185
20.14.2 Field Documentation	185
20.14.2.1 bus	185
20.14.2.2 class_id	185
20.14.2.3 dev	185
20.14.2.4 device_id	185
20.14.2.5 domain	185
20.14.2.6 func	185

CONTENTS xxi

20.14.2.7 linkspeed
20.14.2.8 revision
20.14.2.9 subdevice_id
20.14.2.10subvendor_id
20.14.2.11vendor_id
20.15hwloc_topology_cpubind_support Struct Reference
20.15.1 Detailed Description
20.15.2 Field Documentation
20.15.2.1 get_proc_cpubind
20.15.2.2 get_proc_last_cpu_location
20.15.2.3 get_thisproc_cpubind
20.15.2.4 get_thisproc_last_cpu_location
20.15.2.5 get_thisthread_cpubind
20.15.2.6 get_thisthread_last_cpu_location
20.15.2.7 get_thread_cpubind
20.15.2.8 set_proc_cpubind
20.15.2.9 set_thisproc_cpubind
20.15.2.10set_thisthread_cpubind187
20.15.2.11set_thread_cpubind
20.16hwloc_topology_diff_u::hwloc_topology_diff_generic_s Struct Reference
20.16.1 Field Documentation
20.16.1.1 next
20.16.1.2 type
20.17hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_generic_s Struct Reference
20.17.1 Field Documentation
20.17.1.1 type
20.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference
20.18.1 Field Documentation
20.18.1.1 diff
20.18.1.2 next
20.18.1.3 obj_depth
20.18.1.4 obj_index
20.18.1.5 type
20.19hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s Struct Reference
20.19.1 Detailed Description
20.19.2 Field Documentation
20.19.2.1 name

xxii CONTENTS

20.19.2.2 newvalue	89
20.19.2.3 oldvalue	89
20.19.2.4 type	89
20.20hwloc_topology_diff_obj_attr_u Union Reference	89
20.20.1 Detailed Description	90
20.20.2 Field Documentation	90
20.20.2.1 generic	90
20.20.2.2 string	90
20.20.2.3 uint64	90
20.21 hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s Struct Reference	90
20.21.1 Detailed Description	90
20.21.2 Field Documentation	91
20.21.2.1 index	91
20.21.2.2 newvalue	91
20.21.2.3 oldvalue	91
20.21.2.4 type	91
20.22hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s Struct Reference	91
20.22.1 Field Documentation	91
20.22.1.1 next	91
20.22.1.2 obj_depth	91
20.22.1.3 obj_index	91
20.22.1.4 type	91
20.23hwloc_topology_diff_u Union Reference	91
20.23.1 Detailed Description	92
20.23.2 Field Documentation	92
20.23.2.1 generic	92
20.23.2.2 obj_attr	92
20.23.2.3 too_complex	92
20.24hwloc_topology_discovery_support Struct Reference	92
20.24.1 Detailed Description	92
20.24.2 Field Documentation	92
20.24.2.1 pu	92
20.25hwloc_topology_membind_support Struct Reference	92
20.25.1 Detailed Description	93
20.25.2 Field Documentation	93
20.25.2.1 alloc_membind	93
20.25.2.2 bind_membind	93

CONTENTS xxiii

20.25.2.3 firsttouch_membind	3
20.25.2.4 get_area_membind	3
20.25.2.5 get_proc_membind	3
20.25.2.6 get_thisproc_membind	3
20.25.2.7 get_thisthread_membind	4
20.25.2.8 interleave_membind	4
20.25.2.9 migrate_membind	4
20.25.2.10nexttouch_membind	4
20.25.2.11replicate_membind	4
20.25.2.12set_area_membind	4
20.25.2.13set_proc_membind	4
20.25.2.14set_thisproc_membind	4
20.25.2.15set_thisthread_membind	4
20.26hwloc_topology_support Struct Reference	4
20.26.1 Detailed Description	5
20.26.2 Field Documentation	5
20.26.2.1 cpubind	5
20.26.2.2 discovery	5
20 26 2.3 membind	5

Chapter 1

Hardware Locality

Portable abstraction of hierarchical architectures for high-performance computing

1.1 Introduction

hwloc provides command line tools and a C API to obtain the hierarchical map of key computing elements, such as: NUMA memory nodes, shared caches, processor packages, processor cores, processing units (logical processors or "threads") and even I/O devices. hwloc also gathers various attributes such as cache and memory information, and is portable across a variety of different operating systems and platforms. Additionally it may assemble the topologies of multiple machines into a single one so as to let applications consult the topology of an entire fabric or cluster at once.

hwloc primarily aims at helping high-performance computing (HPC) applications, but is also applicable to any project seeking to exploit code and/or data locality on modern computing platforms.

Note that the hwloc project represents the merger of the libtopology project from inria and the Portable Linux Processor Affinity (PLPA) sub-project from Open MPI. Both of these prior projects are now deprecated. The first hwloc release was essentially a "re-branding" of the libtopology code base, but with both a few genuinely new features and a few PLPA-like features added in. Prior releases of hwloc included documentation about switching from PLPA to hwloc; this documentation has been dropped on the assumption that everyone who was using PLPA has already switched to hwloc.

hwloc supports the following operating systems:

- Linux (including old kernels not having sysfs topology information, with knowledge of cpusets, offline CPUs, ScaleMP vSMP, NumaScale NumaConnect, and Kerrighed support) on all supported hardware, including Intel Xeon Phi (either standalone or as a coprocessor).
- · Solaris
- AIX
- · Darwin / OS X
- · FreeBSD and its variants (such as kFreeBSD/GNU)
- NetBSD
- OSF/1 (a.k.a., Tru64)
- HP-UX
- · Microsoft Windows

· IBM BlueGene/Q Compute Node Kernel (CNK)

Since it uses standard Operating System information, hwloc's support is mostly independant from the processor type (x86, powerpc, ...) and just relies on the Operating System support. The only exception to this is kFreeBSD, which does not support topology information, and hwloc thus uses an x86-only CPUID-based backend (which can be used for other OSes too, see the Components and plugins section).

To check whether hwloc works on a particular machine, just try to build it and run lstopo or lstopo-no-graphics. If some things do not look right (e.g. bogus or missing cache information), see Questions and Bugs below.

hwloc only reports the number of processors on unsupported operating systems; no topology information is available.

For development and debugging purposes, hwloc also offers the ability to work on "fake" topologies:

- · Symmetrical tree of resources generated from a list of level arities
- · Remote machine simulation through the gathering of Linux sysfs topology files

hwloc can display the topology in a human-readable format, either in graphical mode (X11), or by exporting in one of several different formats, including: plain text, PDF, PNG, and FIG (see CLI Examples below). Note that some of the export formats require additional support libraries.

hwloc offers a programming interface for manipulating topologies and objects. It also brings a powerful CPU bitmap API that is used to describe topology objects location on physical/logical processors. See the Programming Interface below. It may also be used to binding applications onto certain cores or memory nodes. Several utility programs are also provided to ease command-line manipulation of topology objects, binding of processes, and so on.

Perl bindings are available from Bernd Kallies on CPAN.

Python bindings are available from Guy Streeter:

- Fedora RPM and tarball.
- git tree (html).

1.2 Installation

hwloc (http://www.open-mpi.org/projects/hwloc/) is available under the BSD license. It is hosted as a sub-project of the overall Open MPI project (http://www.open-mpi.org/). Note that hwloc does not require any functionality from Open MPI – it is a wholly separate (and much smaller!) project and code base. It just happens to be hosted as part of the overall Open MPI project.

Nightly development snapshots are available on the web site. Additionally, the code can be directly cloned from Git:

```
shell$ git clone https://github.com/open-mpi/hwloc.git
shell$ cd hwloc
shell$ ./autogen.sh
```

Note that GNU Autoconf >=2.63, Automake >=1.10 and Libtool >=2.2.6 are required when building from a Git clone. Installation by itself is the fairly common GNU-based process:

```
shell$ ./configure --prefix=...
shell$ make
shell$ make install
```

1.3 CLI Examples 3

The hwloc command-line tool "Istopo" produces human-readable topology maps, as mentioned above. It can also export maps to the "fig" file format. Support for PDF, Postscript, and PNG exporting is provided if the "Cairo" development package (usually cairo-devel or libcairo2-dev) can be found in "Istopo" when hwloc is configured and build.

The hwloc core may also benefit from the following development packages:

- libnuma for memory binding and migration support on Linux (numactl-devel or libnuma-dev package).
- libpciaccess for full I/O device discovery (libpciaccess-devel or libpciaccess-dev package). On Linux, PCI discovery may still be performed (without vendor/device names) even if libpciaccess cannot be used.
- · the AMD OpenCL implementation for OpenCL device discovery.
- · the NVIDIA CUDA Toolkit for CUDA device discovery.
- the NVIDIA Tesla Development Kit for NVML device discovery.
- the NV-CONTROL X extension library (NVCtrl) for NVIDIA display discovery.
- libxml2 for full XML import/export support (otherwise, the internal minimalistic parser will only be able to import XML files that were exported by the same hwloc release). See Importing and exporting topologies from/to XML files for details. The relevant development package is usually libxml2-devel or libxml2-dev.
- libudev on Linux for easier discovery of OS device information (otherwise hwloc will try to manually parse udev raw files). The relevant development package is usually libudev-devel or libudev-dev.
- libtool's ltdl library for dynamic plugin loading. The relevant development package is usually libtool-ltdl-devel or libltdl-dev.

PCI and XML support may be statically built inside the main hwloc library, or as separate dynamically-loaded plugins (see the Components and plugins section).

Note that because of the possibility of GPL taint, the pciutils library libpci will not be used (remember that hwloc is BSD-licensed).


Also note that if you install supplemental libraries in non-standard locations, hwloc's configure script may not be able to find them without some help. You may need to specify additional CPPFLAGS, LDFLAGS, or PKG_CONFIG_PATH values on the configure command line.

For example, if libpciaccess was installed into /opt/pciaccess, hwloc's configure script may not find it be default. Try adding PKG_CONFIG_PATH to the ./configure command line, like this:

```
./configure PKG_CONFIG_PATH=/opt/pciaccess/lib/pkgconfig ...
```

1.3 CLI Examples

On a 4-package 2-core machine with hyper-threading, the 1stopo tool may show the following graphical output:



Here's the equivalent output in textual form:


```
Machine (16GB)
  Package L#0 + L3 L#0 (4096KB)
   L2 L#0 (1024KB) + L1 L#0 (16KB) + Core L#0
      PU L#0 (P#0)
     PU L#1 (P#8)
   L2 L#1 (1024KB) + L1 L#1 (16KB) + Core L#1
      PU L#2 (P#4)
      PU L#3 (P#12)
  Package L#1 + L3 L#1 (4096KB)
   L2 L#2 (1024KB) + L1 L#2 (16KB) + Core L#2
     PU L#4 (P#1)
      PU L#5 (P#9)
    L2 L#3 (1024KB) + L1 L#3 (16KB) + Core L#3
      PU L#6 (P#5)
      PU L#7 (P#13)
  Package L#2 + L3 L#2 (4096KB)
   L2 L#4 (1024KB) + L1 L#4 (16KB) + Core L#4
      PU L#8 (P#2)
      PU L#9 (P#10)
   L2 L#5 (1024KB) + L1 L#5 (16KB) + Core L#5
     PU L#10 (P#6)
      PU L#11 (P#14)
  Package L#3 + L3 L#3 (4096KB)
    L2 L#6 (1024KB) + L1 L#6 (16KB) + Core L#6
     PU L#12 (P#3)
      PU L#13 (P#11)
   L2 L\#7 (1024KB) + L1 L\#7 (16KB) + Core L\#7
```

1.3 CLI Examples 5

```
PU L#14 (P#7)
PU L#15 (P#15)
```

Note that there is also an equivalent output in XML that is meant for exporting/importing topologies but it is hardly readable to human-beings (see Importing and exporting topologies from/to XML files for details).

On a 4-package 2-core Opteron NUMA machine, the 1stopo tool may show the following graphical output:



Here's the equivalent output in textual form:

```
Machine (32GB)

NUMANode L#0 (P#0 8190MB) + Package L#0

L2 L#0 (1024KB) + L1 L#0 (64KB) + Core L#0 + PU L#0 (P#0)

L2 L#1 (1024KB) + L1 L#1 (64KB) + Core L#1 + PU L#1 (P#1)

NUMANode L#1 (P#1 8192MB) + Package L#1

L2 L#2 (1024KB) + L1 L#2 (64KB) + Core L#2 + PU L#2 (P#2)

L2 L#3 (1024KB) + L1 L#3 (64KB) + Core L#3 + PU L#3 (P#3)

NUMANode L#2 (P#2 8192MB) + Package L#2

L2 L#4 (1024KB) + L1 L#4 (64KB) + Core L#4 + PU L#4 (P#4)


L2 L#5 (1024KB) + L1 L#5 (64KB) + Core L#5 + PU L#5 (P#5)

NUMANode L#3 (P#3 8192MB) + Package L#3

L2 L#6 (1024KB) + L1 L#6 (64KB) + Core L#6 + PU L#6 (P#6)

L2 L#7 (1024KB) + L1 L#6 (64KB) + Core L#6 + PU L#6 (P#6)
```

On a 2-package quad-core Xeon (pre-Nehalem, with 2 dual-core dies into each package):



Here's the same output in textual form:

```
Machine (16GB)

Package L#0

L2 L#0 (4096KB)

L1 L#1 (32KB) + Core L#0 + PU L#0 (P#0)

L1 L#1 (32KB) + Core L#1 + PU L#1 (P#4)

L2 L#1 (4096KB)

L1 L#2 (32KB) + Core L#2 + PU L#2 (P#2)

L1 L#3 (32KB) + Core L#3 + PU L#3 (P#6)

Package L#1

L2 L#2 (4096KB)

L1 L#4 (32KB) + Core L#4 + PU L#4 (P#1)

L1 L#5 (32KB) + Core L#5 + PU L#5 (P#5)

L2 L#3 (4096KB)

L1 L#6 (32KB) + Core L#6 + PU L#6 (P#3)

L1 L#6 (32KB) + Core L#6 + PU L#6 (P#3)

L1 L#7 (32KB) + Core L#7 + PU L#7 (P#7)
```

1.4 Programming Interface

The basic interface is available in hwloc.h. Some higher-level functions are available in hwloc/helper.h to reduce the need to manually manipulate objects and follow links between them. Documentation for all these is provided later in this document. Developers may also want to look at hwloc/inlines.h which contains the actual inline code of some hwloc.h routines, and at this document, which provides good higher-level topology traversal examples.

To precisely define the vocabulary used by hwloc, a Terms and Definitions section is available and should probably be read first.

Each hwloc object contains a cpuset describing the list of processing units that it contains. These bitmaps may be used for CPU binding and Memory binding, hwloc offers an extensive bitmap manipulation interface in hwloc/bitmap.h.

Moreover, hwloc also comes with additional helpers for interoperability with several commonly used environments. See the Interoperability With Other Software section for details.

The complete API documentation is available in a full set of HTML pages, man pages, and self-contained PDF files (formatted for both both US letter and A4 formats) in the source tarball in doc/doxygen-doc/.

NOTE: If you are building the documentation from a Git clone, you will need to have Doxygen and pdflatex installed – the documentation will be built during the normal "make" process. The documentation is installed during "make install" to \$prefix/share/doc/hwloc/ and your systems default man page tree (under \$prefix, of course).

1.4.1 Portability


As shown in CLI Examples, hwloc can obtain information on a wide variety of hardware topologies. However, some platforms and/or operating system versions will only report a subset of this information. For example, on an PPC64-based system with 32 cores (each with 2 hardware threads) running a default 2.6.18-based kernel from RHEL 5.4, hwloc is only able to glean information about NUMA nodes and processor units (PUs). No information about caches, packages, or cores is available.

Similarly, Operating System have varying support for CPU and memory binding, e.g. while some Operating Systems provide interfaces for all kinds of CPU and memory bindings, some others provide only interfaces for a limited number of kinds of CPU and memory binding, and some do not provide any binding interface at all. Hwloc's binding functions would then simply return the ENOSYS error (Function not implemented), meaning that the underlying Operating System does not provide any interface for them. CPU binding and Memory binding provide more information on which hwloc binding functions should be preferred because interfaces for them are usually available on the supported Operating Systems.

Here's the graphical output from Istopo on this platform when Simultaneous Multi-Threading (SMT) is enabled:




And here's the graphical output from Istopo on this platform when SMT is disabled:



Notice that hwloc only sees half the PUs when SMT is disabled. PU #15, for example, seems to change location from NUMA node #0 to #1. In reality, no PUs "moved" – they were simply re-numbered when hwloc only saw half as many. Hence, PU #15 in the SMT-disabled picture probably corresponds to PU #30 in the SMT-enabled picture.

This same "PUs have disappeared" effect can be seen on other platforms – even platforms / OSs that provide much more information than the above PPC64 system. This is an unfortunate side-effect of how operating systems report information to hwloc.





Developers using the hwloc API or XML output for portable applications should therefore be extremely careful to not make any assumptions about the structure of data that is returned. For example, per the above reported PPC topology, it is not safe to assume that PUs will always be descendants of cores.

Additionally, future hardware may insert new topology elements that are not available in this version of hwloc. Long-lived applications that are meant to span multiple different hardware platforms should also be careful about making structure assumptions. For example, there may someday be an element "lower" than a PU, or perhaps a new element may exist between a core and a PU.

1.4.2 API Example

The following small C example (named "hwloc-hello.c") prints the topology of the machine and bring the process to the first logical processor of the second core of the machine. More examples are available in the doc/examples/ directory of the source tree.

```
/* Example hwloc API program.
 * See other examples under doc/examples/ in the source tree
 * for more details.
* Copyright © 2009-2015 Inria. All rights reserved.
* Copyright © 2009-2011 Université Bordeaux
* Copyright © 2009-2010 Cisco Systems, Inc. All rights reserved.
\star See COPYING in top-level directory.
* hwloc-hello.c
#include <hwloc.h>
#include <errno.h>
#include <stdio.h>
#include <string.h>
static void print_children(hwloc_topology_t topology,
     hwloc_obj_t obj,
                           int depth)
   char type[32], attr[1024];
   unsigned i;
   hwloc_obj_type_snprintf(type, sizeof(type), obj, 0);
   printf("%*s%s", 2*depth, "", type);
    if (obj->os_index != (unsigned) -1)
     printf("#%u", obj->os_index);
    hwloc_obj_attr_snprintf(attr, sizeof(attr), obj, " ", 0);
    if (*attr)
     printf("(%s)", attr);
   printf("\n");
    for (i = 0; i < obj->arity; i++) {
       print_children(topology, obj->children[i], depth + 1);
int main(void)
    int depth;
   unsigned i, n;
   unsigned long size;
    int levels;
   char string[128];
    int topodepth;
   hwloc_topology_t topology;
hwloc_cpuset_t cpuset;
   hwloc obi t obi:
    /* Allocate and initialize topology object. */
   hwloc_topology_init(&topology);
    /* ... Optionally, put detection configuration here to ignore
      some objects types, define a synthetic topology, etc...
       The default is to detect all the objects of the machine that
       the caller is allowed to access. See Configure Topology
```

```
Detection. */
/* Perform the topology detection. */
hwloc_topology_load(topology);
/* Optionally, get some additional topology information
  in case we need the topology depth later. */
topodepth = hwloc_topology_get_depth(topology);
* First example:
 \star Walk the topology with an array style, from level 0 (always
 * the system level) to the lowest level (always the proc level).
for (depth = 0; depth < topodepth; depth++) {
   printf("*** Objects at level %d\n", depth);
   for (i = 0; i < hwloc_get_nbobjs_by_depth(topology, depth);</pre>
        `i++) {
       hwloc_obj_type_snprintf(string, sizeof(string),
                            hwloc_get_obj_by_depth(topology, depth, i), 0);
       printf("Index %u: %s\n", i, string);
}
/**********************
* Second example:
 \star Walk the topology with a tree style.
 *******
printf("*** Printing overall tree\n");
print_children(topology, hwloc_get_root_obj(topology), 0);
/*********************
* Third example:
 \star Print the number of packages.
 ************************
depth = hwloc_get_type_depth(topology, HWLOC_OBJ_PACKAGE);
if (depth == HWLOC_TYPE_DEPTH_UNKNOWN) {
   printf("*** The number of packages is unknown\n");
} else {
   printf("*** %u package(s)\n",
         hwloc_get_nbobjs_by_depth(topology, depth));
/*********************
 * Fourth example:
 * Compute the amount of cache that the first logical processor
 * has above it.
 *************************
levels = 0;
size = 0;
for (obj = hwloc_get_obj_by_type(topology, HWLOC_OBJ_PU, 0);
    obj;
    obj = obj->parent)
 if (obj->type == HWLOC_OBJ_CACHE) {
   levels++;
   size += obj->attr->cache.size;
printf("*** Logical processor 0 has %d caches totaling %luKB\n",
      levels, size / 1024);
/************************
* Fifth example:
 \star Bind to only one thread of the last core of the machine.
 * First find out where cores are, or else smaller sets of CPUs if
 * the OS doesn't have the notion of a "core".
depth = hwloc_get_type_or_below_depth(topology,
 HWLOC_OBJ_CORE);
/* Get last core. */
obj = hwloc_get_obj_by_depth(topology, depth,
             hwloc_get_nbobjs_by_depth(topology, depth) - 1);
if (obj) {
   /* Get a copy of its cpuset that we may modify. */
   cpuset = hwloc_bitmap_dup(obj->cpuset);
   /\star Get only one logical processor (in case the core is
      SMT/hyper-threaded). */
   hwloc_bitmap_singlify(cpuset);
```

```
/* And try to bind ourself there. */
    if (hwloc_set_cpubind(topology, cpuset, 0)) {
       char *str;
       int error = errno;
       hwloc_bitmap_asprintf(&str, obj->cpuset);
       printf("Couldn't bind to cpuset %s: %s\n", str, strerror(error));
    /* Free our cpuset copy */
    hwloc_bitmap_free(cpuset);
 * Sixth example:
 * Allocate some memory on the last NUMA node, bind some existing
 * memory to the last NUMA node.
 /* Get last node. */
n = hwloc_get_nbobjs_by_type(topology,
 HWLOC_OBJ_NUMANODE);
if (n) {
   void *m;
   size = 1024 * 1024;
   obj = hwloc_get_obj_by_type(topology,
  HWLOC_OBJ_NUMANODE, n - 1);
   m = hwloc_alloc_membind_nodeset(topology, size, obj->
  nodeset,
           HWLOC_MEMBIND_BIND, 0);
   hwloc_free(topology, m, size);
   m = malloc(size);
   hwloc_set_area_membind_nodeset(topology, m, size, obj->
  nodeset,
           HWLOC_MEMBIND_BIND, 0);
    free(m);
/* Destroy topology object. */
hwloc_topology_destroy(topology);
return 0;
```

hwloc provides a pkg-config executable to obtain relevant compiler and linker flags. For example, it can be used thusly to compile applications that utilize the hwloc library (assuming GNU Make):

```
CFLAGS += $(pkg-config --cflags hwloc)
LDLIBS += $(pkg-config --libs hwloc)
cc hwloc-hello.c $(CFLAGS) -o hwloc-hello $(LDLIBS)
```

On a machine with 4GB of RAM and 2 processor packages – each package of which has two processing cores – the output from running hwloc-hello could be something like the following:

```
shell$ ./hwloc-hello
*** Objects at level 0
Index 0: Machine (3938MB)
*** Objects at level 1
Index 0: Package#0
Index 1: Package#1
*** Objects at level 2
Index 0: Core#0
Index 1: Core#1
Index 2: Core#3
Index 3: Core#2
*** Objects at level 3
Index 0: PU#0
Index 1: PU#1
Index 2: PU#2
Index 3: PU#3
*** Printing overall tree
```

```
Machine (3938MB)
Package#0
Core#0
PU#0
Core#1
PU#1
Package#1
Core#3
PU#2
Core#2
PU#3
**** 2 package(s)
shells
```

1.5 Questions and Bugs

Questions should be sent to the devel mailing list (http://www.open-mpi.org/community/lists/hwloc. ~php). Bug reports should be reported in the tracker (https://git.open-mpi.org/trac/hwloc/).

If hwloc discovers an incorrect topology for your machine, the very first thing you should check is to ensure that you have the most recent updates installed for your operating system. Indeed, most of hwloc topology discovery relies on hardware information retrieved through the operation system (e.g., via the /sys virtual filesystem of the Linux kernel). If upgrading your OS or Linux kernel does not solve your problem, you may also want to ensure that you are running the most recent version of the BIOS for your machine.

If those things fail, contact us on the mailing list for additional help. Please attach the output of Istopo after having given the <code>-enable-debug</code> option to ./configure and rebuilt completely, to get debugging output. Also attach the <code>/proc+/sys</code> tarball generated by the installed script <code>hwloc-gather-topology</code> when submitting problems about Linux, or send the output of <code>kstat cpu_info</code> in the Solaris case, or the output of <code>sysctl hw</code> in the Darwin or BSD cases.

1.6 History / Credits

hwloc is the evolution and merger of the libtopology (http://runtime.bordeaux.inria.fr/libtopology/) project and the Portable Linux Processor Affinity (PLPA) (http://www.open-mpi.org/projects/plpa/) project. Because of functional and ideological overlap, these two code bases and ideas were merged and released under the name "hwloc" as an Open MPI sub-project.

libtopology was initially developed by the inria Runtime Team-Project (http://runtime.bordeaux.inria. \leftarrow fr/) (headed by Raymond Namyst (http://dept-info.labri.fr/ \sim namyst/). PLPA was initially developed by the Open MPI development team as a sub-project. Both are now deprecated in favor of hwloc, which is distributed as an Open MPI sub-project.

1.7 Further Reading

The documentation chapters include

- · Terms and Definitions
- Command-Line Tools
- · Environment Variables
- CPU and Memory Binding Overview

14 Hardware Locality

- I/O Devices
- · Miscellaneous objects
- Multi-node Topologies
- · Object attributes
- Importing and exporting topologies from/to XML files
- Synthetic topologies
- Interoperability With Other Software
- Thread Safety
- · Components and plugins
- Embedding hwloc in Other Software
- Frequently Asked Questions

Make sure to have had a look at those too!

Terms and Definitions

Object Interesting kind of part of the system, such as a Core, a Cache, a Memory node, etc. The different types detected by hwloc are detailed in the hwloc obj type t enumeration.

They are topologically sorted by CPU set into a tree.

CPU set The set of logical processors (or processing units) logically included in an object (if it makes sense). They are always expressed using physical logical processor numbers (as announced by the OS). They are implemented as the hww.numbers (as announced by the OS). They are implemented as the hww.numbers (as announced by the OS). They are implemented as the hww.numbers (as announced by the OS). They are implemented as the <a href="https://hww.numbers.com/hww.n

Node set The set of NUMA memory nodes logically included in an object (if it makes sense). They are always expressed using physical node numbers (as announced by the OS). They are implemented with the hwloc_bitmap topaque structure, as bitmaps.

Bitmap A possibly-infinite set of bits used for describing sets of objects such as CPUs (CPU sets) or memory nodes (Node sets). They are implemented with the hwloc bitmap t opaque structure.

Parent object The object logically containing the current object, for example because its CPU set includes the CPU set of the current object.

Ancestor object The parent object, or its own parent object, and so on.

Children object(s) The object (or objects) contained in the current object because their CPU set is included in the CPU set of the current object.

Arity The number of children of an object.

Sibling objects Objects which have the same parent. They usually have the same type (and hence are cousins, as well), but they may not if the topology is asymmetric.


Sibling rank Index to uniquely identify objects which have the same parent, and is always in the range [0, parent arity).


Cousin objects Objects of the same type (and depth) as the current object, even if they do not have the same parent.

Level Set of objects of the same type and depth. All these objects are cousins.

Depth Nesting level in the object tree, starting from the root object. If the topology is symmetric, the depth of a child is equal to the parent depth plus one, and an object depth is also equal to the number of parent/child links between the root object and the given object. If the topology is asymmetric, the difference between some parent and child depths may be larger than one when some intermediate levels (for instance caches) are missing in only some parts of the machine.

16 Terms and Definitions





It should be noted that for PU objects, the logical index – as computed linearly by hwloc – is not the same as the OS index.

See also What happens if my topology is asymmetric? for more details.

18 **Terms and Definitions**

Command-Line Tools

hwloc comes with an extensive C programming interface and several command line utilities. Each of them is fully documented in its own manual page; the following is a summary of the available command line tools.

3.1 Istopo and Istopo-no-graphics

Istopo (also known as hwloc-ls) displays the hierarchical topology map of the current system. The output may be graphical, ascii-art or textual, and can also be exported to numerous file formats such as PDF, PNG, XML, and others. Advanced graphical outputs require the "Cairo" development package (usually cairo-devel or libcairo2-dev).

Istopo and Istopo-no-graphics accept the same command-line options. However graphical outputs are only available in Istopo. Textual outputs (those that do not depend on heavy external libraries such as Cairo) are supported in both Istopo and Istopo-no-graphics.

This command can also display the processes currently bound to a part of the machine (via the -ps option).

Note that Istopo can read XML files and/or alternate chroot filesystems and display topological maps representing those systems (e.g., use Istopo to output an XML file on one system, and then use Istopo to read in that XML file and display it on a different system).

3.2 hwloc-bind

hwloc-bind binds processes to specific hardware objects through a flexible syntax. A simple example is binding an executable to specific cores (or packages or bitmaps or ...). The hwloc-bind(1) man page provides much more detail on what is possible.

hwloc-bind can also be used to retrieve the current process' binding.

3.3 hwloc-calc

hwloc-calc is generally used to create bitmap strings to pass to hwloc-bind. Although hwloc-bind accepts many forms of object specification (i.e., bitmap strings are one of many forms that hwloc-bind understands), they can be useful, compact representations in shell scripts, for example.

hwloc-calc generates bitmap strings from given hardware objects with the ability to aggregate them, intersect them, and more. hwloc-calc generally uses the same syntax than hwloc-bind, but multiple instances may be composed to generate complex combinations.

20 Command-Line Tools

Note that hwloc-calc can also generate lists of logical processors or NUMA nodes that are convenient to pass to some external tools such as taskset or numactl.

3.4 hwloc-info

hwloc-info dumps information about the given objects. It is intended to be used with tools such as grep for filtering certain attribute lines. When no object is specified, hwloc-info prints a summary of the topology.

3.5 hwloc-distrib

hwloc-distrib generates a set of bitmap strings that are uniformly distributed across the machine for the given number of processes. These strings may be used with hwloc-bind to run processes to maximize their memory bandwidth by properly distributing them across the machine.

3.6 hwloc-ps

hwloc-ps is a tool to display the bindings of processes that are currently running on the local machine. By default, hwloc-ps only lists processes that are bound; unbound process (and Linux kernel threads) are not displayed.

3.7 hwloc-gather-topology

hwloc-gather-topology is a Linux-specific tool that saves the relevant topology files of the current machine into a tarball (and the corresponding Istopo output). These files may be used later (possibly offline) for simulating or debugging a machine without actually running on it.

3.8 hwloc-distances

hwloc-distances displays all distance matrices attached to the topology. Note that Istopo may also display distance matrices in its verbose textual output. However Istopo only prints matrices that cover the entire topology while hwloc-distances also displays matrices that ignore part of the topology.

3.9 hwloc-annotate

hwloc-annotate may add object attributes such as string information (see Custom string infos for details) or Misc children objects. It reads an input topology from a XML file and outputs the annotated topology as another XML file.

3.10 hwloc-diff and hwloc-patch

hwloc-diff computes the difference between two topologies and outputs it to another XML file. hwloc-patch reads such a difference file and applies to another topology.

3.11 hwloc-compress-dir

hwloc-compress-dir compresses an entire directory of XML files by using hwloc-diff to save the differences between topologies instead of entire topologies.

3.12 hwloc-assembler

hwloc-assembler combines several XML topology files into a single multi-node XML topology. It may then be used later as input with hwloc_topology_set_xml() or with the HWLOC_XMLFILE environment variable. See Multi-node Topologies for details.

3.13 hwloc-assembler-remote

hwloc-assembler-remote is a frontend to hwloc-assembler. It takes care of contacting the given list of remote hosts (through ssh) and retrieving their topologies as XML before assembling them with hwloc-assembler.

22 Command-Line Tools

Environment Variables

The behavior of the hwloc library and tools may be tuned thanks to the following environment variables.

HWLOC_XMLFILE=/path/to/file.xml enforces the discovery from the given XML file as if hwloc_topology_set_xml() had been called. This file may have been generated earlier with Istopo file.xml. For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, H← WLOC_THISSYSTEM should be set 1 in the environment too, to assert that the loaded file is really the underlying system. See also Importing and exporting topologies from/to XML files.

HWLOC_XML_VERBOSE=1

- HWLOC_SYNTHETIC_VERBOSE=1 enables verbose messages in the XML or synthetic topology backends. hwloc XML backends (see Importing and exporting topologies from/to XML files) can emit some error messages to the error output stream. Enabling these verbose messages within hwloc can be useful for understanding failures to parse input XML topologies. Similarly, enabling verbose messages in the synthetic topology backend can help understand why the description string is invalid. See also Synthetic topologies.
- HWLOC_FSROOT=/path/to/linux/filesystem-root/ switches to reading the topology from the specified Linux filesystem root instead of the main file-system root, as if hwloc_topology_set_fsroot() had been called. Not using the main file-system root causes hwloc_topology_is_thissystem() to return 0. For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, HWLO← C_THISSYSTEM should be set 1 in the environment too, to assert that the loaded file is really the underlying system.
- HWLOC_THISSYSTEM=1 enforces the return value of hwloc_topology_is_thissystem(), as if HWLOC_TOPOLOG
 Y_FLAG_IS_THISSYSTEM was set with hwloc_topology_set_flags(). It means that it makes hwloc assume that
 the selected backend provides the topology for the system on which we are running, even if it is not the O
 S-specific backend but the XML backend for instance. This means making the binding functions actually call the
 OS-specific system calls and really do binding, while the XML backend would otherwise provide empty hooks just
 returning success. This can be used for efficiency reasons to first detect the topology once, save it to an XML file,
 and quickly reload it later through the XML backend, but still having binding functions actually do bind.
- **HWLOC_HIDE_ERRORS=0** enables or disables verbose reporting of errors. The hwloc library may issue warnings to the standard error stream when it detects a problem during topology discovery, for instance if the operating system (or user) gives contradictory topology information. Setting this environment variable to 1 removes the actual displaying of these error messages.
- **HWLOC_GROUPING=1** enables or disables objects grouping based on distances. By default, hwloc uses distance matrices between objects (either read from the OS or given by the user) to find groups of close objects. These groups are described by adding intermediate Group objects in the topology. Setting this environment variable to 0 will disable this grouping. This variable supersedes the obsolete HWLOC IGNORE DISTANCES variable.

24 Environment Variables

HWLOC_GROUPING_ACCURACY=0.05 relaxes distance comparison during grouping. By default, objects may be grouped if their distances form a minimal distance graph. When setting this variable to 0.02, these distances do not have to be strictly equal anymore, they may just be equal with a 2% error. If set to try instead of a numerical value, hwloc will try to group with perfect accuracy (0, the default), then with 0.01, 0.02, 0.05 and finally 0.1. Numbers given in this environment variable should always use a dot as a decimal mark (for instance 0.01 instead of 0,01).

- **HWLOC_GROUPING_VERBOSE=0** enables or disables some verbose messages during grouping. If this variable is set to 1, some debug messages will be displayed during distance-based grouping of objects even if debug was not specific at configure time. This is useful when trying to find an interesting distance grouping accuracy.
- HWLOC_<type>_DISTANCES=index,...:X*Y
- HWLOC_<type>_DISTANCES=begin-end:X*Y*Z
- HWLOC_<type>_DISTANCES=index,...:distance,... sets a distance matrix for objects of the given type and physical indexes. The type should be given as its case-sensitive stringified value (e.g. NUMANode, Package, Cache, Core, PU). If another distance matrix already exists for the given type, either because the user specified it or because the OS offers it, it will be replaced by the given one.

If the variable value is none, the existing distance matrix for the given type is removed. Otherwise, the variable value first consists in a list of physical indexes that may be specified as a comma-separated list (e.g. 0, 2, 4, 1, 3, 5) or as a range of consecutive indexes (0-5). It is followed by a colon and the corresponding distances:

- If X*Y is given, X groups of Y close objects are specified.
- If X*Y*Z is given, X groups of Y groups of Z close objects are specified.
- Otherwise, the comma-separated list of distances should be given. If N objects are considered, the i*N+j-th value gives the distance from the i-th object to the j-th object. These distance values must use a dot as a decimal separator.

Note that distances are ignored in multi-node topologies.

- HWLOC_PCI_<domain>_<bus>_LOCALCPUS=<cpuset> changes the locality of I/O devices behind the specified PCI hostbridge. If no I/O locality information is available or if the BIOS reports incorrect information, it is possible to move a I/O device tree (the entire set of objects behind a host bridge) near a custom set of processors. domain and bus are the PCI domain and primary bus of the corresponding host bridge.
- **HWLOC_PLUGINS_PATH=/path/to/hwloc/plugins/:...** changes the default search directory for plugins. By default, \$libdir/hwloc is used. The variable may contain several colon-separated directories.
- **HWLOC_PLUGINS_VERBOSE=1** displays verbose information about plugins. List which directories are scanned, which files are loaded, and which components are successfully loaded.
- HWLOC_COMPONENTS=list,of,components forces a list of components to enable or disable. Enable or disable the given comma-separated list of components (if they do not conflict with each other). Component names prefixed with are disabled. Once the end of the list is reached, hwloc falls back to enabling the remaining components (sorted by priority) that do not conflict with the already enabled ones, and unless explicitly disabled in the list. If stop is met, the enabling loop immediately stops, no more component is enabled. If the variable is set to an empty string, no specific component is loaded first, all components are loaded in priority order, this is strictly identical to not specifying any variable. The xml component name may be followed by a X ML file to load (xml=file.xml). The synthetic component may be followed by a basic synthetic topology description (synthetic=node:2 pu:3, see Synthetic topologies). This variable does not take precedence over the application selecting components with functions such as hwloc_topology_set_xml(). See Components and plugins for details.
- **HWLOC_COMPONENTS_VERBOSE=1** displays verbose information about components. Display messages when components are registered or enabled. This is the recommended way to list the available components with their priority (all of them are *registered* at startup).

CPU and Memory Binding Overview

Some operating systems do not systematically provide separate functions for CPU and memory binding. This means that CPU binding functions may have have effects on the memory binding policy. Likewise, changing the memory binding policy may change the CPU binding of the current thread. This is often not a problem for applications, so by default hwloc will make use of these functions when they provide better binding support.

If the application does not want the CPU binding to change when changing the memory policy, it needs to use the H← WLOC_MEMBIND_NOCPUBIND flag to prevent hwloc from using OS functions which would change the CPU binding. Additionally, HWLOC_CPUBIND_NOMEMBIND can be passed to CPU binding function to prevent hwloc from using OS functions would change the memory binding policy. Of course, using these flags will reduce hwloc's overall support for binding, so their use is discouraged.

One can avoid using these flags but still closely control both memory and CPU binding by allocating memory, touching each page in the allocated memory, and then changing the CPU binding. The already-really-allocated memory will then be "locked" to physical memory and will not be migrated. Thus, even if the memory binding policy gets changed by the CPU binding order, the already-allocated memory will not change with it. When binding and allocating further memory, the CPU binding should be performed again in case the memory binding altered the previously-selected CPU binding.

Not all operating systems support the notion of a "current" memory binding policy for the current process, but such operating systems often still provide a way to allocate data on a given node set. Conversely, some operating systems support the notion of a "current" memory binding policy and do not permit allocating data on a specific node set without changing the current policy and allocate the data. To provide the most powerful coverage of these facilities, hwloc provides:

- functions that set/get the current memory binding policies (if supported): hwloc_set/get_membind_*() and hwloc_set/get_proc_membind()
- functions that allocate memory bound to specific node set without changing the current memory binding policy (if supported): hwloc_alloc_membind() and hwloc_alloc_membind_nodeset().
- helpers which, if needed, change the current memory binding policy of the process in order to obtain memory binding: hwloc alloc membind policy() and hwloc alloc membind policy nodeset()

An application can thus use the two first sets of functions if it wants to manage separately the global process binding policy and directed allocation, or use the third set of functions if it does not care about the process memory binding policy.

See CPU binding and Memory binding for hwloc's API functions regarding CPU and memory binding, respectively. There are some examples under doc/examples/ in the source tree.

CPU	and	Memory	Binding	Overview

I/O Devices

hwloc usually manipulates processing units and memory but it can also discover I/O devices and report their locality as well. This is useful for placing I/O intensive applications on cores near the I/O devices they use.

6.1 Enabling and requirements

I/O discovery is disabled by default (except in Istopo) so as not to break legacy application by adding unexpected I/O objects to the topology. It can be enabled by passing flags such as HWLOC_TOPOLOGY_FLAG_IO_DEVICES to hwloc_topology_set_flags() before loading the topology.

Note that I/O discovery requires significant help from the operating system. The pciaccess library (the development package is usually libpciaccess-devel or libpciaccess-dev) is needed to fully detect PCI devices and bridges, and the actual locality of these devices is only currently detected on Linux. Also, some operating systems require privileges for probing PCI devices, see Does hwloc require privileged access? for details.

On Linux, PCI discovery may still be performed even if libpciaccess cannot be used. But it misses PCI device names.

6.2 I/O object hierarchy

When I/O discovery is enabled and supported, some additional objects (types HWLOC_OBJ_BRIDGE, HWLOC_OB J_PCI_DEVICE and HWLOC_OBJ_OS_DEVICE) are added to the topology as a child of the object they are close to. For instance, if a I/O Hub is connected to a package, the corresponding hwloc bridge object (and its PCI bridges and devices children) is inserted as a child of the corresponding hwloc package object.

These new objects have neither CPU sets nor node sets (NULL pointers) because they are not directly usable by the user applications. Moreover I/O hierarchies may be highly complex (asymmetric trees of bridges). So I/O objects are placed in specific levels with custom depths. Their lists may still be traversed with regular helpers such as hwloc_get_

next_obj_by_type(). However, hwloc offers some dedicated helpers such as hwloc_get_next_pcidev() and hwloc_get

next_osdev() for convenience (see Finding I/O objects).

An I/O hierarchy is organized as follows: A hostbridge object (HWLOC_OBJ_BRIDGE object with upstream type *Host* and downstream type *PCI*) is attached below a regular object (usually the entire machine or a NUMA node). There may be multiple hostbridges in the machine, attached to different places, but all I/O devices are below one of them. Each hostbridge contains one or several children, either other bridges (usually PCI to PCI) or PCI devices (HWLOC_OBJ_ PCI_DEVICE). The number of bridges between the hostbridge and a PCI device depends on the machine and on the topology flags.

28 I/O Devices

6.3 Software devices

Although each PCI device is uniquely identified by its bus ID (e.g. 0000:01:02.3), the application can hardly find out which PCI device is actually used when manipulating software handle (such as the *eth0* network interface, the *sda* hard drive, or the *mlx4_0* OpenFabrics HCA). Therefore hwloc tries to add software devices (HWLOC_OBJ_OS_DEVICE, also known as OS devices) below their PCI objects.

hwloc first tries to discover the corresponding names, e.g. *eth0*, *sda* or *mlx4_0*, from the operating system. However, this ability is currently only available on Linux for some classes of devices.

hwloc then tries to discover software devices through additional I/O components using external libraries. For instance proprietary graphics drivers do not offer any OS name, but hwloc may still create one OS object per software handle when supported. For instance the opencl and cuda components may add some *opencl0d0* and *cuda0* OS device objects.

Here is a list of OS device objects commonly created by hwloc components when I/O discovery is enabled and supported.

- Hard disks (HWLOC_OBJ_OSDEV_BLOCK)
 - sda (Linux component)
- Network interfaces (HWLOC_OBJ_OSDEV_NETWORK)
 - eth0, wlan0, ib0 (Linux component)
- OpenFabrics HCAs (HWLOC_OBJ_OSDEV_OPENFABRICS)
 - mlx4 0, gib0 (Linux component)
- GPUs (HWLOC OBJ OSDEV GPU)
 - nvml0 for the first NVML device (NVML component, using the NVIDIA Management Library)
 - :0.0 for the first display (GL component, using the NV-CONTROL X extension library, NVCtrl)
- Co-Processors (HWLOC_OBJ_OSDEV_COPROC)
 - opencl0d0 for the first device of the first OpenCL platform, opencl1d3 for the fourth device of the second
 OpenCL platform (OpenCL component)
 - cuda0 for the first NVIDIA CUDA device (CUDA component, using the NVIDIA CUDA Library)
 - mic0 for the first Intel Xeon Phi (MIC) coprocessor (Linux component)
- DMA engine channel (HWLOC_OBJ_OSDEV_DMA)
 - dma0chan0 (Linux component)

When none of the above strategies is supported and enabled, hwloc cannot place any OS object inside PCI objects. Note that some PCI devices may contain multiple software devices (see the example below).

See also Interoperability With Other Software for managing these devices without considering them as hwloc objects.

6.4 Consulting I/O devices and binding

I/O devices may be consulted by traversing the topology manually (with usual routines such as hwloc_get_obj_by_type()) or by using dedicated helpers (such as hwloc_get_pcidev_by_busid(), see Finding I/O objects).

I/O objects do not actually contain any locality information because their CPU sets and node sets are NULL. Their locality must be retrieved by walking up the object tree (through the parent link) until an non-I/O object is found (see

6.5 Examples 29

hwloc_get_non_io_ancestor_obj()). This regular object should have non-NULL CPU sets and node sets which describe the processing units and memory that are immediately close to the I/O device. For instance the path from a OS device to its locality may go across a PCI device parent, one or several bridges, up to a a NUMA node with the same locality.

Command-line tools are also aware of I/O devices. Istopo displays the interesting ones by default (passing -no-io disables it).


hwloc-calc and hwloc-bind may manipulate I/O devices specified by PCI bus ID or by OS device name.

- pci=0000:02:03.0 is replaced by the set of CPUs that are close to the PCI device whose bus ID is given.
- os=eth0 is replaced by CPUs that are close to the I/O device whose software handle is called eth0.

This enables easy binding of I/O-intensive applications near the device they use.

6.5 Examples

The following picture shows a dual-package dual-core host whose PCI bus is connected to the first package and NUMA node.



Six interesting PCI devices were discovered. However hwloc found some corresponding software devices (*eth0*, *eth1*, *sda*, *mlx4* 0, *ib0*, and *ib1*) for only four of these physical devices. The other ones (*PCI 102b:0532* and *PCI 8086:3a20*)

30 I/O Devices

are an unused IDE controller (no disk attached) and a graphic card (no corresponding software device reported to the user by the operating system).

On the contrary, it should be noted three different software devices were found for the last PCI device (*PCI 15b3:634a*). Indeed this OpenFabrics HCA PCI device object contains one one OpenFabrics software device (*mlx4_0*) and two virtual network interface software devices (*ib0* and *ib1*).

PCI link speed is also reported for some bridges and devices because Istopo was privileged when it discovered the topology.

Here is the corresponding textual output:

```
Machine (24GB)
  NUMANode L#0 (P#0 12GB)
    Package L#0 + L3 L#0 (8192KB)
      L2 L#0 (256KB) + L1 L#0 (32KB) + Core L#0 + PU L#0 (P#0)
      L2 L#1 (256KB) + L1 L#1 (32KB) + Core L#1 + PU L#1 (P#2)
    HostBridge
      PCIBridge
        PCI 14e4:163b
          Net "eth0"
        PCI 14e4:163b
          Net "eth1"
      PCIBridge
        PCI 1000:0060
          Block "sda"
      PCIBridge
        PCI 102b:0532
      PCI 8086:3a20
      PCI 15b3:634a
        Net "ib0"
        Net "ib1"
        Net "mlx4_0"
  \label{eq:numanode} \texttt{NUMANode L\#1 (P\#1 12GB) + Package L\#1 + L3 L\#1 (8192KB)}
    L2 L#2 (256KB) + L1 L#2 (32KB) + Core L#2 + PU L#2 (P#1)
    L2 L#3 (256KB) + L1 L#3 (32KB) + Core L#3 + PU L#3 (P#3)
```

Miscellaneous objects

hwloc topologies may be annotated with Misc objects (of type HWLOC_OBJ_MISC) either automatically or by the user. This is an flexible way to annotate topologies with large sets of information since Misc objects may be inserted anywhere in the topology (to annotate specific objects or parts of the topology), even below other Misc objects, and each of them may contain multiple attributes (ee also How do I annotate the topology with private notes?).

These Misc objects may have a Type info attribute to replace Misc with something else in the Istopo output.

7.1 Misc objects added by hwloc

hwloc only uses Misc objects when other object types are not sufficient. This currently includes:

• Memory devices (DIMMs), on Linux when privileged, and when I/O discovery is enabled. These objects have a Type info attribute of value MemoryDevice. They are currently always attached to the root object. Their attributes describe the DIMM vendor, model, etc. lstopo -v displays them as:

```
Misc (MemoryModule) (P#1 Type=MemoryModule DeviceLocation="Bottom-Slot 2(right)" BankLocation="BANK 2" Vendor=Elpida SerialNumber=21733667 AssetTag=9876543210 PartNumber="EBJ81UG8EFU0-GN-F")
```

• Displaying process binding in lstopo —top. These objects have a Type info attribute of value Process and a name attribute made of their PID and program name. They are attached below the object they are bound to. The textual lstopo displays them as:

```
PU L#0 (P#0)
Misc(Process) 4445 myprogram
```

7.2 Annotating topologies with Misc objects

The user may annotate hwloc topologies with its own Misc objects. A Misc object may be inserted anywhere in the topology by specifying its CPU set (using hwloc_topology_insert_misc_object_by_cpuset()). Or it may be inserted as a leaf of the topology by specifying its parent (with hwloc_topology_insert_misc_object_by-parent()).

Micco	llaneous	ah	innte
MISCE	naneous	UU	IECIS

Multi-node Topologies

hwloc is usually used for consulting and manipulating single machine topologies. This includes large systems as long as a single instance of the operating system manages the entire system. However it is sometimes desirable to have multiple independent hosts inside the same topology, for instance when applying algorithms to an entire cluster topology. hwloc therefore offers the ability to agregate multiple host topologies into a single global one.

8.1 Multi-node Objects Specifities

A multi-node topology contains several single-node topologies. Those are assembled by making their own root objects (usually Machine object) children of higher objects. These higher objects include at least the root of the global topology (usually a System object). Some intermediate objects may also exists, for instance to represent switches in a large fabric.

There are actually three possible types of objects that have different properties with respect to cpusets, nodesets and binding. Indeed those cpusets and nodesets were designed for execution and memory binding within a single operating system. Binding on another system or across several different systems would be meaningless.

Local objects Any object that corresponds to the local machine may be manipulated as usual. Obviously, if the multi-node topology does not contain the local machine topology, no such local object exists.

Objects from other nodes Any object that comes from inside another node is represented as usual but its cpusets and nodesets should not be used for binding since binding on another system makes no sense.

Objects above single nodes Any object above single-node topologies does not have any cpuset or nodeset pointer because binding across multiple systems makes no sense. This includes the glocal root object of a multi-node topology and possibly some intermediate objects between this global root and the local root of single-node topologies.

It is important to keep this in mind before binding using multi-node topologies. To make sure binding on an object is possible, one should first check that its cpuset or nodeset pointer is not NULL. Then, one should check whether the object is indeed local.

To find out which machine a given object corresponds to, one may look at the info attributes of the parent Machine object. The HostName info is usually available in Machine objects, it may be retrieved with the following code:

```
hwloc_obj_t machine_obj;
obj = hwloc_get_ancestor_obj_by_type(topology, HWLOC_OBJ_MACHINE, obj);
if (machine_obj)
  return hwloc_obj_get_info_by_name(machine_obj, "HostName");
else
  return NULL:
```

The hwloc assembler scripts (see below) also add AssemblerName and AssemblerIndex info attributes to the Machine objects to identify the corresponding host name and index during assembly.

8.2 Assembling topologies with command-line tools

One way to manipulate multinode topologies is to retrieve other nodes' topologies as XML files and combine them as a global XML topology. It may then be loaded with https://hww.nubelever.nd/ is to retrieve other nodes' topologies as XML files and combine them as a global XML topology. It may then be loaded with https://hww.nubelever.nd/ is to retrieve other nodes' topologies as XML files and combine them as a global XML topology. It may then be loaded with https://hww.nubelever.nd/ is to retrieve other nodes' topologies as XML files and combine them as a global XML topology. It may then be loaded with https://hww.nubelever.nd/ is to retrieve other nodes' topology_set_xml() or with the HWLOC_XMLFILE environment variable.

The hwloc-assembler and hwloc-assembler-remote utilities offer the ability to combine XML topologies or remote nodes' topologies (see Command-Line Tools).

8.3 Assembling topologies with the programming interface

The hwloc programming interface offers the ability to build multinode topologies using the *custom* interface. A new multinode topology has to be initialized with hwloc_topology_init() and then set to custom with hwloc_topology_set—custom(). Topologies and objects mat then be assembled. Later, the custom topology is finalized as usual with hwloc topology load().

A custom topology starts with a single root object of type System. It may be modified by inserting a new child object with hwloc_custom_insert_group_object_by_parent() or by duplicating another topology with hwloc_custom_insert_ctopology(). Both of these operations require to specify the parent object in the custom topology where the insertion will take place. This parent may be either the root (returned by hwloc_get_root_obj()) or an already-inserted object (returned by hwloc_custom_insert_group_object_by_parent()).

Ideally, any existing object in the custom topology could be the parent. However, special care should be taken when traversing the topology to find such an object because most links between objects (children, siblings, cousins) are not setup until hwloc_topology_load() is invoked.

8.4 Example of assembly with the programming interface

If the topologies of two hosts have been previously gathered in XML files host1.xml and host2.xml, the global topology may be assembled with the following code.

```
hwloc_topology_t host1, host2, global;
/* initialize global topology */
hwloc_topology_init(&global);
hwloc_topology_set_custom(global);
/* insert host1 entire topology below the global topology root */
hwloc_topology_init(&host1);
hwloc_topology_load(host1);
hwloc_custom_insert_topology(global, hwloc_get_root_obj(global),
                             host1, NULL);
hwloc_topology_destroy(host1);
/* insert host2 entire topology below the global topology root */
hwloc_topology_init(&host2);
hwloc_topology_load(host2);
hwloc_custom_insert_topology(global, hwloc_get_root_obj(global),
                             host2, NULL);
hwloc_topology_destroy(host2);
/* load and play with the global topology */
```

```
hwloc_topology_load(global);
```

If a intermediate object such as a switch should be inserted above one of the host topologies:

		_	
Multi-n	Ode	Inno	loaies

Object attributes

9.1 Normal attributes

hwloc objects have many attributes. The hwloc_obj structure contains a common set of attributes that are available for object types, for instance their type or logical_index.

Each object also contains an attr field that, if non NULL, points to a union hwloc_obj_attr_u of type-specific attribute structures. For instance, a Cache object obj contains cache-specific information in obj->attr->cache, such as its size and associativity. See hwloc_obj_attr_u for details.

9.2 Custom string infos

Aside from the name field of each object, hwloc annotates many objects with string attributes that are made of a key and a value. Each object contains a list of such pairs that may be consulted manually (looking at the object infos array field) or using the hwloc_obj_get_info_by_name(). The user may additionally add new key-value pairs to any object using hwloc_obj_add_info() or the hwloc-annotate program.

Here is a non-exhaustive list of attributes that may be automatically added by hwloc (with the usual corresponding object in parentheses). Note that these attributes heavily depend on the ability of the operating system to report them. Many of them will therefore be missing on some OS.

- **OSName, OSRelease, OSVersion, HostName, Architecture (Machine object)** The operating system name, release, version, the hostname and the architecture name, as reported by the Unix uname command.
- **Backend (Machine object or topology root object)** The name of the hwloc backend/component that filled the topology. If several components were combined, multiple Backend keys may exist, with different values, for instance x86, Linux and pci.
- LinuxCgroup (Machine object) The name the Linux control group where the calling process is placed.
- **SyntheticDescription (topology root object)** The description string that was given to hwloc to build this synthetic topology.
- **CPUModel (Package or Machine)** The processor model name. Usually added to Package objects, but can be in Machine instead if hwloc failed to discover any package.
- CPUType (Package) A Solaris-specific general processor type name, such as "i86pc".
- **CPUVendor, CPUModelNumber, CPUFamilyNumber, CPUStepping (Package or Machine)** The processor vendor name, model number, family number, and stepping number. Currently available for x86 and Xeon Phi processors

38 Object attributes

on most systems, and for ia64 processors on Linux (except CPUStepping). Usually added to Package objects, but can be in Machine instead if hwloc failed to discover any package.

CPURevision (Package) A POWER/PowerPC-specific general processor revision number, currently only available on Linux.

PlatformName, PlatformModel, PlatformVendor, PlatformBoardID, PlatformRevision,

SystemVersionRegister, ProcessorVersionRegister (Machine) Some POWER/PowerPC-specific attributes describing the platform and processor. Currently only available on Linux. Usually added to Package objects, but can be in Machine instead if hwloc failed to discover any package.

PCIVendor, PCIDevice (PCI devices and bridges) The vendor and device names of the PCI device.

PCISIOT The name/number of the physical slot where the PCI device is plugged.

Vendor, Model, Revision, SerialNumber The vendor and model names, and revision and serial numbers of a Block OS device.

LinuxDeviceID The major/minor device number such as 8:0 on Linux for a Block OS device.

CoProcType (Co-Processor OS devices) The type of co-processor, for instance "MIC", "CUDA" or "OpenCL".

GPUVendor, GPUModel (GPU or Co-Processor OS devices) The vendor and model names of the GPU device.

OpenCLDeviceType, OpenCLPlatformIndex,

OpenCLPlatformName, OpenCLPlatformDeviceIndex (OpenCL GPU OS devices) The type of OpenCL device, the OpenCL platform index and name, and the index of the device within the platform.

OpenCLComputeUnits, OpenCLGlobalMemorySize The number of compute units and global memory size (in kB) of a OpenCL device.

NVIDIAUUID, NVIDIASerial (NVML GPU OS devices) The UUID and Serial of NVIDIA GPUs.

CUDAMultiProcessors, CUDACoresPerMP,

CUDAGlobalMemorySize, CUDAL2CacheSize, CUDASharedMemorySizePerMP (CUDA OS devices) The number of shared multiprocessors, the number of cores per multiprocessor, the global memory size, the (global) L2 cache size, and size of the shared memory in each multiprocessor of a CUDA device. Sizes are in kB.

MICSerialNumber The serial number of an Intel Xeon Phi (MIC) coprocessor. hwloc may run either inside the coprocessor itself, or on the host processor. That attribute is set in both cases, so that the exact same coprocessor may be identified from both point of views, even if there are multiple nodes with multiple MICs. When running hwloc on the host, each hwloc OS device object that corresponds to a Xeon Phi gets such an attribute. When running hwloc inside a Xeon Phi coprocessor, the root object of the topology gets this attribute.

MICFamily, MICSKU, MICActiveCores, MICMemorySize The family, SKU (model), number of active cores, and memory size (in kB) of an Intel Xeon Phi (MIC) coprocessor.

DMIBoardVendor, DMIBoardName, etc. (Machine object) DMI hardware information such as the motherboard and chassis models and vendors, the BIOS revision, etc., as reported by Linux under /sys/class/dmi/id/.

Address, Port (Network interface OS devices) The MAC address and the port number of a software network interface, such as eth4 on Linux.

NodeGUID, SysImageGUID, Port1State, Port2LID, Port2LMC, Port3GID1 (OpenFabrics OS devices) The node GUID and GUID mask, the state of a port #1 (value is 4 when active), the LID and LID mask count of port #2, and GID #1 of port #3.

Type A better type name than the usual one. This may be used to specify where Groups come from. For instance Linux s390 *books* appear as Groups of type *Book*. Block OS devices may have a Type of "Disk", "Tape", "Removable Media Device" or "Other". The Type attribute value is displayed instead of the default object type name in Istopo.

- **Vendor, AssetTag, PartNumber, DeviceLocation, BankLocation (MemoryDevice Misc objects)** Information about memory devices (DIMMs) extracted from SMBIOS.
- **hwlocVersion** The version number of the hwloc library that was used to generate the topology. If the topology was loaded from XML, this is not the hwloc version that loaded it, but rather the first hwloc instance that exported the topology to XML earlier.
- **ProcessName** The name of the process that contains the hwloc library that was used to generate the topology. If the topology was from XML, this is not the hwloc version that loaded it, but rather the first process that exported the topology to XML earlier.

Here is a non-exhaustive list of user-provided info attributes that have a special meaning:

IstopoStyle Enforces the style of an object (background and text colors) in the graphical output of Istopo. See CUS← TOM COLORS in the Istopo(1) manpage for details.

40 **Object attributes**

Importing and exporting topologies from/to XML files

hwloc offers the ability to export topologies to XML files and reload them later. This is for instance useful for loading topologies faster (see I do not want hwloc to rediscover my enormous machine topology every time I rerun a process), manipulating other nodes' topology, or avoiding the need for privileged processes (see Does hwloc require privileged access?).

Topologies may be exported to XML files thanks to https://hwloc.topology.export_xml(), or to a XML memory buffer with https://hwloc.topology.export_xmlbuffer(). The Istopo program can also serve as a XML topology export tool.

XML topologies may then be reloaded later with hwloc_topology_set_xml() and hwloc_topology_set_xml(). The XMLFILE environment variable also tells hwloc to load the topology from the given XML file.

Note

Loading XML topologies disables binding because the loaded topology may not correspond to the physical machine that loads it. This behavior may be reverted by asserting that loaded file really matches the underlying system with the HWLOC_THISSYSTEM environment variable or the HWLOC_TOPOLOGY_FLAG_IS_THISS YSTEM topology flag.

hwloc also offers the ability to export/import Topology differences.

XML topology files are not localized. They use a dot as a decimal separator. Therefore any exported topology can be reloaded on any other machine without requiring to change the locale.

XML exports contain all details about the platform. It means that two very similar nodes still have different $X \leftarrow ML$ exports (e.g. some serial numbers or MAC addresses are different). If a less precise exporting/importing is required, one may want to look at Synthetic topologies instead.

10.1 libxml2 and minimalistic XML backends

hwloc offers two backends for importing/exporting XML.

First, it can use the libxml2 library for importing/exporting XML files. It features full XML support, for instance when those files have to be manipulated by non-hwloc software (e.g. a XSLT parser). The libxml2 backend is enabled by default if libxml2 development headers are available (the relevant development package is usually libxml2-devel or libxml2-dev).

If libxml2 is not available at configure time, or if <code>-disable-libxml2</code> is passed, hwloc falls back to a custom backend. Contrary to the aforementioned full XML backend with libxml2, this minimalistic XML backend cannot be guaranteed to work with external programs. It should only be assumed to be compatible with the same hwloc release (even if using the libxml2 backend). Its advantage is however to always be available without requiring any external dependency.

If libxml2 is available but the core hwloc library should not directly depend on it, the libxml2 support may be built as a dynamicall-loaded plugin. One should pass -enable-plugins to enable plugin support (when supported) and

build as plugins all component that support it. Or pass <code>-enable-plugins=xml_libxml</code> to only build this libxml2 support as a plugin.

10.2 XML import error management

Importing XML files can fail at least because of file access errors, invalid XML syntax or non-hwloc-valid XML contents.

Both backend cannot detect all these errors when the input XML file or buffer is selected (when hwloc_topology_set __xml() or hwloc_topology_set_xmlbuffer() is called). Some errors such non-hwloc-valid contents can only be detected later when loading the topology with hwloc_topology_load().

It is therefore strongly recommended to check the return value of both hwloc_topology_set_xml() (or hwloc_topology = set_xmlbuffer()) and hwloc_topology_load() to handle all these errors.

Synthetic topologies

hwloc may load fake or remote topologies so as to consult them without having the underlying hardware available. Aside from loading XML topologies, hwloc also enables the building of *synthetic* topologies that are described by a single string listing the arity of each levels.

For instance, Istopo may create a topology made of 2 NUMA nodes, containing a single package each, with one cache above two single-threaded cores:

```
$ lstopo -i "node:2 pack:1 cache:1 core:2 pu:1" -
Machine (2048MB)

NUMANode L#0 (P#0 1024MB) + Package L#0 + L2 L#0 (4096KB)
Core L#0 + PU L#0 (P#0)
Core L#1 + PU L#1 (P#1)

NUMANode L#1 (P#1 1024MB) + Package L#1 + L2 L#1 (4096KB)
Core L#2 + PU L#2 (P#2)
Core L#3 + PU L#3 (P#3)
```

Replacing - with file.xml in this command line will export this topology to XML as usual.

Note

Synthetic topologies offer a very basic way to export a topology and reimport it on another machine. It is a lot less precise than XML but may still be enough when only the hierarchy of resources matters.

11.1 Synthetic description string

Each item in the description string gives the type of the level and the number of such children under each object of the previous level. That is why the above topology contains 4 cores (2 cores times 2 nodes).

These type names must be written as machine, node, package, core, cache, pu, group. They do not need to be written case-sensitively, nor entirely (as long as there is no ambiguity, 2 characters such as ma select a Machine level). Type-specific attributes may also be given such as L2iCache (hwloc_obj_type_sscanf() is used for parsing the type names). Note that I/O and Misc objects are not available.

The root object does not appear in the string. A Machine object is used by default, and a System object replaces it if a Machine level is specified in the string.

Cache level depths are automatically chosen by hwloc (only a L2 first, then a L1 under it, then L3 above, then L4 etc.) unless they are specified. Memory and cache sizes are also automatically chosen. The only way to modifying them is to export to XML and manually modify the file.

Each item may be followed parentheses containing a list of space-separated attributes. For instance:

44 Synthetic topologies

• L2iCache: 2 (size=32kB) specifies 2 children of 32kB level-2 instruction caches. The size may be specified in bytes (without any unit suffix) or as TB, GB, MB or kB.

- NUMANode: 3 (memory=16MB) specifies 3 NUMA nodes with 16MB each. The size may be specified in bytes (without any unit suffix) or as TB, GB, MB or kB.
- PU:2 (indexes=0,2,1,3) specifies 2 PU children and the full list of OS indexes among the entire set of 4 PU objects.
- PU: 2 (indexes=numa:core) specifies 2 PU children whose OS indexes are interleaved by NUMA node first and then by package.
- · Attributes in parentheses at the very beginning of the description apply to the root object.

11.2 Loading a synthetic topology

Aside from Istopo, the hwloc programming interface offers the same ability by passing the synthetic description string to hwloc_topology_set_synthetic() before hwloc_topology_load().

Synthetic topologies are created by the synthetic component. This component may be enabled by force by setting the HWLOC COMPONENTS environment variable to something such as synthetic="node:2 core:3 pu:4".

Loading a synthetic topology disables binding support since the topology usually does not match the underlying hardware. Binding may be reenabled as usual by setting HWLOC_THISSYSTEM=1 in the environment or by setting the HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM topology flag.

11.3 Exporting a topology as a synthetic string

The function hwloc_topology_export_synthetic() may export a topology as a synthetic string. It offers a convenient way to quickly describe the contents of a machine. The Istopo tool may also perform such an export by forcing the output format.

```
$ lstopo --of synthetic --no-io
Package:1 Cache:1 Cache:2 Cache:1 Cache:1 PU:2
```

The exported string may be passed back to hwloc for recreating another similar topology. The entire tree will be similar, but some special attributes such processort types may be missing.

Such an export is only possible if the topology is totally symmetric, which means the $symmetric_subtree$ field of the root object is set. This usually implies that I/O objects are disabled since attaching I/O busses often cause the topology to become asymmetric. Passing -no-io to Istopo is therefore often useful to make synthetic export work (as well as not passing any I/O topology flag before exporting with hwloc_topology_export_synthetic()).

Interoperability With Other Software

Although hwloc offers its own portable interface, it still may have to interoperate with specific or non-portable libraries that manipulate similar kinds of objects. hwloc therefore offers several specific "helpers" to assist converting between those specific interfaces and hwloc.

Some external libraries may be specific to a particular OS; others may not always be available. The hwloc core therefore generally does not explicitly depend on these types of libraries. However, when a custom application uses or otherwise depends on such a library, it may optionally include the corresponding hwloc helper to extend the hwloc interface with dedicated helpers.

Most of these helpers use structures that are specific to these external libraries and only meaningful on the local machine. If so, the helper requires the input topology to match the current machine. Some helpers also require I/O device discovery to be supported and enabled for the current topology.

- **Linux specific features** hwloc/linux.h offers Linux-specific helpers that utilize some non-portable features of the Linux system, such as binding threads through their thread ID ("tid") or parsing kernel CPU mask files.
- **Linux libnuma** hwloc/linux-libnuma.h provides conversion helpers between hwloc CPU sets and libnuma-specific types, such as bitmasks. It helps you use libnuma memory-binding functions with hwloc CPU sets.
- **Glibc** hwloc/glibc-sched.h offers conversion routines between Glibc and hwloc CPU sets in order to use hwloc with functions such as sched_getaffinity() or pthread_attr_setaffinity_np().
- **OpenFabrics Verbs** hwloc/openfabrics-verbs.h helps interoperability with the OpenFabrics Verbs interface. For example, it can return a list of processors near an OpenFabrics device. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).
- **Myrinet Express** hwloc/myriexpress.h offers interoperability with the Myrinet Express interface. It can return the list of processors near a Myrinet board managed by the MX driver. Note that if I/O device discovery is enabled, such boards may also appear as PCI objects in the topology.
- Intel Xeon Phi (MIC) hwloc/intel-mic.h helps interoperability with Intel Xeon Phi (MIC) coprocessors by returning the list of processors near these devices. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).
- AMD OpenCL hwloc/opencl.h enables interoperability with the OpenCL interface. Only the AMD implementation currently offers locality information. It may return the list of processors near an AMD/ATI GPU given as a cl_ device_id. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).
- **NVIDIA CUDA** hwloc/cuda.h and hwloc/cudart.h enable interoperability with NVIDIA CUDA Driver and Runtime interfaces. For instance, it may return the list of processors near NVIDIA GPUs. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).

- **NVIDIA Management Library (NVML)** hwloc/nvml.h enables interoperability with the NVIDIA NVML interface. It may return the list of processors near a NVIDIA GPU given as a nvmlDevice_t. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).
- **NVIDIA displays** hwloc/gl.h enables interoperability with NVIDIA displays using the NV-CONTROL X extension (N ← VCtrl library). If I/O device discovery is enabled, it may return the OS device hwloc object that corresponds to a display given as a name such as :0.0 or given as a port/device pair (server/screen).
- Taskset command-line tool The taskset command-line tool is widely used for binding processes. It manipulates CPU set strings in a format that is slightly different from hwloc's one (it does not divide the string in fixed-size subsets and separates them with commas). To ease interoperability, hwloc offers routines to convert hwloc CPU sets from/to taskset-specific string format. Most hwloc command-line tools also support the -taskset option to manipulate taskset-specific strings.

Thread Safety

Like most libraries that mainly fill data structures, hwloc is not thread safe but rather reentrant: all state is held in a hwloc_topology_t instance without mutex protection. That means, for example, that two threads can safely operate on and modify two different hwloc_topology_t instances, but they should not simultaneously invoke functions that modify the *same* instance. Similarly, one thread should not modify a hwloc_topology_t instance while another thread is reading or traversing it. However, two threads can safely read or traverse the same hwloc_topology_t instance concurrently.

When running in multiprocessor environments, be aware that proper thread synchronization and/or memory coherency protection is needed to pass hwloc data (such as hwloc_topology_t pointers) from one processor to another (e.g., a mutex, semaphore, or a memory barrier). Note that this is not a hwloc-specific requirement, but it is worth mentioning.

For reference, hwloc_topology_t modification operations include (but may not be limited to):

Creation and destruction hwloc_topology_init(), hwloc_topology_load(), hwloc_topology← _destroy() (see Topology Creation and Destruction) imply major modifications of the structure, including freeing some objects. No other thread cannot access the topology or any of its objects at the same time.

Also references to objects inside the topology are not valid anymore after these functions return.

Runtime topology modifications hwloc_topology_insert_misc_object_by_* (see Modifying a loaded Topology) may modify the topology significantly by adding objects inside the tree, changing the topology depth, etc. hwloc_topology_restrict modifies the topology even more dramatically by removing some objects.

Although references to former objects may still be valid after insertion or restriction, it is strongly advised to not rely on any such guarantee and always re-consult the topology to reacquire new instances of objects.

Locating topologies hwloc_topology_ignore*, hwloc_topology_set* (see Topology Detection Configuration and Query) do not modify the topology directly, but they do modify internal structures describing the behavior of the upcoming invocation of hwloc_topology_load(). Hence, all of these functions should not be used concurrently.

48 **Thread Safety**

Chapter 14

Components and plugins

hwloc is organized in components that are responsible for discovering objects. Depending on the topology configuration, some components will be used, some will be ignored. The usual default is to enable the native operating system component, (e.g. linux or solaris) and the pci miscellaneous component. If available, an architecture-specific component (such as x86) may also improve the topology detection.

If a XML topology is loaded, the xml discovery component will be used instead of all other components. It internally uses a specific class of components for the actual XML import/export routines (xml_libxml and xml_nolibxml) but these will not be discussed here (see libxml2 and minimalistic XML backends).

14.1 Components enabled by default

The hwloc core contains a list of components sorted by priority. Each one is enabled as long as it does not conflict with the previously enabled ones. This includes native operating system components, architecture-specific ones, and if available, I/O components such as pci.

Usually the native operating system component (when it exists, e.g. linux or aix) is enabled first. Then hwloc looks for an architecture specific component (e.g. x86). Finally there also exist a basic component (no_os) that just tries to discover the number of PUs in the system.

Each component discovers as much topology information as possible. Most of them, including most native OS components, do nothing unless the topology is still empty. Some others, such as x86 and pci, can complete and annotate what other backends found earlier.

Default priorities ensure that clever components are invoked first. Native operating system components have higher priorities, and are therefore invoked first, because they likely offer very detailed topology information. If needed, it will be later extended by architecture-specific information (e.g. from the $\times 86$ component).

If any configuration function such as hwloc_topology_set_xml() is used before loading the topology, the corresponding component is enabled first. Then, as usual, hwloc enables any other component (based on priorities) that does not conflict.

Certain components that manage a virtual topology, for instance XML topology import, synthetic topology description, or custom building, conflict with all other components. Therefore, one of them may only be loaded (e.g. with hwloc-topology_set_xml()) if no other component is enabled.

The environment variable HWLOC_COMPONENTS_VERBOSE may be set to get verbose messages about component registration (including their priority) and enabling.

14.2 Selecting which components to use

Once topology configuration functions such as hwloc_topology_set_custom() have been taken care of, the priority order of the remaining components may be changed through the HWLOC_COMPONENTS environment variable (component names must be separated by commas).

Specifying x86 in this variable will cause the x86 component to take precedence over any other component, including the native operating system component. It is therefore loaded first, before hwloc tries to load all remaining non-conflicting components. In this case, x86 would take care of discovering everything it supports, instead of only completing what the native OS information. This may be useful if the native component is buggy on some platforms.

It is possible to prevent some components from being loaded by prefixing their name with – in the list. For instance x86, -pci will load the x86 component, then let hwloc load all the usual components except pci.

It is possible to prevent all remaining components from being loaded by placing stop in the environment variable. Only the components listed before this keyword will be enabled.

Certain component names (xml and synthetic) accept an argument (e.g. xml=file.xml). These arguments behave exactly as if the corresponding string had been passed to hwloc_topology_set_xml() or hwloc_ctopology_set_synthetic().

14.3 Loading components from plugins

Components may optionally be built as plugins so that the hwloc core library does not directly depend on their dependencies (for instance the libpciaccess library). Plugin support may be enabled with the <code>-enable-plugins</code> configure option. All components buildable as plugins will then be built as plugins. The configure option may be given a comma-separated list of component names to specify the exact list of components to build as plugins.

Plugins are built as independent dynamic libraries that are installed in \$libdir/hwloc. All plugins found in this directory are loaded during topology_init(). A specific list of directories (colon-separated) to scan may be specified in the HWLOC PLUGINS PATH environment variable.

Note that loading a plugin just means that the corresponding component is registered to the hwloc core. Components are then only enabled if the topology configuration requests it, as explained in the previous sections.

Also note that plugins should carefully be enabled and used when embedding hwloc in another project, see Embedding hwloc in Other Software for details.

14.4 Adding new discovery components and plugins

The types and functions cited below are declared in the hwloc/plugins.h header. Components are supposed to only use hwloc haders (hwloc.h and anything under the include/hwloc subdirectory) and nothing from the include/private subdirectory in the source tree.

14.4.1 Basics of discovery components

Each discovery component is defined by a hwloc_disc_component structure which contains an instantiate() callback. This function is invoked when this component is actually used by a topology. It fills a new hwloc_backend structure that usually contains discover() and/or notify_new_object() callbacks taking care of the actual topology discovery.

Note

If two discovery components have the same name, only the highest priority one is actually made available. This offers a way for third-party plugins to override existing components.

14.4.2 Registering a new discovery component

Registering components to the hwloc core relies on a hwloc_component structure. Its data field points to the previously defined hwloc_disc_component structure while its type should be HWLOC_COMPONENT_TYPE \leftarrow DISC. This structure should be named hwloc <name> component.

The configure script should be modified to add <name> to its hwloc_components shell variable so that the component is actually available.

Note

The symbol name of the hwloc_component structure is independent of the name of the discovery component mentioned in the previous section.

When the component is statically built inside the hwloc library, the symbol hwloc_<name>_component is added by configure to the src/static-components.h. The core then registers all components listed in this file.

If the new component may be built as a plugin, the configure script should also define the shell variable hwloc_ <name>_component_maybeplugin=1. When the configure script actually enables the component as a plugin, it will set the variable hwloc_<name>_component to plugin. The build system may then use this variable to change the way the component is built. It should create a hwloc_<name>.so shared object. All these files are loaded in alphabetic order, and the components they contain are registered to the hwloc core.

14.5 Existing components and plugins

All components distributed within hwloc are listed below. The list of actually available components may be listed at running with the HWLOC_COMPONENTS_VERBOSE environment variable (see Environment Variables).

- **aix, darwin, freebsd, hpux, linux, netbsd, osf, solaris, windows** Each officially supported operating system has its own native component, which is statically built when supported, and which is used by default.
- **x86** The x86 architecture (either 32 or 64 bits) has its own component that may complete or replace the previously-found CPU information. It is statically built when supported.
- bgq This component is specific to IBM BlueGene/Q compute node (running CNK). It is built and enabled by default when -host=powerpc64-bgq-linux is passed to configure (see How do I build hwloc for BlueGene/Q?).
- **no_os** A basic component that just tries to detect the number of processing units in the system. It mostly serves on operating systems that are not natively supported. It is always statically built.
- pci PCI object discovery uses the external pciaccess library (aka libpciaccess); see I/O Devices. It may be built as a plugin.
- **linuxpci** This component can probe PCI devices on Linux without the help of external libraries such as libpciaccess. Its priority is lower than the pci component because it misses device names.
- **opencl** The OpenCL component creates co-processor OS device objects such as *opencl0d0* (first device of the first OpenCL platform) or *opencl1d3* (fourth device of the second platform). Only the AMD OpenCL implementation currently offers locality information. **It may be built as a plugin**.

- **cuda** This component creates co-processor OS device objects such as *cuda0* that correspond to NVIDIA GPUs used with CUDA library. **It may be built as a plugin**.
- **nvml** Probing the NVIDIA Management Library creates OS device objects such as *nvml0* that are useful for batch schedulers. It also detects the actual PCIe link bandwidth without depending on power management state and without requiring administrator privileges. **It may be built as a plugin**.
- **gl** Probing the NV-CONTROL X extension (NVCtrl library) creates OS device objects such as :0.0 corresponding to NVIDIA displays. They are useful for graphical applications that need to place computation and/or data near a rendering GPU. **It may be built as a plugin**.

synthetic Synthetic topology support (see Synthetic topologies) is always built statically.

custom Custom topology support (see Multi-node Topologies) is always built statically.

- **xml** XML topology import (see Importing and exporting topologies from/to XML files) is always built statically. It internally uses one of the XML backends (see libxml2 and minimalistic XML backends).
 - xml_nolibxml is a basic and hwloc-specific XML import/export. It is always statically built.
 - xml_libxml relies on the external libxml2 library for provinding a feature-complete XML import/export. It may be built as a plugin.

fake A dummy plugin that does nothing but is used for debugging plugin support.

Chapter 15

Embedding hwloc in Other Software

It can be desirable to include hwloc in a larger software package (be sure to check out the LICENSE file) so that users don't have to separately download and install it before installing your software. This can be advantageous to ensure that your software uses a known-tested/good version of hwloc, or for use on systems that do not have hwloc pre-installed.

When used in "embedded" mode, hwloc will:

- · not install any header files
- · not build any documentation files
- · not build or install any executables or tests
- not build libhwloc.* instead, it will build libhwloc_embedded.*

There are two ways to put hwloc into "embedded" mode. The first is directly from the configure command line:

```
shell$ ./configure --enable-embedded-mode ...
```

The second requires that your software project uses the GNU Autoconf / Automake / Libtool tool chain to build your software. If you do this, you can directly integrate hwloc's m4 configure macro into your configure script. You can then invoke hwloc's configuration tests and build setup by calling an m4 macro (see below).

Although hwloc dynamic shared object plugins may be used in embedded mode, the embedder project will have to manually setup libltdl in its build system so that hwloc can load its plugins at run time. Also, embedders should be aware of complications that can arise due to public and private linker namespaces (e.g., if the embedder project is loaded into a private namespace and then hwloc tries to dynamically load its plugins, such loading may fail since the hwloc plugins can't find the hwloc symbols they need). The embedder project is **strongly** advised not to use hwloc's dynamically loading plugins / libltdl capability.

15.1 Using hwloc's M4 Embedding Capabilities

Every project is different, and there are many different ways of integrating hwloc into yours. What follows is *one* example of how to do it.

If your project uses recent versions Autoconf, Automake, and Libtool to build, you can use hwloc's embedded m4 capabilities. We have tested the embedded m4 with projects that use Autoconf 2.65, Automake 1.11.1, and Libtool 2.2.6b. Slightly earlier versions of may also work but are untested. Autoconf versions prior to 2.65 are almost certain to not work.

You can either copy all the config/hwloc*m4 files from the hwloc source tree to the directory where your project's m4 files reside, or you can tell aclocal to find more m4 files in the embedded hwloc's "config" subdirectory (e.g., add "-\leftarrow lpath/to/embedded/hwloc/config" to your Makefile.am's ACLOCAL AMFLAGS).

The following macros can then be used from your configure script (only HWLOC_SETUP_CORE *must* be invoked if using the m4 macros):

• HWLOC_SETUP_CORE(config-dir-prefix, action-upon-success, action-upon-failure, print_banner_or_not): Invoke the hwloc configuration tests and setup the hwloc tree to build. The first argument is the prefix to use for AC_OUTPUT files – it's where the hwloc tree is located relative to \$top_srcdir. Hence, if your embedded hwloc is located in the source tree at contrib/hwloc, you should pass [contrib/hwloc] as the first argument. If HWLOC_SETUP_CORE and the rest of configure completes successfully, then "make" traversals of the hwloc tree with standard Automake targets (all, clean, install, etc.) should behave as expected. For example, it is safe to list the hwloc directory in the SUBDIRS of a higher-level Makefile.am. The last argument, if not empty, will cause the macro to display an announcement banner that it is starting the hwloc core configuration tests.

HWLOC_SETUP_CORE will set the following environment variables and AC_SUBST them: HWLOC_EMB

EDDED_CFLAGS, HWLOC_EMBEDDED_CPPFLAGS, and HWLOC_EMBEDDED_LIBS. These flags are filled
with the values discovered in the hwloc-specific m4 tests, and can be used in your build process as relevant. The
_CFLAGS, _CPPFLAGS, and _LIBS variables are necessary to build libhwloc (or libhwloc_embedded) itself.

HWLOC_SETUP_CORE also sets HWLOC_EMBEDDED_LDADD environment variable (and AC_SUBSTs it) to contain the location of the libhwloc_embedded.la convenience Libtool archive. It can be used in your build process to link an application or other library against the embedded hwloc library.

NOTE: If the HWLOC_SET_SYMBOL_PREFIX macro is used, it must be invoked *before* HWLOC_SETUP ← CORE.

- HWLOC_BUILD_STANDALONE: HWLOC_SETUP_CORE defaults to building hwloc in an "embedded" mode (described above). If HWLOC_BUILD_STANDALONE is invoked *before* HWLOC_SETUP_CORE, the embedded definitions will not apply (e.g., libhwloc.la will be built, not libhwloc_embedded.la).
- HWLOC_SET_SYMBOL_PREFIX(foo_): Tells the hwloc to prefix all of hwloc's types and public symbols with "foo_"; meaning that function hwloc_init() becomes foo_hwloc_init(). Enum values are prefixed with an uppercase translation if the prefix supplied; HWLOC_OBJ_SYSTEM becomes FOO_HWLOC_OBJ_SYSTEM. This is recommended behavior if you are including hwloc in middleware it is possible that your software will be combined with other software that links to another copy of hwloc. If both uses of hwloc utilize different symbol prefixes, there will be no type/symbol clashes, and everything will compile, link, and run successfully. If you both embed hwloc without changing the symbol prefix and also link against an external hwloc, you may get multiple symbol definitions when linking your final library or application.
- HWLOC_SETUP_DOCS, HWLOC_SETUP_UTILS, HWLOC_SETUP_TESTS: These three macros only apply
 when hwloc is built in "standalone" mode (i.e., they should NOT be invoked unless HWLOC_BUILD_STANDA
 LONE has already been invoked).
- HWLOC_DO_AM_CONDITIONALS: If you embed hwloc in a larger project and build it conditionally with Automake (e.g., if HWLOC_SETUP_CORE is invoked conditionally), you must unconditionally invoke HWLOC_D← O_AM_CONDITIONALS to avoid warnings from Automake (for the cases where hwloc is not selected to be built). This macro is necessary because hwloc uses some AM_CONDITIONALs to build itself, and AM_CONDITIONALs cannot be defined conditionally. Note that it is safe (but unnecessary) to call HWLOC_DO_AM_CONDITIONALS even if HWLOC_SETUP_CORE is invoked unconditionally. If you are not using Automake to build hwloc, this macro is unnecessary (and will actually cause errors because it invoked AM_* macros that will be undefined).

NOTE: When using the HWLOC_SETUP_CORE m4 macro, it may be necessary to explicitly invoke AC_CANONIC ← AL_TARGET (which requires config.sub and config.guess) and/or AC_USE_SYSTEM_EXTENSIONS macros early in the configure script (e.g., after AC_INIT but before AM_INIT_AUTOMAKE). See the Autoconf documentation for further information.

Also note that hwloc's top-level configure.ac script uses exactly the macros described above to build hwloc in a standalone mode (by default). You may want to examine it for one example of how these macros are used.

15.2 Example Embedding hwloc

Here's an example of integrating with a larger project named sandbox that already uses Autoconf, Automake, and Libtool to build itself:

```
# First, cd into the sandbox project source tree
shell$ cd sandbox
shell$ cp -r /somewhere/else/hwloc-<version> my-embedded-hwloc
shell$ edit Makefile.am
  1. Add "-Imy-embedded-hwloc/config" to ACLOCAL_AMFLAGS
  2. Add "my-embedded-hwloc" to SUBDIRS
  3. Add "$(HWLOC_EMBEDDED_LDADD)" and "$(HWLOC_EMBEDDED_LIBS)" to
     sandbox's executable's LDADD line. The former is the name of the
    Libtool convenience library that hwloc will generate. The latter
    is any dependent support libraries that may be needed by
     $ (HWLOC_EMBEDDED_LDADD) .
  4. Add "$(HWLOC_EMBEDDED_CFLAGS)" to AM_CFLAGS
  5. Add "$(HWLOC\_EMBEDDED\_CPPFLAGS)" to AM_CPPFLAGS
shell$ edit configure.ac
 1. Add "HWLOC_SET_SYMBOL_PREFIX(sandbox_hwloc_)" line
  2. Add "HWLOC_SETUP_CORE([my-embedded-hwloc], [happy=yes], [happy=no])" line
  3. Add error checking for happy=no case
shell$ edit sandbox.c
 1. Add #include <hwloc.h>
  2. Add calls to sandbox_hwloc_init() and other hwloc API functions
```

Now you can bootstrap, configure, build, and run the sandbox as normal – all calls to "sandbox_hwloc_*" will use the embedded hwloc rather than any system-provided copy of hwloc.

Embedding	hwloc	in O	ther S	Softwa	re

56

Chapter 16

Frequently Asked Questions

16.1 I do not want hwloc to rediscover my enormous machine topology every time I rerun a process

Although the topology discovery is not expensive on common machines, its overhead may become significant when multiple processes repeat the discovery on large machines (for instance when starting one process per core in a parallel application). The machine topology usually does not vary much, except if some cores are stopped/restarted or if the administrator restrictions are modified. Thus rediscovering the whole topology again and again may look useless.

For this purpose, hwloc offers XML import/export features. It lets you save the discovered topology to a file (for instance with the Istopo program) and reload it later by setting the HWLOC_XMLFILE environment variable. The HWLOC_TH

ISSYSTEM environment variable should also be set to 1 to assert that loaded file is really the underlying system.

Loading a XML topology is usually much faster than querying multiple files or calling multiple functions of the operating system. It is also possible to manipulate such XML files with the C programming interface, and the import/export may also be directed to memory buffer (that may for instance be transmitted between applications through a package). See also Importing and exporting topologies from/to XML files.

16.2 How many topologies may I use in my program?

hwloc lets you manipulate multiple topologies at the same time. However these topologies consume memory and system resources (for instance file descriptors) until they are destroyed. It is therefore discouraged to open the same topology multiple times.

Sharing a single topology between threads is easy (see Thread Safety) since the vast majority of accesses are read-only.

If multiple topologies of different (but similar) nodes are needed in your program, have a look at How to avoid memory waste when manipulating multiple similar topologies?.

16.3 How to avoid memory waste when manipulating multiple similar topologies?

hwloc does not share information between topologies. If multiple similar topologies are loaded in memory, for instance the topologies of different identical nodes of a cluster, lots of information will be duplicated.

hwloc/diff.h (see also Topology differences) offers the ability to compute topology differences, apply or unapply them, or export/import to/from XML. However this feature is limited to basic differences such as attribute changes. It does not support complex modifications such as adding or removing some objects.

16.4 Why is Istopo slow?

Istopo enables most hwloc discovery flags by default so that the output topology is as precise as possible (while hwloc disables many of them by default). This includes I/O device discovery through PCI libraries as well as external libraries such as NVML. To speed up Istopo, you may disable such features with command-line options such as -no-io.

When NVIDIA GPU probing is enabled with CUDA or NVML, one should make sure that the *Persistent* mode is enabled (with nvidia-smi -pm 1) to avoid significant GPU initialization overhead.

When AMD GPU discovery is enabled with OpenCL and hwloc is used remotely over ssh, some spurious round-trips on the network may significantly increase the discovery time. Forcing the DISPLAY environment variable to the remote X server display (usually:0) instead of only setting the COMPUTE variable may avoid this.

Also remember that these components may be disabled at build-time with configure flags such as <code>-disable-opencl</code>, <code>-disable-cuda</code> or <code>-disable-nvml</code>, and at runtime with the environment variable <code>HWLOC_COMPONENT</code> \leftarrow <code>S=-opencl</code>, <code>cuda</code>, <code>nvml</code>.

If loading topologies is slow because the machine contains tons of processors, one should also consider using XML (see I do not want hwloc to rediscover my enormous machine topology every time I rerun a process).

16.5 What should I do when hwloc reports "operating system" warnings?

When the operating system reports invalid locality information (because of either software or hardware bugs), hwloc may fail to insert some objects in the topology because they cannot fit in the already built tree of resources. If so, hwloc will report a warning like the following. The object causing this error is ignored, the discovery continues but the resulting topology will miss some objects and may be asymmetric (see also What happens if my topology is asymmetric?).

```
*********

* hwloc has encountered what looks like an error from the operating system.

* L3 (cpuset 0x000003f0) intersects with NUMANode (P#0 cpuset 0x0000003f) without inclusion!

* Error occurred in topology.c line 940

* Please report this error message to the hwloc user's mailing list,

* along with the output from the hwloc-gather-topology script.
```

As explained in the message, reporting this issue to the hwloc developers (by sending the tarball that is generated by the hwloc-gather-topology script on this platform) is a good way to make sure that this is a software (operating system) or hardware bug (BIOS, etc).

These errors are common on large AMD platforms because several BIOS releases fail to properly report L3 caches. In the above example, the hardware reports a L3 cache that is shared by 2 cores in the first NUMA node and 4 cores in the second NUMA node. That's wrong, it should actually be shared by all 6 cores in a single NUMA node. The resulting topology will miss some L3 caches. If your application not care about cache sharing, or if you do not plan to request cache-aware binding in your process launcher, you may likely ignore this error.

Some platforms report similar warnings about conflicting Packages and NUMANodes. Upgrading the BIOS and/or the operating system may help. Otherwise, the warning may be hidden by setting HWLOC_HIDE_ERRORS=1 in your environment.

16.6 Does hwloc require privileged access?

hwloc discovers the topology by querying the operating system. Some minor features may require privileged access to the operation system. For instance memory device and PCI link speed discovery on Linux is reserved to root, and the entire PCI discovery on FreeBSD requires access to the /dev/pci special file.

To workaround this limitation, it is recommended to export the topology as a XML file generated by the administrator (with the Istopo program) and make it available to all users (see Importing and exporting topologies from/to XML files). It will offer all discovery information to any application without requiring any privileged access anymore. Only the necessary hardware characteristics will be exported, no sensitive information will be disclosed through this XML export.

This XML-based model also has the advantage of speeding up the discovery because reading a XML topology is usually much faster than querying the operating system again.

16.7 hwloc only has a one-dimensional view of the architecture, it ignores distances

hwloc places all objects in a tree. Each level is a one-dimensional view of a set of similar objects. All children of the same object (siblings) are assumed to be equally interconnected (same distance between any of them), while the distance between children of different objects (cousins) is supposed to be larger.

Modern machines exhibit complex hardware interconnects, so this tree may miss some information about the actual physical distances between objects. The hwloc topology may therefore be annotated with distance information that may be used to build a more realistic representation (multi-dimensional) of each level. For instance, the root object may contain a distance matrix that represents the latencies between any pairs of NUMA nodes if the BIOS and/or operating system reports them.

16.8 What happens to my topology if I disable symmetric multithreading, hyper-threading, etc. ?

hwloc creates one PU (processing unit) object per hardware thread. If your machine supports symmetric multithreading, for instance Hyper-Threading, each Core object may contain multiple PU objects:

```
$ lstopo -
...
Core L#0
PU L#0 (P#0)
PU L#1 (P#2)
Core L#1
PU L#2 (P#1)
PU L#3 (P#3)
```

x86 machines usually offer the ability to disable hyper-threading in the BIOS. Or it can be disabled on the Linux kernel command-line at boot time, or later by writing in sysfs virtual files.

If you do so, the hwloc topology structure does not significantly change, but some PU objects will not appear anymore. No level will disappear, you will see the same number of Core objects, but each of them will contain a single PU now. The PU level does not disappear either (remember that hwloc topologies always contain a PU level at the bottom of the topology) even if there is a single PU object per Core parent.

```
$ lstopo -
...
Core L#0
PU L#0 (P#0)
Core L#1
PU L#1 (P#1)
```

16.9 How may I ignore symmetric multithreading, hyper-threading, etc. ?

First, see What happens to my topology if I disable symmetric multithreading, hyper-threading, etc. ? for more information about multithreading.

If you need to ignore symmetric multithreading in software, you should likely manipulate hwloc Core objects directly:

Whenever you want to bind a process or thread to a core, make sure you singlify its cpuset first, so that the task is actually bound to a single thread within this core (to avoid useless migrations).

```
/* bind on the second core */
hwloc_obj_t core = hwloc_get_obj_by_type(topology, HWLOC_OBJ_CORE, 1);
hwloc_cpuset_t set = hwloc_bitmap_dup(core->cpuset);
hwloc_bitmap_singlify(set);
hwloc_set_cpubind(topology, set, 0);
hwloc_bitmap_free(set);
```

With hwloc-calc or hwloc-bind command-line tools, you may specify that you only want a single-thread within each core by asking for their first PU object:

```
$ hwloc-calc core:4-7
0x0000ff00
$ hwloc-calc core:4-7.pu:0
0x00005500
```

When binding a process on the command-line, you may either specify the exact thread that you want to use, or ask hwloc-bind to singlify the cpuset before binding

```
$ hwloc-bind core:3.pu:0 -- echo "hello from first thread on core #3"
hello from first thread on core #3
...
$ hwloc-bind core:3 --single -- echo "hello from a single thread on core #3"
hello from a single thread on core #3
```

16.10 What happens if my topology is asymmetric?

hwloc supports asymmetric topologies even if most platforms are usually symmetric. For example, there may be different types of processors in a single machine, each with different numbers of cores, symmetric multithreading, or levels of caches.

To understand how hwloc manages such cases, one should first remember the meaning of levels and cousin objects. All objects of the same type are gathered as horizontal levels with a given depth. They are also connected through the cousin pointers of the hwloc_obj structure. Some types, such as Caches or Groups, are annotated with a depth or level attribute (for instance L2 cache or Group1). Moreover caches have a type attribute (for instance L1i or L1d). Such attributes are also taken in account when gathering objects as horizontal levels. To be clear: there will be one level for L1i caches, another level for L1d caches, another one for L2, etc.

If the topology is asymmetric (e.g., if a cache is missing in one of the processors), a given horizontal level will still exist if there exist any objects of that type. However, some branches of the overall tree may not have an object located in that horizontal level. Note that this specific hole within one horizontal level does not imply anything for other levels. All objects of the same type are gathered in horizontal levels even if their parents or children have different depths and types.

Moreover, it is important to understand that a same parent object may have children of different types (and therefore, different depths). These children are therefore siblings (because they have the same parent), but they are *not* cousins (because they do not belong to the same horizontal levels).

16.11 How do I annotate the topology with private notes?

Each hwloc object contains a userdata field that may be used by applications to store private pointers. This field is only valid during the lifetime of these container object and topology. It becomes invalid as soon the topology is destroyed, or as soon as the object disappears, for instance when restricting the topology. The userdata field is not exported/imported to/from XML by default since hwloc does not know what it contains. This behavior may be changed by specifying application-specific callbacks with hwloc_topology_set_userdata_export_callback() and hwloc_topology_set_userdata_import_callback().

Each object may also contain some *info* attributes (key name and value) that are setup by hwloc during discovery and that may be extended by the user with hwloc_obj_add_info() (see also Object attributes). Contrary to the userdata field which is unique, multiple info attributes may exist for each object, even with the same name. These attributes are always exported to XML. However only character strings may be used as key names and values.

It is also possible to insert Misc objects with a custom name anywhere as a leaf of the topology (see Miscellaneous objects). And Misc objects may have their own userdata and info attributes just like any other object.

The hwloc-annotate command-line tool may be used for adding Misc objects and info attributes.

There is also a topology-specific userdata pointer that can be used to recognize different topologies by storing a custom pointer. It may be manipulated with $hwloc_topology_set_userdata()$ and $hwloc_topology_get_work_userdata()$.

16.12 Why does Valgrind complain about hwloc memory leaks?

If you are debugging your application with Valgrind, you want to avoid memory leak reports that are caused by hwloc and not by your program.

hwloc itself is often checked with Valgrind to make sure it does not leak memory. However some global variables in hwloc dependencies are never freed. For instance libz allocates its global state once at startup and never frees it so that it may be reused later. Some libxml2 global state is also never freed because hwloc does not know whether it can safely ask libxml2 to free it (the application may also be using libxml2 outside of hwloc).

These unfreed variables cause leak reports in Valgrind. hwloc installs a Valgrind *suppressions* file to hide them. You should pass the following command-line option to Valgrind to use it:

```
--suppressions=/path/to/hwloc-valgrind.supp
```

16.13 How do I handle ABI breaks and API upgrades?

The hwloc interface is extended with every new major release. Any application using the hwloc API should be prepared to check at compile-time whether some features are available in the currently installed hwloc distribution.

For instance, to check whether the hwloc version is at least 1.10, you should use:

```
#include <hwloc.h>
#if HWLOC_API_VERSION >= 0x00010a00
...
#endif
```

The hwloc interface will be deeply modified in release 2.0 to fix several issues of the 1.x interface. The ABI will be broken, which means applications must be recompiled against the new 2.0 interface.

To check that you are not mixing old/recent headers with a recent/old runtime library:

```
#include <hwloc.h>
#if HWLOC_API_VERSION >= 0x00020000
```

```
/* headers are recent */
if (hwloc_get_api_version() < 0x20000)
... error out, the hwloc runtime library is older than 2.0 ...
#else
/* headers are pre-2.0 */
if (hwloc_get_api_version() >= 0x20000)
... error out, the hwloc runtime library is more recent than 2.0 ...
#endif
```

You should not try to remain compatible with very old releases such as 1.1.x or earlier because HWLOC_API_VERS UNION was added in 1.0.0 and hwloc_get_api_version() came only in 1.1.1. Also do not use the old cpuset API since it was deprecated and superseded by the bitmap API in 1.1, and later removed in 1.5.

16.14 How do I build hwloc for BlueGene/Q?

IBM BlueGene/Q machines run a standard Linux on the I/O node and a custom CNK (*Compute Node Kernel*) on the compute nodes. To run on the compute node, hwloc must be cross-compiled from the I/O node with the following configuration line:

```
./configure --host=powerpc64-bgq-linux --disable-shared --enable-static \ CPPFLAGS='-I/bgsys/drivers/ppcfloor -I/bgsys/drivers/ppcfloor/spi/include/kernel/cnk/'
```

CPPFLAGS may have to be updated if your platform headers are installed in a different directory.

16.15 How to get useful topology information on NetBSD?

The NetBSD (and FreeBSD) backend uses x86-specific topology discovery (through the x86 component). This implementation requires CPU binding so as to query topology information from each individual logical processor. This means that hwloc cannot find any useful topology information unless user-level process binding is allowed by the NetBSD kernel. The security.models.extensions.user_set_cpu_affinity sysctl variable must be set to 1 to do so. Otherwise, only the number of logical processors will be detected.

16.16 How do I build for Intel Xeon Phi coprocessor?

Intel Xeon Phi coprocessors usually runs a Linux environment but cross-compiling from the host is required. hwloc uses standard autotools options for cross-compiling. For instance, to build for a *Knights Corner (KNC)* coprocessor:

If building with icc:

```
./configure CC="icc -mmic" --host=x86_64-klom-linux --build=x86_64-unknown-linux-gnu
```

If building with the Xeon Phi-specific GCC that comes with the MPSS environment for instance $/usr/linux-klom-4.7/bin/x86_64-klom-linux-gcc$:

```
export PATH=$PATH:/usr/linux-k1om-4.7/bin/
./configure --host=x86_64-k1om-linux --build=x86_64-unknown-linux-gnu
```

Chapter 17

Module Index

17.1 Modules

Here is	a list	of all	modules:

API version
Object Sets (hwloc_cpuset_t and hwloc_nodeset_t)
Object Types
Object Structure and Attributes
Topology Creation and Destruction
Topology Detection Configuration and Query
Object levels, depths and types
Manipulating Object Type, Sets and Attributes as Strings
CPU binding
Memory binding
Modifying a loaded Topology
Building Custom Topologies
Exporting Topologies to XML
Exporting Topologies to Synthetic
Finding Objects inside a CPU set
Finding Objects covering at least CPU set
Looking at Ancestor and Child Objects
Looking at Cache Objects
Finding objects, miscellaneous helpers
Distributing items over a topology
CPU and node sets of entire topologies
Converting between CPU sets and node sets
Manipulating Distances
Finding I/O objects
The bitmap API
Topology differences
Components and Plugins: Discovery components
Components and Plugins: Discovery backends
Components and Plugins: Generic components
Components and Plugins: Core functions to be used by components
Components and Plugins: PCI functions to be used by components
Linux-specific helpers
Interoperability with Linux libnuma unsigned long masks
Interoperability with Linux libruma bitmask 152

Module Index

Interoperability with (glibc sched affinity .					 	 							 	. 1	154
Interoperability with	OpenCL					 	 							 	. 1	155
Interoperability with t	the CUDA Driver AP	١				 	 							 	. 1	157
Interoperability with t	the CUDA Runtime A	ŀΡΙ				 	 							 	. 1	159
Interoperability with t	the NVIDIA Manager	nent	Libra	ary		 	 							 	. 1	161
Interoperability with	OpenGL displays					 	 							 	. 1	163
Interoperability with	Intel Xeon Phi (MIC)					 	 							 	. 1	165
Interoperability with	OpenFabrics					 	 							 	. 1	166
Interoperability with I	Myrinet Express														3	168

Chapter 18

Data Structure Index

18.1 Data Structures

Here are the data structures with brief descriptions:

hwloc_backend
Discovery backend structure
hwloc_obj_attr_u::hwloc_bridge_attr_s
Bridge specific Object Attribues
hwloc_obj_attr_u::hwloc_cache_attr_s
Cache-specific Object Attributes
hwloc_component
Generic component structure
hwloc_disc_component
Discovery component structure
hwloc_distances_s
Distances between objects
hwloc_obj_attr_u::hwloc_group_attr_s
Group-specific Object Attributes
hwloc_obj
Structure of a topology object
hwloc_obj_attr_u
Object type-specific Attributes
hwloc_obj_info_s Object info
Object info
hwloc_obj_memory_s::hwloc_obj_memory_page_type_s Array of local memory page types, NULL if no local memory and page_types is 0 183
hwloc obj memory s
Object memory
hwloc_obj_attr_u::hwloc_osdev_attr_s
OS Device specific Object Attributes
hwloc_obj_attr_u::hwloc_pcidev_attr_s
PCI Device specific Object Attributes
hwloc topology cpubind support
Flags describing actual PU binding support for this topology
hwloc_topology_diff_u::hwloc_topology_diff_generic_s
hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_generic_s
hwloc topology diff u::hwloc topology diff obj attr s

Data Structure Index

hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s
String attribute modification with an optional name
hwloc_topology_diff_obj_attr_u
One object attribute difference
hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s
Integer attribute modification with an optional index
hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s
hwloc_topology_diff_u
One element of a difference list between two topologies
hwloc_topology_discovery_support
Flags describing actual discovery support for this topology
hwloc_topology_membind_support
Flags describing actual memory binding support for this topology
hwloc_topology_support
Set of flags describing actual support for this topology

Chapter 19

Module Documentation

19.1 API version

Macros

- #define HWLOC_API_VERSION 0x00010b00
- #define HWLOC_COMPONENT_ABI 4

Functions

unsigned hwloc_get_api_version (void)

19.1.1 Detailed Description

19.1.2 Macro Definition Documentation

19.1.2.1 #define HWLOC_API_VERSION 0x00010b00

Indicate at build time which hwloc API version is being used.

19.1.2.2 #define HWLOC_COMPONENT_ABI 4

Current component and plugin ABI version (see hwloc/plugins.h)

19.1.3 Function Documentation

19.1.3.1 unsigned hwloc_get_api_version (void)

Indicate at runtime which hwloc API version was used at build time.

19.2 Object Sets (hwloc_cpuset_t and hwloc_nodeset_t)

Typedefs

- typedef hwloc_bitmap_t hwloc_cpuset_t
- typedef hwloc_const_bitmap_t hwloc_const_cpuset_t
- typedef hwloc_bitmap_t hwloc_nodeset_t
- typedef hwloc_const_bitmap_t hwloc_const_nodeset_t

19.2.1 Detailed Description

Hwloc uses bitmaps to represent two distinct kinds of object sets: CPU sets (hwloc_cpuset_t) and NUMA node sets (hwloc_nodeset_t). These types are both typedefs to a common back end type (hwloc_bitmap_t), and therefore all the hwloc bitmap functions are applicable to both hwloc_cpuset_t and hwloc_nodeset_t (see The bitmap API).

The rationale for having two different types is that even though the actions one wants to perform on these types are the same (e.g., enable and disable individual items in the set/mask), they're used in very different contexts: one for specifying which processors to use and one for specifying which NUMA nodes to use. Hence, the name difference is really just to reflect the intent of where the type is used.

19.2.2 Typedef Documentation

19.2.2.1 typedef hwloc const bitmap thwloc const cpuset t

A non-modifiable hwloc cpuset t.

19.2.2.2 typedef hwloc_const_bitmap_t hwloc_const_nodeset_t

A non-modifiable hwloc nodeset t.

19.2.2.3 typedef hwloc_bitmap_t hwloc_cpuset_t

A CPU set is a bitmap whose bits are set according to CPU physical OS indexes.

It may be consulted and modified with the bitmap API as any hwloc bitmap t (see hwloc/bitmap.h).

Each bit may be converted into a PU object using hwloc get pu obj by os index().

19.2.2.4 typedef hwloc_bitmap_t hwloc_nodeset_t

A node set is a bitmap whose bits are set according to NUMA memory node physical OS indexes.

It may be consulted and modified with the bitmap API as any hwloc_bitmap_t (see hwloc/bitmap.h). Each bit may be converted into a NUMA node object using hwloc get numanode obj by os index().

When binding memory on a system without any NUMA node (when the whole memory is considered as a single memory bank), the nodeset may be either empty (no memory selected) or full (whole system memory selected).

See also Converting between CPU sets and node sets.

19.3 Object Types 69

19.3 Object Types

Typedefs

```
    typedef enum hwloc_obj_cache_type_e hwloc_obj_cache_type_t
```

- typedef enum hwloc_obj_bridge_type_e hwloc_obj_bridge_type_t
- typedef enum hwloc_obj_osdev_type_e hwloc_obj_osdev_type_t

Enumerations

```
    enum hwloc_obj_type_t {
        HWLOC_OBJ_SYSTEM, HWLOC_OBJ_MACHINE, HWLOC_OBJ_NUMANODE, HWLOC_OBJ_PACKAGE,
        HWLOC_OBJ_CACHE, HWLOC_OBJ_CORE, HWLOC_OBJ_PU, HWLOC_OBJ_GROUP,
        HWLOC_OBJ_MISC, HWLOC_OBJ_BRIDGE, HWLOC_OBJ_PCI_DEVICE, HWLOC_OBJ_OS_DEVICE,
        HWLOC_OBJ_TYPE_MAX }
```

- enum hwloc_obj_cache_type_e { HWLOC_OBJ_CACHE_UNIFIED, HWLOC_OBJ_CACHE_DATA, HWLOC_←
 OBJ_CACHE_INSTRUCTION }
- enum hwloc_obj_bridge_type_e { HWLOC_OBJ_BRIDGE_HOST, HWLOC_OBJ_BRIDGE_PCI }
- enum hwloc_obj_osdev_type_e {
 HWLOC_OBJ_OSDEV_BLOCK, HWLOC_OBJ_OSDEV_GPU, HWLOC_OBJ_OSDEV_NETWORK, HWLOC
 _OBJ_OSDEV_OPENFABRICS,
 HWLOC_OBJ_OSDEV_DMA, HWLOC_OBJ_OSDEV_COPROC }
- enum hwloc_compare_types_e { HWLOC_TYPE_UNORDERED }

Functions

int hwloc_compare_types (hwloc_obj_type_t type1, hwloc_obj_type_t type2)

19.3.1 Detailed Description

19.3.2 Typedef Documentation

19.3.2.1 typedef enum hwloc_obj_bridge_type_e hwloc_obj_bridge_type_t

Type of one side (upstream or downstream) of an I/O bridge.

19.3.2.2 typedef enum hwloc_obj_cache_type_e hwloc_obj_cache_type_t

Cache type.

19.3.2.3 typedef enum hwloc_obj_osdev_type_e hwloc_obj_osdev_type_t

Type of a OS device.

19.3.3 Enumeration Type Documentation

19.3.3.1 enum hwloc compare types e

Enumerator

HWLOC_TYPE_UNORDERED Value returned by hwloc_compare_types when types can not be compared.

```
19.3.3.2 enum hwloc_obj_bridge_type_e
```

Type of one side (upstream or downstream) of an I/O bridge.

Enumerator

```
HWLOC_OBJ_BRIDGE_HOST Host-side of a bridge, only possible upstream.HWLOC_OBJ_BRIDGE_PCI PCI-side of a bridge.
```

```
19.3.3.3 enum hwloc_obj_cache_type_e
```

Cache type.

Enumerator

HWLOC_OBJ_CACHE_UNIFIED Unified cache.

HWLOC_OBJ_CACHE_DATA Data cache.

HWLOC_OBJ_CACHE_INSTRUCTION Instruction cache. Only used when the HWLOC_TOPOLOGY_FLAG. — ICACHES topology flag is set.

```
19.3.3.4 enum hwloc_obj_osdev_type_e
```

Type of a OS device.

Enumerator

HWLOC_OBJ_OSDEV_BLOCK Operating system block device. For instance "sda" on Linux.

HWLOC_OBJ_OSDEV_GPU Operating system GPU device. For instance ":0.0" for a GL display, "card0" for a Linux DRM device.

HWLOC_OBJ_OSDEV_NETWORK Operating system network device. For instance the "eth0" interface on Linux.

HWLOC_OBJ_OSDEV_OPENFABRICS Operating system openfabrics device. For instance the "mlx4_0" Infini← Band HCA device on Linux.

HWLOC_OBJ_OSDEV_DMA Operating system dma engine device. For instance the "dma0chan0" DMA channel on Linux.

HWLOC_OBJ_OSDEV_COPROC Operating system co-processor device. For instance "mic0" for a Xeon Phi (MIC) on Linux, "opencl0d0" for a OpenCL device, "cuda0" for a CUDA device.

19.3 Object Types 71

19.3.3.5 enum hwloc_obj_type_t

Type of topology object.

Note

Do not rely on the ordering or completeness of the values as new ones may be defined in the future! If you need to compare types, use hwloc_compare_types() instead.

Enumerator

- **HWLOC_OBJ_SYSTEM** Whole system (may be a cluster of machines). The whole system that is accessible to hwloc. That may comprise several machines in SSI systems like Kerrighed.
- **HWLOC_OBJ_MACHINE** Machine. The typical root object type. A set of processors and memory with cache coherency.
- HWLOC_OBJ_NUMANODE NUMA node. A set of processors around memory which the processors can directly access.
- **HWLOC_OBJ_PACKAGE** Physical package, what goes into a socket. In the physical meaning, i.e. that you can add or remove physically.
- HWLOC_OBJ_CACHE Cache. Can be L1i, L1d, L2, L3, ...
- HWLOC_OBJ_CORE Core. A computation unit (may be shared by several logical processors).
- HWLOC_OBJ_PU Processing Unit, or (Logical) Processor. An execution unit (may share a core with some other logical processors, e.g. in the case of an SMT core). Objects of this kind are always reported and can thus be used as fallback when others are not.
- HWLOC_OBJ_GROUP Group objects. Objects which do not fit in the above but are detected by hwloc and are useful to take into account for affinity. For instance, some operating systems expose their arbitrary processors aggregation this way. And hwloc may insert such objects to group NUMA nodes according to their distances. These objects are ignored when they do not bring any structure.
- **HWLOC_OBJ_MISC** Miscellaneous objects. Objects without particular meaning, that can e.g. be added by the application for its own use, or by hwloc for miscellaneous objects such as MemoryDevice.
- **HWLOC_OBJ_BRIDGE** Bridge. Any bridge that connects the host or an I/O bus, to another I/O bus. Bridge objects have neither CPU sets nor node sets. They are not added to the topology unless I/O discovery is enabled with hwloc_topology_set_flags().
- **HWLOC_OBJ_OS_DEVICE** Operating system device. These objects have neither CPU sets nor node sets. They are not added to the topology unless I/O discovery is enabled with hwloc_topology_set_flags().
- HWLOC_OBJ_TYPE_MAX Sentinel value

19.3.4 Function Documentation

19.3.4.1 int hwloc_compare_types (hwloc_obj_type_t type1, hwloc_obj_type_t type2)

Compare the depth of two object types.

Types shouldn't be compared as they are, since newer ones may be added in the future. This function returns less than, equal to, or greater than zero respectively if type1 objects usually include type2 objects, are the same as type2 objects, or are included in type2 objects. If the types can not be compared (because neither is usually contained in the other), HWLOC_TYPE_UNORDERED is returned. Object types containing CPUs can always be compared (usually, a system contains machines which contain nodes which contain packages which contain caches, which contain cores, which contain processors).

Note

HWLOC_OBJ_PU will always be the deepest.

This does not mean that the actual topology will respect that order: e.g. as of today cores may also contain caches, and packages may also contain nodes. This is thus just to be seen as a fallback comparison method.

19.4 Object Structure and Attributes

Data Structures

- struct hwloc_obj_memory_s
- struct hwloc_obj_memory_s::hwloc_obj_memory_page_type_s
- struct hwloc obj
- union hwloc_obj_attr_u
- struct hwloc_obj_attr_u::hwloc_osdev_attr_s
- struct hwloc_obj_attr_u::hwloc_bridge_attr_s
- struct hwloc_obj_attr_u::hwloc_pcidev_attr_s
- struct hwloc_obj_attr_u::hwloc_group_attr_s
- struct hwloc_obj_attr_u::hwloc_cache_attr_s
- struct hwloc_distances_s
- · struct hwloc obj info s

Typedefs

• typedef struct hwloc_obj * hwloc_obj_t

19.4.1 Detailed Description

19.4.2 Typedef Documentation

19.4.2.1 typedef struct hwloc_obj* hwloc_obj_t

Convenience typedef; a pointer to a struct hwloc_obj.

19.5 Topology Creation and Destruction

Typedefs

typedef struct hwloc_topology * hwloc_topology_t

Functions

- int hwloc_topology_init (hwloc_topology_t *topologyp)
- int hwloc_topology_load (hwloc_topology_t topology)
- void hwloc_topology_destroy (hwloc_topology_t topology)
- int hwloc_topology_dup (hwloc_topology_t *newtopology, hwloc_topology_t oldtopology)
- void hwloc_topology_check (hwloc_topology_t topology)

19.5.1 Detailed Description

19.5.2 Typedef Documentation

19.5.2.1 typedef struct hwloc_topology * hwloc_topology t

Topology context.

To be initialized with hwloc topology init() and built with hwloc topology load().

19.5.3 Function Documentation

19.5.3.1 void hwloc_topology_check (hwloc_topology_t topology)

Run internal checks on a topology structure.

The program aborts if an inconsistency is detected in the given topology.

Parameters

topology	is the topology to be checked

Note

This routine is only useful to developers.

The input topology should have been previously loaded with https://hww.topology_load().

19.5.3.2 void hwloc_topology_destroy (hwloc_topology_t topology)

Terminate and free a topology context.

Parameters

topology is the topology to be freed

19.5.3.3 int hwloc_topology_dup (hwloc topology t * newtopology, hwloc topology t oldtopology)

Duplicate a topology.

The entire topology structure as well as its objects are duplicated into a new one.

This is useful for keeping a backup while modifying a topology.

19.5.3.4 int hwloc_topology_init (hwloc_topology_t * topologyp)

Allocate a topology context.

Parameters

out	topologyp	is assigned a pointer to the new allocated context.
-----	-----------	---

Returns

0 on success, -1 on error.

19.5.3.5 int hwloc_topology_load (hwloc_topology_t topology)

Build the actual topology.

Build the actual topology once initialized with hwloc_topology_init() and tuned with Topology Detection Configuration and Query routines. No other routine may be called earlier using this topology context.

Parameters

topology	is the topology to be loaded with objects.

Returns

0 on success, -1 on error.

Note

On failure, the topology is reinitialized. It should be either destroyed with hww.commons.org/hww.commo

This function may be called only once per topology.

See also

Topology Detection Configuration and Query

19.6 Topology Detection Configuration and Query

Data Structures

- · struct hwloc topology discovery support
- · struct hwloc topology cpubind support
- · struct hwloc topology membind support
- struct hwloc_topology_support

Enumerations

 enum hwloc_topology_flags_e {
 HWLOC_TOPOLOGY_FLAG_WHOLE_SYSTEM, HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM, HWLOC _TOPOLOGY_FLAG_IO_DEVICES, HWLOC_TOPOLOGY_FLAG_IO_BRIDGES,
 HWLOC_TOPOLOGY_FLAG_WHOLE IO, HWLOC_TOPOLOGY_FLAG_ICACHES }

Functions

- int hwloc topology ignore type (hwloc topology t topology, hwloc obj type t type)
- int hwloc topology ignore type keep structure (hwloc topology t topology, hwloc obj type t type)
- int hwloc_topology_ignore_all_keep_structure (hwloc_topology_t topology)
- int hwloc_topology_set_flags (hwloc_topology_t topology, unsigned long flags)
- unsigned long hwloc topology get flags (hwloc topology t topology)
- int hwloc_topology_set_pid (hwloc_topology_t restrict topology, hwloc_pid_t pid)
- int hwloc topology set fsroot (hwloc topology t restrict topology, const char *restrict fsroot path)
- int hwloc_topology_set_synthetic (hwloc_topology_t restrict topology, const char *restrict description)
- int hwloc_topology_set_xml (hwloc_topology_t restrict topology, const char *restrict xmlpath)
- int hwloc_topology_set_xmlbuffer (hwloc_topology_t restrict topology, const char *restrict buffer, int size)
- int hwloc_topology_set_custom (hwloc_topology_t topology)
- int hwloc_topology_set_distance_matrix (hwloc_topology_t restrict topology, hwloc_obj_type_t type, unsigned nbobjs, unsigned *os_index, float *distances)
- int hwloc topology is this system (hwloc topology t restrict topology)
- const struct hwloc_topology_support * hwloc_topology_get_support (hwloc_topology_t restrict topology)
- void hwloc topology set userdata (hwloc topology t topology, const void *userdata)
- void * hwloc_topology_get_userdata (hwloc_topology_t topology)

19.6.1 Detailed Description

Several functions can optionally be called between https://hwloc_topology_load() to configure how the detection should be performed, e.g. to ignore some objects types, define a synthetic topology, etc.

If none of them is called, the default is to detect all the objects of the machine that the caller is allowed to access.

This default behavior may also be modified through environment variables if the application did not modify it already. Setting HWLOC_XMLFILE in the environment enforces the discovery from a XML file as if hwloc_topology_set_xml() had been called. HWLOC_FSROOT switches to reading the topology from the specified Linux filesystem root as if hwloc_topology_set_fsroot() had been called. Finally, HWLOC_THISSYSTEM enforces the return value of hwloc_topology is thissystem().

19.6.2 Enumeration Type Documentation

19.6.2.1 enum hwloc_topology_flags_e

Flags to be set onto a topology context before load.

Flags should be given to hwloc topology set flags(). They may also be returned by hwloc topology get flags().

Enumerator

- HWLOC_TOPOLOGY_FLAG_WHOLE_SYSTEM Detect the whole system, ignore reservations and offline settings. Gather all resources, even if some were disabled by the administrator. For instance, ignore Linux Cgroup/Cpusets and gather all processors and memory nodes, and ignore the fact that some resources may be offline.
- HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM Assume that the selected backend provides the topology for the system on which we are running. This forces hwloc_topology_is_thissystem to return 1, i.e. makes hwloc assume that the selected backend provides the topology for the system on which we are running, even if it is not the OS-specific backend but the XML backend for instance. This means making the binding functions actually call the OS-specific system calls and really do binding, while the XML backend would otherwise provide empty hooks just returning success.

Setting the environment variable HWLOC THISSYSTEM may also result in the same behavior.

This can be used for efficiency reasons to first detect the topology once, save it to an XML file, and quickly reload it later through the XML backend, but still having binding functions actually do bind.

- HWLOC_TOPOLOGY_FLAG_IO_DEVICES Detect PCI devices. By default, I/O devices are ignored. This flag enables I/O device detection using the pci backend. Only the common PCI devices (GPUs, NICs, block devices, ...) and host bridges (objects that connect the host objects to an I/O subsystem) will be added to the topology. Additionally it also enables MemoryDevice misc objects. Uncommon devices and other bridges (such as PCI-to-PCI bridges) will be ignored.
- **HWLOC_TOPOLOGY_FLAG_IO_BRIDGES** Detect PCI bridges. This flag should be combined with HWLOC_← TOPOLOGY_FLAG_IO_DEVICES to enable the detection of both common devices and of all useful bridges (bridges that have at least one device behind them).
- HWLOC_TOPOLOGY_FLAG_WHOLE_IO Detect the whole PCI hierarchy. This flag enables detection of all I/O devices (even the uncommon ones) and bridges (even those that have no device behind them) using the pci backend. This implies HWLOC_TOPOLOGY_FLAG_IO_DEVICES.
- **HWLOC_TOPOLOGY_FLAG_ICACHES** Detect instruction caches. This flag enables detection of Instruction caches, instead of only Data and Unified caches.

19.6.3 Function Documentation

19.6.3.1 unsigned long hwloc_topology_get_flags (hwloc_topology_t topology)

Get OR'ed flags of a topology.

Get the OR'ed set of hwloc_topology_flags_e of a topology.

Returns

the flags previously set with hwloc topology set flags().

19.6.3.2 const struct hwloc_topology_support* hwloc_topology_get_support(hwloc_topology_t restrict topology)

Retrieve the topology support.

19.6.3.3 void* hwloc_topology_get_userdata (hwloc_topology_t topology)

Retrieve the topology-specific userdata pointer.

Retrieve the application-given private data pointer that was previously set with hwloc_topology_set_userdata().

19.6.3.4 int hwloc_topology_ignore_all_keep_structure (hwloc_topology_t topology)

Ignore all objects that do not bring any structure.

Ignore all objects that do not bring any structure: Each ignored object should have a single children or be the only child of its parent. I/O objects may not be ignored, topology flags should be used to configure their discovery instead.

19.6.3.5 int hwloc_topology_ignore_type (hwloc topology t topology, hwloc obj type t type)

Ignore an object type.

Ignore all objects from the given type. The bottom-level type HWLOC_OBJ_PU may not be ignored. The top-level object of the hierarchy will never be ignored, even if this function succeeds. Group objects are always ignored if they do not bring any structure since they are designed to add structure to the topology. I/O objects may not be ignored, topology flags should be used to configure their discovery instead.

19.6.3.6 int hwloc topology ignore type keep structure (hwloc topology t topology, hwloc obj type t type)

Ignore an object type if it does not bring any structure.

Ignore all objects from the given type as long as they do not bring any structure: Each ignored object should have a single children or be the only child of its parent. The bottom-level type HWLOC_OBJ_PU may not be ignored. I/O objects may not be ignored, topology flags should be used to configure their discovery instead.

19.6.3.7 int hwloc_topology_is_thissystem (hwloc_topology_t restrict topology_)

Does the topology context come from this system?

Returns

1 if this topology context was built using the system running this program.

0 instead (for instance if using another file-system root, a XML topology file, or a synthetic topology).

19.6.3.8 int hwloc_topology_set_custom (hwloc_topology_t topology)

Prepare the topology for custom assembly.

The topology then contains a single root object. It must then be built by inserting other topologies with hwloc_custom
_insert_topology() or single objects with hwloc_custom_insert_group_object_by_parent(). hwloc_topology_load() must
be called to finalize the new topology as usual.

Note

If nothing is inserted in the topology, hwloc topology load() will fail with errno set to EINVAL.

The cpuset and nodeset of the root object are NULL because these sets are meaningless when assembling multiple topologies.

On success, the custom component replaces the previously enabled component (if any), but the topology is not actually modified until hwloc_topology_load().

19.6.3.9 int hwloc_topology_set_distance_matrix (hwloc_topology_t restrict topology, hwloc_obj_type_t type, unsigned nbobjs, unsigned * os index, float * distances)

Provide a distance matrix.

Provide the matrix of distances between a set of objects of the given type. The set may or may not contain all the existing objects of this type. The objects are specified by their OS/physical index in the os_index array. The distances matrix follows the same order. The distance from object i to object j in the i*nbobjs+i.

A single latency matrix may be defined for each type. If another distance matrix already exists for the given type, either because the user specified it or because the OS offers it, it will be replaced by the given one. If nbobjs is 0, os_index is NULL and distances is NULL, the existing distance matrix for the given type is removed.

Note

Distance matrices are ignored in multi-node topologies.

19.6.3.10 int hwloc topology set flags (hwloc topology t topology, unsigned long flags)

Set OR'ed flags to non-yet-loaded topology.

Set a OR'ed set of hwloc topology flags e onto a topology that was not yet loaded.

If this function is called multiple times, the last invokation will erase and replace the set of flags that was previously set.

The flags set in a topology may be retrieved with https://www.topology_get_flags()

19.6.3.11 int hwloc_topology_set_fsroot (hwloc_topology_t restrict topology, const char *restrict fsroot_path)

Change the file-system root path when building the topology from sysfs/procfs.

On Linux system, use sysfs and procfs files as if they were mounted on the given fsroot_path instead of the main file-system root. Setting the environment variable HWLOC_FSROOT may also result in this behavior. Not using the main file-system root causes hwloc_topology_is_thissystem() to return 0.

Note that this function does not actually load topology information; it just tells hwloc where to load it from. You'll still need to invoke hwloc topology load() to actually load the topology information.

Returns

- -1 with errno set to ENOSYS on non-Linux and on Linux systems that do not support it.
- -1 with the appropriate errno if fsroot_path cannot be used.

Note

For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, the HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM has to be set to assert that the loaded file is really the underlying system.

On success, the Linux component replaces the previously enabled component (if any), but the topology is not actually modified until hwloc_topology_load().

19.6.3.12 int hwloc_topology_set_pid (hwloc_topology_t restrict topology, hwloc_pid_t pid)

Change which pid the topology is viewed from.

On some systems, processes may have different views of the machine, for instance the set of allowed CPUs. By default, hwloc exposes the view from the current process. Calling hwloc_topology_set_pid() permits to make it expose the topology of the machine from the point of view of another process.

Note

hwloc_pid_t is pid_t on Unix platforms, and HANDLE on native Windows platforms.
-1 is returned and errno is set to ENOSYS on platforms that do not support this feature.

19.6.3.13 int hwloc_topology_set_synthetic (hwloc_topology_t restrict topology, const char *restrict description)

Enable synthetic topology.

Gather topology information from the given description, a space-separated string of numbers describing the arity of each level. Each number may be prefixed with a type and a colon to enforce the type of a level. If only some level types are enforced, hwloc will try to choose the other types according to usual topologies, but it may fail and you may have to specify more level types manually. See also the Synthetic topologies.

If description was properly parsed and describes a valid topology configuration, this function returns 0. Otherwise -1 is returned and errno is set to EINVAL.

Note that this function does not actually load topology information; it just tells hwloc where to load it from. You'll still need to invoke hwloc topology load() to actually load the topology information.

Note

For convenience, this backend provides empty binding hooks which just return success.

On success, the synthetic component replaces the previously enabled component (if any), but the topology is not actually modified until hwloc topology load().

19.6.3.14 void hwloc_topology_set_userdata (hwloc_topology_t topology, const void * userdata)

Set the topology-specific userdata pointer.

Each topology may store one application-given private data pointer. It is initialized to NULL. hwloc will never modify it.

Use it as you wish, after hwloc_topolog_destroy().

This pointer is not exported to XML.

19.6.3.15 int hwloc_topology_set_xml (hwloc_topology_t restrict topology, const char *restrict xmlpath)

Enable XML-file based topology.

Gather topology information from the XML file given at xmlpath. Setting the environment variable HWLOC_XMLFILE may also result in this behavior. This file may have been generated earlier with hwloc_topology_export_xml() or Istopo file.xml.

Note that this function does not actually load topology information; it just tells hwloc where to load it from. You'll still need to invoke hwloc topology load() to actually load the topology information.

Returns

-1 with errno set to EINVAL on failure to read the XML file.

Note

See also hwloc_topology_set_userdata_import_callback() for importing application-specific object userdata. For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, the HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM has to be set to assert that the loaded file is really the underlying system.

On success, the XML component replaces the previously enabled component (if any), but the topology is not actually modified until hwloc_topology_load().

19.6.3.16 int hwloc_topology_set_xmlbuffer(hwloc_topology_t restrict topology, const char *restrict buffer, int size)

Enable XML based topology using a memory buffer (instead of a file, as with hwloc_topology_set_xml()).

Gather topology information from the XML memory buffer given at buffer and of length size. This buffer may have been filled earlier with hwloc_topology_export_xmlbuffer().

Note that this function does not actually load topology information; it just tells hwloc where to load it from. You'll still need to invoke hwloc_topology_load() to actually load the topology information.

Returns

-1 with errno set to EINVAL on failure to read the XML buffer.

Note

See also hwloc_topology_set_userdata_import_callback() for importing application-specific object userdata. For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, the HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM has to be set to assert that the loaded file is really the underlying system.

On success, the XML component replaces the previously enabled component (if any), but the topology is not actually modified until hwloc_topology_load().

19.7 Object levels, depths and types

Enumerations

enum hwloc_get_type_depth_e {
 HWLOC_TYPE_DEPTH_UNKNOWN, HWLOC_TYPE_DEPTH_MULTIPLE, HWLOC_TYPE_DEPTH_BRIDGE,
 HWLOC_TYPE_DEPTH_PCI_DEVICE,
 HWLOC_TYPE_DEPTH_OS_DEVICE }

Functions

- unsigned hwloc_topology_get_depth (hwloc_topology_t restrict topology)
- int hwloc_get_type_depth (hwloc_topology_t topology, hwloc_obj_type_t type)
- static int hwloc_get_type_or_below_depth (hwloc_topology_t topology, hwloc_obj_type_t type)
- static int hwloc_get_type_or_above_depth (hwloc_topology_t topology, hwloc_obj_type_t type)
- hwloc_obj_type_t hwloc_get_depth_type (hwloc_topology_t topology, unsigned depth)
- unsigned hwloc_get_nbobjs_by_depth (hwloc_topology_t topology, unsigned depth)
- static int hwloc_get_nbobjs_by_type (hwloc_topology_t topology, hwloc_obj_type_t type)
- static hwloc_obj_t hwloc_get_root_obj (hwloc_topology_t topology)
- hwloc_obj_t hwloc_get_obj_by_depth (hwloc_topology_t topology, unsigned depth, unsigned idx)
- static hwloc_obj_t hwloc_get_obj_by_type (hwloc_topology_t topology, hwloc_obj_type_t type, unsigned idx)
- static hwloc_obj_t hwloc_get_next_obj_by_depth (hwloc_topology_t topology, unsigned depth, hwloc_obj_t prev)
- static hwloc_obj_t hwloc_get_next_obj_by_type (hwloc_topology_t topology, hwloc_obj_type_t type, hwloc_obj
 _t prev)

19.7.1 Detailed Description

Be sure to see the figure in Terms and Definitions that shows a complete topology tree, including depths, child/sibling/cousin relationships, and an example of an asymmetric topology where one package has fewer caches than its peers.

19.7.2 Enumeration Type Documentation

```
19.7.2.1 enum hwloc_get_type_depth_e
```

Enumerator

```
    HWLOC_TYPE_DEPTH_UNKNOWN No object of given type exists in the topology.
    HWLOC_TYPE_DEPTH_MULTIPLE Objects of given type exist at different depth in the topology.
    HWLOC_TYPE_DEPTH_BRIDGE Virtual depth for bridge object level.
    HWLOC_TYPE_DEPTH_PCI_DEVICE Virtual depth for PCI device object level.
    HWLOC_TYPE_DEPTH_OS_DEVICE Virtual depth for software device object level.
```

19.7.3 Function Documentation

19.7.3.1 hwloc_obj_type_t hwloc_get_depth_type (hwloc_topology_t topology, unsigned depth)

Returns the type of objects at depth depth.

Returns

-1 if depth depth does not exist.

19.7.3.2 unsigned hwloc_get_nbobjs_by_depth (hwloc_topology_t topology, unsigned depth)

Returns the width of level at depth depth.

19.7.3.3 static int hwloc_get_nbobjs_by_type (hwloc_topology_t topology, hwloc_obj_type_t type) [inline], [static]

Returns the width of level type type.

If no object for that type exists, 0 is returned. If there are several levels with objects of that type, -1 is returned.

19.7.3.4 static hwloc_obj_t hwloc_get_next_obj_by_depth (hwloc_topology_t topology, unsigned depth, hwloc_obj_t prev) [inline], [static]

Returns the next object at depth depth.

If prev is NULL, return the first object at depth depth.

19.7.3.5 static hwloc_obj_t hwloc_get_next_obj_by_type (hwloc_topology_t topology, hwloc_obj_type_t type, hwloc_obj_t prev) [inline], [static]

Returns the next object of type type.

If prev is NULL, return the first object at type type. If there are multiple or no depth for given type, return NULL and let the caller fallback to hwloc_get_next_obj_by_depth().

19.7.3.6 hwloc_obj_t hwloc_get_obj_by_depth (hwloc_topology_t topology, unsigned depth, unsigned idx)

Returns the topology object at logical index idx from depth depth.

19.7.3.7 static hwloc_obj_t hwloc_get_obj_by_type (hwloc_topology_t topology, hwloc_obj_type_t type, unsigned idx) [inline], [static]

Returns the topology object at logical index idx with type type.

If no object for that type exists, NULL is returned. If there are several levels with objects of that type, NULL is returned and ther caller may fallback to $\texttt{hwloc_get_obj_by_depth}()$.

19.7.3.8 static hwloc_obj_t hwloc_get_root_obj(hwloc_topology_t topology) [inline], [static]

Returns the top-object of the topology-tree.

Its type is typically HWLOC OBJ MACHINE but it could be different for complex topologies.

19.7.3.9 int hwloc_get_type_depth (hwloc_topology_t topology, hwloc_obj_type_t type)

Returns the depth of objects of type type.

If no object of this type is present on the underlying architecture, or if the OS doesn't provide this kind of information, the function returns HWLOC TYPE DEPTH UNKNOWN.

If type is absent but a similar type is acceptable, see also hwloc_get_type_or_below_depth() and hwloc_get_type_or ⇒ above depth().

If some objects of the given type exist in different levels, for instance L1 and L2 caches, or L1i and L1d caches, the function returns HWLOC_TYPE_DEPTH_MULTIPLE. See hwloc/helper.h to better handle this case

If an I/O object type is given, the function returns a virtual value because I/O objects are stored in special levels that are not CPU-related. This virtual depth may be passed to other hwloc functions such as hwloc_get_obj_by_depth() but it should not be considered as an actual depth by the application. In particular, it should not be compared with any other object depth or with the entire topology depth.

```
19.7.3.10 static int hwloc_get_type_or_above_depth ( hwloc_topology_t topology, hwloc_obj_type_t type ) [inline], [static]
```

Returns the depth of objects of type type or above.

If no object of this type is present on the underlying architecture, the function returns the depth of the first "present" object typically containing type.

If some objects of the given type exist in different levels, for instance L1 and L2 caches, the function returns HWLOC← TYPE DEPTH MULTIPLE.

```
19.7.3.11 static int hwloc_get_type_or_below_depth( hwloc_topology_t topology, hwloc_obj_type_t type ) [inline],
        [static]
```

Returns the depth of objects of type type or below.

If no object of this type is present on the underlying architecture, the function returns the depth of the first "present" object typically found inside type.

If some objects of the given type exist in different levels, for instance L1 and L2 caches, the function returns HWLOC← TYPE DEPTH MULTIPLE.

19.7.3.12 unsigned hwloc_topology_get_depth (hwloc_topology_t restrict topology_)

Get the depth of the hierarchical tree of objects.

This is the depth of HWLOC_OBJ_PU objects plus one.

19.8 Manipulating Object Type, Sets and Attributes as Strings

Functions

- const char * hwloc_obj_type_string (hwloc_obj_type_t type)
- int hwloc_obj_type_sscanf (const char *string, hwloc_obj_type_t *typep, int *depthattrp, void *typeattrp, size_t typeattrsize)
- int hwloc obj type snprintf (char *restrict string, size t size, hwloc obj t obj, int verbose)
- int hwloc_obj_attr_snprintf (char *restrict string, size_t size, hwloc_obj_t obj, const char *restrict separator, int verbose)
- int hwloc obj cpuset snprintf (char *restrict str, size t size, size t nobj, const hwloc obj t *restrict objs)
- static const char * hwloc obj get info by name (hwloc obj t obj, const char *name)
- void hwloc obj add info (hwloc obj t obj, const char *name, const char *value)

19.8.1 Detailed Description

19.8.2 Function Documentation

19.8.2.1 void hwloc_obj_add_info (hwloc_obj_t obj, const char * name, const char * value)

Add the given info name and value pair to the given object.

The info is appended to the existing info array even if another key with the same name already exists.

The input strings are copied before being added in the object infos.

Note

This function may be used to enforce object colors in the Istopo graphical output by using "IstopoStyle" as a name and "Background=#rrggbb" as a value. See CUSTOM COLORS in the Istopo(1) manpage for details. If value contains some non-printable characters, they will be dropped when exporting to XML, see hwloc_
topology_export_xml().

19.8.2.2 int hwloc_obj_attr_snprintf (char *restrict string, size_t size, hwloc_obj_t obj, const char *restrict separator, int verbose)

Stringify the attributes of a given topology object into a human-readable form.

Attribute values are separated by separator.

Only the major attributes are printed in non-verbose mode.

If size is 0, string may safely be NULL.

Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

19.8.2.3 int hwloc_obj_cpuset_snprintf (char *restrict str, size_t size, size_t nobj, const hwloc_obj_t *restrict objs)

Stringify the cpuset containing a set of objects.

If size is 0, string may safely be NULL.

Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

19.8.2.4 static const char* hwloc_obj_get_info_by_name(hwloc_obj_ t obj, const char * name) [inline], [static]

Search the given key name in object infos and return the corresponding value.

If multiple keys match the given name, only the first one is returned.

Returns

NULL if no such key exists.

19.8.2.5 int hwloc_obj_type_snprintf (char *restrict string, size_t size, hwloc_obj_t obj, int verbose)

Stringify the type of a given topology object into a human-readable form.

It differs from hwloc obj type string() because it prints type attributes such as cache depth and type.

If size is 0, string may safely be NULL.

Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

19.8.2.6 int hwloc_obj_type_sscanf (const char * string, hwloc_obj_type_t * typep, int * depthattrp, void * typeattrp, size_t typeattrsize)

Return an object type and attributes from a type string.

Convert strings such as "Package" or "Cache" into the corresponding types. Matching is case-insensitive, and only the first letters are actually required to match.

Types that have specific attributes, for instance caches and groups, may be returned in depthattrp and typeattrp. They are ignored when these pointers are NULL.

For instance "L2i" or "L2iCache" would return type HWLOC_OBJ_CACHE in typep, 2 in depthattrp, and HWL \leftarrow OC_OBJ_CACHE_TYPE_INSTRUCTION in typeattrp (this last pointer should point to a hwloc_obj_cache_type_t). "Group3" would return type HWLOC_OBJ_GROUP type and 3 in depthattrp. Attributes that are not specified in the string (for instance "Group" without a depth, or "L2Cache" without a cache type) are set to -1.

typeattrd is only filled if the size specified in typeattrsize is large enough. It is currently only used for caches, and the required size is at least the size of hwloc_obj_cache_type_t.

Returns

0 if a type was correctly identified, otherwise -1.

Note

This is an extended version of the now deprecated hwloc obj type of string()

19.8.2.7 const char* hwloc_obj_type_string (hwloc_obj_type_t type)

Return a stringified topology object type.

19.9 CPU binding

Enumerations

Functions

- int hwloc_set_cpubind (hwloc_topology_t topology, hwloc_const_cpuset_t set, int flags)
- int hwloc get cpubind (hwloc topology t topology, hwloc cpuset t set, int flags)
- int hwloc_set_proc_cpubind (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_const_cpuset_t set, int flags)
- int hwloc get proc cpubind (hwloc topology t topology, hwloc pid t pid, hwloc cpuset t set, int flags)
- int hwloc_set_thread_cpubind (hwloc_topology_t topology, hwloc_thread_t thread, hwloc_const_cpuset_t set, int flags)
- int hwloc get thread cpubind (hwloc topology t topology, hwloc thread t thread, hwloc cpuset t set, int flags)
- int hwloc_get_last_cpu_location (hwloc_topology_t topology, hwloc_cpuset_t set, int flags)
- int hwloc get proc last cpu location (hwloc topology t topology, hwloc pid t pid, hwloc cpuset t set, int flags)

19.9.1 Detailed Description

It is often useful to call hwloc_bitmap_singlify() first so that a single CPU remains in the set. This way, the process will not even migrate between different CPUs inside the given set. Some operating systems also only support that kind of binding.

Some operating systems do not provide all hwloc-supported mechanisms to bind processes, threads, etc. hwloc_ctopology_get_support() may be used to query about the actual CPU binding support in the currently used operating system.

When the requested binding operation is not available and the HWLOC_CPUBIND_STRICT flag was passed, the function returns -1. errno is set to ENOSYS when it is not possible to bind the requested kind of object processes/threads. errno is set to EXDEV when the requested cpuset can not be enforced (e.g. some systems only allow one CPU, and some other systems only allow one NUMA node).

If HWLOC_CPUBIND_STRICT was not passed, the function may fail as well, or the operating system may use a slightly different operation (with side-effects, smaller binding set, etc.) when the requested operation is not exactly supported.

The most portable version that should be preferred over the others, whenever possible, is the following one which just binds the current program, assuming it is single-threaded:

```
hwloc_set_cpubind(topology, set, 0),
```

If the program may be multithreaded, the following one should be preferred to only bind the current thread:

```
hwloc_set_cpubind(topology, set, HWLOC_CPUBIND_THREAD),
```

See also

Some example codes are available under doc/examples/ in the source tree.

Note

To unbind, just call the binding function with either a full cpuset or a cpuset equal to the system cpuset. On some operating systems, CPU binding may have effects on memory binding, see HWLOC_CPUBIND_NO⊷ MEMBIND

Running Istopo -top or hwloc-ps can be a very convenient tool to check how binding actually happened.

19.9 CPU binding 89

19.9.2 Enumeration Type Documentation

19.9.2.1 enum hwloc cpubind flags t

Process/Thread binding flags.

These bit flags can be used to refine the binding policy.

The default (0) is to bind the current process, assumed to be single-threaded, in a non-strict way. This is the most portable way to bind as all operating systems usually provide it.

Note

Not all systems support all kinds of binding. See the "Detailed Description" section of CPU binding for a description of errors that can occur.

Enumerator

HWLOC_CPUBIND_PROCESS Bind all threads of the current (possibly) multithreaded process.

HWLOC_CPUBIND_THREAD Bind current thread of current process.

HWLOC_CPUBIND_STRICT Request for strict binding from the OS. By default, when the designated CPUs are all busy while other CPUs are idle, operating systems may execute the thread/process on those other CPUs instead of the designated CPUs, to let them progress anyway. Strict binding means that the thread/process will _never_ execute on other cpus than the designated CPUs, even when those are busy with other tasks and other CPUs are idle.

Note

Depending on the operating system, strict binding may not be possible (e.g., the OS does not implement it) or not allowed (e.g., for an administrative reasons), and the function will fail in that case.

When retrieving the binding of a process, this flag checks whether all its threads actually have the same binding. If the flag is not given, the binding of each thread will be accumulated.

Note

This flag is meaningless when retrieving the binding of a thread.

HWLOC_CPUBIND_NOMEMBIND Avoid any effect on memory binding. On some operating systems, some CPU binding function would also bind the memory on the corresponding NUMA node. It is often not a problem for the application, but if it is, setting this flag will make hwloc avoid using OS functions that would also bind memory. This will however reduce the support of CPU bindings, i.e. potentially return -1 with errno set to ENOSYS in some cases.

This flag is only meaningful when used with functions that set the CPU binding. It is ignored when used with functions that get CPU binding information.

19.9.3 Function Documentation

19.9.3.1 int hwloc_get_cpubind (hwloc_topology_t topology, hwloc_cpuset_t set, int flags)

Get current process or thread binding.

Writes into set the physical cpuset which the process or thread (according to flags) was last bound to.

19.9.3.2 int hwloc_get_last_cpu_location (hwloc_topology_t topology, hwloc_cpuset_t set, int flags)

Get the last physical CPU where the current process or thread ran.

The operating system may move some tasks from one processor to another at any time according to their binding, so this function may return something that is already outdated.

flags can include either HWLOC_CPUBIND_PROCESS or HWLOC_CPUBIND_THREAD to specify whether the query should be for the whole process (union of all CPUs on which all threads are running), or only the current thread. If the process is single-threaded, flags can be set to zero to let hwloc use whichever method is available on the underlying OS.

19.9.3.3 int hwloc_get_proc_cpubind (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_cpuset_t set, int flags)

Get the current physical binding of process pid.

Note

hwloc_pid_t is pid_t on Unix platforms, and HANDLE on native Windows platforms.

As a special case on Linux, if a tid (thread ID) is supplied instead of a pid (process ID) and HWLOC_CPUBIND

_THREAD is passed in flags, the binding for that specific thread is returned.

On non-Linux systems, HWLOC_CPUBIND_THREAD can not be used in flags.

19.9.3.4 int hwloc_get_proc_last_cpu_location (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_cpuset_t set, int flags)

Get the last physical CPU where a process ran.

The operating system may move some tasks from one processor to another at any time according to their binding, so this function may return something that is already outdated.

Note

hwloc_pid_t is pid_t on Unix platforms, and HANDLE on native Windows platforms.

As a special case on Linux, if a tid (thread ID) is supplied instead of a pid (process ID) and HWLOC_CPUBIND

_THREAD is passed in flags, the last CPU location of that specific thread is returned.

On non-Linux systems, HWLOC_CPUBIND_THREAD can not be used in flags.

19.9.3.5 int hwloc_get_thread_cpubind (hwloc_topology_t topology, hwloc_thread_t thread, hwloc_cpuset_t set, int flags)

Get the current physical binding of thread tid.

Note

 $\label{loc_thread_tispthread_ton Unix platforms, and HANDLE on native Windows platforms. \\ HWLOC_CPUBIND_PROCESS can not be used in flags. \\$

19.9.3.6 int hwloc_set_cpubind (hwloc_topology t topology, hwloc_const_cpuset_t set, int flags)

Bind current process or thread on cpus given in physical bitmap set.

Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

19.9 CPU binding 91

19.9.3.7 int hwloc_set_proc_cpubind (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_const_cpuset_t set, int flags)

Bind a process pid on cpus given in physical bitmap set.

Note

hwloc_pid_t is pid_t on Unix platforms, and HANDLE on native Windows platforms.

As a special case on Linux, if a tid (thread ID) is supplied instead of a pid (process ID) and HWLOC_CPUBIND

_THREAD is passed in flags, the binding is applied to that specific thread.

On non-Linux systems, HWLOC_CPUBIND_THREAD can not be used in flags.

19.9.3.8 int hwloc_set_thread_cpubind (hwloc_topology_t topology, hwloc_thread_t thread, hwloc_const_cpuset_t set, int flags)

Bind a thread thread on cpus given in physical bitmap set.

Note

hwloc_thread_t is pthread_t on Unix platforms, and HANDLE on native Windows platforms. HWLOC_CPUBIND_PROCESS can not be used in flags.

19.10 Memory binding

Enumerations

enum hwloc_membind_policy_t {
 HWLOC_MEMBIND_DEFAULT, HWLOC_MEMBIND_FIRSTTOUCH, HWLOC_MEMBIND_BIND, HWLOC_M
 EMBIND_INTERLEAVE,
 HWLOC_MEMBIND_REPLICATE, HWLOC_MEMBIND_NEXTTOUCH, HWLOC_MEMBIND_MIXED }

enum hwloc_membind_flags_t {
 HWLOC_MEMBIND_PROCESS, HWLOC_MEMBIND_THREAD, HWLOC_MEMBIND_STRICT, HWLOC_ME
 MBIND_MIGRATE,
 HWLOC_MEMBIND_NOCPUBIND }

Functions

- int hwloc_set_membind_nodeset (hwloc_topology_t topology, hwloc_const_nodeset_t nodeset, hwloc_
 membind_policy_t policy, int flags)
- int hwloc_set_membind (hwloc_topology_t topology, hwloc_const_cpuset_t cpuset, hwloc_membind_policy_
 t policy, int flags)
- int hwloc_get_membind_nodeset (hwloc_topology_t topology, hwloc_nodeset_t nodeset, hwloc_membind_
 policy_t *policy, int flags)
- int hwloc_get_membind (hwloc_topology_t topology, hwloc_cpuset_t cpuset, hwloc_membind_policy_t *policy, int flags)
- int hwloc_set_proc_membind_nodeset (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_const_nodeset_
 t nodeset, hwloc_membind_policy_t policy, int flags)
- int hwloc_set_proc_membind (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_const_cpuset_t cpuset, hwloc_membind_policy_t policy, int flags)
- int hwloc_get_proc_membind_nodeset (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_nodeset_t nodeset, hwloc membind policy t *policy, int flags)
- int hwloc_get_proc_membind (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_cpuset_t cpuset, hwloc_
 membind_policy_t *policy, int flags)
- int hwloc_set_area_membind_nodeset (hwloc_topology_t topology, const void *addr, size_t len, hwloc_const_
 —
 nodeset_t nodeset, hwloc_membind_policy_t policy, int flags)
- int hwloc_set_area_membind (hwloc_topology_t topology, const void *addr, size_t len, hwloc_const_cpuset_t cpuset, hwloc_membind_policy_t policy, int flags)
- int hwloc_get_area_membind_nodeset (hwloc_topology_t topology, const void *addr, size_t len, hwloc_
 nodeset_t nodeset, hwloc_membind_policy_t *policy, int flags)
- int hwloc_get_area_membind (hwloc_topology_t topology, const void *addr, size_t len, hwloc_cpuset_t cpuset, hwloc_membind_policy_t *policy, int flags)
- void * hwloc_alloc (hwloc_topology_t topology, size_t len)
- void * hwloc_alloc_membind_nodeset (hwloc_topology_t topology, size_t len, hwloc_const_nodeset_t nodeset, hwloc_membind_policy_t policy, int flags)
- void * hwloc_alloc_membind (hwloc_topology_t topology, size_t len, hwloc_const_cpuset_t cpuset, hwloc_
 membind_policy_t policy, int flags)
- static void * hwloc_alloc_membind_policy (hwloc_topology_t topology, size_t len, hwloc_const_cpuset_t set, hwloc_membind_policy_t policy, int flags)
- int hwloc free (hwloc topology t topology, void *addr, size t len)

19.10 Memory binding 93

19.10.1 Detailed Description

Memory binding can be done three ways:

explicit memory allocation thanks to hwloc_alloc_membind() and friends: the binding will have effect on the memory allocated by these functions.

- implicit memory binding through binding policy: hwloc_set_membind() and friends only define the current policy of the process, which will be applied to the subsequent calls to malloc() and friends.
- migration of existing memory ranges, thanks to hwloc_set_area_membind() and friends, which move alreadyallocated data.

Not all operating systems support all three ways. hwloc_topology_get_support() may be used to query about the actual memory binding support in the currently used operating system.

When the requested binding operation is not available and the HWLOC_MEMBIND_STRICT flag was passed, the function returns -1. errno will be set to ENOSYS when the system does support the specified action or policy (e.g., some systems only allow binding memory on a per-thread basis, whereas other systems only allow binding memory for all threads in a process). errno will be set to EXDEV when the requested cpuset can not be enforced (e.g., some systems only allow binding memory to a single NUMA node).

If HWLOC_MEMBIND_STRICT was not passed, the function may fail as well, or the operating system may use a slightly different operation (with side-effects, smaller binding set, etc.) when the requested operation is not exactly supported.

The most portable form that should be preferred over the others whenever possible is as follows. It allocates some memory hopefully bound to the specified set. To do so, hwloc will possibly have to change the current memory binding policy in order to actually get the memory bound, if the OS does not provide any other way to simply allocate bound memory without changing the policy for all allocations. That is the difference with hwloc_alloc_membind(), which will never change the current memory binding policy.

Each hwloc memory binding function is available in two forms: one that takes a CPU set argument and another that takes a NUMA memory node set argument (see Object Sets (hwloc_cpuset_t and hwloc_nodeset_t) and The bitmap API for a discussion of CPU sets and NUMA memory node sets). The names of the latter form end with _nodeset. It is also possible to convert between CPU set and node set using hwloc_cpuset_to_nodeset() or hwloc_cpuset_from_nodeset().

See also

Some example codes are available under doc/examples/ in the source tree.

Note

On some operating systems, memory binding affects the CPU binding; see HWLOC_MEMBIND_NOCPUBIND

19.10.2 Enumeration Type Documentation

19.10.2.1 enum hwloc_membind_flags_t

Memory binding flags.

These flags can be used to refine the binding policy. All flags can be logically OR'ed together with the exception of HWLOC_MEMBIND_PROCESS and HWLOC_MEMBIND_THREAD; these two flags are mutually exclusive.

Not all systems support all kinds of binding. hwloc_topology_get_support() may be used to query about the actual memory binding support in the currently used operating system. See the "Detailed Description" section of Memory binding for a description of errors that can occur.

Enumerator

- **HWLOC_MEMBIND_PROCESS** Set policy for all threads of the specified (possibly multithreaded) process. This flag is mutually exclusive with HWLOC MEMBIND THREAD.
- HWLOC_MEMBIND_THREAD Set policy for a specific thread of the current process. This flag is mutually exclusive with HWLOC MEMBIND PROCESS.
- **HWLOC_MEMBIND_STRICT** Request strict binding from the OS. The function will fail if the binding can not be guaranteed / completely enforced.

This flag has slightly different meanings depending on which function it is used with.

- **HWLOC_MEMBIND_MIGRATE** Migrate existing allocated memory. If the memory cannot be migrated and the HWLOC_MEMBIND_STRICT flag is passed, an error will be returned.
- HWLOC_MEMBIND_NOCPUBIND Avoid any effect on CPU binding. On some operating systems, some underlying memory binding functions also bind the application to the corresponding CPU(s). Using this flag will cause hwloc to avoid using OS functions that could potentially affect CPU bindings. Note, however, that using NOCPUBIND may reduce hwloc's overall memory binding support. Specifically: some of hwloc's memory binding functions may fail with errno set to ENOSYS when used with NOCPUBIND.

19.10.2.2 enum hwloc_membind_policy_t

Memory binding policy.

These constants can be used to choose the binding policy. Only one policy can be used at a time (i.e., the values cannot be OR'ed together).

Not all systems support all kinds of binding. hwloc_topology_get_support() may be used to query about the actual memory binding policy support in the currently used operating system. See the "Detailed Description" section of Memory binding for a description of errors that can occur.

Enumerator

- **HWLOC_MEMBIND_DEFAULT** Reset the memory allocation policy to the system default. Depending on the operating system, this may correspond to HWLOC_MEMBIND_FIRSTTOUCH (Linux), or HWLOC_MEMBI ← ND_BIND (AIX, HP-UX, OSF, Solaris, Windows).
- HWLOC_MEMBIND_FIRSTTOUCH Allocate memory but do not immediately bind it to a specific locality. Instead, each page in the allocation is bound only when it is first touched. Pages are individually bound to the local NUMA node of the first thread that touches it. If there is not enough memory on the node, allocation may be done in the specified cpuset before allocating on other nodes.
- HWLOC_MEMBIND_BIND Allocate memory on the specified nodes.
- HWLOC_MEMBIND_INTERLEAVE Allocate memory on the given nodes in an interleaved / round-robin manner. The precise layout of the memory across multiple NUMA nodes is OS/system specific. Interleaving can be useful when threads distributed across the specified NUMA nodes will all be accessing the whole memory range concurrently, since the interleave will then balance the memory references.
- HWLOC_MEMBIND_REPLICATE Replicate memory on the given nodes; reads from this memory will attempt to be serviced from the NUMA node local to the reading thread. Replicating can be useful when multiple threads from the specified NUMA nodes will be sharing the same read-only data. This policy can only be used with existing memory allocations (i.e., the hwloc_set_*membind*() functions); it cannot be used with functions that allocate new memory (i.e., the hwloc alloc*() functions).

19.10 Memory binding 95

HWLOC_MEMBIND_NEXTTOUCH For each page bound with this policy, by next time it is touched (and next time only), it is moved from its current location to the local NUMA node of the thread where the memory reference occurred (if it needs to be moved at all).

HWLOC_MEMBIND_MIXED Returned by get_membind() functions when multiple threads or parts of a memory area have differing memory binding policies.

19.10.3 Function Documentation

19.10.3.1 void* hwloc_alloc (hwloc_topology_t topology, size_t len)

Allocate some memory.

This is equivalent to malloc(), except that it tries to allocate page-aligned memory from the OS.

Note

The allocated memory should be freed with hwloc free().

19.10.3.2 void* hwloc_alloc_membind (hwloc_topology_t topology, size_t len, hwloc_const_cpuset_t cpuset, hwloc_membind_policy_t policy, int flags)

Allocate some memory on memory nodes near the given physical cpuset cpuset.

Returns

NULL with errno set to ENOSYS if the action is not supported and HWLOC_MEMBIND_STRICT is given NULL with errno set to EXDEV if the binding cannot be enforced and HWLOC_MEMBIND_STRICT is given NULL with errno set to ENOMEM if the memory allocation failed even before trying to bind.

Note

The allocated memory should be freed with hwloc free().

19.10.3.3 void* hwloc_alloc_membind_nodeset (hwloc_topology_t topology, size_t len, hwloc_const_nodeset_t nodeset, hwloc_membind_policy_t policy, int flags)

Allocate some memory on the given physical nodeset nodeset.

Returns

NULL with errno set to ENOSYS if the action is not supported and HWLOC_MEMBIND_STRICT is given NULL with errno set to EXDEV if the binding cannot be enforced and HWLOC_MEMBIND_STRICT is given NULL with errno set to ENOMEM if the memory allocation failed even before trying to bind.

Note

The allocated memory should be freed with hwloc_free().

19.10.3.4 static void* hwloc_alloc_membind_policy (hwloc_topology_t topology, size_t len, hwloc_const_cpuset_t set, hwloc_membind_policy_t policy, int flags) [inline], [static]

Allocate some memory on the memory nodes near given cpuset cpuset.

This is similar to hwloc alloc membind policy nodeset, but for a given cpuset.

```
19.10.3.5 static void* hwloc_alloc_membind_policy_nodeset ( hwloc_topology_t topology, size_t len, hwloc_const_nodeset_t nodeset, hwloc_membind_policy_t policy, int flags ) [inline], [static]
```

Allocate some memory on the given nodeset nodeset.

This is similar to hwloc_alloc_membind except that it is allowed to change the current memory binding policy, thus providing more binding support, at the expense of changing the current state.

```
19.10.3.6 int hwloc_free ( hwloc_topology_t topology, void * addr, size_t len )
```

Free memory that was previously allocated by hwloc alloc() or hwloc alloc membind().

19.10.3.7 int hwloc_get_area_membind (hwloc_topology_t topology, const void * addr, size_t len, hwloc_cpuset_t cpuset, hwloc_membind_policy_t * policy, int flags)

Query the CPUs near the physical NUMA node(s) and binding policy of the memory identified by (addr, len).

This function has two output parameters: cpuset and policy. The values returned in these parameters depend on both the flags passed in and the memory binding policies and nodesets of the pages in the address range.

If HWLOC_MEMBIND_STRICT is specified, the target pages are first checked to see if they all have the same memory binding policy and nodeset. If they do not, -1 is returned and errno is set to EXDEV. If they are identical across all pages, the policy is returned in policy. cpuset is set to the union of CPUs near the NUMA node(s) in the nodeset.

If HWLOC_MEMBIND_STRICT is not specified, the union of all NUMA node(s) containing pages in the address range is calculated. cpuset is then set to the CPUs near the NUMA node(s) in this union. If all pages in the target have the same policy, it is returned in policy. Otherwise, policy is set to HWLOC_MEMBIND_MIXED.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

```
19.10.3.8 int hwloc_get_area_membind_nodeset ( hwloc_topology_t topology, const void * addr, size_t len, hwloc_nodeset t nodeset, hwloc_membind_policy_t * policy, int flags )
```

Query the physical NUMA node(s) and binding policy of the memory identified by (addr, len).

This function has two output parameters: nodeset and policy. The values returned in these parameters depend on both the flags passed in and the memory binding policies and nodesets of the pages in the address range.

If HWLOC_MEMBIND_STRICT is specified, the target pages are first checked to see if they all have the same memory binding policy and nodeset. If they do not, -1 is returned and errno is set to EXDEV. If they are identical across all pages, the nodeset and policy are returned in nodeset and policy, respectively.

If HWLOC_MEMBIND_STRICT is not specified, nodeset is set to the union of all NUMA node(s) containing pages in the address range. If all pages in the target have the same policy, it is returned in policy. Otherwise, policy is set to HWLOC MEMBIND MIXED.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

19.10 Memory binding 97

19.10.3.9 int hwloc_get_membind (hwloc_topology_t topology, hwloc_cpuset_t cpuset, hwloc_membind_policy_t * policy, int flags)

Query the default memory binding policy and physical locality of the current process or thread (the locality is returned in cpuset as CPUs near the locality's actual NUMA node(s)).

This function has two output parameters: cpuset and policy. The values returned in these parameters depend on both the flags passed in and the current memory binding policies and nodesets in the queried target.

Passing the HWLOC_MEMBIND_PROCESS flag specifies that the query target is the current policies and nodesets for all the threads in the current process. Passing HWLOC_MEMBIND_THREAD specifies that the query target is the current policy and nodeset for only the thread invoking this function.

If neither of these flags are passed (which is the most portable method), the process is assumed to be single threaded. This allows hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

HWLOC_MEMBIND_STRICT is only meaningful when HWLOC_MEMBIND_PROCESS is also specified. In this case, hwloc will check the default memory policies and nodesets for all threads in the process. If they are not identical, -1 is returned and errno is set to EXDEV. If they are identical, the policy is returned in policy. cpuset is set to the union of CPUs near the NUMA node(s) in the nodeset.

Otherwise, if HWLOC_MEMBIND_PROCESS is specified (and HWLOC_MEMBIND_STRICT is *not* specified), the default nodeset from each thread is logically OR'ed together. cpuset is set to the union of CPUs near the NUMA node(s) in the resulting nodeset. If all threads' default policies are the same, policy is set to that policy. If they are different, policy is set to HWLOC MEMBIND MIXED.

In the HWLOC_MEMBIND_THREAD case (or when neither HWLOC_MEMBIND_PROCESS or HWLOC_MEMBIND — __THREAD is specified), there is only one nodeset and policy. The policy is returned in policy; cpuset is set to the union of CPUs near the NUMA node(s) in the nodeset.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

19.10.3.10 int hwloc_get_membind_nodeset (hwloc_topology_t topology, hwloc_nodeset_t nodeset, hwloc_membind_policy_t * policy, int flags)

Query the default memory binding policy and physical locality of the current process or thread.

This function has two output parameters: nodeset and policy. The values returned in these parameters depend on both the flags passed in and the current memory binding policies and nodesets in the queried target.

Passing the HWLOC_MEMBIND_PROCESS flag specifies that the query target is the current policies and nodesets for all the threads in the current process. Passing HWLOC_MEMBIND_THREAD specifies that the query target is the current policy and nodeset for only the thread invoking this function.

If neither of these flags are passed (which is the most portable method), the process is assumed to be single threaded. This allows hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

HWLOC_MEMBIND_STRICT is only meaningful when HWLOC_MEMBIND_PROCESS is also specified. In this case, hwloc will check the default memory policies and nodesets for all threads in the process. If they are not identical, -1 is returned and errno is set to EXDEV. If they are identical, the values are returned in nodeset and policy.

Otherwise, if HWLOC_MEMBIND_PROCESS is specified (and HWLOC_MEMBIND_STRICT is *not* specified), nodeset is set to the logical OR of all threads' default nodeset. If all threads' default policies are the same, policy is set to that policy. If they are different, policy is set to HWLOC MEMBIND MIXED.

In the HWLOC_MEMBIND_THREAD case (or when neither HWLOC_MEMBIND_PROCESS or HWLOC_MEMBIND THREAD is specified), there is only one nodeset and policy; they are returned in nodeset and policy, respectively.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

19.10.3.11 int hwloc_get_proc_membind (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_cpuset_t cpuset, hwloc membind policy t * policy, int flags)

Query the default memory binding policy and physical locality of the specified process (the locality is returned in cpuset as CPUs near the locality's actual NUMA node(s)).

This function has two output parameters: cpuset and policy. The values returned in these parameters depend on both the flags passed in and the current memory binding policies and nodesets in the queried target.

Passing the HWLOC_MEMBIND_PROCESS flag specifies that the query target is the current policies and nodesets for all the threads in the specified process. If HWLOC_MEMBIND_PROCESS is not specified (which is the most portable method), the process is assumed to be single threaded. This allows hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

Note that it does not make sense to pass HWLOC MEMBIND THREAD to this function.

If HWLOC_MEMBIND_STRICT is specified, hwloc will check the default memory policies and nodesets for all threads in the specified process. If they are not identical, -1 is returned and errno is set to EXDEV. If they are identical, the policy is returned in policy. cpuset is set to the union of CPUs near the NUMA node(s) in the nodeset.

Otherwise, the default nodeset from each thread is logically OR'ed together. cpuset is set to the union of CPUs near the NUMA node(s) in the resulting nodeset. If all threads' default policies are the same, policy is set to that policy. If they are different, policy is set to HWLOC MEMBIND MIXED.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

Note

hwloc_pid_t is pid_t on Unix platforms, and HANDLE on native Windows platforms.

19.10.3.12 int hwloc_get_proc_membind_nodeset (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_nodeset_t nodeset, hwloc_membind_policy_t * policy, int flags)

Query the default memory binding policy and physical locality of the specified process.

This function has two output parameters: nodeset and policy. The values returned in these parameters depend on both the flags passed in and the current memory binding policies and nodesets in the queried target.

Passing the HWLOC_MEMBIND_PROCESS flag specifies that the query target is the current policies and nodesets for all the threads in the specified process. If HWLOC_MEMBIND_PROCESS is not specified (which is the most portable method), the process is assumed to be single threaded. This allows hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

Note that it does not make sense to pass HWLOC_MEMBIND_THREAD to this function.

If HWLOC_MEMBIND_STRICT is specified, hwloc will check the default memory policies and nodesets for all threads in the specified process. If they are not identical, -1 is returned and errno is set to EXDEV. If they are identical, the values are returned in nodeset and policy.

Otherwise, nodeset is set to the logical OR of all threads' default nodeset. If all threads' default policies are the same, policy is set to that policy. If they are different, policy is set to HWLOC_MEMBIND_MIXED.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

Note

hwloc_pid_t is pid_t on Unix platforms, and HANDLE on native Windows platforms.

19.10 Memory binding 99

```
19.10.3.13 int hwloc_set_area_membind ( hwloc_topology_t topology, const void * addr, size_t len, hwloc const cpuset t cpuset, hwloc membind policy t policy, int flags )
```

Bind the already-allocated memory identified by (addr, len) to the NUMA node(s) near physical cpuset.

Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

```
19.10.3.14 int hwloc_set_area_membind_nodeset ( hwloc_topology_t topology, const void * addr, size_t len, hwloc_const_nodeset_t nodeset, hwloc_membind_policy_t policy, int flags )
```

Bind the already-allocated memory identified by (addr, len) to the NUMA node(s) in physical nodeset.

Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

```
19.10.3.15 int hwloc_set_membind ( hwloc_topology_t topology, hwloc_const_cpuset_t cpuset, hwloc_membind_policy_t policy, int flags )
```

Set the default memory binding policy of the current process or thread to prefer the NUMA node(s) near the specified physical cpuset.

If neither HWLOC_MEMBIND_PROCESS nor HWLOC_MEMBIND_THREAD is specified, the current process is assumed to be single-threaded. This is the most portable form as it permits hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

```
19.10.3.16 int hwloc_set_membind_nodeset ( hwloc_topology_t topology, hwloc_const_nodeset_t nodeset, hwloc_membind_policy_t policy, int flags )
```

Set the default memory binding policy of the current process or thread to prefer the NUMA node(s) specified by physical nodeset.

If neither HWLOC_MEMBIND_PROCESS nor HWLOC_MEMBIND_THREAD is specified, the current process is assumed to be single-threaded. This is the most portable form as it permits hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

19.10.3.17 int hwloc_set_proc_membind (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_const_cpuset_t cpuset, hwloc_membind_policy_t policy, int flags)

Set the default memory binding policy of the specified process to prefer the NUMA node(s) near the specified physical cpuset.

Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

Note

hwloc_pid_t is pid_t on Unix platforms, and HANDLE on native Windows platforms.

19.10.3.18 int hwloc_set_proc_membind_nodeset (hwloc_topology_t topology, hwloc_pid_t pid, hwloc_const_nodeset_t nodeset, hwloc_membind_policy_t policy, int flags)

Set the default memory binding policy of the specified process to prefer the NUMA node(s) specified by physical nodeset.

Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

Note

hwloc_pid_t is pid_t on Unix platforms, and HANDLE on native Windows platforms.

19.11 Modifying a loaded Topology

Enumerations

enum hwloc_restrict_flags_e { HWLOC_RESTRICT_FLAG_ADAPT_DISTANCES, HWLOC_RESTRICT_FLAG_ADAPT_IO }

Functions

- hwloc_obj_t hwloc_topology_insert_misc_object_by_cpuset (hwloc_topology_t topology, hwloc_const_cpuset_t cpuset, const char *name)
- hwloc_obj_t hwloc_topology_insert_misc_object_by_parent (hwloc_topology_t topology, hwloc_obj_t parent, const char *name)
- int hwloc_topology_restrict (hwloc_topology_t restrict topology, hwloc_const_cpuset_t cpuset, unsigned long flags)

19.11.1 Detailed Description

19.11.2 Enumeration Type Documentation

19.11.2.1 enum hwloc_restrict_flags_e

Flags to be given to hwloc_topology_restrict().

Enumerator

- **HWLOC_RESTRICT_FLAG_ADAPT_DISTANCES** Adapt distance matrices according to objects being removed during restriction. If this flag is not set, distance matrices are removed.
- **HWLOC_RESTRICT_FLAG_ADAPT_MISC** Move Misc objects to ancestors if their parents are removed during restriction. If this flag is not set, Misc objects are removed when their parents are removed.
- **HWLOC_RESTRICT_FLAG_ADAPT_IO** Move I/O objects to ancestors if their parents are removed during restriction. If this flag is not set, I/O devices and bridges are removed when their parents are removed.

19.11.3 Function Documentation

19.11.3.1 hwloc_obj_t hwloc_topology_insert_misc_object_by_cpuset (hwloc_topology_t topology, hwloc_const_cpuset_t cpuset, const char * name)

Add a MISC object to the topology.

A new MISC object will be created and inserted into the topology at the position given by bitmap cpuset. This offers a way to add new intermediate levels to the topology hierarchy.

cpuset and name will be copied to setup the new object attributes.

Returns

the newly-created object.

NULL if the insertion conflicts with the existing topology tree.

Note

19.11.3.2 hwloc_obj_t hwloc_topology_insert_misc_object_by_parent (hwloc_topology_t topology, hwloc_obj_t parent, const char * name)

Add a MISC object as a leaf of the topology.

A new MISC object will be created and inserted into the topology at the position given by parent. It is appended to the list of existing children, without ever adding any intermediate hierarchy level. This is useful for annotating the topology without actually changing the hierarchy.

name will be copied to the setup the new object attributes. However, the new leaf object will not have any cpuset.

Returns

the newly-created object

Note

If name contains some non-printable characters, they will be dropped when exporting to XML, see hwloc_ topology export xml().

19.11.3.3 int hwloc_topology_restrict (hwloc_topology_t restrict topology, hwloc_const_cpuset_t cpuset, unsigned long flags)

Restrict the topology to the given CPU set.

Topology topology is modified so as to remove all objects that are not included (or partially included) in the CPU set cpuset. All objects CPU and node sets are restricted accordingly.

flags is a OR'ed set of hwloc restrict flags e.

Note

This call may not be reverted by restricting back to a larger cpuset. Once dropped during restriction, objects may not be brought back, except by loading another topology with hwloc_topology_load().

Returns

0 on success.

- -1 with errno set to EINVAL if the input cpuset is invalid. The topology is not modified in this case.
- -1 with errno set to ENOMEM on failure to allocate internal data. The topology is reinitialized in this case. It should be either destroyed with hwloc_topology_destroy() or configured and loaded again.

19.12 Building Custom Topologies

Functions

- int hwloc_custom_insert_topology (hwloc_topology_t newtopology, hwloc_obj_t newparent, hwloc_topology_
 t oldtopology, hwloc_obj_t oldroot)
- hwloc_obj_t hwloc_custom_insert_group_object_by_parent (hwloc_topology_t topology, hwloc_obj_t parent, int groupdepth)

19.12.1 Detailed Description

A custom topology may be initialized by calling hwloc_topology_set_custom() after hwloc_topology_init(). It may then be modified by inserting objects or entire topologies. Once done assembling, hwloc_topology_load() should be invoked as usual to finalize the topology.

19.12.2 Function Documentation

19.12.2.1 hwloc_obj_t hwloc_custom_insert_group_object_by_parent (hwloc_topology_t topology, hwloc_obj_t parent, int groupdepth)

Insert a new group object inside a custom topology.

An object with type HWLOC_OBJ_GROUP is inserted as a new child of object parent.

groupdepth is the depth attribute to be given to the new object. It may for instance be 0 for top-level groups, 1 for their children, and so on.

The custom topology newtopology must have been prepared with hwloc_topology_set_custom() and not loaded with hwloc_topology_load() yet.

parent may be either the root of topology or an object that was added earlier through hwloc_custom_insert_ \leftarrow group_object_by_parent().

Note

The cpuset and nodeset of the new group object are NULL because these sets are meaningless when assembling multiple topologies.

The cpuset and nodeset of the parent object are not modified.

19.12.2.2 int hwloc_custom_insert_topology (hwloc_topology_t newtopology, hwloc_obj_t newparent, hwloc_topology_t oldtopology, hwloc_obj_t oldroot)

Insert an existing topology inside a custom topology.

Duplicate the existing topology oldtopology inside a new custom topology newtopology as a leaf of object newparent.

If oldroot is not NULL, duplicate oldroot and all its children instead of the entire oldtopology. Passing the root object of oldtopology in oldroot is equivalent to passing NULL.

The custom topology newtopology must have been prepared with hwloc_topology_set_custom() and not loaded with hwloc topology load() yet.

newparent may be either the root of newtopology or an object that was added through hwloc_custom_insert_
group_object_by_parent().

The cpuset and nodeset of the newparent object are not modified based on the contents of oldtopology.

19.13 Exporting Topologies to XML

Functions

- int hwloc_topology_export_xml (hwloc_topology_t topology, const char *xmlpath)
- int hwloc_topology_export_xmlbuffer (hwloc_topology_t topology, char **xmlbuffer, int *buflen)
- void hwloc_free_xmlbuffer (hwloc_topology_t topology, char *xmlbuffer)
- void hwloc_topology_set_userdata_export_callback (hwloc_topology_t topology, void(*export_cb)(void *reserved, hwloc_topology_t topology, hwloc_obj_t obj))
- int hwloc_export_obj_userdata (void *reserved, hwloc_topology_t topology, hwloc_obj_t obj, const char *name, const void *buffer, size_t length)
- int hwloc_export_obj_userdata_base64 (void *reserved, hwloc_topology_t topology, hwloc_obj_t obj, const char *name, const void *buffer, size_t length)
- void hwloc_topology_set_userdata_import_callback (hwloc_topology_t topology, void(*import_cb)(hwloc_
 topology_t topology, hwloc_obj_t obj, const char *name, const void *buffer, size_t length))

19.13.1 Detailed Description

19.13.2 Function Documentation

19.13.2.1 int hwloc_export_obj_userdata (void * reserved, hwloc_topology_t topology, hwloc_obj_t obj, const char * name, const void * buffer, size_t length)

Export some object userdata to XML.

This function may only be called from within the export() callback passed to hwloc_topology_set_userdata_export_callback(). It may be invoked one of multiple times to export some userdata to XML. The buffer content of length length is stored with optional name name.

When importing this XML file, the import() callback (if set) will be called exactly as many times as hwloc_export_obj_ was called during export(). It will receive the corresponding name, buffer and length arguments.

reserved, topology and obj must be the first three parameters that were given to the export callback.

Only printable characters may be exported to XML string attributes. If a non-printable character is passed in name or buffer, the function returns -1 with errno set to EINVAL.

If exporting binary data, the application should first encode into printable characters only (or use hwloc_export_cobj_userdata_base64()). It should also take care of portability issues if the export may be reimported on a different architecture.

19.13.2.2 int hwloc_export_obj_userdata_base64 (void * reserved, hwloc_topology_t topology, hwloc_obj_t obj, const char * name, const void * buffer, size_t length)

Encode and export some object userdata to XML.

This function is similar to hwloc_export_obj_userdata() but it encodes the input buffer into printable characters before exporting. On import, decoding is automatically performed before the data is given to the import() callback if any.

This function may only be called from within the export() callback passed to hwloc_topology_set_userdata_export_callback().

The function does not take care of portability issues if the export may be reimported on a different architecture.

19.13.2.3 void hwloc_free_xmlbuffer (hwloc_topology_t topology, char * xmlbuffer)

Free a buffer allocated by hwloc topology export xmlbuffer()

19.13.2.4 int hwloc topology export xml (hwloc topology t topology, const char * xmlpath)

Export the topology into an XML file.

This file may be loaded later through hwloc topology set xml().

Returns

-1 if a failure occured.

Note

 $See \ also \ hwloc_topology_set_userdata_export_callback() \ for \ exporting \ application-specific \ object \ userdata.$

The topology-specific userdata pointer is ignored when exporting to XML.

Only printable characters may be exported to XML string attributes. Any other character, especially any non-AS← CII character, will be silently dropped.

If name is "-", the XML output is sent to the standard output.

19.13.2.5 int hwloc_topology_export_xmlbuffer (hwloc_topology_t topology, char ** xmlbuffer, int * buflen)

Export the topology into a newly-allocated XML memory buffer.

xmlbuffer is allocated by the callee and should be freed with hwloc free xmlbuffer() later in the caller.

This memory buffer may be loaded later through hwloc_topology_set_xmlbuffer().

Returns

-1 if a failure occured.

Note

 $See\ also\ hwloc_topology_set_userdata_export_callback()\ for\ exporting\ application-specific\ object\ userdata.$

The topology-specific userdata pointer is ignored when exporting to XML.

Only printable characters may be exported to XML string attributes. Any other

Only printable characters may be exported to XML string attributes. Any other character, especially any non-AS← CII character, will be silently dropped.

19.13.2.6 void hwloc_topology_set_userdata_export_callback (hwloc_topology_t topology, void(*)(void *reserved, hwloc_topology_t topology, hwloc_obj_t obj) export_cb)

Set the application-specific callback for exporting object userdata.

The object userdata pointer is not exported to XML by default because hwloc does not know what it contains.

This function lets applications set <code>export_cb</code> to a callback function that converts this opaque userdata into an exportable string.

export_cb is invoked during XML export for each object whose userdata pointer is not NULL. The callback should use hwloc_export_obj_userdata() or hwloc_export_obj_userdata_base64() to actually export something to XML (possibly multiple times per object).

export_cb may be set to NULL if userdata should not be exported to XML.

Note

The topology-specific userdata pointer is ignored when exporting to XML.

19.13.2.7 void hwloc_topology_set_userdata_import_callback (hwloc_topology_t topology, void(*)(hwloc_topology_t topology, hwloc_obj_t obj, const char *name, const void *buffer, size_t length) import_cb)

Set the application-specific callback for importing userdata.

On XML import, userdata is ignored by default because hwloc does not know how to store it in memory.

This function lets applications set $import_cb$ to a callback function that will get the XML-stored userdata and store it in the object as expected by the application.

import_cb is called during hwloc_topology_load() as many times as hwloc_export_obj_userdata() was called during export. The topology is not entirely setup yet. Object attributes are ready to consult, but links between objects are not.

import_cb may be NULL if userdata should be ignored during import.

Note

buffer contains length characters followed by a null byte ('\0').

This function should be called before hwloc_topology_load().

The topology-specific userdata pointer is ignored when importing from XML.

19.14 Exporting Topologies to Synthetic

Enumerations

Functions

• int hwloc_topology_export_synthetic (hwloc_topology_t topology, char *buffer, size_t buflen, unsigned long flags)

19.14.1 Detailed Description

19.14.2 Enumeration Type Documentation

19.14.2.1 enum hwloc topology export synthetic flags e

Flags for exporting synthetic topologies.

Flags to be given as a OR'ed set to hwloc topology export synthetic().

Enumerator

HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_FLAG_NO_EXTENDED_TYPES Export extended types such as L2dcache as basic types such as Cache. This is required if loading the synthetic description with hwloc < 1.9.

HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_FLAG_NO_ATTRS Do not export level attributes. Ignore level attributes such as memory/cache sizes or PU indexes. This is required if loading the synthetic description with hwloc < 1.10.

19.14.3 Function Documentation

19.14.3.1 int hwloc_topology_export_synthetic (hwloc_topology_t topology, char * buffer, size_t buflen, unsigned long flags)

Export the topology as a synthetic string.

At most buflen characters will be written in buffer, including the terminating \0.

This exported string may be given back to hwloc_topology_set_synthetic().

flags is a OR'ed set of hwloc_topology_export_synthetic_flags_e.

Returns

The number of characters that were written, not including the terminating \0.

-1 if the topology could not be exported, for instance if it is not symmetric.

Note

A 1024-byte buffer should be large enough for exporting topologies in the vast majority of cases.

19.15 Finding Objects inside a CPU set

Functions

- static hwloc_obj_t hwloc_get_first_largest_obj_inside_cpuset (hwloc_topology_t topology, hwloc_const_cpuset ← t set)
- int hwloc_get_largest_objs_inside_cpuset (hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_
 t *restrict objs, int max)
- static hwloc_obj_t hwloc_get_next_obj_inside_cpuset_by_depth (hwloc_topology_t topology, hwloc_const_
 cpuset_t set, unsigned depth, hwloc_obj_t prev)
- static hwloc_obj_t hwloc_get_next_obj_inside_cpuset_by_type (hwloc_topology_t topology, hwloc_const_
 cpuset t set, hwloc obj type t type, hwloc obj t prev)
- static hwloc_obj_t hwloc_get_obj_inside_cpuset_by_depth (hwloc_topology_t topology, hwloc_const_cpuset_← t set, unsigned depth, unsigned idx)
- static hwloc_obj_t hwloc_get_obj_inside_cpuset_by_type (hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_type_t type, unsigned idx)
- static unsigned hwloc_get_nbobjs_inside_cpuset_by_depth (hwloc_topology_t topology, hwloc_const_cpuset_t set, unsigned depth)
- static int hwloc_get_nbobjs_inside_cpuset_by_type (hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_type_t type)
- static int hwloc_get_obj_index_inside_cpuset (hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_
 obj_t obj)

19.15.1 Detailed Description

19.15.2 Function Documentation

```
19.15.2.1 static hwloc_obj_t hwloc_get_first_largest_obj_inside_cpuset ( hwloc_topology_t topology, hwloc_const_cpuset_t set ) [inline], [static]
```

Get the first largest object included in the given couset set.

Returns

the first object that is included in set and whose parent is not.

This is convenient for iterating over all largest objects within a CPU set by doing a loop getting the first largest object and clearing its CPU set from the remaining CPU set.

Note

This function cannot work if the root object does not have a CPU set, e.g. if the topology is made of different machines.

```
19.15.2.2 int hwloc_get_largest_objs_inside_cpuset ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_t *restrict objs, int max )
```

Get the set of largest objects covering exactly a given cpuset set.

Returns

the number of objects returned in objs.

Note

This function cannot work if the root object does not have a CPU set, e.g. if the topology is made of different machines.

```
19.15.2.3 static unsigned hwloc_get_nbobjs_inside_cpuset_by_depth ( hwloc_topology_t topology, hwloc_const_cpuset_t set, unsigned depth ) [inline], [static]
```

Return the number of objects at depth depth included in CPU set set.

Note

This function cannot work if objects at the given depth do not have CPU sets or if the topology is made of different machines.

```
19.15.2.4 static int hwloc_get_nbobjs_inside_cpuset_by_type ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_type_t type ) [inline], [static]
```

Return the number of objects of type type included in CPU set set.

If no object for that type exists inside CPU set set, 0 is returned. If there are several levels with objects of that type inside CPU set set, -1 is returned.

Note

This function cannot work if objects of the given type do not have CPU sets or if the topology is made of different machines.

```
19.15.2.5 static hwloc_obj_t hwloc_get_next_obj_inside_cpuset_by_depth ( hwloc_topology_t topology, hwloc_const_cpuset_t set, unsigned depth, hwloc_obj_t prev ) [inline], [static]
```

Return the next object at depth depth included in CPU set set.

If prev is NULL, return the first object at depth depth included in set. The next invokation should pass the previous return value in prev so as to obtain the next object in set.

Note

This function cannot work if objects at the given depth do not have CPU sets or if the topology is made of different machines.

```
19.15.2.6 static hwloc_obj_t hwloc_get_next_obj_inside_cpuset_by_type ( hwloc_topology_t topology, hwloc const cpuset t set, hwloc obj type t type, hwloc obj t prev ) [inline], [static]
```

Return the next object of type type included in CPU set set.

If there are multiple or no depth for given type, return \mathtt{NULL} and let the caller fallback to $\mathsf{hwloc_get_next_obj_inside_} \leftarrow \mathsf{cpuset_by_depth}().$

Note

This function cannot work if objects of the given type do not have CPU sets or if the topology is made of different machines.

```
19.15.2.7 static int hwloc_get_obj_index_inside_cpuset ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_t obj ) [inline], [static]
```

Return the logical index among the objects included in CPU set set.

Consult all objects in the same level as obj and inside CPU set set in the logical order, and return the index of obj within them. If set covers the entire topology, this is the logical index of obj. Otherwise, this is similar to a logical index within the part of the topology defined by CPU set set.

```
19.15.2.8 static hwloc_obj_t hwloc_get_obj_inside_cpuset_by_depth ( hwloc_topology_t topology, hwloc_const_cpuset_t set, unsigned depth, unsigned idx ) [inline], [static]
```

Return the (logically) idx -th object at depth depth included in CPU set set.

Note

This function cannot work if objects at the given depth do not have CPU sets or if the topology is made of different machines.

```
19.15.2.9 static hwloc_obj_t hwloc_get_obj_inside_cpuset_by_type ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_type_t type, unsigned idx ) [inline], [static]
```

Return the idx -th object of type type included in CPU set set.

If there are multiple or no depth for given type, return NULL and let the caller fallback to hwloc_get_obj_inside_cpuset ← by depth().

Note

This function cannot work if objects of the given type do not have CPU sets or if the topology is made of different machines.

19.16 Finding Objects covering at least CPU set

Functions

- static hwloc_obj_t hwloc_get_child_covering_cpuset (hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc obj_t parent)
- static hwloc_obj_t hwloc_get_obj_covering_cpuset (hwloc_topology_t topology, hwloc_const_cpuset_t set)
- static hwloc_obj_t hwloc_get_next_obj_covering_cpuset_by_depth (hwloc_topology_t topology, hwloc_const_
 cpuset_t set, unsigned depth, hwloc_obj_t prev)
- static hwloc_obj_t hwloc_get_next_obj_covering_cpuset_by_type (hwloc_topology_t topology, hwloc_const_copuset_t set, hwloc_obj_type_t type, hwloc_obj_t prev)

19.16.1 Detailed Description

19.16.2 Function Documentation

19.16.2.1 static hwloc_obj_t hwloc_get_child_covering_cpuset(hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_t parent) [inline], [static]

Get the child covering at least CPU set set.

Returns

NULL if no child matches or if set is empty.

Note

This function cannot work if parent does not have a CPU set.

```
19.16.2.2 static hwloc_obj_t hwloc_get_next_obj_covering_cpuset_by_depth ( hwloc_topology_t topology, hwloc_const_cpuset_t set, unsigned depth, hwloc_obj_t prev ) [inline], [static]
```

Iterate through same-depth objects covering at least CPU set set.

If object prev is \mathtt{NULL} , return the first object at depth depth covering at least part of CPU set \mathtt{set} . The next invokation should pass the previous return value in \mathtt{prev} so as to obtain the next object covering at least another part of \mathtt{set} .

Note

This function cannot work if objects at the given depth do not have CPU sets or if the topology is made of different machines.

```
19.16.2.3 static hwloc_obj_t hwloc_get_next_obj_covering_cpuset_by_type ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_type_t type, hwloc_obj_t prev ) [inline], [static]
```

Iterate through same-type objects covering at least CPU set $\mathtt{set}.$

If object prev is NULL, return the first object of type type covering at least part of CPU set set. The next invokation should pass the previous return value in prev so as to obtain the next object of type type covering at least another part of set.

If there are no or multiple depths for type type, NULL is returned. The caller may fallback to $hwloc_get_next_obj_{\leftarrow}$ covering_cpuset_by_depth() for each depth.

Note

This function cannot work if objects of the given type do not have CPU sets or if the topology is made of different machines.

19.16.2.4 static hwloc_obj_t hwloc_get_obj_covering_cpuset (hwloc_topology_t topology, hwloc_const_cpuset_t set) [inline], [static]

Get the lowest object covering at least CPU set set.

Returns

NULL if no object matches or if set is empty.

Note

This function cannot work if the root object does not have a CPU set, e.g. if the topology is made of different machines.

19.17 Looking at Ancestor and Child Objects

Functions

- static hwloc_obj_t hwloc_get_ancestor_obj_by_depth (hwloc_topology_t topology, unsigned depth, hwloc_obj_t obi)
- static hwloc_obj_t hwloc_get_ancestor_obj_by_type (hwloc_topology_t topology, hwloc_obj_type_t type, hwloc
 obj_t obj)
- static hwloc_obj_t hwloc_get_common_ancestor_obj (hwloc_topology_t topology, hwloc_obj_t obj1, hwloc_obj
 t obj2)
- static int hwloc obj is in subtree (hwloc topology t topology, hwloc obj t obj, hwloc obj t subtree root)
- static hwloc_obj_t hwloc_get_next_child (hwloc_topology_t topology, hwloc_obj_t parent, hwloc_obj_t prev)

19.17.1 Detailed Description

Be sure to see the figure in Terms and Definitions that shows a complete topology tree, including depths, child/sibling/cousin relationships, and an example of an asymmetric topology where one package has fewer caches than its peers.

19.17.2 Function Documentation

```
19.17.2.1 static hwloc_obj_t hwloc_get_ancestor_obj_by_depth ( hwloc_topology_t topology, unsigned depth, hwloc_obj_t obj ) [inline], [static]
```

Returns the ancestor object of obj at depth depth.

```
19.17.2.2 static hwloc_obj_t hwloc_get_ancestor_obj_by_type ( hwloc_topology_t topology, hwloc_obj_type_t type, hwloc_obj_t obj ) [inline], [static]
```

Returns the ancestor object of obj with type type.

```
19.17.2.3 static hwloc_obj_t hwloc_get_common_ancestor_obj( hwloc_topology_t topology, hwloc_obj_t obj1, hwloc_obj_t obj2) [inline], [static]
```

Returns the common parent object to objects IvI1 and IvI2.

```
19.17.2.4 static hwloc_obj_t hwloc_get_next_child ( hwloc_topology_t topology, hwloc_obj_t parent, hwloc_obj_t prev
) [inline],[static]
```

Return the next child.

If prev is NULL, return the first child.

```
19.17.2.5 static int hwloc_obj_is_in_subtree ( hwloc_topology_t topology, hwloc_obj_t obj, hwloc_obj_t subtree_root )
[inline], [static]
```

Returns true if obj is inside the subtree beginning with ancestor object subtree_root.

NI	^	٠	0

This function assumes that both ${\tt obj}$ and ${\tt subtree_root}$ have a ${\tt cpuset}.$

19.18 Looking at Cache Objects

Functions

- static int hwloc_get_cache_type_depth (hwloc_topology_t topology, unsigned cachelevel, hwloc_obj_cache_
 type t cachetype)
- static hwloc obj t hwloc get cache covering cpuset (hwloc topology t topology, hwloc const cpuset t set)
- static hwloc_obj_t hwloc_get_shared_cache_covering_obj (hwloc_topology_t topology, hwloc_obj_t obj)

19.18.1 Detailed Description

19.18.2 Function Documentation

19.18.2.1 static hwloc_obj_t hwloc_get_cache_covering_cpuset (hwloc_topology_t topology, hwloc_const_cpuset_t set) [inline], [static]

Get the first cache covering a cpuset set.

Returns

NULL if no cache matches.

Note

This function cannot work if the root object does not have a CPU set, e.g. if the topology is made of different machines.

```
19.18.2.2 static int hwloc_get_cache_type_depth ( hwloc_topology_t topology, unsigned cachelevel, hwloc_obj_cache_type_t cachetype ) [inline], [static]
```

Find the depth of cache objects matching cache depth and type.

Return the depth of the topology level that contains cache objects whose attributes match cachedepth and cachetype. This function intends to disambiguate the case where $hwloc_get_type_depth()$ returns $HWLOC_TY \leftarrow PE_DEPTH_MULTIPLE$.

If no cache level matches, HWLOC_TYPE_DEPTH_UNKNOWN is returned.

If cachetype is HWLOC_OBJ_CACHE_UNIFIED, the depth of the unique matching unified cache level is returned.

If cachetype is HWLOC_OBJ_CACHE_DATA or HWLOC_OBJ_CACHE_INSTRUCTION, either a matching cache, or a unified cache is returned.

If cachetype is -1, it is ignored and multiple levels may match. The function returns either the depth of a uniquely matching level or HWLOC_TYPE_DEPTH_MULTIPLE.

```
19.18.2.3 static hwloc_obj_t hwloc_get_shared_cache_covering_obj( hwloc_topology_t topology, hwloc_obj_t obj )
[inline], [static]
```

Get the first cache shared between an object and somebody else.

Returns

NULL if no cache matches or if an invalid object is given.

19.19 Finding objects, miscellaneous helpers

Functions

- static hwloc obj t hwloc get pu obj by os index (hwloc topology t topology, unsigned os index)
- static hwloc_obj_t hwloc_get_numanode_obj_by_os_index (hwloc_topology_t topology, unsigned os_index)
- unsigned hwloc_get_closest_objs (hwloc_topology_t topology, hwloc_obj_t src, hwloc_obj_t *restrict objs, unsigned max)
- static hwloc_obj_t hwloc_get_obj_below_by_type (hwloc_topology_t topology, hwloc_obj_type_t type1, unsigned idx1, hwloc obj_type t type2, unsigned idx2)
- static hwloc_obj_t hwloc_get_obj_below_array_by_type (hwloc_topology_t topology, int nr, hwloc_obj_type_
 t *typev, unsigned *idxv)

19.19.1 Detailed Description

Be sure to see the figure in Terms and Definitions that shows a complete topology tree, including depths, child/sibling/cousin relationships, and an example of an asymmetric topology where one package has fewer caches than its peers.

19.19.2 Function Documentation

19.19.2.1 unsigned hwloc_get_closest_objs (hwloc_topology_t topology, hwloc_obj_t src, hwloc_obj_t *restrict objs, unsigned max)

Do a depth-first traversal of the topology to find and sort.

all objects that are at the same depth than src. Report in objs up to max physically closest ones to src.

Returns

```
the number of objects returned in objs. 0 if src is an I/O object.
```

Note

This function requires the src object to have a CPU set.

```
19.19.2.2 static hwloc_obj_t hwloc_get_numanode_obj_by_os_index ( hwloc_topology_t topology, unsigned os_index ) [inline], [static]
```

Returns the object of type HWLOC OBJ NUMANODE with os index.

```
19.19.2.3 static hwloc_obj_t hwloc_get_obj_below_array_by_type ( hwloc_topology_t topology, int nr, hwloc_obj_type_t * typev, unsigned * idxv ) [inline], [static]
```

Find an object below a chain of objects specified by types and indexes.

This is a generalized version of hwloc_get_obj_below_by_type().

Arrays typev and idxv must contain nr types and indexes.

Start from the top system object and walk the arrays typev and idxv. For each type and logical index couple in the arrays, look under the previously found object to find the index-th object of the given type. Indexes are specified within the parent, not withing the entire system.

For instance, if nr is 3, typev contains NODE, PACKAGE and CORE, and idxv contains 0, 1 and 2, return the third core object below the second package below the first NUMA node.

Note

This function requires all these objects and the root object to have a CPU set.

```
19.19.2.4 static hwloc_obj_t hwloc_get_obj_below_by_type( hwloc_topology_t topology, hwloc_obj_type_t type1, unsigned idx1, hwloc_obj_type_t type2, unsigned idx2) [inline], [static]
```

Find an object below another object, both specified by types and indexes.

Start from the top system object and find object of type type1 and logical index idx1. Then look below this object and find another object of type type2 and logical index idx2. Indexes are specified within the parent, not withing the entire system.

For instance, if type1 is PACKAGE, idx1 is 2, type2 is CORE and idx2 is 3, return the fourth core object below the third package.

Note

This function requires these objects to have a CPU set.

```
19.19.2.5 static hwloc_obj_t hwloc_get_pu_obj_by_os_index ( hwloc_topology_t topology, unsigned os_index ) [inline], [static]
```

Returns the object of type HWLOC_OBJ_PU with os_index.

This function is useful for converting a CPU set into the PU objects it contains. When retrieving the current binding (e.g. with hwloc_get_cpubind()), one may iterate over the bits of the resulting CPU set with hwloc_bitmap_foreach_begin(), and find the corresponding PUs with this function.

19.20 Distributing items over a topology

Enumerations

enum hwloc_distrib_flags_e { HWLOC_DISTRIB_FLAG_REVERSE }

Functions

static int hwloc_distrib (hwloc_topology_t topology, hwloc_obj_t *roots, unsigned n_roots, hwloc_cpuset_t *set, unsigned n, unsigned until, unsigned long flags)

19.20.1 Detailed Description

19.20.2 Enumeration Type Documentation

19.20.2.1 enum hwloc distrib flags e

Flags to be given to hwloc_distrib().

Enumerator

HWLOC_DISTRIB_FLAG_REVERSE Distrib in reverse order, starting from the last objects.

19.20.3 Function Documentation

19.20.3.1 static int hwloc_distrib (hwloc_topology_t topology, hwloc_obj_t * roots, unsigned n_roots, hwloc_cpuset_t * set, unsigned n, unsigned until, unsigned long flags) [inline], [static]

Distribute n items over the topology under roots.

Array set will be filled with n cpusets recursively distributed linearly over the topology under objects roots, down to depth until (which can be INT MAX to distribute down to the finest level).

n_roots is usually 1 and roots only contains the topology root object so as to distribute over the entire topology.

This is typically useful when an application wants to distribute n threads over a machine, giving each of them as much private cache as possible and keeping them locally in number order.

The caller may typically want to also call hwloc_bitmap_singlify() before binding a thread so that it does not move at all. flags should be 0 or a OR'ed set of hwloc distrib flags e.

Note

This function requires the roots objects to have a CPU set.

This function replaces the now deprecated hwloc_distribute() and hwloc_distributev() functions.

19.21 CPU and node sets of entire topologies

Functions

- static hwloc_const_cpuset_t hwloc_topology_get_complete_cpuset (hwloc_topology_t topology)
- static hwloc_const_cpuset_t hwloc_topology_get_topology_cpuset (hwloc_topology_t topology)
- static hwloc const cpuset thwloc topology get online cpuset (hwloc topology t topology)
- static hwloc_const_cpuset_t hwloc_topology_get_allowed_cpuset (hwloc_topology_t topology)
- static hwloc_const_nodeset_t hwloc_topology_get_complete_nodeset (hwloc_topology_t topology)
- static hwloc_const_nodeset_t hwloc_topology_get_topology_nodeset (hwloc_topology_t topology)
- static hwloc const nodeset thwloc topology get allowed nodeset (hwloc topology t topology)

19.21.1 Detailed Description

19.21.2 Function Documentation

```
19.21.2.1 static hwloc_const_cpuset_t hwloc_topology_get_allowed_cpuset ( hwloc_topology_t topology )
[inline], [static]
```

Get allowed CPU set.

Returns

the CPU set of allowed logical processors of the system. If the topology is the result of a combination of several systems, NULL is returned.

Note

The returned cpuset is not newly allocated and should thus not be changed or freed, hwloc_bitmap_dup() must be used to obtain a local copy.

```
19.21.2.2 static hwloc_const_nodeset_t hwloc_topology_get_allowed_nodeset( hwloc_topology_t topology )
[inline], [static]
```

Get allowed node set.

Returns

the node set of allowed memory of the system. If the topology is the result of a combination of several systems, NULL is returned.

Note

The returned nodeset is not newly allocated and should thus not be changed or freed, hwloc_bitmap_dup() must be used to obtain a local copy.

19.21.2.3 static hwloc_const_cpuset_t hwloc_topology_get_complete_cpuset (hwloc_topology_t topology)
[inline], [static]

Get complete CPU set.

Returns

the complete CPU set of logical processors of the system. If the topology is the result of a combination of several systems, NULL is returned.

Note

The returned cpuset is not newly allocated and should thus not be changed or freed; hwloc_bitmap_dup() must be used to obtain a local copy.

19.21.2.4 static hwloc_const_nodeset_t hwloc_topology_get_complete_nodeset (hwloc_topology_t topology) [inline], [static]

Get complete node set.

Returns

the complete node set of memory of the system. If the topology is the result of a combination of several systems, NULL is returned.

Note

The returned nodeset is not newly allocated and should thus not be changed or freed; hwloc_bitmap_dup() must be used to obtain a local copy.

19.21.2.5 static hwloc_const_cpuset_t hwloc_topology_get_online_cpuset(hwloc_topology_t topology) [inline], [static]

Get online CPU set.

Returns

the CPU set of online logical processors of the system. If the topology is the result of a combination of several systems, NULL is returned.

Note

The returned cpuset is not newly allocated and should thus not be changed or freed; hwloc_bitmap_dup() must be used to obtain a local copy.

19.21.2.6 static hwloc_const_cpuset_t hwloc_topology_get_topology_cpuset (hwloc_topology_t topology)
[inline], [static]

Get topology CPU set.

Returns

the CPU set of logical processors of the system for which hwloc provides topology information. This is equivalent to the cpuset of the system object. If the topology is the result of a combination of several systems, NULL is returned.

Note

The returned cpuset is not newly allocated and should thus not be changed or freed; hwloc_bitmap_dup() must be used to obtain a local copy.

```
19.21.2.7 static hwloc_const_nodeset_t hwloc_topology_get_topology_nodeset ( hwloc_topology_t topology ) [inline], [static]
```

Get topology node set.

Returns

the node set of memory of the system for which hwloc provides topology information. This is equivalent to the nodeset of the system object. If the topology is the result of a combination of several systems, NULL is returned.

Note

The returned nodeset is not newly allocated and should thus not be changed or freed; hwloc_bitmap_dup() must be used to obtain a local copy.

19.22 Converting between CPU sets and node sets

Functions

- static void hwloc_cpuset_to_nodeset (hwloc_topology_t topology, hwloc_const_cpuset_t _cpuset, hwloc_
 nodeset_t nodeset)
- static void hwloc_cpuset_to_nodeset_strict (struct hwloc_topology *topology, hwloc_const_cpuset_t _cpuset, hwloc nodeset t nodeset)
- static void hwloc_cpuset_from_nodeset_strict (struct hwloc_topology *topology, hwloc_cpuset_t _cpuset, hwloc_const_nodeset_t nodeset)

19.22.1 Detailed Description

There are two semantics for converting cpusets to nodesets depending on how non-NUMA machines are handled.

When manipulating nodesets for memory binding, non-NUMA machines should be considered as having a single NUMA node. The standard conversion routines below should be used so that marking the first bit of the nodeset means that memory should be bound to a non-NUMA whole machine.

When manipulating nodesets as an actual list of NUMA nodes without any need to handle memory binding on non-N← UMA machines, the strict conversion routines may be used instead.

19.22.2 Function Documentation

```
19.22.2.1 static void hwloc_cpuset_from_nodeset ( hwloc_topology_t topology, hwloc_cpuset_t _cpuset, hwloc_const nodeset t nodeset ) [inline], [static]
```

Convert a NUMA node set into a CPU set and handle non-NUMA cases.

If the topology contains no NUMA nodes, the machine is considered as a single memory node, and the following behavior is used: If nodeset is empty, cpuset will be emptied as well. Otherwise cpuset will be entirely filled. This is useful for manipulating memory binding sets.

```
19.22.2.2 static void hwloc_cpuset_from_nodeset_strict ( struct hwloc_topology * topology, hwloc_cpuset_t _cpuset, hwloc_const_nodeset_t nodeset ) [inline], [static]
```

Convert a NUMA node set into a CPU set without handling non-NUMA cases.

This is the strict variant of <a href="https://hww.nc.gov.

```
19.22.2.3 static void hwloc_cpuset_to_nodeset ( hwloc_topology_t topology, hwloc_const_cpuset_t _cpuset, hwloc nodeset t nodeset ) [inline], [static]
```

Convert a CPU set into a NUMA node set and handle non-NUMA cases.

If some NUMA nodes have no CPUs at all, this function never sets their indexes in the output node set, even if a full CPU set is given in input.

If the topology contains no NUMA nodes, the machine is considered as a single memory node, and the following behavior is used: If cpuset is empty, nodeset will be emptied as well. Otherwise nodeset will be entirely filled.

19.22.2.4 static void hwloc_cpuset_to_nodeset_strict(struct hwloc_topology * topology, hwloc_const_cpuset_t_cpuset, hwloc_nodeset t nodeset) [inline], [static]

Convert a CPU set into a NUMA node set without handling non-NUMA cases.

This is the strict variant of hwloc_cpuset_to_nodeset. It does not fix non-NUMA cases. If the topology contains some NUMA nodes, behave exactly the same. However, if the topology contains no NUMA nodes, return an empty nodeset.

Generated on Sun Jun 14 2015 21:56:30 for Hardware Locality (hwloc) by Doxygen

19.23 Manipulating Distances

Functions

- static const struct hwloc_distances_s * hwloc_get_whole_distance_matrix_by_depth (hwloc_topology_t topology, unsigned depth)
- static const struct hwloc_distances_s * hwloc_get_whole_distance_matrix_by_type (hwloc_topology_t topology, hwloc_obj_type_t type)
- static const struct hwloc_distances_s * hwloc_get_distance_matrix_covering_obj_by_depth (hwloc_topology_t topology, hwloc_obj_t obj, unsigned depth, unsigned *firstp)
- static int hwloc_get_latency (hwloc_topology_t topology, hwloc_obj_t obj1, hwloc_obj_t obj2, float *latency, float *reverse_latency)

19.23.1 Detailed Description

19.23.2 Function Documentation

19.23.2.1 static const struct hwloc_distances_s* hwloc_get_distance_matrix_covering_obj_by_depth (hwloc_topology_t topology, hwloc_obj_t obj, unsigned depth, unsigned * firstp) [static]

Get distances for the given depth and covering some objects.

Return a distance matrix that describes depth depth and covers at least object obj and all its children.

When looking for the distance between some objects, a common ancestor should be passed in obj.

firstp is set to logical index of the first object described by the matrix.

The returned structure belongs to the hwloc library. The caller should not modify or free it.

```
19.23.2.2 static int hwloc_get_latency ( hwloc_topology_t topology, hwloc_obj_t obj1, hwloc_obj_t obj2, float * latency, float * reverse_latency ) [inline], [static]
```

Get the latency in both directions between two objects.

Look at ancestor objects from the bottom to the top until one of them contains a distance matrix that matches the objects exactly.

latency gets the value from object obj1 to obj2, while reverse_latency gets the reverse-direction value, which may be different on some architectures.

Returns

-1 if no ancestor contains a matching latency matrix.

```
19.23.2.3 static const struct hwloc_distances_s* hwloc_get_whole_distance_matrix_by_depth ( hwloc_topology_t topology, unsigned depth ) [static]
```

Get the distances between all objects at the given depth.

Returns

a distances structure containing a matrix with all distances between all objects at the given depth.

Slot i+nbobjs*j contains the distance from the object of logical index i the object of logical index j.

Note

This function only returns matrices covering the whole topology, without any unknown distance value. Those matrices are available in top-level object of the hierarchy. Matrices of lower objects are not reported here since they cover only part of the machine.

The returned structure belongs to the hwloc library. The caller should not modify or free it.

Returns

NULL if no such distance matrix exists.

19.23.2.4 static const struct hwloc_distances_s* hwloc_get_whole_distance_matrix_by_type (hwloc_topology_t topology, hwloc_obj_type_t type) [static]

Get the distances between all objects of a given type.

Returns

a distances structure containing a matrix with all distances between all objects of the given type.

Slot i+nbobjs*j contains the distance from the object of logical index i the object of logical index j.

Note

This function only returns matrices covering the whole topology, without any unknown distance value. Those matrices are available in top-level object of the hierarchy. Matrices of lower objects are not reported here since they cover only part of the machine.

The returned structure belongs to the hwloc library. The caller should not modify or free it.

Returns

NULL if no such distance matrix exists.

19.24 Finding I/O objects

Functions

- static hwloc_obj_t hwloc_get_non_io_ancestor_obj (hwloc_topology_t topology, hwloc_obj_t ioobj)
- static hwloc obj t hwloc get next pcidev (hwloc topology t topology, hwloc obj t prev)
- static hwloc_obj_t hwloc_get_pcidev_by_busid (hwloc_topology_t topology, unsigned domain, unsigned bus, unsigned dev, unsigned func)
- static hwloc_obj_t hwloc_get_pcidev_by_busidstring (hwloc_topology_t topology, const char *busid)
- static hwloc_obj_t hwloc_get_next_osdev (hwloc_topology_t topology, hwloc_obj_t prev)
- static hwloc_obj_t hwloc_get_next_bridge (hwloc_topology_t topology, hwloc_obj_t prev)
- static int hwloc_bridge_covers_pcibus (hwloc_obj_t bridge, unsigned domain, unsigned bus)
- static hwloc_obj_t hwloc_get_hostbridge_by_pcibus (hwloc_topology_t topology, unsigned domain, unsigned bus)

19.24.1 Detailed Description

19.24.2 Function Documentation

```
19.24.2.1 static int hwloc_bridge_covers_pcibus ( hwloc_obj_t bridge, unsigned domain, unsigned bus ) [inline], [static]
```

19.24.2.2 static hwloc_obj_t hwloc_get_hostbridge_by_pcibus (hwloc_topology_t topology, unsigned domain, unsigned bus) [inline], [static]

Find the hostbridge that covers the given PCI bus.

This is useful for finding the locality of a bus because it is the hostbridge parent cpuset.

```
19.24.2.3 static hwloc_obj_t hwloc_get_next_bridge ( hwloc_topology_t topology, hwloc_obj_t prev ) [inline], [static]
```

Get the next bridge in the system.

Returns

the first bridge if prev is NULL.

```
19.24.2.4 static hwloc_obj_t hwloc_get_next_osdev ( hwloc_topology_t topology, hwloc_obj_t prev ) [inline], [static]
```

Get the next OS device in the system.

Returns

the first OS device if ${\tt prev}$ is ${\tt NULL}.$

```
19.24.2.5 static hwloc_obj_t hwloc_get_next_pcidev ( hwloc_topology_t topology, hwloc_obj_t prev ) [inline], [static]
```

Get the next PCI device in the system.

Returns

the first PCI device if prev is NULL.

```
19.24.2.6 static hwloc_obj_t hwloc_get_non_io_ancestor_obj ( hwloc_topology_t topology, hwloc_obj_t ioobj )
[inline], [static]
```

Get the first non-I/O ancestor object.

Given the I/O object ioobj, find the smallest non-I/O ancestor object. This regular object may then be used for binding because its locality is the same as ioobj.

```
19.24.2.7 static hwloc_obj_t hwloc_get_pcidev_by_busid ( hwloc_topology_t topology, unsigned domain, unsigned bus, unsigned dev, unsigned func ) [inline], [static]
```

Find the PCI device object matching the PCI bus id given domain, bus device and function PCI bus id.

```
19.24.2.8 static hwloc_obj_t hwloc_get_pcidev_by_busidstring ( hwloc_topology_t topology, const char * busid )
[inline], [static]
```

Find the PCI device object matching the PCI bus id given as a string xxxx:yy:zz.t or yy:zz.t.

19.25 The bitmap API 129

19.25 The bitmap API

Macros

- #define hwloc bitmap foreach begin(id, bitmap)
- #define hwloc_bitmap_foreach_end()

Typedefs

- typedef struct hwloc bitmap s * hwloc bitmap t
- typedef const struct hwloc_bitmap_s * hwloc_const_bitmap_t

Functions

- hwloc bitmap t hwloc bitmap alloc (void)
- hwloc bitmap t hwloc bitmap_alloc_full (void)
- void hwloc bitmap free (hwloc bitmap t bitmap)
- hwloc_bitmap_t hwloc_bitmap_dup (hwloc_const_bitmap_t bitmap)
- · void hwloc bitmap copy (hwloc bitmap t dst, hwloc const bitmap t src)
- int hwloc bitmap snprintf (char *restrict buf, size t buflen, hwloc const bitmap t bitmap)
- int hwloc_bitmap_asprintf (char **strp, hwloc_const_bitmap_t bitmap)
- int hwloc bitmap sscanf (hwloc bitmap t bitmap, const char *restrict string)
- int hwloc_bitmap_list_snprintf (char *restrict buf, size_t buflen, hwloc_const_bitmap_t bitmap)
- int hwloc_bitmap_list_asprintf (char **strp, hwloc_const_bitmap_t bitmap)
- int hwloc_bitmap_list_sscanf (hwloc_bitmap_t bitmap, const char *restrict string)
- int hwloc bitmap taskset snprintf (char *restrict buf, size t buflen, hwloc const bitmap t bitmap)
- int hwloc bitmap taskset asprintf (char **strp, hwloc const bitmap t bitmap)
- int hwloc bitmap taskset sscanf (hwloc bitmap t bitmap, const char *restrict string)
- void hwloc bitmap zero (hwloc bitmap t bitmap)
- void hwloc bitmap fill (hwloc bitmap t bitmap)
- void hwloc bitmap only (hwloc bitmap t bitmap, unsigned id)
- · void hwloc bitmap allbut (hwloc bitmap t bitmap, unsigned id)
- · void hwloc bitmap from ulong (hwloc bitmap t bitmap, unsigned long mask)
- void hwloc_bitmap_from_ith_ulong (hwloc_bitmap_t bitmap, unsigned i, unsigned long mask)
- void hwloc bitmap set (hwloc bitmap t bitmap, unsigned id)
- void hwloc bitmap set range (hwloc bitmap t bitmap, unsigned begin, int end)
- · void hwloc bitmap set ith ulong (hwloc bitmap t bitmap, unsigned i, unsigned long mask)
- void hwloc_bitmap_clr (hwloc_bitmap_t bitmap, unsigned id)
- void hwloc bitmap clr range (hwloc bitmap t bitmap, unsigned begin, int end)
- void hwloc bitmap singlify (hwloc bitmap t bitmap)
- unsigned long hwloc_bitmap_to_ulong (hwloc_const_bitmap_t bitmap)
- unsigned long hwloc_bitmap_to_ith_ulong (hwloc_const_bitmap_t bitmap, unsigned i)
- int hwloc_bitmap_isset (hwloc_const_bitmap_t bitmap, unsigned id)
- int hwloc bitmap iszero (hwloc const bitmap t bitmap)
- int hwloc_bitmap_isfull (hwloc_const_bitmap_t bitmap)
- int hwloc_bitmap_first (hwloc_const_bitmap_t bitmap)
- int hwloc_bitmap_next (hwloc_const_bitmap_t bitmap, int prev)
- int hwloc_bitmap_last (hwloc_const_bitmap_t bitmap)
- int hwloc bitmap weight (hwloc const bitmap t bitmap)

- void hwloc_bitmap_or (hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap_t bitmap_t bitmap_t bitmap_t
- void hwloc_bitmap_and (hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t bitmap2)
- void hwloc_bitmap_andnot (hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap_t bitmap_t bitmap_t bitmap_t
- void hwloc_bitmap_xor (hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap2)
- void hwloc bitmap not (hwloc bitmap t res, hwloc const bitmap t bitmap)
- int hwloc bitmap intersects (hwloc const bitmap t bitmap1, hwloc const bitmap t bitmap2)
- int hwloc bitmap isincluded (hwloc const bitmap t sub bitmap, hwloc const bitmap t super bitmap)
- int hwloc_bitmap_isequal (hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t bitmap2)
- int hwloc bitmap compare first (hwloc const bitmap t bitmap1, hwloc const bitmap t bitmap2)
- int hwloc_bitmap_compare (hwloc_const_bitmap_t bitmap_t bitmap_t bitmap_t bitmap_t

19.25.1 Detailed Description

The hwloc_bitmap_t type represents a set of objects, typically OS processors – which may actually be hardware threads (represented by hwloc_cpuset_t, which is a typedef for hwloc_bitmap_t) – or memory nodes (represented by hwloc_cmodeset_t, which is also a typedef for hwloc_bitmap_t).

Both CPU and node sets are always indexed by OS physical number.

Note

CPU sets and nodesets are described in Object Sets (hwloc_cpuset_t and hwloc_nodeset_t).

A bitmap may be of infinite size.

Note

Several examples of using the bitmap API are available under the doc/examples/ directory in the source tree. Regression tests such as tests/hwloc bitmap*.c also make intensive use of this API.

19.25.2 Macro Definition Documentation

19.25.2.1 #define hwloc_bitmap_foreach_begin(id, bitmap)

Loop macro iterating on bitmap bitmap.

index is the loop variable; it should be an unsigned int. The first iteration will set index to the lowest index in the bitmap. Successive iterations will iterate through, in order, all remaining indexes that in the bitmap. To be specific: each iteration will return a value for index such that hwloc_bitmap_isset(bitmap, index) is true.

The assert prevents the loop from being infinite if the bitmap is infinite.

```
19.25.2.2 #define hwloc_bitmap_foreach_end( )
```

Value:

```
} \
} while (0)
```

19.25.3 Typedef Documentation

19.25.3.1 typedef struct hwloc_bitmap_s* hwloc_bitmap_t

Set of bits represented as an opaque pointer to an internal bitmap.

19.25 The bitmap API 131

```
19.25.3.2 typedef const struct hwloc_bitmap_s* hwloc_const_bitmap_t
a non-modifiable hwloc_bitmap_t
19.25.4 Function Documentation
19.25.4.1 void hwloc_bitmap_allbut ( hwloc_bitmap_t bitmap, unsigned id )
Fill the bitmap and clear the index id.
19.25.4.2 hwloc_bitmap_t hwloc_bitmap_alloc ( void )
Allocate a new empty bitmap.
Returns
     A valid bitmap or NULL.
The bitmap should be freed by a corresponding call to hwloc bitmap free().
19.25.4.3 hwloc_bitmap_t hwloc_bitmap_alloc_full ( void )
Allocate a new full bitmap.
19.25.4.4 void hwloc_bitmap_and ( hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t
         bitmap2)
And bitmaps bitmap1 and bitmap2 and store the result in bitmap res.
res can be the same as bitmap1 or bitmap2
19.25.4.5 void hwloc_bitmap_andnot ( hwloc_bitmap t res, hwloc_const_bitmap t bitmap1, hwloc_const_bitmap t
         bitmap2)
And bitmap bitmap1 and the negation of bitmap2 and store the result in bitmap res.
res can be the same as bitmap1 or bitmap2
19.25.4.6 int hwloc_bitmap_asprintf ( char ** strp, hwloc_const_bitmap_t bitmap_)
Stringify a bitmap into a newly allocated string.
19.25.4.7 void hwloc_bitmap_clr ( hwloc_bitmap_t bitmap, unsigned id )
Remove index id from bitmap bitmap.
```

19.25.4.8 void hwloc_bitmap_clr_range (hwloc_bitmap_t bitmap, unsigned begin, int end)

Remove indexes from begin to end in bitmap bitmap.

If end is -1, the range is infinite.

19.25.4.9 int hwloc_bitmap_compare (hwloc_const_bitmap t bitmap1, hwloc_const_bitmap t bitmap2)

Compare bitmaps bitmap1 and bitmap2 in lexicographic order.

Lexicographic comparison of bitmaps, starting for their highest indexes. Compare last indexes first, then second, etc. The empty bitmap is considered lower than anything.

Note

This is different from the non-existing hwloc_bitmap_compare_last() which would only compare the highest index of each bitmap.

19.25.4.10 int hwloc_bitmap_compare_first (hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t bitmap2)

Compare bitmaps bitmap1 and bitmap2 using their lowest index.

Smaller least significant bit is smaller. The empty bitmap is considered higher than anything.

19.25.4.11 void hwloc_bitmap_copy (hwloc_bitmap_t dst, hwloc_const_bitmap_t src)

Copy the contents of bitmap src into the already allocated bitmap dst.

19.25.4.12 hwloc_bitmap_t hwloc_bitmap_dup (hwloc_const_bitmap_t bitmap)

Duplicate bitmap bitmap by allocating a new bitmap and copying bitmap contents.

If bitmap is NULL, NULL is returned.

19.25.4.13 void hwloc_bitmap_fill (hwloc_bitmap_t bitmap)

Fill bitmap bitmap with all possible indexes (even if those objects don't exist or are otherwise unavailable)

19.25.4.14 int hwloc_bitmap_first (hwloc_const_bitmap_t bitmap_)

Compute the first index (least significant bit) in bitmap bitmap.

Returns

-1 if no index is set.

19.25.4.15 void hwloc_bitmap_free (hwloc_bitmap_t bitmap)

Free bitmap bitmap.

If bitmap is NULL, no operation is performed.

19.25 The bitmap API 133

```
19.25.4.16 void hwloc_bitmap_from_ith_ulong ( hwloc_bitmap_t bitmap, unsigned i, unsigned long mask )
Setup bitmap bitmap from unsigned long mask used as i -th subset.
19.25.4.17 void hwloc_bitmap_from_ulong ( hwloc_bitmap_t bitmap, unsigned long mask )
Setup bitmap bitmap from unsigned long mask.
19.25.4.18 int hwloc_bitmap_intersects ( hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap2 )
Test whether bitmaps bitmap1 and bitmap2 intersects.
19.25.4.19 int hwloc_bitmap_isequal ( hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap t bitmap2 )
Test whether bitmap bitmap1 is equal to bitmap bitmap2.
19.25.4.20 int hwloc_bitmap_isfull ( hwloc_const_bitmap_t bitmap )
Test whether bitmap bitmap is completely full.
19.25.4.21 int hwloc_bitmap_isincluded ( hwloc_const_bitmap_t sub_bitmap, hwloc_const_bitmap_t super_bitmap_)
Test whether bitmap sub_bitmap is part of bitmap super_bitmap.
19.25.4.22 int hwloc_bitmap_isset ( hwloc_const_bitmap_t bitmap, unsigned id )
Test whether index id is part of bitmap bitmap.
19.25.4.23 int hwloc_bitmap_iszero ( hwloc_const_bitmap_t bitmap )
Test whether bitmap bitmap is empty.
19.25.4.24 int hwloc_bitmap_last ( hwloc_const_bitmap_t bitmap )
Compute the last index (most significant bit) in bitmap bitmap.
Returns
     -1 if no index is bitmap, or if the index bitmap is infinite.
19.25.4.25 int hwloc_bitmap_list_asprintf ( char ** strp, hwloc_const_bitmap_t bitmap )
Stringify a bitmap into a newly allocated list string.
```

```
19.25.4.26 int hwloc_bitmap_list_snprintf ( char *restrict buf, size_t buflen, hwloc_const_bitmap_t bitmap )
```

Stringify a bitmap in the list format.

Lists are comma-separated indexes or ranges. Ranges are dash separated indexes. The last range may not have a ending indexes if the bitmap is infinite.

Up to buflen characters may be written in buffer buf.

If buflen is 0, buf may safely be NULL.

Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

```
19.25.4.27 int hwloc_bitmap_list_sscanf ( hwloc_bitmap_t bitmap, const char *restrict string )
```

Parse a list string and stores it in bitmap bitmap.

```
19.25.4.28 int hwloc_bitmap_next ( hwloc_const_bitmap_t bitmap, int prev )
```

Compute the next index in bitmap bitmap which is after index prev.

If prev is -1, the first index is returned.

Returns

-1 if no index with higher index is bitmap.

```
19.25.4.29 void hwloc_bitmap_not ( hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap_)
```

Negate bitmap bitmap and store the result in bitmap res.

res can be the same as bitmap

19.25.4.30 void hwloc_bitmap_only (hwloc_bitmap_t bitmap, unsigned id)

Empty the bitmap bitmap and add bit id.

19.25.4.31 void hwloc_bitmap_or (hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t bitmap2)

Or bitmaps bitmap1 and bitmap2 and store the result in bitmap res.

res can be the same as bitmap1 or bitmap2

19.25.4.32 void hwloc_bitmap_set (hwloc_bitmap_t bitmap, unsigned id)

Add index id in bitmap bitmap.

19.25 The bitmap API 135

19.25.4.33 void hwloc_bitmap_set_ith_ulong (hwloc_bitmap_t bitmap, unsigned i, unsigned long mask)

Replace i -th subset of bitmap bitmap with unsigned long mask.

19.25.4.34 void hwloc_bitmap_set_range (hwloc_bitmap_t bitmap, unsigned begin, int end)

Add indexes from begin to end in bitmap bitmap.

If end is -1, the range is infinite.

19.25.4.35 void hwloc_bitmap_singlify (hwloc_bitmap_t bitmap)

Keep a single index among those set in bitmap bitmap.

May be useful before binding so that the process does not have a chance of migrating between multiple logical CPUs in the original mask.

19.25.4.36 int hwloc_bitmap_snprintf (char *restrict buf, size_t buflen, hwloc_const_bitmap_t bitmap)

Stringify a bitmap.

Up to buflen characters may be written in buffer buf.

If buflen is 0, buf may safely be NULL.

Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

19.25.4.37 int hwloc_bitmap_sscanf (hwloc_bitmap_t bitmap, const char *restrict string)

Parse a bitmap string and stores it in bitmap bitmap.

19.25.4.38 int hwloc_bitmap_taskset_asprintf (char ** strp, hwloc_const_bitmap_t bitmap)

Stringify a bitmap into a newly allocated taskset-specific string.

19.25.4.39 int hwloc_bitmap_taskset_snprintf (char *restrict buf, size_t buflen, hwloc_const_bitmap_t bitmap)

Stringify a bitmap in the taskset-specific format.

The taskset command manipulates bitmap strings that contain a single (possible very long) hexadecimal number starting with 0x.

Up to buflen characters may be written in buffer buf.

If buflen is 0, buf may safely be NULL.

Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

```
19.25.4.40 int hwloc_bitmap_taskset_sscanf ( hwloc_bitmap_t bitmap, const char *restrict string )
Parse a taskset-specific bitmap string and stores it in bitmap bitmap.
19.25.4.41 unsigned long hwloc_bitmap_to_ith_ulong ( hwloc_const_bitmap_t bitmap, unsigned i )
Convert the i -th subset of bitmap bitmap into unsigned long mask.
19.25.4.42 unsigned long hwloc_bitmap_to_ulong ( hwloc_const_bitmap_t bitmap )
Convert the beginning part of bitmap bitmap into unsigned long mask.
19.25.4.43 int hwloc_bitmap_weight ( hwloc_const_bitmap_t bitmap_)
Compute the "weight" of bitmap bitmap (i.e., number of indexes that are in the bitmap).
Returns
     the number of indexes that are in the bitmap.
19.25.4.44 void hwloc_bitmap_xor ( hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap_t, hwloc_const_bitmap_t
          bitmap2)
Xor bitmaps bitmap1 and bitmap2 and store the result in bitmap res.
res can be the same as bitmap1 or bitmap2
19.25.4.45 void hwloc_bitmap_zero ( hwloc_bitmap_t bitmap )
Empty the bitmap bitmap.
```

19.26 Topology differences

Data Structures

- union hwloc_topology_diff_obj_attr_u
- struct hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s
- struct hwloc topology diff obj attr u::hwloc topology diff obj attr string s
- struct hwloc topology diff obj attr u::hwloc topology diff obj attr generic s
- union hwloc topology diff u
- struct hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s
- · struct hwloc topology diff u::hwloc topology diff obj attr s
- struct hwloc_topology_diff_u::hwloc_topology_diff_generic_s

Typedefs

- typedef enum hwloc_topology_diff_obj_attr_type_e hwloc_topology_diff_obj_attr_type_t
- typedef enum hwloc_topology_diff_type_e hwloc_topology_diff_type_t
- typedef union hwloc topology diff u * hwloc topology diff t

Enumerations

- enum hwloc_topology_diff_obj_attr_type_e { HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_SIZE, HWLOC_TOPO
 LOGY_DIFF_OBJ_ATTR_NAME, HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_INFO }
- enum hwloc_topology_diff_type_e { HWLOC_TOPOLOGY_DIFF_OBJ_ATTR, HWLOC_TOPOLOGY_DIFF_T
 — OO_COMPLEX }
- enum hwloc_topology_diff_apply_flags_e { HWLOC_TOPOLOGY_DIFF_APPLY_REVERSE }

Functions

- int hwloc_topology_diff_build (hwloc_topology_t topology, hwloc_topology_t newtopology, unsigned long flags, hwloc_topology_diff_t *diff)
- int hwloc_topology_diff_apply (hwloc_topology_t topology, hwloc_topology_diff_t diff, unsigned long flags)
- int hwloc_topology_diff_destroy (hwloc_topology_t topology, hwloc_topology_diff_t diff)
- int hwloc_topology_diff_load_xml (hwloc_topology_t topology, const char *xmlpath, hwloc_topology_diff_t *diff, char **refname)
- int hwloc_topology_diff_export_xml (hwloc_topology_t topology, hwloc_topology_diff_t diff, const char *refname, const char *xmlpath)
- int hwloc_topology_diff_load_xmlbuffer (hwloc_topology_t topology, const char *xmlbuffer, int buflen, hwloc_
 topology_diff_t *diff, char **refname)
- int hwloc_topology_diff_export_xmlbuffer (hwloc_topology_t topology, hwloc_topology_diff_t diff, const char *refname, char **xmlbuffer, int *buflen)

19.26.1 Detailed Description

Applications that manipulate many similar topologies, for instance one for each node of a homogeneous cluster, may want to compress topologies to reduce the memory footprint.

This file offers a way to manipulate the difference between topologies and export/import it to/from XML. Compression may therefore be achieved by storing one topology entirely while the others are only described by their differences with

the former. The actual topology can be reconstructed when actually needed by applying the precomputed difference to the reference topology.

This interface targets very similar nodes. Only very simple differences between topologies are actually supported, for instance a change in the memory size, the name of the object, or some info attribute. More complex differences such as adding or removing objects cannot be represented in the difference structures and therefore return errors.

It means that there is no need to apply the difference when looking at the tree organization (how many levels, how many objects per level, what kind of objects, CPU and node sets, etc) and when binding to objects. However the difference must be applied when looking at object attributes such as the name, the memory size or info attributes.

19.26.2 Typedef Documentation

19.26.2.1 typedef enum hwloc_topology_diff_obj_attr_type_e hwloc_topology_diff_obj_attr_type_t

Type of one object attribute difference.

19.26.2.2 typedef union hwloc_topology_diff_u * hwloc_topology_diff_t

One element of a difference list between two topologies.

19.26.2.3 typedef enum hwloc_topology_diff_type_e hwloc_topology_diff_type_t

Type of one element of a difference list.

19.26.3 Enumeration Type Documentation

19.26.3.1 enum hwloc_topology_diff_apply_flags_e

Flags to be given to hwloc_topology_diff_apply().

Enumerator

HWLOC_TOPOLOGY_DIFF_APPLY_REVERSE Apply topology diff in reverse direction.

19.26.3.2 enum hwloc_topology_diff_obj_attr_type_e

Type of one object attribute difference.

Enumerator

HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_SIZE The object local memory is modified. The union is a hwloc_← topology_diff_obj_attr_uint64_s (and the index field is ignored).

HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_NAME The object name is modified. The union is a hwloc_topology ← diff_obj_attr_string_s (and the name field is ignored).

HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_INFO the value of an info attribute is modified. The union is a hwloc
_topology_diff_obj_attr_string_s.

19.26.3.3 enum hwloc_topology_diff_type_e

Type of one element of a difference list.

Enumerator

```
HWLOC_TOPOLOGY_DIFF_OBJ_ATTR
HWLOC_TOPOLOGY_DIFF_TOO_COMPLEX
```

19.26.4 Function Documentation

19.26.4.1 int hwloc_topology_diff_apply (hwloc_topology_t topology, hwloc_topology_diff_t diff, unsigned long flags)

Apply a topology diff to an existing topology.

flags is an OR'ed set of hwloc_topology_diff_apply_flags_e.

The new topology is modified in place. hwloc_topology_dup() may be used to duplicate it before patching.

If the difference cannot be applied entirely, all previous applied elements are unapplied before returning.

Returns

0 on success.

-N if applying the difference failed while trying to apply the N-th part of the difference. For instance -1 is returned if the very first difference element could not be applied.

19.26.4.2 int hwloc_topology_diff_build (hwloc_topology_t topology, hwloc_topology_t newtopology, unsigned long flags, hwloc_topology_diff_t * diff)

Compute the difference between 2 topologies.

The difference is stored as a list of hwloc_topology_diff_t entries starting at diff. It is computed by doing a depth-first traversal of both topology trees simultaneously.

If the difference between 2 objects is too complex to be represented (for instance if some objects have different types, or different numbers of children), a special diff entry of type HWLOC_TOPOLOGY_DIFF_TOO_COMPLEX is queued. The computation of the diff does not continue below these objects. So each such diff entry means that the difference between two subtrees could not be computed.

Returns

0 if the difference can be represented properly.

0 with diff pointing to NULL if there is no difference between the topologies.

1 if the difference is too complex (see above). Some entries in the list will be of type HWLOC_TOPOLOGY_DI ← FF TOO COMPLEX.

-1 on any other error.

Note

flags is currently not used. It should be 0.

The output diff has to be freed with hwloc_topology_diff_destroy().

The output diff can only be exported to XML or passed to hwloc_topology_diff_apply() if 0 was returned, i.e. if no entry of type HWLOC_TOPOLOGY_DIFF_TOO_COMPLEX is listed.

The output diff may be modified by removing some entries from the list. The removed entries should be freed by passing them to to hwloc_topology_diff_destroy() (possible as another list).

19.26.4.3 int hwloc_topology_diff_destroy (hwloc_topology_t topology, hwloc_topology_diff_t diff)

Destroy a list of topology differences.

Note

The topology parameter must be a valid topology but it is not required that it is related to diff.

19.26.4.4 int hwloc_topology_diff_export_xml (hwloc_topology_t topology, hwloc_topology_diff_t diff, const char * refname, const char * xmlpath)

Export a list of topology differences to a XML file.

If not NULL, refname defines an identifier string for the reference topology which was used as a base when computing this difference. This identifier is usually the name of the other XML file that contains the reference topology. This attribute is given back when reading the diff from XML.

Note

The topology parameter must be a valid topology but it is not required that it is related to diff.

19.26.4.5 int hwloc_topology_diff_export_xmlbuffer (hwloc_topology_t topology, hwloc_topology_diff_t diff, const char * refname, char ** xmlbuffer, int * buflen)

Export a list of topology differences to a XML buffer.

If not NULL, refname defines an identifier string for the reference topology which was used as a base when computing this difference. This identifier is usually the name of the other XML file that contains the reference topology. This attribute is given back when reading the diff from XML.

Note

The XML buffer should later be freed with hwloc_free_xmlbuffer().

The topology parameter must be a valid topology but it is not required that it is related to diff.

19.26.4.6 int hwloc_topology_diff_load_xml (hwloc_topology_t topology, const char * xmlpath, hwloc_topology_diff_t * diff, char ** refname)

Load a list of topology differences from a XML file.

If not NULL, refname will be filled with the identifier string of the reference topology for the difference file, if any was specified in the XML file. This identifier is usually the name of the other XML file that contains the reference topology.

Note

The topology parameter must be a valid topology but it is not required that it is related to diff. the pointer returned in refname should later be freed by the caller.

19.26.4.7 int hwloc_topology_diff_load_xmlbuffer (hwloc_topology_t topology, const char * xmlbuffer, int buflen, hwloc_topology_diff_t * diff, char ** refname)

Load a list of topology differences from a XML buffer.

If not NULL, refname will be filled with the identifier string of the reference topology for the difference file, if any was specified in the XML file. This identifier is usually the name of the other XML file that contains the reference topology.

Note

The topology parameter must be a valid topology but it is not required that it is related to diff. the pointer returned in refname should later be freed by the caller.

19.27 Components and Plugins: Discovery components

Data Structures

· struct hwloc_disc_component

Typedefs

typedef enum hwloc_disc_component_type_e hwloc_disc_component_type_t

Enumerations

19.27.1 Detailed Description

19.27.2 Typedef Documentation

19.27.2.1 typedef enum hwloc_disc_component_type_e hwloc_disc_component_type_t

Discovery component type.

19.27.3 Enumeration Type Documentation

19.27.3.1 enum hwloc_disc_component_type_e

Discovery component type.

Enumerator

HWLOC_DISC_COMPONENT_TYPE_CPU CPU-only discovery through the OS, or generic no-OS support.

HWLOC_DISC_COMPONENT_TYPE_GLOBAL xml, synthetic or custom, platform-specific components such as bgq. Anything the discovers CPU and everything else. No misc backend is expected to complement a global component.

HWLOC_DISC_COMPONENT_TYPE_MISC OpenCL, Cuda, etc.

19.28 Components and Plugins: Discovery backends

Data Structures

· struct hwloc backend

Enumerations

enum hwloc_backend_flag_e { HWLOC_BACKEND_FLAG_NEED_LEVELS }

Functions

- struct hwloc_backend * hwloc_backend_alloc (struct hwloc_disc_component *component)
- int hwloc_backend_enable (struct hwloc_topology *topology, struct hwloc_backend *backend)
- int hwloc_backends_get_obj_cpuset (struct hwloc_backend *caller, struct hwloc_obj *obj, hwloc_bitmap_
 t cpuset)
- int hwloc_backends_notify_new_object (struct hwloc_backend *caller, struct hwloc_obj *obj)
- 19.28.1 Detailed Description
- 19.28.2 Enumeration Type Documentation
- 19.28.2.1 enum hwloc_backend_flag_e

Backend flags.

Enumerator

HWLOC_BACKEND_FLAG_NEED_LEVELS Levels should be reconnected before this backend discover() is used.

19.28.3 Function Documentation

19.28.3.1 struct hwloc_backend* hwloc_backend_alloc (struct hwloc_disc_component * component)

Allocate a backend structure, set good default values, initialize backend->component and topology, etc. The caller will then modify whatever needed, and call <a href="https://hww.nuber.com/hww.nuber

19.28.3.2 int hwloc_backend_enable (struct hwloc_topology * topology, struct hwloc_backend * backend)

Enable a previously allocated and setup backend.

19.28.3.3 int hwloc_backends_get_obj_cpuset (struct hwloc_backend * caller, struct hwloc_obj * obj, hwloc_bitmap_t cpuset)

Used by backends discovery callbacks to request locality information from others.

Traverse the list of enabled backends until one has a get obj cpuset() method, and call it.

19.28.3.4 int hwloc_backends_notify_new_object (struct hwloc_backend * caller, struct hwloc_obj * obj)

Used by backends discovery callbacks to notify other backends of new objects.

Traverse the list of enabled backends (all but caller) and invoke their notify_new_object() method to notify them that a new object just got added to the topology.

Currently only used for notifying of new PCI device objects.

19.29 Components and Plugins: Generic components

Data Structures

struct hwloc_component

Typedefs

typedef enum hwloc_component_type_e hwloc_component_type_t

Enumerations

```
    enum hwloc_component_type_e { HWLOC_COMPONENT_TYPE_DISC, HWLOC_COMPONENT_TYPE_XML }
```

```
19.29.1 Detailed Description
```

19.29.2 Typedef Documentation

```
19.29.2.1 typedef enum hwloc_component_type_e hwloc_component_type_t
```

Generic component type.

19.29.3 Enumeration Type Documentation

```
19.29.3.1 enum hwloc_component_type_e
```

Generic component type.

Enumerator

```
HWLOC_COMPONENT_TYPE_DISCThe data field must point to a struct hwloc_disc_component.HWLOC_COMPONENT_TYPE_XMLThe data field must point to a struct hwloc_xml_component.
```

19.30 Components and Plugins: Core functions to be used by components

Typedefs

typedef void(* hwloc_report_error_t) (const char *msg, int line)

Functions

- struct hwloc obj * hwloc insert object by cpuset (struct hwloc topology *topology, hwloc obj t obj)
- void hwloc_report_os_error (const char *msg, int line)
- int hwloc_hide_errors (void)
- struct hwloc_obj * hwloc_insert_object_by_cpuset (struct hwloc_topology *topology, hwloc_obj_t obj, hwloc_
 report error t report error)
- void hwloc_insert_object_by_parent (struct hwloc_topology *topology, hwloc_obj_t parent, hwloc_obj_t obj)
- static struct hwloc_obj * hwloc_alloc_setup_object (hwloc_obj_type_t type, signed os_index)
- int hwloc fill object sets (hwloc obj t obj)
- static int hwloc_plugin_check_namespace (const char *pluginname, const char *symbol)

19.30.1 Detailed Description

19.30.2 Typedef Documentation

19.30.2.1 typedef void(* hwloc_report_error_t) (const char *msg, int line)

Type of error callbacks during object insertion.

19.30.3 Function Documentation

```
19.30.3.1 struct hwloc_obj* hwloc_insert_object_by_cpuset ( struct hwloc_topology * topology, hwloc_obj_t obj, hwloc_report_error_t report_error_)
```

Add an object to the topology and specify which error callback to use.

Aside from the error callback selection, this function is identical to hwloc_insert_object_by_cpuset()

```
19.30.3.2 static struct hwloc_obj* hwloc_alloc_setup_object ( hwloc_obj_type_t type, signed os_index ) [static]
```

Allocate and initialize an object of the given type and physical index.

```
19.30.3.3 int hwloc_fill_object_sets ( hwloc_obj_t obj )
```

Setup object cpusets/nodesets by OR'ing its children.

Used when adding an object late in the topology, after propagating sets up and down. The caller should use this after inserting by cpuset (which means the cpusets is already OK). Typical case: PCI backend adding a hostbridge parent.

```
19.30.3.4 int hwloc_hide_errors ( void )
```

Check whether insertion errors are hidden.

19.30.3.5 struct hwloc_obj* hwloc_insert_object_by_cpuset (struct hwloc_topology * topology, hwloc_obj_t obj)

Add an object to the topology.

It is sorted along the tree of other objects according to the inclusion of cpusets, to eventually be added as a child of the smallest object including this object.

If the cpuset is empty, the type of the object (and maybe some attributes) must be enough to find where to insert the object. This is especially true for NUMA nodes with memory and no CPUs.

The given object should not have children.

This shall only be called before levels are built.

In case of error, hwloc_report_os_error() is called.

Returns the object on success. Returns NULL and frees obj on error. Returns another object and frees obj if it was merged with an identical pre-existing object.

19.30.3.6 void hwloc_insert_object_by_parent (struct hwloc_topology * topology, hwloc_obj t parent, hwloc_obj t obj)

Insert an object somewhere in the topology.

It is added as the last child of the given parent. The cpuset is completely ignored, so strange objects such as I/O devices should preferably be inserted with this.

When used for "normal" children with cpusets (when importing from XML when duplicating a topology), the caller should make sure children are inserted in order.

The given object may have children.

Remember to call topology connect() afterwards to fix handy pointers.

```
19.30.3.7 static int hwloc_plugin_check_namespace ( const char * pluginname, const char * symbol ) [inline], [static]
```

Make sure that plugins can lookup core symbols.

This is a sanity check to avoid lazy-lookup failures when libhwloc is loaded within a plugin, and later tries to load its own plugins. This may fail (and abort the program) if libhwloc symbols are in a private namespace.

Returns

0 on success.

-1 if the plugin cannot be successfully loaded. The caller plugin init() callback should return a negative error code as well.

Plugins should call this function in their init() callback to avoid later crashes if lazy symbol resolution is used by the upper layer that loaded hwloc (e.g. OpenCL implementations using dlopen with RTLD LAZY).

Note

The build system must define HWLOC_INSIDE_PLUGIN if and only if building the caller as a plugin. This function should remain inline so plugins can call it even when they cannot find libhwloc symbols.

19.30.3.8 void hwloc_report_os_error (const char * msg, int line)

Report an insertion error from a backend.

19.31 Components and Plugins: PCI functions to be used by components

Functions

- int hwloc_insert_pci_device_list (struct hwloc_backend *backend, struct hwloc_obj *first_obj)
- unsigned hwloc_pci_find_cap (const unsigned char *config, unsigned cap)
- int hwloc_pci_find_linkspeed (const unsigned char *config, unsigned offset, float *linkspeed)
- int hwloc_pci_prepare_bridge (hwloc_obj_t obj, const unsigned char *config)

19.31.1 Detailed Description

19.31.2 Function Documentation

19.31.2.1 int hwloc_insert_pci_device_list (struct hwloc_backend * backend, struct hwloc_obj * first_obj)

Insert a list of PCI devices and bridges in the backend topology.

Insert a list of objects (either PCI device or bridges) starting at first_obj (linked by next_sibling in the topology, and ending with NULL). Objects are placed under the right bridges, and the remaining upstream bridges are then inserted in the topology by calling the get_obj_cpuset() callback to find their locality.

19.31.2.2 unsigned hwloc_pci_find_cap (const unsigned char * config, unsigned cap)

Return the offset of the given capability in the PCI config space buffer.

This function requires a 256-bytes config space. Unknown/unavailable bytes should be set to 0xff.

19.31.2.3 int hwloc pci find linkspeed (const unsigned char * config, unsigned offset, float * linkspeed)

Fill linkspeed by reading the PCI config space where PCI_CAP_ID_EXP is at position offset.

Needs 20 bytes of EXP capability block starting at offset in the config space for registers up to link status.

19.31.2.4 int hwloc_pci_prepare_bridge (hwloc_obj_t obj, const unsigned char * config)

Modify the PCI device object into a bridge and fill its attribute if a bridge is found in the PCI config space.

This function requires 64 bytes of common configuration header at the beginning of config.

19.32 Linux-specific helpers

Functions

- int hwloc_linux_parse_cpumap_file (FILE *file, hwloc_cpuset_t set)
- int hwloc_linux_set_tid_cpubind (hwloc_topology_t topology, pid_t tid, hwloc_const_cpuset_t set)
- int hwloc_linux_get_tid_cpubind (hwloc_topology_t topology, pid_t tid, hwloc_cpuset_t set)
- int hwloc_linux_get_tid_last_cpu_location (hwloc_topology_t topology, pid_t tid, hwloc_bitmap_t set)

19.32.1 Detailed Description

This includes helpers for manipulating Linux kernel cpumap files, and hwloc equivalents of the Linux sched_setaffinity and sched_getaffinity system calls.

19.32.2 Function Documentation

```
19.32.2.1 int hwloc_linux_get_tid_cpubind ( hwloc_topology_t topology, pid_t tid, hwloc_cpuset_t set )
```

Get the current binding of thread tid.

The behavior is exactly the same as the Linux sched getaffinity system call, but uses a hwloc cpuset.

Note

This is equivalent to calling hwloc_get_proc_cpubind() with HWLOC_CPUBIND_THREAD as flags.

```
19.32.2.2 int hwloc_linux_get_tid_last_cpu_location ( hwloc_topology_t topology, pid_t tid, hwloc_bitmap_t set )
```

Get the last physical CPU where thread tid ran.

Note

This is equivalent to calling hwloc get proc last cpu location() with HWLOC CPUBIND THREAD as flags.

```
19.32.2.3 int hwloc_linux_parse_cpumap_file ( FILE * file, hwloc_cpuset_t set )
```

Convert a linux kernel cpumap file file into hwloc CPU set.

Might be used when reading CPU set from sysfs attributes such as topology and caches for processors, or local_cpus for devices.

```
19.32.2.4 int hwloc_linux_set_tid_cpubind ( hwloc_topology_t topology, pid_t tid, hwloc_const_cpuset_t set )
```

Bind a thread tid on cpus given in cpuset set.

The behavior is exactly the same as the Linux sched_setaffinity system call, but uses a hwloc cpuset.

Note

This is equivalent to calling hwloc_set_proc_cpubind() with hwloc_set_proc_cpubind() with <a href="https://hww.nubind.com/hwl.

19.33 Interoperability with Linux libnuma unsigned long masks

Functions

static int hwloc_cpuset_to_linux_libnuma_ulongs (hwloc_topology_t topology, hwloc_const_cpuset_t cpuset, unsigned long *mask, unsigned long *maxnode)

- static int hwloc_nodeset_to_linux_libnuma_ulongs (hwloc_topology_t topology, hwloc_const_nodeset_t nodeset, unsigned long *mask, unsigned long *maxnode)
- static int hwloc_cpuset_from_linux_libnuma_ulongs (hwloc_topology_t topology, hwloc_cpuset_t cpuset, const unsigned long *mask, unsigned long maxnode)
- static int hwloc_nodeset_from_linux_libnuma_ulongs (hwloc_topology_t topology, hwloc_nodeset_t nodeset, const unsigned long *mask, unsigned long maxnode)

19.33.1 Detailed Description

This interface helps converting between Linux libnuma unsigned long masks and hwloc cpusets and nodesets.

It also offers a consistent behavior on non-NUMA machines or non-NUMA-aware kernels by assuming that the machines have a single NUMA node.

Note

Topology topology must match the current machine.

The behavior of libnuma is undefined if the kernel is not NUMA-aware. (when CONFIG_NUMA is not set in the kernel configuration). This helper and libnuma may thus not be strictly compatible in this case, which may be detected by checking whether numa_available() returns -1.

19.33.2 Function Documentation

19.33.2.1 static int hwloc_cpuset_from_linux_libnuma_ulongs (hwloc_topology_t topology, hwloc_cpuset_t cpuset, const unsigned long * mask, unsigned long maxnode) [inline], [static]

Convert the array of unsigned long mask into hwloc CPU set.

mask is a array of unsigned long that will be read. maxnode contains the maximal node number that may be read in mask.

This function may be used after calling get_mempolicy or any other function that takes an array of unsigned long as output parameter (and possibly a maximal node number as input parameter).

19.33.2.2 static int hwloc_cpuset_to_linux_libnuma_ulongs (hwloc_topology_t topology, hwloc_const_cpuset_t cpuset, unsigned long * mask, unsigned long * maxnode) [inline], [static]

Convert hwloc CPU set cpuset into the array of unsigned long mask.

mask is the array of unsigned long that will be filled. maxnode contains the maximal node number that may be stored in mask. maxnode will be set to the maximal node number that was found, plus one.

This function may be used before calling set_mempolicy, mbind, migrate_pages or any other function that takes an array of unsigned long and a maximal node number as input parameter.

19.33.2.3 static int hwloc_nodeset_from_linux_libnuma_ulongs (hwloc_topology_t topology, hwloc_nodeset_t nodeset, const unsigned long * mask, unsigned long maxnode) [inline], [static]

Convert the array of unsigned long mask into hwloc NUMA node set.

mask is a array of unsigned long that will be read. maxnode contains the maximal node number that may be read in mask.

This function may be used after calling get_mempolicy or any other function that takes an array of unsigned long as output parameter (and possibly a maximal node number as input parameter).

19.33.2.4 static int hwloc_nodeset_to_linux_libnuma_ulongs (hwloc_topology_t topology, hwloc_const_nodeset_t nodeset, unsigned long * mask, unsigned long * maxnode) [inline], [static]

Convert hwloc NUMA node set nodeset into the array of unsigned long mask.

mask is the array of unsigned long that will be filled. maxnode contains the maximal node number that may be stored in mask. maxnode will be set to the maximal node number that was found, plus one.

This function may be used before calling set_mempolicy, mbind, migrate_pages or any other function that takes an array of unsigned long and a maximal node number as input parameter.

19.34 Interoperability with Linux libnuma bitmask

Functions

- static int hwloc_cpuset_from_linux_libnuma_bitmask (hwloc_topology_t topology, hwloc_cpuset_t cpuset, const struct bitmask *bitmask)
- static int hwloc_nodeset_from_linux_libnuma_bitmask (hwloc_topology_t topology, hwloc_nodeset_t nodeset, const struct bitmask *bitmask)

19.34.1 Detailed Description

This interface helps converting between Linux libnuma bitmasks and hwloc cpusets and nodesets.

It also offers a consistent behavior on non-NUMA machines or non-NUMA-aware kernels by assuming that the machines have a single NUMA node.

Note

Topology topology must match the current machine.

The behavior of libnuma is undefined if the kernel is not NUMA-aware. (when CONFIG_NUMA is not set in the kernel configuration). This helper and libnuma may thus not be strictly compatible in this case, which may be detected by checking whether numa available() returns -1.

19.34.2 Function Documentation

19.34.2.1 static int hwloc_cpuset_from_linux_libnuma_bitmask (hwloc_topology_t topology, hwloc_cpuset_t cpuset, const struct bitmask * bitmask *) [inline], [static]

Convert libnuma bitmask bitmask into hwloc CPU set cpuset.

This function may be used after calling many numa_functions that use a struct bitmask as an output parameter.

```
19.34.2.2 static struct bitmask * hwloc_cpuset_to_linux_libnuma_bitmask ( hwloc_topology_t topology, hwloc_const_cpuset_t cpuset ) [static]
```

Convert hwloc CPU set cpuset into the returned libnuma bitmask.

The returned bitmask should later be freed with numa_bitmask_free.

This function may be used before calling many numa_functions that use a struct bitmask as an input parameter.

Returns

newly allocated struct bitmask.

19.34.2.3 static int hwloc_nodeset_from_linux_libnuma_bitmask(hwloc_topology_t topology, hwloc_nodeset_t nodeset, const struct bitmask * bitmask

Convert libnuma bitmask bitmask into hwloc NUMA node set nodeset.

This function may be used after calling many numa_ functions that use a struct bitmask as an output parameter.

```
19.34.2.4 static struct bitmask * hwloc_nodeset_to_linux_libnuma_bitmask ( hwloc_topology_t topology, hwloc_const_nodeset_t nodeset ) [static]
```

Convert hwloc NUMA node set nodeset into the returned libnuma bitmask.

The returned bitmask should later be freed with numa_bitmask_free.

This function may be used before calling many numa_functions that use a struct bitmask as an input parameter.

Returns

newly allocated struct bitmask.

19.35 Interoperability with glibc sched affinity

Functions

- static int hwloc_cpuset_to_glibc_sched_affinity (hwloc_topology_t topology, hwloc_const_cpuset_t hwlocset, cpu_set_t *schedset, size_t schedsetsize)
- static int hwloc_cpuset_from_glibc_sched_affinity (hwloc_topology_t topology, hwloc_cpuset_t hwlocset, const cpu_set_t *schedset, size_t schedsetsize)

19.35.1 Detailed Description

This interface offers ways to convert between hwloc cpusets and glibc cpusets such as those manipulated by sched_ getaffinity() or pthread attr setaffinity np().

Note

Topology topology must match the current machine.

19.35.2 Function Documentation

19.35.2.1 static int hwloc_cpuset_from_glibc_sched_affinity (hwloc_topology_t topology, hwloc_cpuset_t hwlocset, const cpu_set_t * schedset, size_t * schedsetsize) [inline], [static]

Convert glibc sched affinity CPU set schedset into hwloc CPU set.

This function may be used before calling sched_setaffinity or any other function that takes a cpu_set_t as input parameter.

schedsetsize should be sizeof(cpu_set_t) unless schedset was dynamically allocated with CPU_ALLOC

19.35.2.2 static int hwloc_cpuset_to_glibc_sched_affinity (hwloc_topology_t topology, hwloc_const_cpuset_t hwlocset, cpu_set_t * schedset, size_t schedsetsize) [inline], [static]

Convert hwloc CPU set toposet into glibc sched affinity CPU set schedset.

This function may be used before calling sched_setaffinity or any other function that takes a cpu_set_t as input parameter

schedsetsize should be sizeof(cpu_set_t) unless schedset was dynamically allocated with CPU_ALLOC

19.36 Interoperability with OpenCL

Functions

- static int hwloc_opencl_get_device_cpuset (hwloc_topology_t topology, cl_device_id device, hwloc_cpuset_t set)
- static hwloc_obj_t hwloc_opencl_get_device_osdev_by_index (hwloc_topology_t topology, unsigned platform_
 index, unsigned device_index)
- static hwloc obj t hwloc opencl get device osdev (hwloc topology t topology, cl device id device)

19.36.1 Detailed Description

This interface offers ways to retrieve topology information about OpenCL devices.

Only the AMD OpenCL interface currently offers useful locality information about its devices.

19.36.2 Function Documentation

19.36.2.1 static int hwloc_opencl_get_device_cpuset (hwloc_topology_t topology, cl_device_id device, hwloc_cpuset_t set) [inline], [static]

Get the CPU set of logical processors that are physically close to OpenCL device device.

Return the CPU set describing the locality of the OpenCL device device.

Topology topology and device device must match the local machine. I/O devices detection and the OpenCL component are not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see hwloc_opencl_get_device_osdev() and hwloc_opencl_get_device_osdev_by_index().

This function is currently only implemented in a meaningful way for Linux with the AMD OpenCL implementation; other systems will simply get a full cpuset.

```
19.36.2.2 static hwloc_obj_t hwloc_opencl_get_device_osdev ( hwloc_topology_t topology, cl_device_id device )
[inline], [static]
```

Get the hwloc OS device object corresponding to OpenCL device device.

Return the hwloc OS device object that describes the given OpenCL device device. Return NULL if there is none.

Topology topology and device device must match the local machine. I/O devices detection and the OpenCL component must be enabled in the topology. If not, the locality of the object may still be found using $hwloc_opencl_\leftarrow get_device_cpuset()$.

Note

The corresponding hwloc PCI device may be found by looking at the result parent pointer.

```
19.36.2.3 static hwloc_obj_t hwloc_opencl_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned platform_index, unsigned device_index ) [inline], [static]
```

Get the hwloc OS device object corresponding to the OpenCL device for the given indexes.

Return the OS device object describing the OpenCL device whose platform index is platform_index, and whose device index within this platform if device_index. Return NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the OpenCL component must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

19.37 Interoperability with the CUDA Driver API

Functions

- static int hwloc_cuda_get_device_pci_ids (hwloc_topology_t topology, CUdevice cudevice, int *domain, int *bus, int *dev)
- static int hwloc_cuda_get_device_cpuset (hwloc_topology_t topology, CUdevice cudevice, hwloc_cpuset_t set)
- static hwloc_obj_t hwloc_cuda_get_device_pcidev (hwloc_topology_t topology, CUdevice cudevice)
- static hwloc_obj_t hwloc_cuda_get_device_osdev (hwloc_topology_t topology, CUdevice cudevice)
- static hwloc_obj_t hwloc_cuda_get_device_osdev_by_index (hwloc_topology_t topology, unsigned idx)

19.37.1 Detailed Description

This interface offers ways to retrieve topology information about CUDA devices when using the CUDA Driver API.

19.37.2 Function Documentation

```
19.37.2.1 static int hwloc_cuda_get_device_cpuset ( hwloc_topology_t topology, CUdevice cudevice, hwloc_cpuset_t set )
[inline], [static]
```

Get the CPU set of logical processors that are physically close to device cudevice.

Return the CPU set describing the locality of the CUDA device cudevice.

Topology topology and device cudevice must match the local machine. I/O devices detection and the CUDA component are not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see hwloc cuda get device osdev() and hwloc cuda get device osdev by index().

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
19.37.2.2 static hwloc_obj_t hwloc_cuda_get_device_osdev ( hwloc_topology_t topology, CUdevice cudevice )
[inline],[static]
```

Get the hwloc OS device object corresponding to CUDA device cudevice.

Return the hwloc OS device object that describes the given CUDA device cudevice. Return NULL if there is none.

Topology topology and device cudevice must match the local machine. I/O devices detection and the NVML component must be enabled in the topology. If not, the locality of the object may still be found using hwloc_cuda_get—device_cpuset().

Note

The corresponding hwloc PCI device may be found by looking at the result parent pointer.

```
19.37.2.3 static hwloc_obj_t hwloc_cuda_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned idx ) [inline], [static]
```

Get the hwloc OS device object corresponding to the CUDA device whose index is idx.

Return the OS device object describing the CUDA device whose index is idx. Return NULL if there is none.

158 Module Documentation

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the CUDA component must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

This function is identical to hwloc_cudart_get_device_osdev_by_index().

19.37.2.4 static int hwloc_cuda_get_device_pci_ids (hwloc_topology_t topology, CUdevice cudevice, int * domain, int * bus, int * dev) [inline], [static]

Return the domain, bus and device IDs of the CUDA device cudevice.

Device cudevice must match the local machine.

19.37.2.5 static hwloc_obj_t hwloc_cuda_get_device_pcidev (hwloc_topology_t topology, CUdevice cudevice) [inline], [static]

Get the hwloc PCI device object corresponding to the CUDA device cudevice.

Return the PCI device object describing the CUDA device cudevice. Return NULL if there is none.

Topology topology and device cudevice must match the local machine. I/O devices detection must be enabled in topology topology. The CUDA component is not needed in the topology.

19.38 Interoperability with the CUDA Runtime API

Functions

- static int hwloc_cudart_get_device_pci_ids (hwloc_topology_t topology, int idx, int *domain, int *bus, int *dev)
- · static int hwloc cudart get device cpuset (hwloc topology t topology, int idx, hwloc cpuset t set)
- static hwloc_obj_t hwloc_cudart_get_device_pcidev (hwloc_topology_t topology, int idx)
- static hwloc obj t hwloc cudart get device osdev by index (hwloc topology t topology, unsigned idx)

19.38.1 Detailed Description

This interface offers ways to retrieve topology information about CUDA devices when using the CUDA Runtime API.

19.38.2 Function Documentation

```
19.38.2.1 static int hwloc_cudart_get_device_cpuset ( hwloc_topology_t topology, int idx, hwloc_cpuset_t set ) [inline],[static]
```

Get the CPU set of logical processors that are physically close to device idx.

Return the CPU set describing the locality of the CUDA device whose index is idx.

Topology topology and device idx must match the local machine. I/O devices detection and the CUDA component are not needed in the topology.

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
19.38.2.2 static hwloc_obj_t hwloc_cudart_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned idx )
[inline], [static]
```

Get the hwloc OS device object corresponding to the CUDA device whose index is idx.

Return the OS device object describing the CUDA device whose index is idx. Return NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the CUDA component must be enabled in the topology. If not, the locality of the object may still be found using hwloc_cudart_get_device_cpuset().

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object. This function is identical to hwloc_cuda_get_device_osdev_by_index().

```
19.38.2.3 static int hwloc_cudart_get_device_pci_ids ( hwloc_topology_t topology, int idx, int * domain, int * bus, int * dev )
[inline], [static]
```

Return the domain, bus and device IDs of the CUDA device whose index is idx.

Device index idx must match the local machine.

160 Module Documentation

19.38.2.4 static hwloc_obj_t hwloc_cudart_get_device_pcidev (hwloc_topology_t topology, int idx) [inline], [static]

Get the hwloc PCI device object corresponding to the CUDA device whose index is idx.

Return the PCI device object describing the CUDA device whose index is idx. Return NULL if there is none.

Topology topology and device idx must match the local machine. I/O devices detection must be enabled in topology topology. The CUDA component is not needed in the topology.

Generated on Sun Jun 14 2015 21:56:30 for Hardware Locality (hwloc) by Doxygen

19.39 Interoperability with the NVIDIA Management Library

Functions

- static int hwloc_nvml_get_device_cpuset (hwloc_topology_t topology, nvmlDevice_t device, hwloc_cpuset_t set)
- static hwloc_obj_t hwloc_nvml_get_device_osdev_by_index (hwloc_topology_t topology, unsigned idx)
- static hwloc_obj_t hwloc_nvml_get_device_osdev (hwloc_topology_t topology, nvmlDevice_t device)

19.39.1 Detailed Description

This interface offers ways to retrieve topology information about devices managed by the NVIDIA Management Library (NVML).

19.39.2 Function Documentation

19.39.2.1 static int hwloc_nvml_get_device_cpuset (hwloc_topology_t topology, nvmlDevice_t device, hwloc_cpuset_t set) [inline], [static]

Get the CPU set of logical processors that are physically close to NVML device device.

Return the CPU set describing the locality of the NVML device device.

Topology topology and device device must match the local machine. I/O devices detection and the NVML component are not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see hwloc_nvml_get_device_osdev, and hwloc_nvml_get_device_osdev, by index().

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
19.39.2.2 static hwloc_obj_t hwloc_nvml_get_device_osdev ( hwloc_topology_t topology, nvmlDevice_t device )
[inline],[static]
```

Get the hwloc OS device object corresponding to NVML device device.

Return the hwloc OS device object that describes the given NVML device device. Return NULL if there is none.

Topology topology and device device must match the local machine. I/O devices detection and the NVML component must be enabled in the topology. If not, the locality of the object may still be found using hwloc_nvml_get_device cuset().

Note

The corresponding hwloc PCI device may be found by looking at the result parent pointer.

```
19.39.2.3 static hwloc_obj_t hwloc_nvml_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned idx ) [inline], [static]
```

Get the hwloc OS device object corresponding to the NVML device whose index is idx.

Return the OS device object describing the NVML device whose index is idx. Returns NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the NVML component must be enabled in the topology.

162 Module Documentation

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

19.40 Interoperability with OpenGL displays

Functions

- static hwloc_obj_t hwloc_gl_get_display_osdev_by_port_device (hwloc_topology_t topology, unsigned port, unsigned device)
- static hwloc obj t hwloc gl get display osdev by name (hwloc topology t topology, const char *name)
- static int hwloc_gl_get_display_by_osdev (hwloc_topology_t topology, hwloc_obj_t osdev, unsigned *port, unsigned *device)

19.40.1 Detailed Description

This interface offers ways to retrieve topology information about OpenGL displays.

Only the NVIDIA display locality information is currently available, using the NV-CONTROL X11 extension and the NVCtrl library.

19.40.2 Function Documentation

```
19.40.2.1 static int hwloc_gl_get_display_by_osdev ( hwloc_topology_t topology, hwloc_obj_t osdev, unsigned * port, unsigned * device ) [inline], [static]
```

Get the OpenGL display port and device corresponding to the given hwloc OS object.

Return the OpenGL display port (server) in port and device (screen) in screen that correspond to the given hwloc OS device object. Return -1 if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the GL component must be enabled in the topology.

```
19.40.2.2 static hwloc_obj_t hwloc_gl_get_display_osdev_by_name ( hwloc_topology_t topology, const char * name ) [inline], [static]
```

Get the hwloc OS device object corresponding to the OpenGL display given by name.

Return the OS device object describing the OpenGL display whose name is name, built as ":port.device" such as ":0.0" . Return NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the GL component must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

```
19.40.2.3 static hwloc_obj_t hwloc_gl_get_display_osdev_by_port_device ( hwloc_topology_t topology, unsigned port, unsigned device ) [inline], [static]
```

Get the hwloc OS device object corresponding to the OpenGL display given by port and device index.

Return the OS device object describing the OpenGL display whose port (server) is port and device (screen) is device. Return NULL if there is none.

164 Module Documentation

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the GL component must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

19.41 Interoperability with Intel Xeon Phi (MIC)

Functions

- static int hwloc_intel_mic_get_device_cpuset (hwloc_topology_t topology, int idx, hwloc_cpuset_t set)
- static hwloc_obj_t hwloc_intel_mic_get_device_osdev_by_index (hwloc_topology_t topology, unsigned idx)

19.41.1 Detailed Description

This interface offers ways to retrieve topology information about Intel Xeon Phi (MIC) devices.

19.41.2 Function Documentation

```
19.41.2.1 static int hwloc_intel_mic_get_device_cpuset ( hwloc_topology_t topology, int idx, hwloc_cpuset_t set ) [inline], [static]
```

Get the CPU set of logical processors that are physically close to MIC device whose index is idx.

Return the CPU set describing the locality of the MIC device whose index is idx.

Topology topology and device index idx must match the local machine. I/O devices detection is not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see <a href="https://hww.nuc.en/beauto.com/hww.nuc.en/beauto.

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
19.41.2.2 static hwloc_obj_t hwloc_intel_mic_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned idx )
[inline], [static]
```

Get the hwloc OS device object corresponding to the MIC device for the given index.

Return the OS device object describing the MIC device whose index is idx. Return NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

166 Module Documentation

19.42 Interoperability with OpenFabrics

Functions

- static int hwloc_ibv_get_device_cpuset (hwloc_topology_t topology, struct ibv_device *ibdev, hwloc_cpuset_t set)
- static hwloc obj t hwloc ibv get device osdev by name (hwloc topology t topology, const char *ibname)
- static hwloc obj t hwloc ibv get device osdev (hwloc topology t topology, struct ibv device *ibdev)

19.42.1 Detailed Description

This interface offers ways to retrieve topology information about OpenFabrics devices.

19.42.2 Function Documentation

```
19.42.2.1 static int hwloc_ibv_get_device_cpuset ( hwloc_topology_t topology, struct ibv_device * ibdev, hwloc_cpuset_t set ) [inline], [static]
```

Get the CPU set of logical processors that are physically close to device ibdev.

Return the CPU set describing the locality of the OpenFabrics device ibdev.

Topology topology and device ibdev must match the local machine. I/O devices detection is not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see hwloc ibv get device osdev() and hwloc ibv get device osdev by name().

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
19.42.2.2 static hwloc_obj_t hwloc_ibv_get_device_osdev ( hwloc_topology_t topology, struct ibv_device * ibdev )
[inline], [static]
```

Get the hwloc OS device object corresponding to the OpenFabrics device ibdev.

Return the OS device object describing the OpenFabrics device ibdev. Returns NULL if there is none.

Topology topology and device ibdev must match the local machine. I/O devices detection must be enabled in the topology. If not, the locality of the object may still be found using $hwloc_ibv_get_device_cpuset()$.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

```
19.42.2.3 static hwloc_obj_t hwloc_ibv_get_device_osdev_by_name ( hwloc_topology_t topology, const char * ibname ) [inline], [static]
```

Get the hwloc OS device object corresponding to the OpenFabrics device named ibname.

Return the OS device object describing the OpenFabrics device whose name is ibname. Returns NULL if there is none. The name ibname is usually obtained from ibv get device name().

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

168 Module Documentation

19.43 Interoperability with Myrinet Express

Functions

- static int hwloc_mx_board_get_device_cpuset (hwloc_topology_t topology, unsigned id, hwloc_cpuset_t set)
- static int hwloc_mx_endpoint_get_device_cpuset (hwloc_topology_t topology, mx_endpoint_t endpoint, hwloc
 cpuset t set)

19.43.1 Detailed Description

This interface offers ways to retrieve topology information about Myrinet Express hardware.

19.43.2 Function Documentation

19.43.2.1 static int hwloc_mx_board_get_device_cpuset (hwloc_topology_t topology, unsigned id, hwloc_cpuset_t set)
[inline], [static]

Get the CPU set of logical processors that are physically close the MX board id.

Return the CPU set describing the locality of the Myrinet Express board whose index is id.

Topology topology and device id must match the local machine. I/O devices detection is not needed in the topology. The function only returns the locality of the device. No additional information about the device is available.

19.43.2.2 static int hwloc_mx_endpoint_get_device_cpuset (hwloc_topology_t topology, mx_endpoint_t endpoint, hwloc_cpuset_t set) [inline], [static]

Get the CPU set of logical processors that are physically close the MX endpoint endpoint.

Return the CPU set describing the locality of the Myrinet Express board that runs the MX endpoint endpoint.

 $\label{topology} \textbf{Topology and device id must match the local machine. I/O devices detection is not needed in the topology.}$

The function only returns the locality of the endpoint. No additional information about the endpoint or device is available.

Chapter 20

Data Structure Documentation

20.1 hwloc_backend Struct Reference

```
#include <plugins.h>
```

Data Fields

- · unsigned long flags
- int is_custom
- int is_thissystem
- void * private_data
- void(* disable)(struct hwloc_backend *backend)
- int(* discover)(struct hwloc_backend *backend)
- int(* get_obj_cpuset)(struct hwloc_backend *backend, struct hwloc_backend *caller, struct hwloc_obj *obj, hwloc_bitmap_t cpuset)
- int(* notify_new_object)(struct hwloc_backend *backend, struct hwloc_backend *caller, struct hwloc_obj *obj)

20.1.1 Detailed Description

Discovery backend structure.

A backend is the instantiation of a discovery component. When a component gets enabled for a topology, its instantiate() callback creates a backend.

hwloc_backend_alloc() initializes all fields to default values that the component may change (except "component" and "next") before enabling the backend with hwloc_backend_enable().

20.1.2 Field Documentation

20.1.2.1 void(* hwloc_backend::disable) (struct hwloc_backend *backend)

Callback for freeing the private data. May be NULL.

20.1.2.2 int(* hwloc_backend::discover) (struct hwloc_backend *backend)

Main discovery callback. returns > 0 if it modified the topology tree, -1 on error, 0 otherwise. May be NULL if type is HWLOC_DISC_COMPONENT_TYPE_MISC.

20.1.2.3 unsigned long hwloc_backend::flags

Backend flags, as an OR'ed set of HWLOC BACKEND FLAG *.

20.1.2.4 int(* hwloc_backend::get_obj_cpuset) (struct hwloc_backend *backend, struct hwloc_backend *caller, struct hwloc_obj *obj, hwloc_bitmap_t cpuset)

Callback used by the PCI backend to retrieve the locality of a PCI object from the OS/cpu backend. May be NULL.

20.1.2.5 int hwloc_backend::is_custom

Backend-specific 'is_custom' property. Shortcut on !strcmp(..->component->name, "custom"). Only the custom component should touch this.

20.1.2.6 int hwloc_backend::is_thissystem

Backend-specific 'is_thissystem' property. Set to 0 or 1 if the backend should enforce the thissystem flag when it gets enabled. Set to -1 if the backend doesn't care (default).

20.1.2.7 int(* hwloc_backend::notify_new_object) (struct hwloc_backend *backend, struct hwloc_backend *caller, struct hwloc_obj *obj)

Callback called by backends to notify this backend that a new object was added. returns > 0 if it modified the topology tree, 0 otherwise. May be NULL.

20.1.2.8 void* hwloc_backend::private_data

Backend private data, or NULL if none.

The documentation for this struct was generated from the following file:

· plugins.h

20.2 hwloc_obj_attr_u::hwloc_bridge_attr_s Struct Reference

```
#include <hwloc.h>
```

Data Fields

union { struct hwloc_pcidev_attr_s pci } upstream

```
    hwloc_obj_bridge_type_t upstream_type
    union {
        struct {
            unsigned short domain
            unsigned char secondary_bus
            unsigned char subordinate_bus
        } pci
    } downstream
```

- hwloc_obj_bridge_type_t downstream_type
- · unsigned depth

20.2.1 Detailed Description

Bridge specific Object Attribues.

20.2.2 Field Documentation

```
20.2.2.1 unsigned hwloc_obj_attr_u::hwloc_bridge_attr_s::depth
```

20.2.2.2 unsigned short hwloc_obj_attr_u::hwloc_bridge_attr_s::domain

20.2.2.3 union { ... } hwloc_obj_attr_u::hwloc_bridge_attr_s::downstream

20.2.2.4 hwloc obj bridge type t hwloc_obj_attr_u::hwloc_bridge_attr_s::downstream_type

20.2.2.5 struct { ... } hwloc_obj_attr_u::hwloc_bridge_attr_s::pci

20.2.2.6 struct hwloc_pcidev_attr_s hwloc_obj_attr_u::hwloc_bridge_attr_s::pci

20.2.2.7 unsigned char hwloc_obj_attr_u::hwloc_bridge_attr_s::secondary_bus

20.2.2.8 unsigned char hwloc_obj_attr_u::hwloc_bridge_attr_s::subordinate_bus

20.2.2.9 union { ... } hwloc_obj_attr_u::hwloc_bridge_attr_s::upstream

20.2.2.10 hwloc_obj_bridge_type_t hwloc_obj_attr_u::hwloc_bridge_attr_s::upstream_type

The documentation for this struct was generated from the following file:

· hwloc.h

20.3 hwloc_obj_attr_u::hwloc_cache_attr_s Struct Reference

```
#include <hwloc.h>
```

Data Fields

· hwloc uint64 t size

- · unsigned depth
- · unsigned linesize
- · int associativity
- hwloc_obj_cache_type_t type

20.3.1 Detailed Description

Cache-specific Object Attributes.

20.3.2 Field Documentation

20.3.2.1 int hwloc_obj_attr_u::hwloc_cache_attr_s::associativity

Ways of associativity, -1 if fully associative, 0 if unknown.

20.3.2.2 unsigned hwloc_obj_attr_u::hwloc_cache_attr_s::depth

Depth of cache (e.g., L1, L2, ...etc.)

20.3.2.3 unsigned hwloc obj attr u::hwloc cache attr s::linesize

Cache-line size in bytes. 0 if unknown.

20.3.2.4 hwloc_uint64_t hwloc_obj_attr_u::hwloc_cache_attr_s::size

Size of cache in bytes.

20.3.2.5 hwloc_obj_cache_type_t hwloc_obj_attr_u::hwloc_cache_attr_s::type

Cache type.

The documentation for this struct was generated from the following file:

· hwloc.h

20.4 hwloc_component Struct Reference

```
#include <plugins.h>
```

Data Fields

- unsigned abi
- int(* init)(unsigned long flags)
- void(* finalize)(unsigned long flags)
- hwloc_component_type_t type
- · unsigned long flags
- void * data

20.4.1 Detailed Description

Generic component structure.

Generic components structure, either statically listed by configure in static-components.h or dynamically loaded as a plugin.

20.4.2 Field Documentation

20.4.2.1 unsigned hwloc_component::abi

Component ABI version, set to HWLOC COMPONENT ABI.

20.4.2.2 void* hwloc_component::data

Component data, pointing to a struct hwloc_disc_component or struct hwloc_xml_component.

20.4.2.3 void(* hwloc_component::finalize) (unsigned long flags)

Process-wide component termination callback.

This optional callback is called after unregistering the component from the hwloc core (before unloading the plugin).

flags is always 0 for now.

Note

If the component uses Itdl for loading its own plugins, it should load/unload them only in init() and finalize(), to avoid race conditions with hwloc's use of Itdl.

20.4.2.4 unsigned long hwloc_component::flags

Component flags, unused for now.

20.4.2.5 int(* hwloc_component::init) (unsigned long flags)

Process-wide component initialization callback.

This optional callback is called when the component is registered to the hwloc core (after loading the plugin).

When the component is built as a plugin, this callback should call hwloc_check_plugin_namespace() and return an negative error code on error.

flags is always 0 for now.

Returns

0 on success, or a negative code on error.

Note

If the component uses Itdl for loading its own plugins, it should load/unload them only in init() and finalize(), to avoid race conditions with hwloc's use of Itdl.

20.4.2.6 hwloc_component_type_t hwloc_component::type

Component type.

The documentation for this struct was generated from the following file:

· plugins.h

20.5 hwloc_disc_component Struct Reference

#include <plugins.h>

Data Fields

- hwloc_disc_component_type_t type
- const char * name
- · unsigned excludes
- struct hwloc_backend *(* instantiate)(struct hwloc_disc_component *component, const void *data1, const void *data2, const void *data3)
- · unsigned priority

20.5.1 Detailed Description

Discovery component structure.

This is the major kind of components, taking care of the discovery. They are registered by generic components, either statically-built or as plugins.

20.5.2 Field Documentation

20.5.2.1 unsigned hwloc_disc_component::excludes

Component types to exclude, as an OR'ed set of HWLOC_DISC_COMPONENT_TYPE_*.

For a GLOBAL component, this usually includes all other types (\sim 0).

Other components only exclude types that may bring conflicting topology information. MISC components should likely not be excluded since they usually bring non-primary additional information.

20.5.2.2 struct hwloc_backend*(* hwloc_disc_component::instantiate) (struct hwloc_disc_component *component, const void *data1, const void *data2, const void *data3)

Instantiate callback to create a backend from the component. Parameters data1, data2, data3 are NULL except for components that have special enabling routines such as hwloc topology set xml().

20.5.2.3 const char* hwloc_disc_component::name

Name. If this component is built as a plugin, this name does not have to match the plugin filename.

20.5.2.4 unsigned hwloc_disc_component::priority

Component priority. Used to sort topology->components, higher priority first. Also used to decide between two components with the same name.

Usual values are 50 for native OS (or platform) components, 45 for x86, 40 for no-OS fallback, 30 for global components (xml/synthetic/custom), 20 for pci, 10 for other misc components (opencl etc.).

20.5.2.5 hwloc_disc_component_type_t hwloc_disc_component::type

Discovery component type.

The documentation for this struct was generated from the following file:

· plugins.h

20.6 hwloc_distances_s Struct Reference

#include <hwloc.h>

Data Fields

- unsigned relative_depth
- unsigned nbobjs
- float * latency
- · float latency_max
- float latency_base

20.6.1 Detailed Description

Distances between objects.

One object may contain a distance structure describing distances between all its descendants at a given relative depth. If the containing object is the root object of the topology, then the distances are available for all objects in the machine.

If the latency pointer is not NULL, the pointed array contains memory latencies (non-zero values), see below.

In the future, some other types of distances may be considered. In these cases, latency may be NULL.

20.6.2 Field Documentation

20.6.2.1 float* hwloc_distances_s::latency

Matrix of latencies between objects, stored as a one-dimension array. May be \mathtt{NULL} if the distances considered here are not latencies.

Unless defined by the user, this currently contains latencies between NUMA nodes (as reported in the System Locality Distance Information Table (SLIT) in the ACPI specification), which may or may not be accurate. It corresponds to the latency for accessing the memory of one node from a core in another node.

Values are normalized to get 1.0 as the minimal value in the matrix. Latency from i-th to j-th object is stored in slot i*nbobjs+j.

20.6.2.2 float hwloc_distances_s::latency_base

The multiplier that should be applied to latency matrix to retrieve the original OS-provided latencies. Usually 10 on Linux since ACPI SLIT uses 10 for local latency.

20.6.2.3 float hwloc_distances_s::latency_max

The maximal value in the latency matrix.

20.6.2.4 unsigned hwloc_distances_s::nbobjs

Number of objects considered in the matrix. It is the number of descendant objects at relative_depth below the containing object. It corresponds to the result of hwloc_get_nbobjs_inside_cpuset_by_depth().

20.6.2.5 unsigned hwloc_distances_s::relative_depth

Relative depth of the considered objects below the object containing this distance information.

The documentation for this struct was generated from the following file:

· hwloc.h

20.7 hwloc_obj_attr_u::hwloc_group_attr_s Struct Reference

#include <hwloc.h>

Data Fields

· unsigned depth

20.7.1 Detailed Description

Group-specific Object Attributes.

20.7.2 Field Documentation

20.7.2.1 unsigned hwloc_obj_attr_u::hwloc_group_attr_s::depth

Depth of group object.

The documentation for this struct was generated from the following file:

· hwloc.h

20.8 hwloc_obj Struct Reference

#include <hwloc.h>

Data Fields

- hwloc_obj_type_t type
- unsigned os_index
- char * name
- · struct hwloc obj memory s memory
- union hwloc_obj_attr_u * attr
- unsigned depth
- unsigned logical_index
- signed os_level
- struct hwloc_obj * next_cousin
- struct hwloc obj * prev cousin
- struct hwloc_obj * parent
- · unsigned sibling rank
- struct hwloc_obj * next_sibling
- struct hwloc obj * prev sibling
- · unsigned arity
- struct hwloc_obj ** children
- struct hwloc_obj * first_child
- struct hwloc obj * last child
- void * userdata
- · hwloc cpuset t cpuset
- · hwloc cpuset t complete cpuset
- hwloc_cpuset_t online_cpuset
- · hwloc cpuset tallowed cpuset
- hwloc nodeset t nodeset
- hwloc_nodeset_t complete_nodeset
- hwloc_nodeset_t allowed_nodeset
- struct hwloc distances s ** distances
- · unsigned distances count
- struct hwloc obj info s * infos
- · unsigned infos_count
- · int symmetric subtree

20.8.1 Detailed Description

Structure of a topology object.

Applications must not modify any field except hwloc_obj.userdata.

20.8.2 Field Documentation

20.8.2.1 hwloc_cpuset_t hwloc_obj::allowed_cpuset

The CPU set of allowed logical processors.

This includes the CPUs contained in this object which are allowed for binding, i.e. passing them to the hwloc binding functions should not return permission errors. This is usually restricted by administration rules. Some of them may however be offline so binding to them may still not be possible, see online_cpuset.

Note

Its value must not be changed, hwloc_bitmap_dup must be used instead.

20.8.2.2 hwloc_nodeset_t hwloc_obj::allowed_nodeset

The set of allowed NUMA memory nodes.

This includes the NUMA memory nodes contained in this object which are allowed for memory allocation, i.e. passing them to NUMA node-directed memory allocation should not return permission errors. This is usually restricted by administration rules.

If there are no NUMA nodes in the machine, all the memory is close to this object, so allowed_nodeset is full.

Note

Its value must not be changed, hwloc_bitmap_dup must be used instead.

20.8.2.3 unsigned hwloc_obj::arity

Number of children.

20.8.2.4 union hwloc_obj_attr_u* hwloc_obj::attr

Object type-specific Attributes, may be NULL if no attribute value was found.

20.8.2.5 struct hwloc obj** hwloc_obj::children

Children, children[0 .. arity -1].

20.8.2.6 hwloc_cpuset_t hwloc_obj::complete_cpuset

The complete CPU set of logical processors of this object,.

This includes not only the same as the cpuset field, but also the CPUs for which topology information is unknown or incomplete, and the CPUs that are ignored when the HWLOC_TOPOLOGY_FLAG_WHOLE_SYSTEM flag is not set. Thus no corresponding PU object may be found in the topology, because the precise position is undefined. It is however known that it would be somewhere under this object.

Note

Its value must not be changed, hwloc_bitmap_dup must be used instead.

20.8.2.7 hwloc_nodeset_t hwloc_obj::complete_nodeset

The complete NUMA node set of this object,.

This includes not only the same as the nodeset field, but also the NUMA nodes for which topology information is unknown or incomplete, and the nodes that are ignored when the HWLOC_TOPOLOGY_FLAG_WHOLE_SYSTE

M flag is not set. Thus no corresponding NODE object may be found in the topology, because the precise position is undefined. It is however known that it would be somewhere under this object.

If there are no NUMA nodes in the machine, all the memory is close to this object, so complete_nodeset is full.

Note

Its value must not be changed, hwloc_bitmap_dup must be used instead.

20.8.2.8 hwloc_cpuset_t hwloc_obj::cpuset

CPUs covered by this object.

This is the set of CPUs for which there are PU objects in the topology under this object, i.e. which are known to be physically contained in this object and known how (the children path between this object and the PU objects).

If the HWLOC_TOPOLOGY_FLAG_WHOLE_SYSTEM configuration flag is set, some of these CPUs may be offline, or not allowed for binding, see online cpuset and allowed cpuset.

Note

Its value must not be changed, hwloc_bitmap_dup must be used instead.

20.8.2.9 unsigned hwloc_obj::depth

Vertical index in the hierarchy. If the topology is symmetric, this is equal to the parent depth plus one, and also equal to the number of parent/child links from the root object to here.

20.8.2.10 struct hwloc_distances_s** hwloc_obj::distances

Distances between all objects at same depth below this object.

20.8.2.11 unsigned hwloc_obj::distances_count

20.8.2.12 struct hwloc_obj* hwloc_obj::first_child

First child.

20.8.2.13 struct hwloc obj info s* hwloc_obj::infos

Array of stringified info type=name.

20.8.2.14 unsigned hwloc_obj::infos_count

Size of infos array.

20.8.2.15 struct hwloc_obj* hwloc_obj::last_child

Last child.

20.8.2.16 unsigned hwloc_obj::logical_index

Horizontal index in the whole list of similar objects, hence guaranteed unique across the entire machine. Could be a "cousin_rank" since it's the rank within the "cousin" list below.

20.8.2.17 struct hwloc_obj_memory_s hwloc_obj::memory

Memory attributes.

20.8.2.18 char* hwloc_obj::name

Object description if any.

20.8.2.19 struct hwloc_obj* hwloc_obj::next_cousin

Next object of same type and depth.

20.8.2.20 struct hwloc_obj* hwloc_obj::next_sibling

Next object below the same parent.

20.8.2.21 hwloc_nodeset_t hwloc_obj::nodeset

NUMA nodes covered by this object or containing this object.

This is the set of NUMA nodes for which there are NODE objects in the topology under or above this object, i.e. which are known to be physically contained in this object or containing it and known how (the children path between this object and the NODE objects).

In the end, these nodes are those that are close to the current object.

If the HWLOC_TOPOLOGY_FLAG_WHOLE_SYSTEM configuration flag is set, some of these nodes may not be allowed for allocation, see allowed nodeset.

If there are no NUMA nodes in the machine, all the memory is close to this object, so nodeset is full.

Note

Its value must not be changed, hwloc_bitmap_dup must be used instead.

20.8.2.22 hwloc cpuset thwloc_obj::online_cpuset

The CPU set of online logical processors.

This includes the CPUs contained in this object that are online, i.e. draw power and can execute threads. It may however not be allowed to bind to them due to administration rules, see allowed cpuset.

Note

Its value must not be changed, hwloc_bitmap_dup must be used instead.

20.8.2.23 unsigned hwloc_obj::os_index

OS-provided physical index number. It is not guaranteed unique across the entire machine, except for PUs and NUMA nodes.

20.8.2.24 signed hwloc_obj::os_level

OS-provided physical level, -1 if unknown or meaningless.

20.8.2.25 struct hwloc_obj* hwloc_obj::parent

Parent, NULL if root (system object)

20.8.2.26 struct hwloc_obj* hwloc_obj::prev_cousin

Previous object of same type and depth.

20.8.2.27 struct hwloc_obj* hwloc_obj::prev_sibling

Previous object below the same parent.

20.8.2.28 unsigned hwloc_obj::sibling_rank

Index in parent's children[] array.

20.8.2.29 int hwloc_obj::symmetric_subtree

Set if the subtree of objects below this object is symmetric, which means all children and their children have identical subtrees. If set in the topology root object, Istopo may export the topology as a synthetic string.

20.8.2.30 hwloc_obj_type_t hwloc_obj::type

Type of object.

20.8.2.31 void* hwloc_obj::userdata

Application-given private data pointer, initialized to NULL, use it as you wish. See <a href="https://hww.nuc.edu.nuc.

The documentation for this struct was generated from the following file:

· hwloc.h

20.9 hwloc_obj_attr_u Union Reference

#include <hwloc.h>

Data Structures

- struct hwloc_bridge_attr_s
- struct hwloc_cache_attr_s
- struct hwloc_group_attr_s
- struct hwloc_osdev_attr_s
- struct hwloc_pcidev_attr_s

Data Fields

- struct hwloc_obj_attr_u::hwloc_cache_attr_s cache
- struct hwloc_obj_attr_u::hwloc_group_attr_s group
- struct hwloc_obj_attr_u::hwloc_pcidev_attr_s pcidev
- struct hwloc_obj_attr_u::hwloc_bridge_attr_s bridge
- · struct hwloc obj attr u::hwloc osdev attr s osdev

20.9.1 Detailed Description

Object type-specific Attributes.

20.9.2 Field Documentation

```
20.9.2.1 struct hwloc_obj_attr_u::hwloc_bridge_attr_s hwloc_obj_attr_u::bridge
```

20.9.2.2 struct hwloc_obj_attr_u::hwloc_cache_attr_s hwloc_obj_attr_u::cache

20.9.2.3 struct hwloc obj attr_u::hwloc group attr_s hwloc_obj_attr_u::group

20.9.2.4 struct hwloc_obj_attr_u::hwloc_osdev_attr_s hwloc_obj_attr_u::osdev

20.9.2.5 struct hwloc_obj_attr_u::hwloc_pcidev_attr_s hwloc_obj_attr_u::pcidev

The documentation for this union was generated from the following file:

· hwloc.h

20.10 hwloc_obj_info_s Struct Reference

```
#include <hwloc.h>
```

Data Fields

- char * name
- char * value

20.10.1 Detailed Description

Object info.

20.10.2 Field Documentation

20.10.2.1 char* hwloc_obj_info_s::name

Info name.

20.10.2.2 char* hwloc_obj_info_s::value

Info value.

The documentation for this struct was generated from the following file:

· hwloc.h

20.11 hwloc_obj_memory_s::hwloc_obj_memory_page_type_s Struct Reference

```
#include <hwloc.h>
```

Data Fields

- hwloc_uint64_t size
- · hwloc uint64 t count

20.11.1 Detailed Description

Array of local memory page types, NULL if no local memory and page_types is 0.

The array is sorted by increasing size fields. It contains page_types_len slots.

20.11.2 Field Documentation

20.11.2.1 hwloc_uint64_t hwloc_obj_memory_s::hwloc_obj_memory_page_type_s::count

Number of pages of this size.

20.11.2.2 hwloc_uint64_t hwloc_obj_memory_s::hwloc_obj_memory_page_type_s::size

Size of pages.

The documentation for this struct was generated from the following file:

· hwloc.h

20.12 hwloc_obj_memory_s Struct Reference

```
#include <hwloc.h>
```

Data Structures

struct hwloc_obj_memory_page_type_s

Data Fields

- hwloc_uint64_t total_memory
- hwloc_uint64_t local_memory
- unsigned page_types_len
- struct hwloc_obj_memory_s::hwloc_obj_memory_page_type_s * page_types

20.12.1 Detailed Description

Object memory.

20.12.2 Field Documentation

```
20.12.2.1 hwloc_uint64_t hwloc_obj_memory_s::local_memory
```

Local memory (in bytes)

```
20.12.2.2 struct hwloc_obj_memory_s::hwloc_obj_memory_page_type_s * hwloc_obj_memory_s::page_types
```

20.12.2.3 unsigned hwloc_obj_memory_s::page_types_len

Size of array page_types.

```
20.12.2.4 hwloc_uint64_t hwloc_obj_memory_s::total_memory
```

Total memory (in bytes) in this object and its children.

The documentation for this struct was generated from the following file:

· hwloc.h

20.13 hwloc_obj_attr_u::hwloc_osdev_attr_s Struct Reference

```
#include <hwloc.h>
```

Data Fields

hwloc_obj_osdev_type_t type

20.13.1 Detailed Description

OS Device specific Object Attributes.

20.13.2 Field Documentation

20.13.2.1 hwloc_obj_osdev_type_t hwloc_obj_attr_u::hwloc_osdev_attr_s::type

The documentation for this struct was generated from the following file:

· hwloc.h

20.14 hwloc_obj_attr_u::hwloc_pcidev_attr_s Struct Reference

#include <hwloc.h>

Data Fields

- · unsigned short domain
- · unsigned char bus
- · unsigned char dev
- · unsigned char func
- unsigned short class_id
- · unsigned short vendor_id
- · unsigned short device_id
- unsigned short subvendor_id
- · unsigned short subdevice_id
- unsigned char revision
- float linkspeed

20.14.1 Detailed Description

PCI Device specific Object Attributes.

20.14.2 Field Documentation

20.14.2.1	unsigned char hwloc_obj_attr_u::hwloc_pcidev_attr_s::bus
20.14.2.2	unsigned short hwloc_obj_attr_u::hwloc_pcidev_attr_s::class_id
20.14.2.3	unsigned char hwloc_obj_attr_u::hwloc_pcidev_attr_s::dev
20.14.2.4	unsigned short hwloc_obj_attr_u::hwloc_pcidev_attr_s::device_id
20.14.2.5	unsigned short hwloc_obj_attr_u::hwloc_pcidev_attr_s::domain
20.14.2.6	unsigned char hwloc_obj_attr_u::hwloc_pcidev_attr_s::func
20.14.2.7	float hwloc_obj_attr_u::hwloc_pcidev_attr_s::linkspeed
20.14.2.8	unsigned char hwloc_obj_attr_u::hwloc_pcidev_attr_s::revision

20.14.2.9 unsigned short hwloc_obj_attr_u::hwloc_pcidev_attr_s::subdevice_id

20.14.2.10 unsigned short hwloc_obj_attr_u::hwloc_pcidev_attr_s::subvendor_id

20.14.2.11 unsigned short hwloc_obj_attr_u::hwloc_pcidev_attr_s::vendor_id

The documentation for this struct was generated from the following file:

· hwloc.h

20.15 hwloc_topology_cpubind_support Struct Reference

#include <hwloc.h>

Data Fields

- · unsigned char set thisproc cpubind
- unsigned char get_thisproc_cpubind
- unsigned char set_proc_cpubind
- · unsigned char get proc cpubind
- · unsigned char set thisthread cpubind
- unsigned char get_thisthread_cpubind
- unsigned char set_thread_cpubind
- · unsigned char get_thread_cpubind
- · unsigned char get thisproc last cpu location
- · unsigned char get_proc_last_cpu_location
- · unsigned char get_thisthread_last_cpu_location

20.15.1 Detailed Description

Flags describing actual PU binding support for this topology.

20.15.2 Field Documentation

20.15.2.1 unsigned char hwloc_topology_cpubind_support::get_proc_cpubind

Getting the binding of a whole given process is supported.

20.15.2.2 unsigned char hwloc_topology_cpubind_support::get_proc_last_cpu_location

Getting the last processors where a whole process ran is supported

20.15.2.3 unsigned char hwloc_topology_cpubind_support::get_thisproc_cpubind

Getting the binding of the whole current process is supported.

20.15.2.4 unsigned char hwloc_topology_cpubind_support::get_thisproc_last_cpu_location

Getting the last processors where the whole current process ran is supported

20.15.2.5 unsigned char hwloc_topology_cpubind_support::get_thisthread_cpubind

Getting the binding of the current thread only is supported.

20.15.2.6 unsigned char hwloc_topology_cpubind_support::get_thisthread_last_cpu_location

Getting the last processors where the current thread ran is supported

20.15.2.7 unsigned char hwloc_topology_cpubind_support::get_thread_cpubind

Getting the binding of a given thread only is supported.

20.15.2.8 unsigned char hwloc_topology_cpubind_support::set_proc_cpubind

Binding a whole given process is supported.

20.15.2.9 unsigned char hwloc_topology_cpubind_support::set_thisproc_cpubind

Binding the whole current process is supported.

20.15.2.10 unsigned char hwloc_topology_cpubind_support::set_thisthread_cpubind

Binding the current thread only is supported.

20.15.2.11 unsigned char hwloc_topology_cpubind_support::set_thread_cpubind

Binding a given thread only is supported.

The documentation for this struct was generated from the following file:

· hwloc.h

20.16 hwloc_topology_diff_u::hwloc_topology_diff_generic_s Struct Reference

#include <diff.h>

Data Fields

- hwloc_topology_diff_type_t type
- union hwloc topology diff u * next

20.16.1 Field Documentation

- 20.16.1.1 union hwloc_topology_diff_u* hwloc_topology_diff_u::hwloc_topology_diff_generic_s::next
- 20.16.1.2 hwloc_topology_diff_type_t hwloc_topology_diff_u::hwloc_topology_diff_generic_s::type

The documentation for this struct was generated from the following file:

· diff.h

20.17 hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_generic_s Struct Reference

```
#include <diff.h>
```

Data Fields

hwloc_topology_diff_obj_attr_type_t type

20.17.1 Field Documentation

20.17.1.1 hwloc_topology_diff_obj_attr_type_t hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_generic_s
::type

The documentation for this struct was generated from the following file:

· diff.h

20.18 hwloc topology diff u::hwloc topology diff obj attr s Struct Reference

```
#include <diff.h>
```

Data Fields

- hwloc_topology_diff_type_t type
- union hwloc topology diff u * next
- · unsigned obj_depth
- · unsigned obj_index
- union hwloc_topology_diff_obj_attr_u diff

20.18.1 Field Documentation

- 20.18.1.1 union hwloc_topology_diff_obj_attr_u hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s::diff
- 20.18.1.2 union hwloc_topology_diff_u* hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s::next

```
20.18.1.3 unsigned hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s::obj_depth
```

20.18.1.4 unsigned hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s::obj_index

20.18.1.5 hwloc topology diff type t hwloc topology diff u::hwloc topology diff obj attr s::type

The documentation for this struct was generated from the following file:

· diff.h

20.19 hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s Struct Reference

```
#include <diff.h>
```

Data Fields

- hwloc_topology_diff_obj_attr_type_t type
- char * name
- char * oldvalue
- char * newvalue

20.19.1 Detailed Description

String attribute modification with an optional name.

20.19.2 Field Documentation

20.19.2.1 char* hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s::name

20.19.2.2 char* hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s::newvalue

20.19.2.3 char* hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s::oldvalue

20.19.2.4 hwloc_topology_diff_obj_attr_type_t hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s::type

The documentation for this struct was generated from the following file:

· diff.h

20.20 hwloc_topology_diff_obj_attr_u Union Reference

#include <diff.h>

Data Structures

- struct hwloc_topology_diff_obj_attr_generic_s
- struct hwloc_topology_diff_obj_attr_string_s
- struct hwloc_topology_diff_obj_attr_uint64_s

Data Fields

- struct hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_generic_s generic
- struct hwloc topology diff obj attr u::hwloc topology diff obj attr uint64 s uint64
- struct hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s string

20.20.1 Detailed Description

One object attribute difference.

20.20.2 Field Documentation

- 20.20.2.1 struct hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_generic_s hwloc_topology_diff_obj_attr_u::generic
- 20.20.2.2 struct hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s hwloc_topology_diff_obj_attr_u::string
- 20.20.2.3 struct hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s hwloc_topology_diff_obj_attr_u::uint64

The documentation for this union was generated from the following file:

· diff.h

20.21 hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s Struct Reference

#include <diff.h>

Data Fields

- hwloc_topology_diff_obj_attr_type_t type
- hwloc uint64 t index
- hwloc_uint64_t oldvalue
- hwloc_uint64_t newvalue

20.21.1 Detailed Description

Integer attribute modification with an optional index.

20.21.2 Field Documentation

- 20.21.2.1 hwloc_uint64_t hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s::index
- 20.21.2.2 hwloc_uint64_t hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s::newvalue
- 20.21.2.3 hwloc_uint64_t hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s::oldvalue
- 20.21.2.4 hwloc_topology_diff_obj_attr_type_t hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s::type

The documentation for this struct was generated from the following file:

· diff.h

20.22 hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s Struct Reference

#include <diff.h>

Data Fields

- hwloc_topology_diff_type_t type
- union hwloc_topology_diff_u * next
- · unsigned obj depth
- unsigned obj_index

20.22.1 Field Documentation

- 20.22.1.1 union hwloc_topology_diff_u* hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s::next
- 20.22.1.2 unsigned hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s::obj_depth
- 20.22.1.3 unsigned hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s::obj_index
- 20.22.1.4 hwloc topology diff type t hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s::type

The documentation for this struct was generated from the following file:

• diff.h

20.23 hwloc_topology_diff_u Union Reference

#include <diff.h>

Data Structures

- struct hwloc_topology_diff_generic_s
- struct hwloc_topology_diff_obj_attr_s
- · struct hwloc topology diff too complex s

Data Fields

- struct hwloc_topology_diff_u::hwloc_topology_diff_generic_s generic
- struct hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s obj_attr
- struct hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s too_complex

20.23.1 Detailed Description

One element of a difference list between two topologies.

20.23.2 Field Documentation

20.23.2.1 struct hwloc topology diff u::hwloc topology diff generic s hwloc_topology_diff_u::generic

20.23.2.2 struct hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s hwloc_topology_diff_u::obj_attr

20.23.2.3 struct hwloc topology diff u::hwloc topology diff too complex s hwloc_topology_diff_u::too_complex

The documentation for this union was generated from the following file:

· diff.h

20.24 hwloc_topology_discovery_support Struct Reference

#include <hwloc.h>

Data Fields

unsigned char pu

20.24.1 Detailed Description

Flags describing actual discovery support for this topology.

20.24.2 Field Documentation

20.24.2.1 unsigned char hwloc_topology_discovery_support::pu

Detecting the number of PU objects is supported.

The documentation for this struct was generated from the following file:

· hwloc.h

20.25 hwloc_topology_membind_support Struct Reference

#include <hwloc.h>

Data Fields

- · unsigned char set thisproc membind
- · unsigned char get_thisproc_membind
- unsigned char set_proc_membind
- unsigned char get_proc_membind
- · unsigned char set thisthread membind
- · unsigned char get thisthread membind
- · unsigned char set area membind
- · unsigned char get_area_membind
- · unsigned char alloc membind
- · unsigned char firsttouch membind
- · unsigned char bind_membind
- · unsigned char interleave membind
- · unsigned char replicate_membind
- · unsigned char nexttouch membind
- unsigned char migrate_membind

20.25.1 Detailed Description

Flags describing actual memory binding support for this topology.

20.25.2 Field Documentation

20.25.2.1 unsigned char hwloc_topology_membind_support::alloc_membind

Allocating a bound memory area is supported.

20.25.2.2 unsigned char hwloc_topology_membind_support::bind_membind

Bind policy is supported.

20.25.2.3 unsigned char hwloc_topology_membind_support::firsttouch_membind

First-touch policy is supported.

20.25.2.4 unsigned char hwloc_topology_membind_support::get_area_membind

Getting the binding of a given memory area is supported.

20.25.2.5 unsigned char hwloc_topology_membind_support::get_proc_membind

Getting the binding of a whole given process is supported.

20.25.2.6 unsigned char hwloc_topology_membind_support::get_thisproc_membind

Getting the binding of the whole current process is supported.

20.25.2.7 unsigned char hwloc_topology_membind_support::get_thisthread_membind

Getting the binding of the current thread only is supported.

20.25.2.8 unsigned char hwloc_topology_membind_support::interleave_membind Interleave policy is supported.

20.25.2.9 unsigned char hwloc_topology_membind_support::migrate_membind

Migration flags is supported.

20.25.2.10 unsigned char hwloc_topology_membind_support::nexttouch_membind

Next-touch migration policy is supported.

20.25.2.11 unsigned char hwloc_topology_membind_support::replicate_membind Replication policy is supported.

20.25.2.12 unsigned char hwloc_topology_membind_support::set_area_membind Binding a given memory area is supported.

20.25.2.13 unsigned char hwloc_topology_membind_support::set_proc_membind Binding a whole given process is supported.

20.25.2.14 unsigned char hwloc_topology_membind_support::set_thisproc_membind Binding the whole current process is supported.

20.25.2.15 unsigned char hwloc_topology_membind_support::set_thisthread_membind

Binding the current thread only is supported.

The documentation for this struct was generated from the following file:

· hwloc.h

20.26 hwloc_topology_support Struct Reference

#include <hwloc.h>

Data Fields

- struct hwloc_topology_discovery_support * discovery
- struct hwloc_topology_cpubind_support * cpubind
- struct hwloc_topology_membind_support * membind

20.26.1 Detailed Description

Set of flags describing actual support for this topology.

This is retrieved with hwloc_topology_get_support() and will be valid until the topology object is destroyed. Note: the values are correct only after discovery.

20.26.2 Field Documentation

- 20.26.2.1 struct hwloc_topology_cpubind_support* hwloc_topology_support::cpubind
- 20.26.2.2 struct hwloc_topology_discovery_support* hwloc_topology_support::discovery
- 20.26.2.3 struct hwloc_topology_membind_support* hwloc_topology_support::membind

The documentation for this struct was generated from the following file:

· hwloc.h

Data	Structure	Docum	antation

Index

API version, 67	hwloc_get_proc_last_cpu_location, 90
HWLOC_API_VERSION, 67	hwloc_get_thread_cpubind, 90
HWLOC_COMPONENT_ABI, 67	hwloc_set_cpubind, 90
hwloc_get_api_version, 67	hwloc_set_proc_cpubind, 90
abi	hwloc_set_thread_cpubind, 91
hwloc_component, 173	cache
alloc_membind	hwloc_obj_attr_u, 182
hwloc_topology_membind_support, 193	children
allowed_cpuset	hwloc_obj, 178
hwloc_obj, 177	class_id
allowed_nodeset	hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185
hwloc_obj, 177	complete_cpuset
arity	hwloc_obj, 178
hwloc_obj, 178	complete_nodeset
associativity	hwloc_obj, 178
hwloc_obj_attr_u::hwloc_cache_attr_s, 172	Components and Plugins: Core functions to be used b
attr	components, 146
hwloc_obj, 178	•
	hwlocinsert_object_by_cpuset, 146
bind_membind	hwloc_alloc_setup_object, 146 hwloc fill object sets, 146
hwloc_topology_membind_support, 193	,
bridge	hwloc_hide_errors, 146
hwloc_obj_attr_u, 182	hwloc_insert_object_by_cpuset, 146
Building Custom Topologies, 103	hwloc_insert_object_by_parent, 147
hwloc_custom_insert_group_object_by_parent, 103	hwloc_plugin_check_namespace, 147
hwloc_custom_insert_topology, 103	hwloc_report_error_t, 146
bus	hwloc_report_os_error, 147
hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185	Components and Plugins: Discovery backends, 143 HWLOC_BACKEND_FLAG_NEED_LEVELS, 143
CPU and node sets of entire topologies, 120	hwloc_backend_alloc, 143
hwloc_topology_get_allowed_cpuset, 120	hwloc_backend_enable, 143
hwloc_topology_get_allowed_nodeset, 120	hwloc_backend_flag_e, 143
hwloc_topology_get_complete_cpuset, 120	hwloc_backends_get_obj_cpuset, 143
hwloc_topology_get_complete_nodeset, 121	hwloc_backends_notify_new_object, 143
hwloc_topology_get_online_cpuset, 121	Components and Plugins: Discovery components, 142
hwloc_topology_get_topology_cpuset, 121	HWLOC_DISC_COMPONENT_TYPE_CPU, 142
hwloc_topology_get_topology_nodeset, 122	HWLOC_DISC_COMPONENT_TYPE_GLOBA←
CPU binding, 88	L, 142
HWLOC_CPUBIND_NOMEMBIND, 89	HWLOC_DISC_COMPONENT_TYPE_MISC, 142
HWLOC CPUBIND PROCESS, 89	hwloc_disc_component_type_e, 142
HWLOC CPUBIND STRICT, 89	hwloc_disc_component_type_t, 142
HWLOC_CPUBIND_THREAD, 89	Components and Plugins: Generic components, 145
hwloc_cpubind_flags_t, 89	HWLOC COMPONENT TYPE DISC, 145
hwloc get cpubind, 89	HWLOC_COMPONENT_TYPE_XML, 145
hwloc_get_last_cpu_location, 89	hwloc_component_type_e, 145
hwloc get proc coubind, 90	hwloc component type t. 145

Components and Plugins: PCI functions to be used by components, 148	excludes hwloc_disc_component, 174
hwloc insert pci device list, 148	Exporting Topologies to Synthetic, 108
hwloc_pci_find_cap, 148	HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_F↔
hwloc_pci_find_linkspeed, 148	LAG_NO_ATTRS, 108
·	HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_F↔
hwloc_pci_prepare_bridge, 148	
Converting between CPU sets and node sets, 123	LAG_NO_EXTENDED_TYPES, 108
hwloc_cpuset_from_nodeset, 123	hwloc_topology_export_synthetic, 108
hwloc_cpuset_from_nodeset_strict, 123	hwloc_topology_export_synthetic_flags_e, 108
hwloc_cpuset_to_nodeset, 123	Exporting Topologies to XML, 105
hwloc_cpuset_to_nodeset_strict, 123	hwloc_export_obj_userdata, 105
count	hwloc_export_obj_userdata_base64, 105
hwloc_obj_memory_s::hwloc_obj_memory_page_	hwloc_free_xmlbuffer, 105
type_s, 183	hwloc_topology_export_xml, 106
cpubind	hwloc_topology_export_xmlbuffer, 106
hwloc_topology_support, 195	hwloc_topology_set_userdata_export_callback, 106
cpuset	hwloc_topology_set_userdata_import_callback, 107
hwloc_obj, 178	
	finalize
data	hwloc_component, 173
hwloc_component, 173	Finding I/O objects, 127
depth	hwloc_bridge_covers_pcibus, 127
hwloc_obj, 179	hwloc_get_hostbridge_by_pcibus, 127
hwloc_obj_attr_u::hwloc_bridge_attr_s, 171	hwloc_get_next_bridge, 127
hwloc_obj_attr_u::hwloc_cache_attr_s, 172	hwloc_get_next_osdev, 127
hwloc_obj_attr_u::hwloc_group_attr_s, 176	hwloc_get_next_pcidev, 127
dev	hwloc_get_non_io_ancestor_obj, 128
hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185	hwloc_get_pcidev_by_busid, 128
device_id	hwloc_get_pcidev_by_busidstring, 128
hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185	Finding Objects covering at least CPU set, 112
diff	hwloc_get_child_covering_cpuset, 112
hwloc_topology_diff_u::hwloc_topology_diff_obj_ ←	hwloc_get_next_obj_covering_cpuset_by_depth, 112
attr_s, 188	hwloc_get_next_obj_covering_cpuset_by_type, 112
disable	hwloc_get_obj_covering_cpuset, 113
hwloc_backend, 169	Finding Objects inside a CPU set, 109
discover	hwloc_get_first_largest_obj_inside_cpuset, 109
hwloc_backend, 169	hwloc_get_largest_objs_inside_cpuset, 109
discovery	hwloc_get_nbobjs_inside_cpuset_by_depth, 110
hwloc_topology_support, 195	hwloc_get_nbobjs_inside_cpuset_by_type, 110
distances	hwloc_get_nsobjs_mside_cpuset_by_depth, 110
hwloc_obj, 179	hwloc_get_next_obj_inside_cpuset_by_type, 110
distances_count	hwloc_get_obj_index_inside_cpuset, 111
hwloc_obj, 179	hwloc_get_obj_inside_cpuset_by_depth, 111
Distributing items over a topology, 119	hwloc get obj inside cpuset by type, 111
HWLOC_DISTRIB_FLAG_REVERSE, 119	Finding objects, miscellaneous helpers, 117
hwloc distrib, 119	hwloc_get_closest_objs, 117
-	
hwloc_distrib_flags_e, 119	hwloc_get_numanode_obj_by_os_index, 117
domain	hwloc_get_obj_below_array_by_type, 117
hwloc_obj_attr_u::hwloc_bridge_attr_s, 171	hwloc_get_obj_below_by_type, 118
hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185	hwloc_get_pu_obj_by_os_index, 118
downstream	first_child
hwloc_obj_attr_u::hwloc_bridge_attr_s, 171	hwloc_obj, 179
downstream_type	firsttouch_membind
hwloc_obj_attr_u::hwloc_bridge_attr_s, 171	hwloc_topology_membind_support, 193

flags	Components and Plugins: Discovery components,
hwloc_backend, 170	142
hwloc_component, 173	HWLOC_DISC_COMPONENT_TYPE_GLOBAL
func	Components and Plugins: Discovery components,
hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185	142
	HWLOC_DISC_COMPONENT_TYPE_MISC
generic	Components and Plugins: Discovery components,
hwloc_topology_diff_obj_attr_u, 190	142
hwloc_topology_diff_u, 192	HWLOC_DISTRIB_FLAG_REVERSE
get_area_membind	Distributing items over a topology, 119
hwloc_topology_membind_support, 193	HWLOC MEMBIND BIND
get_obj_cpuset	Memory binding, 94
hwloc_backend, 170	HWLOC_MEMBIND_DEFAULT
get_proc_cpubind	Memory binding, 94
hwloc_topology_cpubind_support, 186	HWLOC_MEMBIND_FIRSTTOUCH
get_proc_last_cpu_location	Memory binding, 94
hwloc_topology_cpubind_support, 186	HWLOC MEMBIND INTERLEAVE
get_proc_membind	Memory binding, 94
hwloc_topology_membind_support, 193	HWLOC_MEMBIND_MIGRATE
get_thisproc_cpubind	Memory binding, 94
hwloc_topology_cpubind_support, 186	HWLOC_MEMBIND_MIXED
get_thisproc_last_cpu_location	Memory binding, 95
hwloc_topology_cpubind_support, 186	HWLOC_MEMBIND_NEXTTOUCH
get_thisproc_membind	
hwloc_topology_membind_support, 193	Memory binding, 94
get_thisthread_cpubind	HWLOC_MEMBIND_NOCPUBIND
hwloc_topology_cpubind_support, 187	Memory binding, 94
get_thisthread_last_cpu_location	HWLOC_MEMBIND_PROCESS
hwloc_topology_cpubind_support, 187	Memory binding, 94
get_thisthread_membind	HWLOC_MEMBIND_REPLICATE
hwloc_topology_membind_support, 193	Memory binding, 94
get_thread_cpubind	HWLOC_MEMBIND_STRICT
hwloc_topology_cpubind_support, 187	Memory binding, 94
group	HWLOC_MEMBIND_THREAD
hwloc_obj_attr_u, 182	Memory binding, 94
<u>-</u> <u>-</u>	HWLOC_OBJ_BRIDGE
HWLOC_API_VERSION	Object Types, 71
API version, 67	HWLOC_OBJ_BRIDGE_HOST
HWLOC_BACKEND_FLAG_NEED_LEVELS	Object Types, 70
Components and Plugins: Discovery backends, 143	HWLOC_OBJ_BRIDGE_PCI
HWLOC_COMPONENT_ABI	Object Types, 70
API version, 67	HWLOC_OBJ_CACHE
HWLOC_COMPONENT_TYPE_DISC	Object Types, 71
Components and Plugins: Generic components, 145	HWLOC_OBJ_CACHE_DATA
HWLOC_COMPONENT_TYPE_XML	Object Types, 70
Components and Plugins: Generic components, 145	HWLOC_OBJ_CACHE_INSTRUCTION
HWLOC_CPUBIND_NOMEMBIND	Object Types, 70
CPU binding, 89	HWLOC_OBJ_CACHE_UNIFIED
HWLOC_CPUBIND_PROCESS	Object Types, 70
CPU binding, 89	HWLOC_OBJ_CORE
HWLOC_CPUBIND_STRICT	Object Types, 71
CPU binding, 89	HWLOC_OBJ_GROUP
HWLOC_CPUBIND_THREAD	Object Types, 71
CPU binding, 89	HWLOC_OBJ_MACHINE
HWLOC_DISC_COMPONENT_TYPE_CPU	Object Types, 71

HWLOC_OBJ_MISC	HWLOC_TOPOLOGY_FLAG_IO_BRIDGES
Object Types, 71	Topology Detection Configuration and Query, 77
HWLOC_OBJ_NUMANODE	HWLOC_TOPOLOGY_FLAG_IO_DEVICES
Object Types, 71	Topology Detection Configuration and Query, 77
HWLOC_OBJ_OS_DEVICE	HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM
Object Types, 71	Topology Detection Configuration and Query, 77
HWLOC_OBJ_OSDEV_BLOCK	HWLOC_TOPOLOGY_FLAG_WHOLE_IO
Object Types, 70	Topology Detection Configuration and Query, 77
HWLOC_OBJ_OSDEV_COPROC	HWLOC_TOPOLOGY_FLAG_WHOLE_SYSTEM
Object Types, 70	Topology Detection Configuration and Query, 77
HWLOC_OBJ_OSDEV_DMA	HWLOC_TYPE_DEPTH_BRIDGE
Object Types, 70	Object levels, depths and types, 82
HWLOC_OBJ_OSDEV_GPU	HWLOC_TYPE_DEPTH_MULTIPLE
Object Types, 70	Object levels, depths and types, 82
HWLOC_OBJ_OSDEV_NETWORK	HWLOC_TYPE_DEPTH_OS_DEVICE
Object Types, 70	Object levels, depths and types, 82
HWLOC_OBJ_OSDEV_OPENFABRICS	HWLOC_TYPE_DEPTH_PCI_DEVICE
Object Types, 70	Object levels, depths and types, 82
HWLOC_OBJ_PACKAGE	HWLOC_TYPE_DEPTH_UNKNOWN
Object Types, 71	Object levels, depths and types, 82
HWLOC_OBJ_PCI_DEVICE	HWLOC_TYPE_UNORDERED
Object Types, 71	Object Types, 70
HWLOC_OBJ_PU	hwlocinsert_object_by_cpuset
Object Types, 71	Components and Plugins: Core functions to be used
HWLOC_OBJ_SYSTEM	by components, 146
Object Types, 71	hwloc_alloc
HWLOC_OBJ_TYPE_MAX	Memory binding, 95
Object Types, 71	hwloc_alloc_membind
HWLOC_RESTRICT_FLAG_ADAPT_DISTANCES	Memory binding, 95
Modifying a loaded Topology, 101	hwloc_alloc_membind_nodeset
HWLOC_RESTRICT_FLAG_ADAPT_IO	Memory binding, 95
Modifying a loaded Topology, 101	hwloc_alloc_membind_policy
HWLOC_RESTRICT_FLAG_ADAPT_MISC	Memory binding, 95
Modifying a loaded Topology, 101	hwloc_alloc_membind_policy_nodeset
HWLOC_TOPOLOGY_DIFF_APPLY_REVERSE	Memory binding, 96
Topology differences, 138	hwloc_alloc_setup_object
HWLOC_TOPOLOGY_DIFF_OBJ_ATTR	Components and Plugins: Core functions to be used
Topology differences, 139	by components, 146
HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_INFO	hwloc_backend, 169
Topology differences, 138	disable, 169
HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_NAME	discover, 169
Topology differences, 138	flags, 170
HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_SIZE	get_obj_cpuset, 170
Topology differences, 138	is_custom, 170
HWLOC_TOPOLOGY_DIFF_TOO_COMPLEX	is_thissystem, 170
Topology differences, 139	notify_new_object, 170
HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_FLAG_←	private_data, 170
NO_ATTRS	hwloc_backend_alloc
Exporting Topologies to Synthetic, 108	Components and Plugins: Discovery backends, 143
HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_FLAG_←	hwloc_backend_enable
NO_EXTENDED_TYPES	Components and Plugins: Discovery backends, 143
Exporting Topologies to Synthetic, 108	hwloc_backend_flag_e
HWLOC_TOPOLOGY_FLAG_ICACHES	Components and Plugins: Discovery backends, 143
Topology Detection Configuration and Query, 77	hwloc_backends_get_obj_cpuset

Organization and Physics a Pierce and backgrounds 440	The bitmen ADI 400
Components and Plugins: Discovery backends, 143	The bitmap API, 133
hwloc_backends_notify_new_object	hwloc_bitmap_list_asprintf
Components and Plugins: Discovery backends, 143	The bitmap API, 133
hwloc_bitmap_allbut	hwloc_bitmap_list_snprintf
The bitmap API, 131	The bitmap API, 133
hwloc_bitmap_alloc	hwloc_bitmap_list_sscanf
The bitmap API, 131	The bitmap API, 134
hwloc_bitmap_alloc_full	hwloc_bitmap_next
The bitmap API, 131	The bitmap API, 134
hwloc_bitmap_and	hwloc_bitmap_not
The bitmap API, 131	The bitmap API, 134
hwloc_bitmap_andnot	hwloc bitmap only
The bitmap API, 131	The bitmap API, 134
hwloc_bitmap_asprintf	hwloc_bitmap_or
The bitmap API, 131	The bitmap API, 134
hwloc_bitmap_clr	hwloc_bitmap_set
The bitmap API, 131	The bitmap API, 134
•	hwloc bitmap set ith ulong
hwloc_bitmap_clr_range	
The bitmap API, 131	The bitmap API, 134
hwloc_bitmap_compare	hwloc_bitmap_set_range
The bitmap API, 132	The bitmap API, 135
hwloc_bitmap_compare_first	hwloc_bitmap_singlify
The bitmap API, 132	The bitmap API, 135
hwloc_bitmap_copy	hwloc_bitmap_snprintf
The bitmap API, 132	The bitmap API, 135
hwloc_bitmap_dup	hwloc_bitmap_sscanf
The bitmap API, 132	The bitmap API, 135
hwloc_bitmap_fill	hwloc_bitmap_t
The bitmap API, 132	The bitmap API, 130
hwloc_bitmap_first	hwloc_bitmap_taskset_asprintf
The bitmap API, 132	The bitmap API, 135
hwloc_bitmap_foreach_begin	hwloc_bitmap_taskset_snprintf
The bitmap API, 130	The bitmap API, 135
hwloc_bitmap_foreach_end	hwloc_bitmap_taskset_sscanf
The bitmap API, 130	The bitmap API, 135
hwloc_bitmap_free	hwloc_bitmap_to_ith_ulong
The bitmap API, 132	The bitmap API, 136
hwloc_bitmap_from_ith_ulong	hwloc_bitmap_to_ulong
The bitmap API, 132	The bitmap API, 136
hwloc_bitmap_from_ulong	hwloc_bitmap_weight
The bitmap API, 133	The bitmap API, 136
hwloc_bitmap_intersects	hwloc_bitmap_xor
The bitmap API, 133	The bitmap API, 136
hwloc_bitmap_isequal	hwloc_bitmap_zero
The bitmap API, 133	The bitmap API, 136
hwloc_bitmap_isfull	hwloc_bridge_covers_pcibus
The bitmap API, 133	Finding I/O objects, 127
hwloc_bitmap_isincluded	hwloc_compare_types
The bitmap API, 133	Object Types, 71
hwloc_bitmap_isset	hwloc_compare_types_e
The bitmap API, 133	Object Types, 70
hwloc_bitmap_iszero	hwloc_component, 172
The bitmap API, 133	abi, 173
hwloc_bitmap_last	data, 173

finalize, 173 flags, 173 flags, 173 init, 173 type, 173 hwloc_component_type_e Components and Plugins: Generic components, 145 hwloc_component_type_t Components and Plugins: Generic components, 145 hwloc_const_bitmap_t The bitmap API, 130 hwloc_const_cpuset_t Interoperability with the CUDA Runtime API, 159 hwloc_cudart_get_device_pci_ids Interoperability with the CUDA Runtime API, 159 hwloc_cudart_get_device_pcidev Interoperability with the CUDA Runtime API, 159 hwloc_cudart_get_device_pci_ids Interoperability with the CUD	
init, 173 type, 173 hwloc_component_type_e Components and Plugins: Generic components, 145 hwloc_component_type_t Components and Plugins: Generic components, 145 hwloc_components and Plugins: Generic components, 145 hwloc_const_bitmap_t The bitmap API, 130 hwloc_const_cpuset_t Interoperability with the CUDA Runtime API, 159 hwloc_cudart_get_device_pcidev Interoperability with the CUDA Runtime API, 159 hwloc_custom_insert_group_object_by_parent Building Custom Topologies, 103 hwloc_custom_insert_topology Building Custom Topologies, 103	
type, 173 hwloc_cudart_get_device_pci_ids hwloc_component_type_e Components and Plugins: Generic components, 145 hwloc_component_type_t Components and Plugins: Generic components, 145 hwloc_const_bitmap_t The bitmap API, 130 hwloc_cudart_get_device_pci_ids Interoperability with the CUDA Runtime API, 159 hwloc_cudart_get_device_pci_dev Interoperability with the CUDA Runtime API, 159 hwloc_custom_insert_group_object_by_parent Building Custom Topologies, 103 hwloc_custom_insert_topology Building Custom Topologies, 103	
hwloc_component_type_e	
Components and Plugins: Generic components, 145 hwloc_component_type_t Interoperability with the CUDA Runtime API, 159 Components and Plugins: Generic components, 145 hwloc_const_bitmap_t Building Custom Topologies, 103 hwloc_const_cpuset_t Building Custom Topologies, 103	
hwloc_component_type_t Interoperability with the CUDA Runtime API, 159 Components and Plugins: Generic components, 145 hwloc_const_bitmap_t Building Custom Topologies, 103 The bitmap API, 130 hwloc_custom_insert_topology hwloc_const_cpuset_t Building Custom Topologies, 103	
Components and Plugins: Generic components, 145 hwloc_const_bitmap_t The bitmap API, 130 hwloc_const_cpuset_t hwloc_custom_insert_group_object_by_parent Building Custom Topologies, 103 hwloc_custom_insert_topology Building Custom Topologies, 103	
hwloc_const_bitmap_t Building Custom Topologies, 103 The bitmap API, 130 hwloc_custom_insert_topology hwloc_const_cpuset_t Building Custom Topologies, 103	
The bitmap API, 130 hwloc_custom_insert_topology hwloc_const_cpuset_t Building Custom Topologies, 103	
hwloc_const_cpuset_t Building Custom Topologies, 103	
Object Sets (hwloc_cpuset_t and hwloc_nodeset_t), hwloc_disc_component, 174	
68 excludes, 174	
hwloc_const_nodeset_t instantiate, 174	
Object Sets (hwloc_cpuset_t and hwloc_nodeset_t), name, 174	
68 priority, 174	
hwloc_cpubind_flags_t type, 175	
CPU binding, 89 hwloc_disc_component_type_e	
hwloc_cpuset_from_glibc_sched_affinity	ıts,
Interoperability with glibc sched affinity, 154 142	
hwloc_cpuset_from_linux_libnuma_bitmask	
Interoperability with Linux libnuma bitmask, 152 Components and Plugins: Discovery componer	ıts,
hwloc cpuset from linux libnuma ulongs 142	
Interoperability with Linux libnuma unsigned long hwloc_distances_s, 175	
masks, 150 latency, 175	
hwloc_cpuset_from_nodeset latency_base, 175	
Converting between CPU sets and node sets, 123 latency_max, 176	
hwloc_cpuset_from_nodeset_strict nbobjs, 176	
Converting between CPU sets and node sets, 123 relative_depth, 176	
hwloc_cpuset_t hwloc_distrib	
Object Sets (hwloc_cpuset_t and hwloc_nodeset_t), Distributing items over a topology, 119	
hwloc_cpuset_to_glibc_sched_affinity Distributing items over a topology, 119 Interoperability with glibc sched affinity, 154 hwloc export obj userdata	
hwloc_cpuset_to_linux_libnuma_bitmask Exporting Topologies to XML, 105	
Interoperability with Linux libnuma bitmask, 152 hwloc_export_obj_userdata_base64	
hwloc_cpuset_to_linux_libnuma_ulongs Exporting Topologies to XML, 105	
Interoperability with Linux libnuma unsigned long hwloc_fill_object_sets	
masks, 150 Components and Plugins: Core functions to be us	ed
hwloc_cpuset_to_nodeset by components, 146	
Converting between CPU sets and node sets, 123 hwloc_free	
hwloc_cpuset_to_nodeset_strict Memory binding, 96	
Converting between CPU sets and node sets, 123 hwloc_free_xmlbuffer	
hwloc_cuda_get_device_cpuset Exporting Topologies to XML, 105	
Interoperability with the CUDA Driver API, 157 hwloc_get_ancestor_obj_by_depth	
hwloc_cuda_get_device_osdev Looking at Ancestor and Child Objects, 114	
Interoperability with the CUDA Driver API, 157 hwloc_get_ancestor_obj_by_type	
budge and and desire and the index	
nwioc cuda det device osdev by index Looking at Ancestor and Uniid Objects, 114	
hwloc_cuda_get_device_osdev_by_index Looking at Ancestor and Child Objects, 114 Interoperability with the CUDA Driver API, 157 hwloc get api version	
Interoperability with the CUDA Driver API, 157 hwloc_get_api_version	
Interoperability with the CUDA Driver API, 157 hwloc_get_api_version hwloc_cuda_get_device_pci_ids API version, 67	
Interoperability with the CUDA Driver API, 157 hwloc_get_api_version hwloc_cuda_get_device_pci_ids Interoperability with the CUDA Driver API, 158 API version, 67 hwloc_get_area_membind	
Interoperability with the CUDA Driver API, 157 hwloc_get_api_version hwloc_cuda_get_device_pci_ids API version, 67	

hwloc_get_cache_covering_cpuset	hwloc_get_next_osdev
Looking at Cache Objects, 116	Finding I/O objects, 127
hwloc_get_cache_type_depth	hwloc_get_next_pcidev
Looking at Cache Objects, 116	Finding I/O objects, 127
hwloc_get_child_covering_cpuset	hwloc_get_non_io_ancestor_obj
Finding Objects covering at least CPU set, 112	Finding I/O objects, 128
hwloc_get_closest_objs	hwloc_get_numanode_obj_by_os_index
Finding objects, miscellaneous helpers, 117	Finding objects, miscellaneous helpers, 117
hwloc_get_common_ancestor_obj	hwloc_get_obj_below_array_by_type
Looking at Ancestor and Child Objects, 114	Finding objects, miscellaneous helpers, 117
hwloc_get_cpubind	hwloc_get_obj_below_by_type
CPU binding, 89	Finding objects, miscellaneous helpers, 118
hwloc_get_depth_type	hwloc_get_obj_by_depth
Object levels, depths and types, 82	Object levels, depths and types, 83
hwloc_get_distance_matrix_covering_obj_by_depth	hwloc_get_obj_by_type
Manipulating Distances, 125	Object levels, depths and types, 83
hwloc_get_first_largest_obj_inside_cpuset	hwloc_get_obj_covering_cpuset
Finding Objects inside a CPU set, 109	Finding Objects covering at least CPU set, 113
hwloc_get_hostbridge_by_pcibus	hwloc_get_obj_index_inside_cpuset
Finding I/O objects, 127	Finding Objects inside a CPU set, 111
hwloc_get_largest_objs_inside_cpuset	hwloc_get_obj_inside_cpuset_by_depth
Finding Objects inside a CPU set, 109	Finding Objects inside a CPU set, 111
hwloc_get_last_cpu_location	hwloc_get_obj_inside_cpuset_by_type
CPU binding, 89	Finding Objects inside a CPU set, 111
hwloc_get_latency	hwloc_get_pcidev_by_busid
Manipulating Distances, 125	Finding I/O objects, 128
hwloc_get_membind	hwloc_get_pcidev_by_busidstring
Memory binding, 96	Finding I/O objects, 128
hwloc_get_membind_nodeset	hwloc_get_proc_cpubind
Memory binding, 97	CPU binding, 90
hwloc_get_nbobjs_by_depth	hwloc_get_proc_last_cpu_location
Object levels, depths and types, 83	CPU binding, 90
hwloc_get_nbobjs_by_type	hwloc_get_proc_membind
Object levels, depths and types, 83	Memory binding, 97
hwloc_get_nbobjs_inside_cpuset_by_depth	hwloc_get_proc_membind_nodeset
Finding Objects inside a CPU set, 110	Memory binding, 98
hwloc_get_nbobjs_inside_cpuset_by_type	hwloc_get_pu_obj_by_os_index
Finding Objects inside a CPU set, 110	Finding objects, miscellaneous helpers, 118
hwloc_get_next_bridge	hwloc_get_root_obj
Finding I/O objects, 127	Object levels, depths and types, 83
hwloc_get_next_child	hwloc_get_shared_cache_covering_obj
Looking at Ancestor and Child Objects, 114	Looking at Cache Objects, 116
hwloc_get_next_obj_by_depth	hwloc_get_thread_cpubind
Object levels, depths and types, 83	CPU binding, 90
hwloc_get_next_obj_by_type	hwloc_get_type_depth
Object levels, depths and types, 83	Object levels, depths and types, 83
hwloc_get_next_obj_covering_cpuset_by_depth	hwloc_get_type_depth_e
Finding Objects covering at least CPU set, 112	Object levels, depths and types, 82
hwloc_get_next_obj_covering_cpuset_by_type	hwloc_get_type_or_above_depth
Finding Objects covering at least CPU set, 112	Object levels, depths and types, 84
hwloc_get_next_obj_inside_cpuset_by_depth	hwloc_get_type_or_below_depth
Finding Objects inside a CPU set, 110	Object levels, depths and types, 84
hwloc_get_next_obj_inside_cpuset_by_type	hwloc_get_whole_distance_matrix_by_depth
Finding Objects inside a CPU set, 110	Manipulating Distances, 125

hwloc_get_whole_distance_matrix_by_type	hwloc_nodeset_to_linux_libnuma_bitmask
Manipulating Distances, 126	Interoperability with Linux libnuma bitmask, 153
hwloc_gl_get_display_by_osdev	hwloc_nodeset_to_linux_libnuma_ulongs
Interoperability with OpenGL displays, 163	Interoperability with Linux libnuma unsigned long
hwloc_gl_get_display_osdev_by_name	masks, 151
Interoperability with OpenGL displays, 163	hwloc_nvml_get_device_cpuset
hwloc_gl_get_display_osdev_by_port_device	Interoperability with the NVIDIA Management Library,
Interoperability with OpenGL displays, 163	161
hwloc_hide_errors	hwloc_nvml_get_device_osdev
Components and Plugins: Core functions to be used	Interoperability with the NVIDIA Management Library,
by components, 146	161
hwloc_ibv_get_device_cpuset	hwloc_nvml_get_device_osdev_by_index
Interoperability with OpenFabrics, 166	Interoperability with the NVIDIA Management Library,
hwloc_ibv_get_device_osdev	161
Interoperability with OpenFabrics, 166	hwloc_obj, 176
hwloc_ibv_get_device_osdev_by_name	allowed_cpuset, 177
Interoperability with OpenFabrics, 166	allowed_nodeset, 177
hwloc_insert_object_by_cpuset	arity, 178
Components and Plugins: Core functions to be used	attr, 178
by components, 146	children, 178
hwloc_insert_object_by_parent	complete_cpuset, 178
Components and Plugins: Core functions to be used	complete_nodeset, 178
by components, 147	cpuset, 178
hwloc_insert_pci_device_list	depth, 179
Components and Plugins: PCI functions to be used	distances, 179
by components, 148	distances_count, 179
hwloc_intel_mic_get_device_cpuset	first_child, 179
Interoperability with Intel Xeon Phi (MIC), 165	infos, 179
hwloc_intel_mic_get_device_osdev_by_index	infos_count, 179
Interoperability with Intel Xeon Phi (MIC), 165	last_child, 179
hwloc_linux_get_tid_cpubind	logical_index, 179
Linux-specific helpers, 149	memory, 179
hwloc_linux_get_tid_last_cpu_location	name, 179
Linux-specific helpers, 149	next_cousin, 180
hwloc_linux_parse_cpumap_file	next_sibling, 180
Linux-specific helpers, 149	nodeset, 180
hwloc_linux_set_tid_cpubind	online_cpuset, 180
Linux-specific helpers, 149	os_index, 180
hwloc_membind_flags_t	os_level, 180
Memory binding, 93	parent, 180
hwloc_membind_policy_t	prev_cousin, 181
Memory binding, 94	prev_sibling, 181
hwloc_mx_board_get_device_cpuset	sibling_rank, 181
Interoperability with Myrinet Express, 168	symmetric_subtree, 181
hwloc_mx_endpoint_get_device_cpuset	type, 181
Interoperability with Myrinet Express, 168	userdata, 181
hwloc_nodeset_from_linux_libnuma_bitmask	hwloc_obj_add_info
Interoperability with Linux libnuma bitmask, 152	Manipulating Object Type, Sets and Attributes as
hwloc_nodeset_from_linux_libnuma_ulongs	Strings, 85
Interoperability with Linux libnuma unsigned long	hwloc_obj_attr_snprintf
masks, 150	Manipulating Object Type, Sets and Attributes as
hwloc_nodeset_t	Strings, 85
Object Sets (hwloc_cpuset_t and hwloc_nodeset_t),	hwloc_obj_attr_u, 181
68	bridge, 182

cache, 182	Looking at Ancestor and Child Objects, 114
group, 182	hwloc_obj_memory_s, 183
osdev, 182	local_memory, 184
pcidev, 182	page_types, 184
hwloc_obj_attr_u::hwloc_bridge_attr_s, 170	page_types_len, 184
depth, 171	total_memory, 184
domain, 171	hwloc_obj_memory_s::hwloc_obj_memory_page_type <-
downstream, 171	_s, 183
downstream_type, 171	count, 183
pci, 171	size, 183
secondary_bus, 171	hwloc_obj_osdev_type_e
subordinate_bus, 171	Object Types, 70
upstream, 171	hwloc_obj_osdev_type_t
upstream_type, 171	Object Types, 69
hwloc_obj_attr_u::hwloc_cache_attr_s, 171	hwloc_obj_t
associativity, 172	Object Structure and Attributes, 73
depth, 172	hwloc_obj_type_snprintf
linesize, 172	Manipulating Object Type, Sets and Attributes as
size, 172	Strings, 86
type, 172	
hwloc_obj_attr_u::hwloc_group_attr_s, 176	hwloc_obj_type_sscanf
_ -	Manipulating Object Type, Sets and Attributes as Strings, 86
depth, 176	
hwloc_obj_attr_u::hwloc_osdev_attr_s, 184	hwloc_obj_type_string
type, 185	Manipulating Object Type, Sets and Attributes as
hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185	Strings, 86
bus, 185	hwloc_obj_type_t
class_id, 185	Object Types, 70
dev, 185	hwloc_opencl_get_device_cpuset
device_id, 185	Interoperability with OpenCL, 155
domain, 185	hwloc_opencl_get_device_osdev
func, 185	Interoperability with OpenCL, 155
linkspeed, 185	hwloc_opencl_get_device_osdev_by_index
revision, 185	Interoperability with OpenCL, 155
subdevice_id, 185	hwloc_pci_find_cap
subvendor_id, 186	Components and Plugins: PCI functions to be used
vendor_id, 186	by components, 148
hwloc_obj_bridge_type_e	hwloc_pci_find_linkspeed
Object Types, 70	Components and Plugins: PCI functions to be used
hwloc_obj_bridge_type_t	by components, 148
Object Types, 69	hwloc_pci_prepare_bridge
hwloc_obj_cache_type_e	Components and Plugins: PCI functions to be used
Object Types, 70	by components, 148
hwloc_obj_cache_type_t	hwloc_plugin_check_namespace
Object Types, 69	Components and Plugins: Core functions to be used
hwloc_obj_cpuset_snprintf	by components, 147
Manipulating Object Type, Sets and Attributes as	hwloc_report_error_t
Strings, 85	Components and Plugins: Core functions to be used
hwloc_obj_get_info_by_name	by components, 146
Manipulating Object Type, Sets and Attributes as	hwloc_report_os_error
Strings, 86	Components and Plugins: Core functions to be used
hwloc_obj_info_s, 182	by components, 147
	• • •
name, 182	hwloc_restrict_flags_e
value, 182	Modifying a loaded Topology, 101
hwloc_obj_is_in_subtree	hwloc_set_area_membind

Mamary hinding 00	ganaria 100
Memory binding, 98	generic, 190
hwloc_set_area_membind_nodeset	string, 190
Memory binding, 99	uint64, 190
hwloc_set_cpubind	hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_←
CPU binding, 90	obj_attr_generic_s, 188
hwloc_set_membind	type, 188
Memory binding, 99	hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_←
hwloc_set_membind_nodeset	obj_attr_string_s, 189
Memory binding, 99	name, 189
hwloc_set_proc_cpubind	newvalue, 189
CPU binding, 90	oldvalue, 189
hwloc_set_proc_membind	type, 189
Memory binding, 99	hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_
hwloc_set_proc_membind_nodeset	obj_attr_uint64_s, 190
Memory binding, 100	index, 191
hwloc_set_thread_cpubind	newvalue, 191
CPU binding, 91	oldvalue, 191
hwloc_topology_check	type, 191
Topology Creation and Destruction, 74	hwloc_topology_diff_t
hwloc_topology_cpubind_support, 186	Topology differences, 138
get_proc_cpubind, 186	hwloc_topology_diff_type_e
get_proc_last_cpu_location, 186	Topology differences, 138
get_thisproc_cpubind, 186	hwloc_topology_diff_type_t
get_thisproc_last_cpu_location, 186	Topology differences, 138
get_thisthread_cpubind, 187	hwloc_topology_diff_u, 191
get_thisthread_last_cpu_location, 187	generic, 192
get_thread_cpubind, 187	obj_attr, 192
set_proc_cpubind, 187	too_complex, 192
set_thisproc_cpubind, 187	hwloc_topology_diff_u::hwloc_topology_diff_generic_s,
set_thisthread_cpubind, 187	187
set_thread_cpubind, 187	next, 188
hwloc_topology_destroy	type, 188
Topology Creation and Destruction, 74	hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s,
hwloc_topology_diff_apply	188
Topology differences, 139	diff, 188
hwloc_topology_diff_apply_flags_e	next, 188
Topology differences, 138	obj_depth, 188
hwloc_topology_diff_build	obj_index, 189
Topology differences, 139	type, 189
hwloc_topology_diff_destroy	hwloc_topology_diff_u::hwloc_topology_diff_too_←
Topology differences, 139	complex_s, 191
hwloc_topology_diff_export_xml	next, 191
Topology differences, 140	obj_depth, 191
hwloc_topology_diff_export_xmlbuffer	obj_index, 191
Topology differences, 140	type, 191
hwloc_topology_diff_load_xml	hwloc_topology_discovery_support, 192
Topology differences, 140	pu, 192
hwloc_topology_diff_load_xmlbuffer	hwloc_topology_dup
Topology differences, 140	Topology Creation and Destruction, 75
hwloc_topology_diff_obj_attr_type_e	hwloc_topology_export_synthetic
Topology differences, 138	Exporting Topologies to Synthetic, 108
hwloc_topology_diff_obj_attr_type_t	hwloc_topology_export_synthetic_flags_e
Topology differences, 138	Exporting Topologies to Synthetic, 108
hwloc_topology_diff_obj_attr_u, 189	hwloc_topology_export_xml

Exporting Topologies to XML, 106	replicate_membind, 194
hwloc_topology_export_xmlbuffer	set_area_membind, 194
Exporting Topologies to XML, 106	set_proc_membind, 194
hwloc_topology_flags_e	set_thisproc_membind, 194
Topology Detection Configuration and Query, 77	set_thisthread_membind, 194
hwloc_topology_get_allowed_cpuset	hwloc_topology_restrict
CPU and node sets of entire topologies, 120	Modifying a loaded Topology, 102
hwloc_topology_get_allowed_nodeset	hwloc_topology_set_custom
CPU and node sets of entire topologies, 120	Topology Detection Configuration and Query, 78
hwloc_topology_get_complete_cpuset	hwloc_topology_set_distance_matrix
CPU and node sets of entire topologies, 120	Topology Detection Configuration and Query, 78
hwloc_topology_get_complete_nodeset	hwloc_topology_set_flags
CPU and node sets of entire topologies, 121	Topology Detection Configuration and Query, 79
hwloc_topology_get_depth	hwloc_topology_set_fsroot
Object levels, depths and types, 84	Topology Detection Configuration and Query, 79
hwloc_topology_get_flags	hwloc_topology_set_pid
Topology Detection Configuration and Query, 77	Topology Detection Configuration and Query, 79
hwloc_topology_get_online_cpuset	hwloc_topology_set_synthetic
CPU and node sets of entire topologies, 121	Topology Detection Configuration and Query, 80
hwloc_topology_get_support	hwloc_topology_set_userdata
Topology Detection Configuration and Query, 77	Topology Detection Configuration and Query, 80
hwloc_topology_get_topology_cpuset	hwloc_topology_set_userdata_export_callback
CPU and node sets of entire topologies, 121	Exporting Topologies to XML, 106
hwloc_topology_get_topology_nodeset	hwloc_topology_set_userdata_import_callback
CPU and node sets of entire topologies, 122	Exporting Topologies to XML, 107
hwloc_topology_get_userdata	hwloc_topology_set_xml
Topology Detection Configuration and Query, 77	Topology Detection Configuration and Query, 80
hwloc_topology_ignore_all_keep_structure	hwloc_topology_set_xmlbuffer
Topology Detection Configuration and Query, 78	Topology Detection Configuration and Query, 81
hwloc_topology_ignore_type	hwloc_topology_support, 194
Topology Detection Configuration and Query, 78	cpubind, 195
hwloc_topology_ignore_type_keep_structure	discovery, 195
Topology Detection Configuration and Query, 78	membind, 195
hwloc_topology_init	hwloc_topology_t
Topology Creation and Destruction, 75	Topology Creation and Destruction, 74
hwloc_topology_insert_misc_object_by_cpuset	
Modifying a loaded Topology, 101	index
hwloc_topology_insert_misc_object_by_parent	hwloc_topology_diff_obj_attr_u::hwloc_topology_
Modifying a loaded Topology, 102	diff_obj_attr_uint64_s, 191
hwloc_topology_is_thissystem	infos
Topology Detection Configuration and Query, 78	hwloc_obj, 179
hwloc_topology_load	infos_count
Topology Creation and Destruction, 75	hwloc_obj, 179
hwloc_topology_membind_support, 192	init
alloc_membind, 193	hwloc_component, 173
bind_membind, 193	instantiate
firsttouch membind, 193	hwloc_disc_component, 174
get_area_membind, 193	interleave_membind
get_proc_membind, 193	hwloc_topology_membind_support, 194
get_thisproc_membind, 193	Interoperability with glibc sched affinity, 154
get_thisthread_membind, 193	hwloc_cpuset_from_glibc_sched_affinity, 154
interleave_membind, 194	hwloc_cpuset_to_glibc_sched_affinity, 154
migrate_membind, 194	Interoperability with Intel Xeon Phi (MIC), 165
nexttouch_membind, 194	hwloc_intel_mic_get_device_cpuset, 165

hoden betal asia and decine and so business 405	hoden distances a 470
hwloc_intel_mic_get_device_osdev_by_index, 165	hwloc_distances_s, 176
Interoperability with Linux libnuma bitmask, 152	linesize
hwloc_cpuset_from_linux_libnuma_bitmask, 152	hwloc_obj_attr_u::hwloc_cache_attr_s, 172
hwloc_cpuset_to_linux_libnuma_bitmask, 152	linkspeed
hwloc_nodeset_from_linux_libnuma_bitmask, 152	hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185
hwloc_nodeset_to_linux_libnuma_bitmask, 153	Linux-specific helpers, 149
Interoperability with Linux libnuma unsigned long masks,	hwloc_linux_get_tid_cpubind, 149
150	hwloc_linux_get_tid_last_cpu_location, 149
hwloc_cpuset_from_linux_libnuma_ulongs, 150	hwloc_linux_parse_cpumap_file, 149
hwloc_cpuset_to_linux_libnuma_ulongs, 150	hwloc_linux_set_tid_cpubind, 149
hwloc_nodeset_from_linux_libnuma_ulongs, 150	local_memory
hwloc_nodeset_to_linux_libnuma_ulongs, 151	hwloc_obj_memory_s, 184
Interoperability with Myrinet Express, 168	logical_index
hwloc_mx_board_get_device_cpuset, 168	hwloc_obj, 179
hwloc_mx_endpoint_get_device_cpuset, 168	Looking at Ancestor and Child Objects, 114
Interoperability with OpenCL, 155	hwloc_get_ancestor_obj_by_depth, 114
hwloc_opencl_get_device_cpuset, 155	hwloc_get_ancestor_obj_by_type, 114
hwloc_opencl_get_device_osdev, 155	hwloc_get_common_ancestor_obj, 114
hwloc_opencl_get_device_osdev_by_index, 155	hwloc_get_next_child, 114
Interoperability with OpenFabrics, 166	hwloc_obj_is_in_subtree, 114
hwloc_ibv_get_device_cpuset, 166	Looking at Cache Objects, 116
hwloc_ibv_get_device_osdev, 166	hwloc_get_cache_covering_cpuset, 116
hwloc_ibv_get_device_osdev_by_name, 166	hwloc_get_cache_type_depth, 116
Interoperability with OpenGL displays, 163	hwloc_get_shared_cache_covering_obj, 116
hwloc_gl_get_display_by_osdev, 163	nwioo_got_sharod_ddono_ddvoring_ddj, 110
hwloc_gl_get_display_osdev_by_name, 163	Manipulating Distances, 125
hwloc_gl_get_display_osdev_by_port_device, 163	hwloc_get_distance_matrix_covering_obj_by_depth,
Interoperability with the CUDA Driver API, 157	125
hwloc_cuda_get_device_cpuset, 157	hwloc_get_latency, 125
	- -
hwloc_cuda_get_device_osdev, 157	hwloc_get_whole_distance_matrix_by_depth, 125
hwloc_cuda_get_device_osdev_by_index, 157	hwloc_get_whole_distance_matrix_by_type, 126
hwloc_cuda_get_device_pci_ids, 158	Manipulating Object Type, Sets and Attributes as Strings,
hwloc_cuda_get_device_pcidev, 158	85
Interoperability with the CUDA Runtime API, 159	hwloc_obj_add_info, 85
hwloc_cudart_get_device_cpuset, 159	hwloc_obj_attr_snprintf, 85
hwloc_cudart_get_device_osdev_by_index, 159	hwloc_obj_cpuset_snprintf, 85
hwloc_cudart_get_device_pci_ids, 159	hwloc_obj_get_info_by_name, 86
hwloc_cudart_get_device_pcidev, 159	hwloc_obj_type_snprintf, 86
Interoperability with the NVIDIA Management Library, 161	hwloc_obj_type_sscanf, 86
hwloc_nvml_get_device_cpuset, 161	hwloc_obj_type_string, 86
hwloc_nvml_get_device_osdev, 161	membind
hwloc_nvml_get_device_osdev_by_index, 161	hwloc_topology_support, 195
is_custom	memory
hwloc_backend, 170	hwloc_obj, 179
is_thissystem	Memory binding, 92
hwloc_backend, 170	HWLOC_MEMBIND_BIND, 94
	HWLOC_MEMBIND_DEFAULT, 94
last child	HWLOC MEMBIND FIRSTTOUCH, 94
hwloc_obj, 179	HWLOC MEMBIND INTERLEAVE, 94
latency	HWLOC MEMBIND MIGRATE, 94
hwloc_distances_s, 175	HWLOC_MEMBIND_MIXED, 95
latency_base	HWLOC MEMBIND NEXTTOUCH, 94
hwloc_distances_s, 175	HWLOC MEMBIND NOCPUBIND, 94
latency_max	HWLOC_MEMBIND_PROCESS, 94
atonoj_max	1111LOO_WEWDHAD_1 1100LOO, 07

HWLOC_MEMBIND_REPLICATE, 94 HWLOC_MEMBIND_STRICT, 94	hwloc_topology_diff_u::hwloc_topology_diff_too_← complex_s, 191
HWLOC_MEMBIND_THREAD, 94	next_cousin
hwloc_alloc, 95	hwloc_obj, 180
hwloc alloc membind, 95	next_sibling
hwloc_alloc_membind_nodeset, 95	hwloc_obj, 180
hwloc_alloc_membind_policy, 95	nexttouch_membind
hwloc_alloc_membind_policy_nodeset, 96	hwloc_topology_membind_support, 194
hwloc_free, 96	nodeset
hwloc_get_area_membind, 96	hwloc_obj, 180
hwloc_get_area_membind_nodeset, 96	notify_new_object
hwloc_get_membind, 96	hwloc_backend, 170
hwloc_get_membind_nodeset, 97	-
hwloc_get_proc_membind, 97	obj_attr
hwloc_get_proc_membind_nodeset, 98	hwloc_topology_diff_u, 192
hwloc_membind_flags_t, 93	obj_depth
hwloc_membind_policy_t, 94	hwloc_topology_diff_u::hwloc_topology_diff_obj_
hwloc_set_area_membind, 98	attr_s, 188
hwloc_set_area_membind_nodeset, 99	hwloc_topology_diff_u::hwloc_topology_diff_too_
	complex_s, 191
hwloc_set_membind, 99	obj_index
hwloc_set_membind_nodeset, 99	hwloc_topology_diff_u::hwloc_topology_diff_obj_
hwloc_set_proc_membind, 99	attr_s, 189
hwloc_set_proc_membind_nodeset, 100	hwloc_topology_diff_u::hwloc_topology_diff_too_
migrate_membind	complex_s, 191
hwloc_topology_membind_support, 194	Object levels, depths and types, 82
Modifying a loaded Topology, 101	HWLOC_TYPE_DEPTH_BRIDGE, 82
HWLOC_RESTRICT_FLAG_ADAPT_DISTANCES,	HWLOC_TYPE_DEPTH_MULTIPLE, 82
101	HWLOC_TYPE_DEPTH_OS_DEVICE, 82
HWLOC_RESTRICT_FLAG_ADAPT_IO, 101	HWLOC_TYPE_DEPTH_PCI_DEVICE, 82
HWLOC_RESTRICT_FLAG_ADAPT_MISC, 101	HWLOC_TYPE_DEPTH_UNKNOWN, 82
hwloc_restrict_flags_e, 101	hwloc_get_depth_type, 82
hwloc_topology_insert_misc_object_by_cpuset, 101	hwloc_get_nbobjs_by_depth, 83
hwloc_topology_insert_misc_object_by_parent, 102	hwloc_get_nbobjs_by_type, 83
hwloc_topology_restrict, 102	hwloc_get_next_obj_by_depth, 83
	hwloc_get_next_obj_by_type, 83
name	hwloc_get_obj_by_depth, 83
hwloc_disc_component, 174	hwloc_get_obj_by_type, 83
hwloc_obj, 179	hwloc_get_root_obj, 83
hwloc obj info s, 182	hwloc_get_type_depth, 83
hwloc_topology_diff_obj_attr_u::hwloc_topology_	hwloc_get_type_depth_e, 82
diff_obj_attr_string_s, 189	hwloc_get_type_or_above_depth, 84
nbobjs	hwloc_get_type_or_below_depth, 84
hwloc_distances_s, 176	hwloc_topology_get_depth, 84
newvalue	Object Sets (hwloc_cpuset_t and hwloc_nodeset_t), 68
hwloc_topology_diff_obj_attr_u::hwloc_topology_	hwloc_const_cpuset_t, 68
diff_obj_attr_string_s, 189	hwloc_const_nodeset_t, 68
hwloc_topology_diff_obj_attr_u::hwloc_topology_	hwloc_cpuset_t, 68
diff_obj_attr_uint64_s, 191	hwloc_nodeset_t, 68
next	Object Structure and Attributes, 73
hwloc_topology_diff_u::hwloc_topology_diff_←	hwloc_obj_t, 73
generic_s, 188	Object Types, 69
hwloc_topology_diff_u::hwloc_topology_diff_obj_←	HWLOC_OBJ_BRIDGE, 71
attr_s, 188	HWLOC_OBJ_BRIDGE_HOST, 70
u0, 100	200_000_0111001,70

HWLOC_OBJ_BRIDGE_PCI, 70	pcidev
HWLOC_OBJ_CACHE, 71	hwloc_obj_attr_u, 182
HWLOC_OBJ_CACHE_DATA, 70	prev_cousin
HWLOC_OBJ_CACHE_INSTRUCTION, 70	hwloc_obj, 181
HWLOC_OBJ_CACHE_UNIFIED, 70	prev_sibling
HWLOC_OBJ_CORE, 71	hwloc_obj, 181
HWLOC_OBJ_GROUP, 71	priority
HWLOC_OBJ_MACHINE, 71	hwloc_disc_component, 174
HWLOC_OBJ_MISC, 71	private_data
HWLOC_OBJ_NUMANODE, 71	hwloc_backend, 170
HWLOC_OBJ_OS_DEVICE, 71	pu
HWLOC_OBJ_OSDEV_BLOCK, 70	hwloc_topology_discovery_support, 192
HWLOC_OBJ_OSDEV_COPROC, 70	
HWLOC_OBJ_OSDEV_DMA, 70	relative_depth
HWLOC_OBJ_OSDEV_GPU, 70	hwloc_distances_s, 176
HWLOC_OBJ_OSDEV_NETWORK, 70	replicate_membind
HWLOC_OBJ_OSDEV_OPENFABRICS, 70	hwloc_topology_membind_support, 194
HWLOC_OBJ_PACKAGE, 71	revision
HWLOC_OBJ_PCI_DEVICE, 71	hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185
HWLOC OBJ PU, 71	
HWLOC_OBJ_SYSTEM, 71	secondary bus
HWLOC_OBJ_TYPE_MAX, 71	hwloc obj attr u::hwloc bridge attr s, 171
HWLOC TYPE UNORDERED, 70	set area membind
hwloc_compare_types, 71	hwloc topology membind support, 194
hwloc_compare_types_e, 70	set_proc_cpubind
hwloc_obj_bridge_type_e, 70	hwloc_topology_cpubind_support, 187
hwloc_obj_bridge_type_t, 69	set_proc_membind
hwloc_obj_cache_type_e, 70	hwloc_topology_membind_support, 194
hwloc_obj_cache_type_t, 69	set_thisproc_cpubind
hwloc_obj_osdev_type_e, 70	hwloc_topology_cpubind_support, 187
hwloc_obj_osdev_type_t, 69	set_thisproc_membind
hwloc_obj_type_t, 70	hwloc_topology_membind_support, 194
oldvalue	set_thisthread_cpubind
hwloc_topology_diff_obj_attr_u::hwloc_topology_←	hwloc_topology_cpubind_support, 187
diff obj attr string s, 189	set_thisthread_membind
hwloc_topology_diff_obj_attr_u::hwloc_topology_	hwloc_topology_membind_support, 194
diff_obj_attr_uint64_s, 191	set thread cpubind
online_cpuset	hwloc_topology_cpubind_support, 187
hwloc_obj, 180	sibling_rank
os_index	hwloc_obj, 181
hwloc_obj, 180	size
	hwloc obj attr u::hwloc cache attr s, 172
os_level	
hwloc_obj, 180	hwloc_obj_memory_s::hwloc_obj_memory_page_←
osdev	type_s, 183
hwloc_obj_attr_u, 182	string
naga tunaa	hwloc_topology_diff_obj_attr_u, 190
page_types	subdevice_id
hwloc_obj_memory_s, 184	hwloc_obj_attr_u::hwloc_pcidev_attr_s, 185
page_types_len	subordinate_bus
hwloc_obj_memory_s, 184	hwloc_obj_attr_u::hwloc_bridge_attr_s, 171
parent	subvendor_id
hwloc_obj, 180	hwloc_obj_attr_u::hwloc_pcidev_attr_s, 186
pci	symmetric_subtree
hwloc_obj_attr_u::hwloc_bridge_attr_s, 171	hwloc_obj, 181

The bitmap API, 129	hwloc_topology_destroy, 74
hwloc_bitmap_allbut, 131	hwloc_topology_dup, 75
hwloc_bitmap_alloc, 131	hwloc_topology_init, 75
hwloc_bitmap_alloc_full, 131	hwloc_topology_load, 75
hwloc_bitmap_and, 131	hwloc_topology_t, 74
hwloc_bitmap_andnot, 131	Topology Detection Configuration and Query, 76
hwloc_bitmap_asprintf, 131	HWLOC_TOPOLOGY_FLAG_ICACHES, 77
hwloc_bitmap_clr, 131	HWLOC_TOPOLOGY_FLAG_IO_BRIDGES, 77
hwloc_bitmap_clr_range, 131	HWLOC_TOPOLOGY_FLAG_IO_DEVICES, 77
hwloc_bitmap_compare, 132	HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM, 77
hwloc bitmap compare first, 132	HWLOC TOPOLOGY FLAG WHOLE IO, 77
hwloc_bitmap_copy, 132	HWLOC_TOPOLOGY_FLAG_WHOLE_SYSTEM,
hwloc_bitmap_dup, 132	77
hwloc_bitmap_till, 132	
	hwloc_topology_flags_e, 77
hwloc_bitmap_first, 132	hwloc_topology_get_flags, 77
hwloc_bitmap_foreach_begin, 130	hwloc_topology_get_support, 77
hwloc_bitmap_foreach_end, 130	hwloc_topology_get_userdata, 77
hwloc_bitmap_free, 132	hwloc_topology_ignore_all_keep_structure, 78
hwloc_bitmap_from_ith_ulong, 132	hwloc_topology_ignore_type, 78
hwloc_bitmap_from_ulong, 133	hwloc_topology_ignore_type_keep_structure, 78
hwloc_bitmap_intersects, 133	hwloc_topology_is_thissystem, 78
hwloc_bitmap_isequal, 133	hwloc_topology_set_custom, 78
hwloc_bitmap_isfull, 133	hwloc_topology_set_distance_matrix, 78
hwloc_bitmap_isincluded, 133	hwloc_topology_set_flags, 79
hwloc_bitmap_isset, 133	hwloc_topology_set_fsroot, 79
hwloc_bitmap_iszero, 133	hwloc_topology_set_pid, 79
hwloc_bitmap_last, 133	hwloc_topology_set_synthetic, 80
hwloc_bitmap_list_asprintf, 133	hwloc_topology_set_userdata, 80
hwloc_bitmap_list_snprintf, 133	hwloc_topology_set_xml, 80
hwloc_bitmap_list_sscanf, 134	hwloc_topology_set_xmlbuffer, 81
hwloc_bitmap_next, 134	Topology differences, 137
hwloc_bitmap_not, 134	HWLOC_TOPOLOGY_DIFF_APPLY_REVERSE,
hwloc_bitmap_only, 134	138
hwloc_bitmap_or, 134	HWLOC_TOPOLOGY_DIFF_OBJ_ATTR, 139
hwloc_bitmap_set, 134	HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_INFO, 138
hwloc_bitmap_set_ith_ulong, 134	HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_NAME,
hwloc_bitmap_set_range, 135	138
hwloc_bitmap_singlify, 135	HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_SIZE, 138
hwloc_bitmap_snprintf, 135	HWLOC_TOPOLOGY_DIFF_TOO_COMPLEX, 139
hwloc_bitmap_sscanf, 135	hwloc_topology_diff_apply, 139
hwloc_bitmap_t, 130	hwloc_topology_diff_apply_flags_e, 138
hwloc_bitmap_taskset_asprintf, 135	hwloc_topology_diff_build, 139
hwloc_bitmap_taskset_snprintf, 135	hwloc_topology_diff_destroy, 139
hwloc_bitmap_taskset_sscanf, 135	hwloc_topology_diff_export_xml, 140
hwloc_bitmap_to_ith_ulong, 136	hwloc_topology_diff_export_xmlbuffer, 140
hwloc_bitmap_to_ulong, 136	hwloc_topology_diff_load_xml, 140
hwloc_bitmap_weight, 136	hwloc_topology_diff_load_xmlbuffer, 140
hwloc_bitmap_xor, 136	hwloc_topology_diff_obj_attr_type_e, 138
hwloc_bitmap_zero, 136	hwloc_topology_diff_obj_attr_type_t, 138
hwloc_const_bitmap_t, 130	hwloc_topology_diff_t, 138
too_complex	hwloc_topology_diff_type_e, 138
hwloc_topology_diff_u, 192	hwloc_topology_diff_type_t, 138
Topology Creation and Destruction, 74	total_memory
hwloc_topology_check, 74	hwloc_obj_memory_s, 184

```
type
     hwloc component, 173
    hwloc_disc_component, 175
     hwloc obj, 181
    hwloc_obj_attr_u::hwloc_cache_attr_s, 172
     hwloc_obj_attr_u::hwloc_osdev_attr_s, 185
     hwloc topology diff obj attr u::hwloc topology ~
         diff_obj_attr_generic_s, 188
     hwloc_topology_diff_obj_attr_u::hwloc_topology_
         diff_obj_attr_string_s, 189
    hwloc_topology_diff_obj_attr_u::hwloc_topology_
         diff_obj_attr_uint64_s, 191
     hwloc_topology_diff_u::hwloc_topology_diff_ ~
         generic_s, 188
     hwloc_topology_diff_u::hwloc_topology_diff_obj_
         attr_s, 189
     hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_too\_{\leftarrow}
         complex_s, 191
uint64
    hwloc_topology_diff_obj_attr_u, 190
upstream
    hwloc_obj_attr_u::hwloc_bridge_attr_s, 171
upstream type
    hwloc_obj_attr_u::hwloc_bridge_attr_s, 171
userdata
    hwloc_obj, 181
value
     hwloc_obj_info_s, 182
vendor id
    hwloc_obj_attr_u::hwloc_pcidev_attr_s, 186
```