Hardware Locality (hwloc) 1.10rc1

Generated by Doxygen 1.8.8

Wed Sep 24 2014 16:12:37

# **Contents**

1	Hardware Locality 1			
	1.1	Introduction	1	
	1.2	Installation	2	
	1.3	CLI Examples	3	
	1.4	Programming Interface	8	
		1.4.1 Portability	8	
		1.4.2 API Example	12	
	1.5	Questions and Bugs	15	
	1.6	History / Credits	15	
	1.7	Further Reading	15	
_	_			
2	Ierm	ns and Definitions	17	
3	Com	mand-Line Tools	21	
	3.1	Istopo and Istopo-no-graphics	21	
	3.2	hwloc-bind	21	
	3.3	hwloc-calc	21	
	3.4	hwloc-info	22	
	3.5	hwloc-distrib	22	
	3.6	hwloc-ps	22	
	3.7	hwloc-gather-topology	22	
	3.8	hwloc-distances	22	
	3.9	hwloc-annotate	22	
	3.10	hwloc-diff and hwloc-patch	22	
	3.11	hwloc-compress-dir	23	
	3.12	hwloc-assembler	23	
	3.13	hwloc-assembler-remote	23	
4	Envi	ronment Variables	25	

iv CONTENTS

5	CPU	and Memory Binding Overview	27
6 I/O Devices			
	6.1	Enabling and requirements	29
	6.2	I/O object hierarchy	29
	6.3	Software devices	30
	6.4	Consulting I/O devices and binding	30
	6.5	Examples	31
7	Mult	i-node Topologies	33
	7.1	Multi-node Objects Specifities	33
	7.2	Assembling topologies with command-line tools	34
	7.3	Assembling topologies with the programming interface	34
	7.4	Example of assembly with the programming interface	34
8	Obje	ect attributes	37
	8.1	Normal attributes	37
	8.2	Custom string infos	37
9	Impo	orting and exporting topologies from/to XML files	39
	9.1	libxml2 and minimalistic XML backends	39
	9.2	XML import error management	40
10	Synt	hetic topologies	41
	10.1	Synthetic description string	41
	10.2	Loading a synthetic topology	42
	10.3	Exporting a topology as a synthetic string	42
11	Inter	operability With Other Software	43
12	Thre	ad Safety	45
13	Com	ponents and plugins	47
	13.1	Components enabled by default	47
	13.2	Selecting which components to use	48
	13.3	Loading components from plugins	48
	13.4	Adding new discovery components and plugins	48
		13.4.1 Basics of discovery components	48
		13.4.2 Registering a new discovery component	49
	13.5	Existing components and plugins	49

CONTENTS

14	Embedding hwloc in Other Software	51
	14.1 Using hwloc's M4 Embedding Capabilities	51
	14.2 Example Embedding hwloc	53
15	Frequently Asked Questions	55
	15.1 I do not want hwloc to rediscover my enormous machine topology every time I rerun a process	55
	15.2 How many topologies may I use in my program?	55
	15.3 How to avoid memory waste when manipulating multiple similar topologies?	55
	15.4 Why is Istopo slow?	56
	15.5 What should I do when hwloc reports "operating system" warnings?	56
	15.6 Does hwloc require privileged access?	56
	15.7 hwloc only has a one-dimensional view of the architecture, it ignores distances	57
	15.8 How may I ignore symmetric multithreading, hyper-threading, ?	57
	15.9 What happens if my topology is asymmetric?	58
	15.10How do I annotate the topology with private notes?	58
	15.11Why does Valgrind complain about hwloc memory leaks?	59
	15.12How do I handle API upgrades?	59
	15.13How do I build hwloc for BlueGene/Q?	59
	15.14How to get useful topology information on NetBSD?	59
40	Mandada Indon	~4
16	Module Index	61
	16.1 Modules	61
17	Data Structure Index	63
	17.1 Data Structures	63
18	Module Documentation	65
10	18.1 API version	00
	10.1 /11/00/00/01	65
	18.1.1 Detailed Description	65
	18.1.1 Detailed Description       18.1.2 Macro Definition Documentation	65 65
	18.1.1 Detailed Description	65 65 65
	18.1.1 Detailed Description	65 65 65
	18.1.1 Detailed Description	65 65 65 65
	18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 HWLOC_API_VERSION  18.1.2.2 HWLOC_COMPONENT_ABI  18.1.3 Function Documentation  18.1.3.1 hwloc_get_api_version	65 65 65 65 65
	18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 HWLOC_API_VERSION  18.1.2.2 HWLOC_COMPONENT_ABI  18.1.3 Function Documentation  18.1.3.1 hwloc_get_api_version  18.2 Object Sets (hwloc_cpuset_t and hwloc_nodeset_t)	65 65 65 65 65
	18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 HWLOC_API_VERSION  18.1.2.2 HWLOC_COMPONENT_ABI  18.1.3 Function Documentation  18.1.3.1 hwloc_get_api_version  18.2 Object Sets (hwloc_cpuset_t and hwloc_nodeset_t)  18.2.1 Detailed Description	65 65 65 65 65 66 66
	18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 HWLOC_API_VERSION  18.1.2.2 HWLOC_COMPONENT_ABI  18.1.3 Function Documentation  18.1.3.1 hwloc_get_api_version  18.2 Object Sets (hwloc_cpuset_t and hwloc_nodeset_t)  18.2.1 Detailed Description  18.2.2 Typedef Documentation	65 65 65 65 66 66 66
	18.1.1 Detailed Description  18.1.2 Macro Definition Documentation  18.1.2.1 HWLOC_API_VERSION  18.1.2.2 HWLOC_COMPONENT_ABI  18.1.3 Function Documentation  18.1.3.1 hwloc_get_api_version  18.2 Object Sets (hwloc_cpuset_t and hwloc_nodeset_t)  18.2.1 Detailed Description	65 65 65 65 65 66 66 66 66

vi CONTENTS

		18.2.2.3 hwloc_cpuset_t	36
		18.2.2.4 hwloc_nodeset_t	36
18.3	Object	Types	37
	18.3.1	Detailed Description	37
	18.3.2	Typedef Documentation	37
		18.3.2.1 hwloc_obj_bridge_type_t	37
		18.3.2.2 hwloc_obj_cache_type_t	37
		18.3.2.3 hwloc_obj_osdev_type_t	37
	18.3.3	Enumeration Type Documentation	38
		18.3.3.1 hwloc_compare_types_e	38
		18.3.3.2 hwloc_obj_bridge_type_e	38
		18.3.3.3 hwloc_obj_cache_type_e	38
		18.3.3.4 hwloc_obj_osdev_type_e	38
		18.3.3.5 hwloc_obj_type_t	39
	18.3.4	Function Documentation	39
		18.3.4.1 hwloc_compare_types	39
18.4	Object	Structure and Attributes	71
	18.4.1	Detailed Description	71
	18.4.2	Typedef Documentation	71
		18.4.2.1 hwloc_obj_t	71
18.5	Topolog	gy Creation and Destruction	72
	18.5.1	Detailed Description	72
	18.5.2	Typedef Documentation	72
		18.5.2.1 hwloc_topology_t	72
	18.5.3	Function Documentation	72
		18.5.3.1 hwloc_topology_check	72
		18.5.3.2 hwloc_topology_destroy	72
		18.5.3.3 hwloc_topology_init	72
		18.5.3.4 hwloc_topology_load	73
18.6	Topolog	gy Detection Configuration and Query	74
	18.6.1	Detailed Description	74
	18.6.2	Enumeration Type Documentation	75
		18.6.2.1 hwloc_topology_flags_e	75
	18.6.3	Function Documentation	75
		18.6.3.1 hwloc_topology_get_flags	75
		18.6.3.2 hwloc_topology_get_support	75
		18.6.3.3 hwloc_topology_get_userdata	76

CONTENTS vii

	18.6.3.4 hwloc_topology_ignore_all_keep_structure	76
	18.6.3.5 hwloc_topology_ignore_type	76
	18.6.3.6 hwloc_topology_ignore_type_keep_structure	76
	18.6.3.7 hwloc_topology_is_thissystem	76
	18.6.3.8 hwloc_topology_set_custom	76
	18.6.3.9 hwloc_topology_set_distance_matrix	77
	18.6.3.10 hwloc_topology_set_flags	77
	18.6.3.11 hwloc_topology_set_fsroot	77
	18.6.3.12 hwloc_topology_set_pid	77
	18.6.3.13 hwloc_topology_set_synthetic	78
	18.6.3.14 hwloc_topology_set_userdata	78
	18.6.3.15 hwloc_topology_set_xml	78
	18.6.3.16 hwloc_topology_set_xmlbuffer	79
18.7 Object	levels, depths and types	80
	Detailed Description	
18.7.2	Enumeration Type Documentation	80
	18.7.2.1 hwloc_get_type_depth_e	80
18.7.3	Function Documentation	80
	18.7.3.1 hwloc_get_depth_type	80
	18.7.3.2 hwloc_get_nbobjs_by_depth	81
	18.7.3.3 hwloc_get_nbobjs_by_type	81
	18.7.3.4 hwloc_get_next_obj_by_depth	81
	18.7.3.5 hwloc_get_next_obj_by_type	81
	18.7.3.6 hwloc_get_obj_by_depth	81
	18.7.3.7 hwloc_get_obj_by_type	81
	18.7.3.8 hwloc_get_root_obj	81
	18.7.3.9 hwloc_get_type_depth	82
	18.7.3.10 hwloc_get_type_or_above_depth	82
	18.7.3.11 hwloc_get_type_or_below_depth	82
	18.7.3.12 hwloc_topology_get_depth	82
18.8 Manipu	ulating Object Type, Sets and Attributes as Strings	83
18.8.1	Detailed Description	83
18.8.2	Function Documentation	83
	18.8.2.1 hwloc_obj_add_info	
	18.8.2.2 hwloc_obj_attr_snprintf	83
	18.8.2.3 hwloc_obj_cpuset_snprintf	
	18.8.2.4 hwloc_obj_get_info_by_name	84

viii CONTENTS

CONTENTS ix

18.10.3.16hwloc_set_membind_nodeset
18.10.3.17hwloc_set_proc_membind
18.10.3.18hwloc_set_proc_membind_nodeset
18.11 Modifying a loaded Topology
18.11.1 Detailed Description
18.11.2 Enumeration Type Documentation
18.11.2.1 hwloc_restrict_flags_e
18.11.3 Function Documentation
18.11.3.1 hwloc_topology_dup
18.11.3.2 hwloc_topology_insert_misc_object_by_cpuset
18.11.3.3 hwloc_topology_insert_misc_object_by_parent
18.11.3.4 hwloc_topology_restrict
18.12Building Custom Topologies
18.12.1 Detailed Description
18.12.2 Function Documentation
18.12.2.1 hwloc_custom_insert_group_object_by_parent
18.12.2.2 hwloc_custom_insert_topology
18.13Exporting Topologies to XML
18.13.1 Detailed Description
18.13.2 Function Documentation
18.13.2.1 hwloc_export_obj_userdata
18.13.2.2 hwloc_export_obj_userdata_base64
18.13.2.3 hwloc_free_xmlbuffer
18.13.2.4 hwloc_topology_export_xml
18.13.2.5 hwloc_topology_export_xmlbuffer
18.13.2.6 hwloc_topology_set_userdata_export_callback
18.13.2.7 hwloc_topology_set_userdata_import_callback
18.14Exporting Topologies to Synthetic
18.14.1 Detailed Description
18.14.2 Enumeration Type Documentation
18.14.2.1 hwloc_topology_export_synthetic_flags_e
18.14.3 Function Documentation
18.14.3.1 hwloc_topology_export_synthetic
18.15Finding Objects inside a CPU set
18.15.1 Detailed Description
18.15.2 Function Documentation
18.15.2.1 hwloc_get_first_largest_obj_inside_cpuset

CONTENTS

18.15.2.2 hwloc_get_largest_objs_inside_cpuset
18.15.2.3 hwloc_get_nbobjs_inside_cpuset_by_depth
18.15.2.4 hwloc_get_nbobjs_inside_cpuset_by_type
18.15.2.5 hwloc_get_next_obj_inside_cpuset_by_depth
18.15.2.6 hwloc_get_next_obj_inside_cpuset_by_type
18.15.2.7 hwloc_get_obj_index_inside_cpuset
18.15.2.8 hwloc_get_obj_inside_cpuset_by_depth
18.15.2.9 hwloc_get_obj_inside_cpuset_by_type
18.16Finding Objects covering at least CPU set
18.16.1 Detailed Description
18.16.2 Function Documentation
18.16.2.1 hwloc_get_child_covering_cpuset
18.16.2.2 hwloc_get_next_obj_covering_cpuset_by_depth
18.16.2.3 hwloc_get_next_obj_covering_cpuset_by_type
18.16.2.4 hwloc_get_obj_covering_cpuset
18.17Looking at Ancestor and Child Objects
18.17.1 Detailed Description
18.17.2 Function Documentation
18.17.2.1 hwloc_get_ancestor_obj_by_depth
18.17.2.2 hwloc_get_ancestor_obj_by_type
18.17.2.3 hwloc_get_common_ancestor_obj
18.17.2.4 hwloc_get_next_child
18.17.2.5 hwloc_obj_is_in_subtree
18.18Looking at Cache Objects
18.18.1 Detailed Description
18.18.2 Function Documentation
18.18.2.1 hwloc_get_cache_covering_cpuset
18.18.2.2 hwloc_get_cache_type_depth
18.18.2.3 hwloc_get_shared_cache_covering_obj
18.19Finding objects, miscellaneous helpers
18.19.1 Detailed Description
18.19.2 Function Documentation
18.19.2.1 hwloc_get_closest_objs
18.19.2.2 hwloc_get_numanode_obj_by_os_index
18.19.2.3 hwloc_get_obj_below_array_by_type
18.19.2.4 hwloc_get_obj_below_by_type
18.19.2.5 hwloc_get_pu_obj_by_os_index

CONTENTS xi

18.20 Distributing items over a topology
18.20.1 Detailed Description
18.20.2 Enumeration Type Documentation
18.20.2.1 hwloc_distrib_flags_e
18.20.3 Function Documentation
18.20.3.1 hwloc_distrib
18.21 CPU and node sets of entire topologies
18.21.1 Detailed Description
18.21.2 Function Documentation
18.21.2.1 hwloc_topology_get_allowed_cpuset
18.21.2.2 hwloc_topology_get_allowed_nodeset
18.21.2.3 hwloc_topology_get_complete_cpuset
18.21.2.4 hwloc_topology_get_complete_nodeset
18.21.2.5 hwloc_topology_get_online_cpuset
18.21.2.6 hwloc_topology_get_topology_cpuset
18.21.2.7 hwloc_topology_get_topology_nodeset
18.22Converting between CPU sets and node sets
18.22.1 Detailed Description
18.22.2 Function Documentation
18.22.2.1 hwloc_cpuset_from_nodeset
18.22.2.2 hwloc_cpuset_from_nodeset_strict
18.22.2.3 hwloc_cpuset_to_nodeset
18.22.2.4 hwloc_cpuset_to_nodeset_strict
18.23Manipulating Distances
18.23.1 Detailed Description
18.23.2 Function Documentation
18.23.2.1 hwloc_get_distance_matrix_covering_obj_by_depth
18.23.2.2 hwloc_get_latency
18.23.2.3 hwloc_get_whole_distance_matrix_by_depth
18.23.2.4 hwloc_get_whole_distance_matrix_by_type
18.24Finding I/O objects
18.24.1 Detailed Description
18.24.2 Function Documentation
18.24.2.1 hwloc_bridge_covers_pcibus
18.24.2.2 hwloc_get_hostbridge_by_pcibus
18.24.2.3 hwloc_get_next_bridge
18.24.2.4 hwloc_get_next_osdev

xii CONTENTS

CONTENTS xiii

	18.25.4.25hwloc_bitmap_list_asprintf	. 131
	18.25.4.26hwloc_bitmap_list_snprintf	. 131
	18.25.4.27hwloc_bitmap_list_sscanf	. 132
	18.25.4.28hwloc_bitmap_next	. 132
	18.25.4.29hwloc_bitmap_not	. 132
	18.25.4.30hwloc_bitmap_only	. 132
	18.25.4.31hwloc_bitmap_or	. 132
	18.25.4.32hwloc_bitmap_set	. 132
	18.25.4.33hwloc_bitmap_set_ith_ulong	. 132
	18.25.4.34hwloc_bitmap_set_range	. 132
	18.25.4.35hwloc_bitmap_singlify	. 133
	18.25.4.36hwloc_bitmap_snprintf	. 133
	18.25.4.37hwloc_bitmap_sscanf	. 133
	18.25.4.38hwloc_bitmap_taskset_asprintf	. 133
	18.25.4.39hwloc_bitmap_taskset_snprintf	. 133
	18.25.4.40hwloc_bitmap_taskset_sscanf	. 133
	18.25.4.41hwloc_bitmap_to_ith_ulong	. 133
	18.25.4.42hwloc_bitmap_to_ulong	. 134
	18.25.4.43hwloc_bitmap_weight	. 134
	18.25.4.44hwloc_bitmap_xor	. 134
	18.25.4.45hwloc_bitmap_zero	. 134
18.26Topolog	gy differences	. 135
18.26.1	Detailed Description	. 136
18.26.2	Typedef Documentation	. 136
	18.26.2.1 hwloc_topology_diff_obj_attr_type_t	. 136
	18.26.2.2 hwloc_topology_diff_t	. 136
	18.26.2.3 hwloc_topology_diff_type_t	. 136
18.26.3	B Enumeration Type Documentation	. 136
	18.26.3.1 hwloc_topology_diff_apply_flags_e	. 136
	18.26.3.2 hwloc_topology_diff_obj_attr_type_e	. 136
	18.26.3.3 hwloc_topology_diff_type_e	. 137
18.26.4	Function Documentation	. 137
	18.26.4.1 hwloc_topology_diff_apply	. 137
	18.26.4.2 hwloc_topology_diff_build	. 137
	18.26.4.3 hwloc_topology_diff_destroy	. 138
	18.26.4.4 hwloc_topology_diff_export_xml	. 138
	18.26.4.5 hwloc_topology_diff_export_xmlbuffer	. 138

xiv CONTENTS

18.26.4.6 hwloc_topology_diff_load_xml
18.26.4.7 hwloc_topology_diff_load_xmlbuffer
18.27Components and Plugins: Discovery components
18.27.1 Detailed Description
18.27.2 Typedef Documentation
18.27.2.1 hwloc_disc_component_type_t140
18.27.3 Enumeration Type Documentation
18.27.3.1 hwloc_disc_component_type_e
18.28Components and Plugins: Discovery backends
18.28.1 Detailed Description
18.28.2 Enumeration Type Documentation
18.28.2.1 hwloc_backend_flag_e
18.28.3 Function Documentation
18.28.3.1 hwloc_backend_alloc
18.28.3.2 hwloc_backend_enable
18.28.3.3 hwloc_backends_get_obj_cpuset
18.28.3.4 hwloc_backends_notify_new_object
18.29Components and Plugins: Generic components
18.29.1 Detailed Description
18.29.2 Typedef Documentation
18.29.2.1 hwloc_component_type_t
18.29.3 Enumeration Type Documentation
18.29.3.1 hwloc_component_type_e
18.30Components and Plugins: Core functions to be used by components
18.30.1 Detailed Description
18.30.2 Typedef Documentation
18.30.2.1 hwloc_report_error_t
18.30.3 Function Documentation
18.30.3.1 hwlocinsert_object_by_cpuset
18.30.3.2 hwloc_alloc_setup_object
18.30.3.3 hwloc_fill_object_sets
18.30.3.4 hwloc_hide_errors
18.30.3.5 hwloc_insert_object_by_cpuset
18.30.3.6 hwloc_insert_object_by_parent
18.30.3.7 hwloc_plugin_check_namespace
18.30.3.8 hwloc_report_os_error
18.31Components and Plugins: PCI functions to be used by components

CONTENTS xv

18.31.1 Detailed Description
18.31.2 Function Documentation
18.31.2.1 hwloc_insert_pci_device_list
18.31.2.2 hwloc_pci_find_cap
18.31.2.3 hwloc_pci_find_linkspeed
18.31.2.4 hwloc_pci_prepare_bridge
18.32Linux-specific helpers
18.32.1 Detailed Description
18.32.2 Function Documentation
18.32.2.1 hwloc_linux_get_tid_cpubind
18.32.2.2 hwloc_linux_get_tid_last_cpu_location
18.32.2.3 hwloc_linux_parse_cpumap_file
18.32.2.4 hwloc_linux_set_tid_cpubind
18.33 Interoperability with Linux libnuma unsigned long masks
18.33.1 Detailed Description
18.33.2 Function Documentation
18.33.2.1 hwloc_cpuset_from_linux_libnuma_ulongs
18.33.2.2 hwloc_cpuset_to_linux_libnuma_ulongs
18.33.2.3 hwloc_nodeset_from_linux_libnuma_ulongs
18.33.2.4 hwloc_nodeset_to_linux_libnuma_ulongs
18.34Interoperability with Linux libnuma bitmask
18.34.1 Detailed Description
18.34.2 Function Documentation
18.34.2.1 hwloc_cpuset_from_linux_libnuma_bitmask
18.34.2.2 hwloc_cpuset_to_linux_libnuma_bitmask
18.34.2.3 hwloc_nodeset_from_linux_libnuma_bitmask
18.34.2.4 hwloc_nodeset_to_linux_libnuma_bitmask
18.35 Interoperability with glibc sched affinity
18.35.1 Detailed Description
18.35.2 Function Documentation
18.35.2.1 hwloc_cpuset_from_glibc_sched_affinity
18.35.2.2 hwloc_cpuset_to_glibc_sched_affinity
18.36Interoperability with OpenCL
18.36.1 Detailed Description
18.36.2 Function Documentation
18.36.2.1 hwloc_opencl_get_device_cpuset
18.36.2.2 hwloc_opencl_get_device_osdev

xvi CONTENTS

18.36.2.3 hwloc_opencl_get_device_osdev_by_index
18.37Interoperability with the CUDA Driver API
18.37.1 Detailed Description
18.37.2 Function Documentation
18.37.2.1 hwloc_cuda_get_device_cpuset
18.37.2.2 hwloc_cuda_get_device_osdev
18.37.2.3 hwloc_cuda_get_device_osdev_by_index
18.37.2.4 hwloc_cuda_get_device_pci_ids
18.37.2.5 hwloc_cuda_get_device_pcidev
18.38 Interoperability with the CUDA Runtime API
18.38.1 Detailed Description
18.38.2 Function Documentation
18.38.2.1 hwloc_cudart_get_device_cpuset
18.38.2.2 hwloc_cudart_get_device_osdev_by_index
18.38.2.3 hwloc_cudart_get_device_pci_ids
18.38.2.4 hwloc_cudart_get_device_pcidev
18.39Interoperability with the NVIDIA Management Library
18.39.1 Detailed Description
18.39.2 Function Documentation
18.39.2.1 hwloc_nvml_get_device_cpuset
18.39.2.2 hwloc_nvml_get_device_osdev
18.39.2.3 hwloc_nvml_get_device_osdev_by_index
18.40Interoperability with OpenGL displays
18.40.1 Detailed Description
18.40.2 Function Documentation
18.40.2.1 hwloc_gl_get_display_by_osdev
18.40.2.2 hwloc_gl_get_display_osdev_by_name
18.40.2.3 hwloc_gl_get_display_osdev_by_port_device
18.41Interoperability with Intel Xeon Phi (MIC)
18.41.1 Detailed Description
18.41.2 Function Documentation
18.41.2.1 hwloc_intel_mic_get_device_cpuset
18.41.2.2 hwloc_intel_mic_get_device_osdev_by_index
18.42Interoperability with OpenFabrics
18.42.1 Detailed Description
18.42.2 Function Documentation
18.42.2.1 hwloc_ibv_get_device_cpuset

CONTENTS xvii

			18.42.2.2	hwloc_ibv_get_device_osdev	 	 . 164
			18.42.2.3	hwloc_ibv_get_device_osdev_by_name	 	 . 164
	18.43	3Interop	erability wi	ith Myrinet Express	 	 . 166
		18.43.1	Detailed [	Description	 	 . 166
		18.43.2	! Function	Documentation	 	 . 166
			18.43.2.1	hwloc_mx_board_get_device_cpuset	 	 . 166
			18.43.2.2	hwloc_mx_endpoint_get_device_cpuset	 	 . 166
19	Data	Structu	ire Docum	nentation		167
	19.1	hwloc_l	backend S	Struct Reference	 	 . 167
		19.1.1	Detailed I	Description	 	 . 167
		19.1.2	Field Doc	sumentation	 	 . 167
			19.1.2.1	disable	 	 . 167
			19.1.2.2	discover	 	 . 168
			19.1.2.3	flags	 	 . 168
			19.1.2.4	get_obj_cpuset	 	 . 168
			19.1.2.5	is_custom	 	 . 168
			19.1.2.6	is_thissystem	 	 . 168
			19.1.2.7	notify_new_object	 	 . 168
			19.1.2.8	private_data	 	 . 168
	19.2	hwloc_e	obj_attr_u:	::hwloc_bridge_attr_s Struct Reference	 	 . 168
		19.2.1	Detailed I	Description	 	 . 169
		19.2.2	Field Doc	cumentation	 	 . 169
			19.2.2.1	depth	 	 . 169
			19.2.2.2	domain	 	 . 169
			19.2.2.3	downstream	 	 . 169
			19.2.2.4	downstream_type	 	 . 169
			19.2.2.5	pci	 	 . 169
			19.2.2.6	pci	 	 . 169
			19.2.2.7	secondary_bus	 	 . 169
			19.2.2.8	subordinate_bus	 	 . 169
			19.2.2.9	upstream	 	 . 169
			19.2.2.10	upstream_type	 	 . 169
	19.3	hwloc_e	obj_attr_u:	::hwloc_cache_attr_s Struct Reference	 	 . 169
		19.3.1	Detailed I	Description	 	 . 170
		19.3.2	Field Doc	cumentation	 	 . 170
			19.3.2.1	associativity	 	 . 170

xviii CONTENTS

19.3.2.2	2 depth	170
19.3.2.3	3 linesize	170
19.3.2.4	4 size	170
19.3.2.5	5 type	170
19.4 hwloc_compone	ent Struct Reference	170
19.4.1 Detailed	d Description	171
19.4.2 Field Do	ocumentation	171
19.4.2.1	1 abi	171
19.4.2.2	2 data	171
19.4.2.3	3 finalize	171
19.4.2.4	4 flags	171
19.4.2.5	5 init	171
19.4.2.6	6 type	172
19.5 hwloc_disc_con	mponent Struct Reference	172
19.5.1 Detailed	d Description	172
19.5.2 Field Do	ocumentation	172
19.5.2.1	1 excludes	172
	2 instantiate	
19.5.2.3	3 name	172
	4 priority	
	5 type	
<del>-</del>	s_s Struct Reference	
	d Description	
	ocumentation	
19.6.2.1	1 latency	173
19.6.2.2	2 latency_base	174
	3 latency_max	
	4 nbobjs	
	5 relative_depth	
19.7 hwloc_obj_attr_	_u::hwloc_group_attr_s Struct Reference	174
19.7.1 Detailed	d Description	174
	ocumentation	
	1 depth	
_ ,	ct Reference	
	d Description	
19.8.2 Field Do	ocumentation	
19.8.2.1	1 allowed_cpuset	175

CONTENTS xix

	19.8.2.2	allowed_nodeset
	19.8.2.3	arity
	19.8.2.4	attr
	19.8.2.5	children
	19.8.2.6	complete_cpuset
	19.8.2.7	complete_nodeset
	19.8.2.8	cpuset
	19.8.2.9	depth
	19.8.2.10	distances
	19.8.2.11	distances_count
	19.8.2.12	first_child
	19.8.2.13	infos
	19.8.2.14	infos_count
	19.8.2.15	last_child
	19.8.2.16	logical_index
	19.8.2.17	memory
	19.8.2.18	name
	19.8.2.19	next_cousin
	19.8.2.20	next_sibling
	19.8.2.21	nodeset
	19.8.2.22	online_cpuset
	19.8.2.23	os_index
	19.8.2.24	os_level
	19.8.2.25	parent
	19.8.2.26	prev_cousin
	19.8.2.27	prev_sibling
	19.8.2.28	sibling_rank
	19.8.2.29	symmetric_subtree
	19.8.2.30	type
	19.8.2.31	userdata
19.9	hwloc_obj_attr_u	Union Reference
	19.9.1 Detailed D	Description
	19.9.2 Field Doc	umentation
	19.9.2.1	bridge
	19.9.2.2	cache
	19.9.2.3	group
	19.9.2.4	osdev

XX CONTENTS

19.9.2.5 pcidev
19.10hwloc_obj_info_s Struct Reference
19.10.1 Detailed Description
19.10.2 Field Documentation
19.10.2.1 name
19.10.2.2 value
19.11hwloc_obj_memory_s::hwloc_obj_memory_page_type_s Struct Reference
19.11.1 Detailed Description
19.11.2 Field Documentation
19.11.2.1 count
19.11.2.2 size
19.12hwloc_obj_memory_s Struct Reference
19.12.1 Detailed Description
19.12.2 Field Documentation
19.12.2.1 local_memory
19.12.2.2 page_types
19.12.2.3 page_types_len
19.12.2.4 total_memory
19.13hwloc_obj_attr_u::hwloc_osdev_attr_s Struct Reference
19.13.1 Detailed Description
19.13.2 Field Documentation
19.13.2.1 type
19.14hwloc_obj_attr_u::hwloc_pcidev_attr_s Struct Reference
19.14.1 Detailed Description
19.14.2 Field Documentation
19.14.2.1 bus
19.14.2.2 class_id
19.14.2.3 dev
19.14.2.4 device_id
19.14.2.5 domain
19.14.2.6 func
19.14.2.7 linkspeed
19.14.2.8 revision
19.14.2.9 subdevice_id
19.14.2.10subvendor_id
19.14.2.11vendor_id
19.15hwloc_topology_cpubind_support Struct Reference

CONTENTS xxi

19.15.1 Detailed Description	184
19.15.2 Field Documentation	184
19.15.2.1 get_proc_cpubind	184
19.15.2.2 get_proc_last_cpu_location	184
19.15.2.3 get_thisproc_cpubind	184
19.15.2.4 get_thisproc_last_cpu_location	185
19.15.2.5 get_thisthread_cpubind	185
19.15.2.6 get_thisthread_last_cpu_location	185
19.15.2.7 get_thread_cpubind	185
19.15.2.8 set_proc_cpubind	185
19.15.2.9 set_thisproc_cpubind	185
19.15.2.10set_thisthread_cpubind	185
19.15.2.11set_thread_cpubind	185
19.16hwloc_topology_diff_u::hwloc_topology_diff_generic_s Struct Reference	185
19.16.1 Field Documentation	186
19.16.1.1 next	186
19.16.1.2 type	186
19.17hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_generic_s Struct Reference	186
19.17.1 Field Documentation	186
19.17.1.1 type	186
19.17.1.1 type	
	186
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference	186 186
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference	186 186 186
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference	186 186 186 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference	186 186 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference	186 186 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference  19.18.1 Field Documentation  19.18.1.1 diff  19.18.1.2 next  19.18.1.3 obj_depth  19.18.1.4 obj_index	186 186 187 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference  19.18.1 Field Documentation  19.18.1.1 diff  19.18.1.2 next  19.18.1.3 obj_depth  19.18.1.4 obj_index  19.18.1.5 type	186 186 187 187 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference  19.18.1 Field Documentation  19.18.1.1 diff  19.18.1.2 next  19.18.1.3 obj_depth  19.18.1.4 obj_index  19.18.1.5 type  19.19hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s Struct Reference	186 186 187 187 187 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference  19.18.1 Field Documentation  19.18.1.1 diff  19.18.1.2 next  19.18.1.3 obj_depth  19.18.1.4 obj_index  19.18.1.5 type  19.19hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s Struct Reference  19.19.1 Detailed Description	186 186 187 187 187 187 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference  19.18.1 Field Documentation  19.18.1.1 diff  19.18.1.2 next  19.18.1.3 obj_depth  19.18.1.4 obj_index  19.18.1.5 type  19.19hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s Struct Reference  19.19.1 Detailed Description  19.19.2 Field Documentation	186 186 187 187 187 187 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference  19.18.1 Field Documentation  19.18.1.1 diff  19.18.1.2 next  19.18.1.3 obj_depth  19.18.1.4 obj_index  19.18.1.5 type  19.19hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s Struct Reference  19.19.1 Detailed Description  19.19.2 Field Documentation  19.19.2.1 name	186 186 187 187 187 187 187 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference  19.18.1 Field Documentation  19.18.1.1 diff  19.18.1.2 next  19.18.1.3 obj_depth  19.18.1.4 obj_index  19.18.1.5 type  19.19hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s Struct Reference  19.19.1 Detailed Description  19.19.2 Field Documentation  19.19.2.1 name  19.19.2.2 newvalue	186 186 187 187 187 187 187 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference  19.18.1 Field Documentation  19.18.1.1 diff  19.18.1.2 next  19.18.1.3 obj_depth  19.18.1.4 obj_index  19.18.1.5 type  19.19hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s Struct Reference  19.19.1 Detailed Description  19.19.2 Field Documentation  19.19.2.1 name  19.19.2.2 newvalue  19.19.2.3 oldvalue	186 186 187 187 187 187 187 187 187 187
19.18hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s Struct Reference  19.18.1 Field Documentation  19.18.1.1 diff  19.18.1.2 next  19.18.1.3 obj_depth  19.18.1.4 obj_index  19.18.1.5 type  19.19hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s Struct Reference  19.19.1 Detailed Description  19.19.2 Field Documentation  19.19.2.1 name  19.19.2.2 newvalue  19.19.2.3 oldvalue  19.19.2.4 type	186 186 187 187 187 187 187 187 187 187

xxii CONTENTS

19.20.2.1 generic
19.20.2.2 string
19.20.2.3 uint64
19.21 hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s Struct Reference
19.21.1 Detailed Description
19.21.2 Field Documentation
19.21.2.1 index
19.21.2.2 newvalue
19.21.2.3 oldvalue
19.21.2.4 type
19.22hwloc_topology_diff_u::hwloc_topology_diff_too_complex_s Struct Reference
19.22.1 Field Documentation
19.22.1.1 next
19.22.1.2 obj_depth
19.22.1.3 obj_index
19.22.1.4 type
19.23hwloc_topology_diff_u Union Reference
19.23.1 Detailed Description
19.23.2 Field Documentation
19.23.2.1 generic
19.23.2.2 obj_attr
19.23.2.3 too_complex
19.24hwloc_topology_discovery_support Struct Reference
19.24.1 Detailed Description
19.24.2 Field Documentation
19.24.2.1 pu
19.25hwloc_topology_membind_support Struct Reference
19.25.1 Detailed Description
19.25.2 Field Documentation
19.25.2.1 alloc_membind
19.25.2.2 bind_membind
19.25.2.3 firsttouch_membind
19.25.2.4 get_area_membind
19.25.2.5 get_proc_membind
19.25.2.6 get_thisproc_membind
19.25.2.7 get_thisthread_membind
19.25.2.8 interleave_membind

CONTENTS xxiii

19.25.2.9	migrate_membind	 	 	 	 192
19.25.2.10	nexttouch_membind	 	 	 	 192
19.25.2.11	replicate_membind	 	 	 	 192
19.25.2.12	set_area_membind	 	 	 	 192
19.25.2.13	set_proc_membind	 	 	 	 192
19.25.2.14	lset_thisproc_membind .	 	 	 	 193
19.25.2.15	set_thisthread_membind	 	 	 	 193
19.26hwloc_topology_s	upport Struct Reference	 	 	 	 193
19.26.1 Detailed D	escription	 	 	 	 193
19.26.2 Field Docu	umentation	 	 	 	 193
19.26.2.1	cpubind	 	 	 	 193
19.26.2.2	discovery	 	 	 	 193
19.26.2.3	membind	 	 	 	 193
ndex					194

## Chapter 1

## **Hardware Locality**

## Portable abstraction of hierarchical architectures for high-performance computing

### 1.1 Introduction

hwloc provides command line tools and a C API to obtain the hierarchical map of key computing elements, such as : NUMA memory nodes, shared caches, processor sockets, processor cores, processing units (logical processors or "threads") and even I/O devices. hwloc also gathers various attributes such as cache and memory information, and is portable across a variety of different operating systems and platforms. Additionally it may assemble the topologies of multiple machines into a single one so as to let applications consult the topology of an entire fabric or cluster at once.

hwloc primarily aims at helping high-performance computing (HPC) applications, but is also applicable to any project seeking to exploit code and/or data locality on modern computing platforms.

Note that the hwloc project represents the merger of the libtopology project from inria and the Portable Linux Processor Affinity (PLPA) sub-project from Open MPI. Both of these prior projects are now deprecated. The first hwloc release was essentially a "re-branding" of the libtopology code base, but with both a few genuinely new features and a few PLPA-like features added in. Prior releases of hwloc included documentation about switching from PLPA to hwloc; this documentation has been dropped on the assumption that everyone who was using PLPA has already switched to hwloc.

hwloc supports the following operating systems:

- Linux (including old kernels not having sysfs topology information, with knowledge of cpusets, offline CPUs, ScaleMP vSMP, NumaScale NumaConnect, and Kerrighed support)
- Solaris
- AIX
- Darwin / OS X
- FreeBSD and its variants (such as kFreeBSD/GNU)
- NetBSD
- OSF/1 (a.k.a., Tru64)
- HP-UX
- · Microsoft Windows
- IBM BlueGene/Q Compute Node Kernel (CNK)

2 Hardware Locality

Since it uses standard Operating System information, hwloc's support is mostly independant from the processor type (x86, powerpc, ...) and just relies on the Operating System support. The only exception to this is kFreeBSD, which does not support topology information, and hwloc thus uses an x86-only CPUID-based backend (which can be used for other OSes too, see the Components and plugins section).

To check whether hwloc works on a particular machine, just try to build it and run lstopo or lstopo-no-graphics. If some things do not look right (e.g. bogus or missing cache information), see Questions and Bugs below.

hwloc only reports the number of processors on unsupported operating systems; no topology information is available.

For development and debugging purposes, hwloc also offers the ability to work on "fake" topologies:

- · Symmetrical tree of resources generated from a list of level arities
- · Remote machine simulation through the gathering of Linux sysfs topology files

hwloc can display the topology in a human-readable format, either in graphical mode (X11), or by exporting in one of several different formats, including: plain text, PDF, PNG, and FIG (see CLI Examples below). Note that some of the export formats require additional support libraries.

hwloc offers a programming interface for manipulating topologies and objects. It also brings a powerful CPU bitmap API that is used to describe topology objects location on physical/logical processors. See the Programming Interface below. It may also be used to binding applications onto certain cores or memory nodes. Several utility programs are also provided to ease command-line manipulation of topology objects, binding of processes, and so on.

Perl bindings are available from Bernd Kallies on CPAN.

Python bindings are available from Guy Streeter:

```
Fedora RPM and tarball.git tree (html).
```

## 1.2 Installation

hwloc (http://www.open-mpi.org/projects/hwloc/) is available under the BSD license. It is hosted as a sub-project of the overall Open MPI project (http://www.open-mpi.org/). Note that hwloc does not require any functionality from Open MPI – it is a wholly separate (and much smaller!) project and code base. It just happens to be hosted as part of the overall Open MPI project.

Nightly development snapshots are available on the web site. Additionally, the code can be directly cloned from Git:

```
shell$ git clone https://github.com/open-mpi/hwloc.git
shell$ cd hwloc
shell$ ./autogen.sh
```

Note that GNU Autoconf >=2.63, Automake >=1.10 and Libtool >=2.2.6 are required when building from a Git clone.

Installation by itself is the fairly common GNU-based process:

```
shell$ ./configure --prefix=...
shell$ make
shell$ make install
```

The hwloc command-line tool "Istopo" produces human-readable topology maps, as mentioned above. It can also export maps to the "fig" file format. Support for PDF, Postscript, and PNG exporting is provided if the "Cairo" development package (usually cairo-devel or libcairo2-dev) can be found in "Istopo" when hwloc is configured and build.

The hwloc core may also benefit from the following development packages:

1.3 CLI Examples 3

• libnuma for memory binding and migration support on Linux (numactl-devel or libnuma-dev package).

- hwloc can use one of two different libraries for full I/O device discovery:
  - 1. libpciaccess (BSD). The relevant development package is usually libpciaccess-devel or libpciaccess-dev.

On Linux, PCI discovery may still be performed even if none of the above libraries can be used.

- · the AMD OpenCL implementation for OpenCL device discovery.
- the NVIDIA CUDA Toolkit for CUDA device discovery.
- the NVIDIA Tesla Development Kit for NVML device discovery.
- the NV-CONTROL X extension library (NVCtrl) for NVIDIA display discovery.
- libxml2 for full XML import/export support (otherwise, the internal minimalistic parser will only be able to import XML files that were exported by the same hwloc release). See Importing and exporting topologies from/to XML files for details. The relevant development package is usually libxml2-devel or libxml2-dev.
- libtool's ltdl library for dynamic plugin loading. The relevant development package is usually libtool-ltdl-devel or libltdl-dev.

PCI and XML support may be statically built inside the main hwloc library, or as separate dynamically-loaded plugins (see the Components and plugins section).

Note that because of the possibility of GPL taint, the pciutils library libpci will not be used (remember that hwloc is BSD-licensed).

Also note that if you install supplemental libraries in non-standard locations, hwloc's configure script may not be able to find them without some help. You may need to specify additional CPPFLAGS, LDFLAGS, or PKG\_CONFIG\_PATH values on the configure command line.


For example, if libpciaccess was installed into /opt/pciaccess, hwloc's configure script may not find it be default. Try adding PKG\_CONFIG\_PATH to the ./configure command line, like this:

```
./configure PKG_CONFIG_PATH=/opt/pciaccess/lib/pkgconfig ...
```

## 1.3 CLI Examples

On a 4-socket 2-core machine with hyperthreading, the 1stopo tool may show the following graphical output:

4 Hardware Locality



Here's the equivalent output in textual form:

```
Machine (16GB)
  Socket L#0 + L3 L#0 (4096KB)
   L2 L#0 (1024KB) + L1 L#0 (16KB) + Core L#0
     PU L#0 (P#0)
     PU L#1 (P#8)
   L2 L#1 (1024KB) + L1 L#1 (16KB) + Core L#1
     PU L#2 (P#4)
      PU L#3 (P#12)
  Socket L#1 + L3 L#1 (4096KB)
   L2 L#2 (1024KB) + L1 L#2 (16KB) + Core L#2
     PU L#4 (P#1)
     PU L#5 (P#9)
    L2 L#3 (1024KB) + L1 L#3 (16KB) + Core L#3
      PU L#6 (P#5)
     PU L#7 (P#13)
  Socket L#2 + L3 L#2 (4096KB)
   L2 L#4 (1024KB) + L1 L#4 (16KB) + Core L#4
      PU L#8 (P#2)
     PU L#9 (P#10)
   L2 L#5 (1024KB) + L1 L#5 (16KB) + Core L#5
     PU L#10 (P#6)
      PU L#11 (P#14)
  Socket L#3 + L3 L#3 (4096KB)
    L2 L\#6 (1024KB) + L1 L\#6 (16KB) + Core L\#6
      PU L#12 (P#3)
      PU L#13 (P#11)
   L2 L#7 (1024KB) + L1 L#7 (16KB) + Core L#7
      PU L#14 (P#7)
      PU L#15 (P#15)
```


Finally, here's the equivalent output in XML. Long lines were artificially broken for document clarity (in the real output,

1.3 CLI Examples 5

each XML tag is on a single line), and only socket #0 is shown for brevity:

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE topology SYSTEM "hwloc.dtd">
<topology>
  <object type="Machine" os_index="0" cpuset="0x0000fffff"</pre>
      complete_cpuset="0x0000fffff" online_cpuset="0x0000fffff"
     allowed cpuset="0x0000ffff"
      dmi_board_vendor="Dell Computer Corporation" dmi_board_name="0RD318"
     local_memory="16648183808">
    <page_type size="4096" count="4064498"/>
    <page_type size="2097152" count="0"/>
    <object type="Socket" os_index="0" cpuset="0x00001111" ... >
      <object type="Cache" cpuset="0x00001111" ...</pre>
          cache_size="4194304" depth="3" cache_linesize="64">
        <object type="Cache" cpuset="0x00000101" ...</pre>
            cache_size="1048576" depth="2" cache_linesize="64">
          <object type="Cache" cpuset="0x00000101" ...</pre>
              cache_size="16384" depth="1" cache_linesize="64">
            <object type="Core" os_index="0" ... >
              <object type="PU" os_index="0" cpuset="0x00000001"</pre>
                  complete_cpuset="0x00000001" online_cpuset="0x00000001"
                  allowed_cpuset="0x00000001"/>
              <object type="PU" os_index="8" cpuset="0x00000100"</pre>
                  complete_cpuset="0x00000100" online_cpuset="0x00000100"
                   allowed_cpuset="0x00000100"/>
            </object>
          </object>
        </object>
        <object type="Cache" cpuset="0x00001010" ...</pre>
            cache_size="1048576" depth="2" cache_linesize="64">
          <object type="Cache" cpuset="0x00001010"</pre>
              cache_size="16384" depth="1" cache_linesize="64">
            <object type="Core" os_index="1" cpuset="0x00001010" ... >
              <object type="PU" os_index="4" cpuset="0x00000010"</pre>
                   complete_cpuset="0x00000010" online_cpuset="0x00000010"
                   allowed cpuset="0x00000010"/>
              <object type="PU" os_index="12" cpuset="0x00001000"</pre>
                  complete_cpuset="0x00001000" online_cpuset="0x00001000"
                  allowed_cpuset="0x00001000"/>
            </object>
          </object>
        </object>
      </object>
    <!-- ...other sockets listed here ... -->
  </object>
</topology>
```

On a 4-socket 2-core Opteron NUMA machine, the 1stopo tool may show the following graphical output:



6 Hardware Locality

Here's the equivalent output in textual form:

```
Machine (32GB)

NUMANode L#0 (P#0 8190MB) + Socket L#0

L2 L#0 (1024KB) + L1 L#0 (64KB) + Core L#0 + PU L#0 (P#0)

L2 L#1 (1024KB) + L1 L#1 (64KB) + Core L#1 + PU L#1 (P#1)

NUMANode L#1 (P#1 8192MB) + Socket L#1

L2 L#2 (1024KB) + L1 L#2 (64KB) + Core L#2 + PU L#2 (P#2)

L2 L#3 (1024KB) + L1 L#3 (64KB) + Core L#3 + PU L#3 (P#3)

NUMANode L#2 (P#2 8192MB) + Socket L#2

L2 L#4 (1024KB) + L1 L#4 (64KB) + Core L#4 + PU L#4 (P#4)

L2 L#5 (1024KB) + L1 L#5 (64KB) + Core L#5 + PU L#5 (P#5)

NUMANode L#3 (P#3 8192MB) + Socket L#3

L2 L#6 (1024KB) + L1 L#6 (64KB) + Core L#6 + PU L#6 (P#6)


L2 L#7 (1024KB) + L1 L#6 (64KB) + Core L#6 + PU L#6 (P#6)
```

And here's the equivalent output in XML. Similar to above, line breaks were added and only PU #0 is shown for brevity:

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE topology SYSTEM "hwloc.dtd">
<topology>
  <object type="Machine" os_index="0" cpuset="0x000000ff"</pre>
      complete_cpuset="0x000000ff" online_cpuset="0x000000ff"
      allowed_cpuset="0x000000ff" nodeset="0x000000ff"
      complete_nodeset="0x000000ff" allowed_nodeset="0x000000ff"
      dmi_board_vendor="TYAN Computer Corp" dmi_board_name="S4881 ">
    <page_type size="4096" count="0"/>
    <page_type size="2097152" count="0"/>
    <object type="NUMANode" os_index="0" cpuset="0x00000003" ...</pre>
        nodeset="0x00000001" ... local_memory="7514177536">
      <page_type size="4096" count="1834516"/>
      <page_type size="2097152" count="0"/>
      <object type="Socket" os_index="0" cpuset="0x00000003" ... >
        <object type="Cache" cpuset="0x00000001" ...</pre>
            cache_size="1048576" depth="2" cache_linesize="64">
          <object type="Cache" cpuset="0x00000001" ...</pre>
              cache_size="65536" depth="1" cache_linesize="64">
            <object type="Core" os_index="0" ... >
              <object type="PU" os_index="0" cpuset="0x00000001"</pre>
                  complete_cpuset="0x00000001" online_cpuset="0x00000001"
                  allowed_cpuset="0x00000001" nodeset="0x00000001"
                  complete_nodeset="0x00000001" allowed_nodeset="0x00000001"/>
            </object>
          </object>
        </object>
 <!-- ...more objects listed here ... -->
</topology>
```

On a 2-socket quad-core Xeon (pre-Nehalem, with 2 dual-core dies into each socket):

1.3 CLI Examples 7



#### Here's the same output in textual form:

```
Machine (16GB)

Socket L#0

L2 L#0 (4096KB)

L1 L#1 (32KB) + Core L#0 + PU L#0 (P#0)

L1 L#1 (4096KB)

L1 L#2 (32KB) + Core L#1 + PU L#1 (P#4)

L2 L#1 (4096KB)

L1 L#2 (32KB) + Core L#2 + PU L#2 (P#2)

L1 L#3 (32KB) + Core L#3 + PU L#3 (P#6)

Socket L#1

L2 L#2 (4096KB)

L1 L#4 (32KB) + Core L#4 + PU L#4 (P#1)

L1 L#5 (32KB) + Core L#5 + PU L#5 (P#5)

L2 L#3 (4096KB)

L1 L#6 (32KB) + Core L#6 + PU L#6 (P#3)

L1 L#6 (32KB) + Core L#6 + PU L#6 (P#3)

L1 L#7 (32KB) + Core L#7 + PU L#7 (P#7)
```

#### And the same output in XML (line breaks added, only PU #0 shown):

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE topology SYSTEM "hwloc.dtd">
<topology>
  <object type="Machine" os_index="0" cpuset="0x000000ff"</pre>
      complete_cpuset="0x000000ff" online_cpuset="0x000000ff"
      allowed_cpuset="0x000000ff" dmi_board_vendor="Dell Inc."
      dmi_board_name="0NR282" local_memory="16865292288">
    <page_type size="4096" count="4117503"/>
    <page_type size="2097152" count="0"/>
    <object type="Socket" os_index="0" cpuset="0x00000055" ... >
      <object type="Cache" cpuset="0x00000011" ...</pre>
          cache_size="4194304" depth="2" cache_linesize="64">
        <object type="Cache" cpuset="0x00000001" ...</pre>
            cache_size="32768" depth="1" cache_linesize="64">
          <object type="Core" os_index="0" ... >
            <object type="PU" os_index="0" cpuset="0x00000001"</pre>
                complete_cpuset="0x00000001" online_cpuset="0x00000001"
                allowed_cpuset="0x00000001"/>
          </object>
        </object>
        <object type="Cache" cpuset="0x00000010" ...</pre>
            cache_size="32768" depth="1" cache_linesize="64">
          <object type="Core" os_index="1" ... >
            <object type="PU" os_index="4" cpuset="0x00000010" ...</pre>
                complete_cpuset="0x00000010" online_cpuset="0x00000010"
```

8 Hardware Locality

## 1.4 Programming Interface

The basic interface is available in **hwloc.h**. Some higher-level functions are available in **hwloc/helper.h** to reduce the need to manually manipulate objects and follow links between them. Documentation for all these is provided later in this document. Developers may also want to look at hwloc/inlines.h which contains the actual inline code of some **hwloc.h** routines, and at this document, which provides good higher-level topology traversal examples.

To precisely define the vocabulary used by hwloc, a Terms and Definitions section is available and should probably be read first.

Each hwloc object contains a cpuset describing the list of processing units that it contains. These bitmaps may be used for CPU binding and Memory binding. hwloc offers an extensive bitmap manipulation interface in **hwloc/bitmap.h**.

Moreover, hwloc also comes with additional helpers for interoperability with several commonly used environments. See the Interoperability With Other Software section for details.

The complete API documentation is available in a full set of HTML pages, man pages, and self-contained PDF files (formatted for both both US letter and A4 formats) in the source tarball in doc/doxygen-doc/.

**NOTE:** If you are building the documentation from a Git clone, you will need to have Doxygen and pdflatex installed – the documentation will be built during the normal "make" process. The documentation is installed during "make install" to \$prefix/share/doc/hwloc/ and your systems default man page tree (under \$prefix, of course).

#### 1.4.1 Portability


As shown in CLI Examples, hwloc can obtain information on a wide variety of hardware topologies. However, some platforms and/or operating system versions will only report a subset of this information. For example, on an PPC64-based system with 32 cores (each with 2 hardware threads) running a default 2.6.18-based kernel from RHEL 5.4, hwloc is only able to glean information about NUMA nodes and processor units (PUs). No information about caches, sockets, or cores is available.

Similarly, Operating System have varying support for CPU and memory binding, e.g. while some Operating Systems provide interfaces for all kinds of CPU and memory bindings, some others provide only interfaces for a limited number of kinds of CPU and memory binding, and some do not provide any binding interface at all. Hwloc's binding functions would then simply return the ENOSYS error (Function not implemented), meaning that the underlying Operating System does not provide any interface for them. CPU binding and Memory binding provide more information on which hwloc binding functions should be preferred because interfaces for them are usually available on the supported Operating Systems.

Here's the graphical output from Istopo on this platform when Simultaneous Multi-Threading (SMT) is enabled:



And here's the graphical output from Istopo on this platform when SMT is disabled:




Notice that hwloc only sees half the PUs when SMT is disabled. PU #15, for example, seems to change location from NUMA node #0 to #1. In reality, no PUs "moved" – they were simply re-numbered when hwloc only saw half as many. Hence, PU #15 in the SMT-disabled picture probably corresponds to PU #30 in the SMT-enabled picture.

This same "PUs have disappeared" effect can be seen on other platforms – even platforms / OSs that provide much more information than the above PPC64 system. This is an unfortunate side-effect of how operating systems report

10 Hardware Locality

information to hwloc.

Note that upgrading the Linux kernel on the same PPC64 system mentioned above to 2.6.34, hwloc is able to discover all the topology information. The following picture shows the entire topology layout when SMT is enabled:



12 Hardware Locality

Developers using the hwloc API or XML output for portable applications should therefore be extremely careful to not make any assumptions about the structure of data that is returned. For example, per the above reported PPC topology, it is not safe to assume that PUs will always be descendants of cores.

Additionally, future hardware may insert new topology elements that are not available in this version of hwloc. Long-lived applications that are meant to span multiple different hardware platforms should also be careful about making structure assumptions. For example, there may someday be an element "lower" than a PU, or perhaps a new element may exist between a core and a PU.

### 1.4.2 API Example

The following small C example (named "hwloc-hello.c") prints the topology of the machine and bring the process to the first logical processor of the second core of the machine. More examples are available in the doc/examples/ directory of the source tree.

```
/* Example hwloc API program.
* See other examples under doc/examples/ in the source tree
 * for more details.
* Copyright © 2009-2014 Inria. All rights reserved.
* Copyright © 2009-2011 Université Bordeaux 1
* Copyright © 2009-2010 Cisco Systems, Inc. All rights reserved.
\star See COPYING in top-level directory.
* hwloc-hello.c
#include <hwloc.h>
#include <errno.h>
#include <stdio.h>
#include <string.h>
static void print_children(hwloc_topology_t topology,
     hwloc_obj_t obj,
                           int depth)
   char string[128];
   hwloc_obj_snprintf(string, sizeof(string), topology, obj, "#", 0);
   printf("%*s%s\n", 2*depth, "", string);
    for (i = 0; i < obj->arity; i++) {
        print_children(topology, obj->children[i], depth + 1);
int main(void)
    int depth;
   unsigned i, n;
   unsigned long size;
    int levels;
   char string[128];
    int topodepth;
   hwloc_topology_t topology;
hwloc_cpuset_t cpuset;
   hwloc obj t obj;
    /* Allocate and initialize topology object. */
   hwloc_topology_init(&topology);
    /* ... Optionally, put detection configuration here to ignore
      some objects types, define a synthetic topology, etc...
       The default is to detect all the objects of the machine that
       the caller is allowed to access. See Configure Topology
       Detection. */
    /* Perform the topology detection. */
   hwloc_topology_load(topology);
```

```
/* Optionally, get some additional topology information
  in case we need the topology depth later. */
topodepth = hwloc_topology_get_depth(topology);
/*********************
* First example:
* Walk the topology with an array style, from level 0 (always
 \star the system level) to the lowest level (always the proc level).
for (depth = 0; depth < topodepth; depth++) {</pre>
   printf("*** Objects at level %d\n", depth);
   for (i = 0; i < hwloc_get_nbobjs_by_depth(topology, depth);</pre>
       i++) {
       hwloc_obj_snprintf(string, sizeof(string), topology,
                hwloc_get_obj_by_depth(topology, depth, i),
                 "#", 0);
       printf("Index %u: %s\n", i, string);
   }
}
/************************
* Second example:
\star Walk the topology with a tree style.
 ********
printf("*** Printing overall tree\n");
print_children(topology, hwloc_get_root_obj(topology), 0);
/*********************
* Third example:
* Print the number of sockets.
 depth = hwloc_get_type_depth(topology, HWLOC_OBJ_SOCKET);
if (depth == HWLOC_TYPE_DEPTH_UNKNOWN) {
   printf("*** The number of sockets is unknown\n");
} else {
   printf("*** %u socket(s)\n",
         hwloc_get_nbobjs_by_depth(topology, depth));
}
/**********************
* Fourth example:
 \star Compute the amount of cache that the first logical processor
 * has above it.
 levels = 0:
size = 0;
for (obj = hwloc_get_obj_by_type(topology, HWLOC_OBJ_PU, 0);
    obj;
    obj = obj->parent)
 if (obj->type == HWLOC_OBJ_CACHE) {
   levels++;
   size += obj->attr->cache.size;
printf("*** Logical processor 0 has %d caches totaling %luKB\n",
      levels, size / 1024);
/************************
* Fifth example:
\star Bind to only one thread of the last core of the machine.
\star First find out where cores are, or else smaller sets of CPUs if
 * the OS doesn't have the notion of a "core".
 ************************
depth = hwloc_get_type_or_below_depth(topology,
 HWLOC_OBJ_CORE);
/* Get last core. */
obj = hwloc_get_obj_by_depth(topology, depth,
             hwloc_get_nbobjs_by_depth(topology, depth) - 1);
if (obj) {
   /* Get a copy of its cpuset that we may modify. */
   cpuset = hwloc_bitmap_dup(obj->cpuset);
   /\star Get only one logical processor (in case the core is
      SMT/hyperthreaded). */
   hwloc_bitmap_singlify(cpuset);
   /\star And try to bind ourself there. \star/
   if (hwloc_set_cpubind(topology, cpuset, 0)) {
    char *str;
```

14 Hardware Locality

```
int error = errno;
           hwloc_bitmap_asprintf(&str, obj->cpuset);
           printf("Couldn't bind to cpuset %s: %s\n", str, strerror(error));
       /* Free our cpuset copy */
       hwloc_bitmap_free(cpuset);
    * Sixth example:
    * Allocate some memory on the last NUMA node, bind some existing
    * memory to the last NUMA node.
     ***********************
   /* Get last node. */
   n = hwloc_get_nbobjs_by_type(topology,
     HWLOC_OBJ_NODE);
   if (n) {
       void *m;
       size = 1024 * 1024;
       obj = hwloc_get_obj_by_type(topology,
     HWLOC_OBJ_NODE, n - 1);
      m = hwloc_alloc_membind_nodeset(topology, size, obj->
     nodeset,
               HWLOC_MEMBIND_DEFAULT, 0);
       hwloc_free(topology, m, size);
       m = malloc(size);
       hwloc_set_area_membind_nodeset(topology, m, size, obj->
     nodeset,
              HWLOC_MEMBIND_DEFAULT, 0);
       free(m);
   /* Destroy topology object. */
   hwloc_topology_destroy(topology);
   return 0:
}
```

hwloc provides a pkg-config executable to obtain relevant compiler and linker flags. For example, it can be used thusly to compile applications that utilize the hwloc library (assuming GNU Make):

```
CFLAGS += $(pkg-config --cflags hwloc)
LDLIBS += $(pkg-config --libs hwloc)
cc hwloc-hello.c $(CFLAGS) -o hwloc-hello $(LDLIBS)
```

On a machine with 4GB of RAM and 2 processor sockets – each socket of which has two processing cores – the output from running hwloc-hello could be something like the following:

```
shell$ ./hwloc-hello
*** Objects at level 0
Index 0: Machine (3938MB)
*** Objects at level 1
Index 0: Socket#0
Index 1: Socket#1
*** Objects at level 2
Index 0: Core#0
Index 1: Core#1
Index 2: Core#3
Index 3: Core#2
*** Objects at level 3
Index 0: PU#0
Index 1: PU#1
Index 2: PU#2
Index 3: PU#3
*** Printing overall tree
Machine (3938MB)
  Socket.#0
```

```
Core#0
PU#0
Core#1
PU#1
Socket#1
Core#3
PU#2
Core#2
PU#3
*** 2 socket(s)
shell$
```

## 1.5 Questions and Bugs

Questions should be sent to the devel mailing list (http://www.open-mpi.org/community/lists/hwloc.ephp). Bug reports should be reported in the tracker (https://git.open-mpi.org/trac/hwloc/).

If hwloc discovers an incorrect topology for your machine, the very first thing you should check is to ensure that you have the most recent updates installed for your operating system. Indeed, most of hwloc topology discovery relies on hardware information retrieved through the operation system (e.g., via the /sys virtual filesystem of the Linux kernel). If upgrading your OS or Linux kernel does not solve your problem, you may also want to ensure that you are running the most recent version of the BIOS for your machine.

If those things fail, contact us on the mailing list for additional help. Please attach the output of Istopo after having given the <code>-enable-debug</code> option to ./configure and rebuilt completely, to get debugging output. Also attach the <code>/proc+/sys</code> tarball generated by the installed script <code>hwloc-gather-topology</code> when submitting problems about Linux, or send the output of <code>kstat cpu\_info</code> in the Solaris case, or the output of <code>sysctl hw</code> in the Darwin or BSD cases.

## 1.6 History / Credits

hwloc is the evolution and merger of the libtopology (http://runtime.bordeaux.inria.fr/libtopology/) project and the Portable Linux Processor Affinity (PLPA) (http://www.open-mpi.org/projects/plpa/) project. Because of functional and ideological overlap, these two code bases and ideas were merged and released under the name "hwloc" as an Open MPI sub-project.

libtopology was initially developed by the inria Runtime Team-Project (http://runtime.bordeaux.inria.  $\leftarrow$  fr/) (headed by Raymond Namyst (http://dept-info.labri.fr/~namyst/). PLPA was initially developed by the Open MPI development team as a sub-project. Both are now deprecated in favor of hwloc, which is distributed as an Open MPI sub-project.

## 1.7 Further Reading

The documentation chapters include

- · Terms and Definitions
- · Command-Line Tools
- Environment Variables
- · CPU and Memory Binding Overview
- I/O Devices

16 Hardware Locality

- Multi-node Topologies
- · Object attributes
- Importing and exporting topologies from/to XML files
- Synthetic topologies
- Interoperability With Other Software
- Thread Safety
- Components and plugins
- Embedding hwloc in Other Software
- Frequently Asked Questions

Make sure to have had a look at those too!

# **Terms and Definitions**

**Object** Interesting kind of part of the system, such as a Core, a Cache, a Memory node, etc. The different types detected by hwloc are detailed in the hwloc obj type t enumeration.

They are topologically sorted by CPU set into a tree.

**CPU set** The set of logical processors (or processing units) logically included in an object (if it makes sense). They are always expressed using physical logical processor numbers (as announced by the OS). They are implemented as the <a href="https://hww.numbers.com/hww.numbers">hww.numbers</a> (as announced by the OS). They are implemented as the <a href="https://hww.numbers.com/hww.numbers">hww.numbers</a> (as announced by the OS). They are implemented as the <a href="https://hww.numbers.com/hww.numbers">hww.numbers</a> (as announced by the OS). They are implemented as the <a href="https://hww.numbers.com/hww.n

**Node set** The set of NUMA memory nodes logically included in an object (if it makes sense). They are always expressed using physical node numbers (as announced by the OS). They are implemented with the <a href="https://hww.numbers.com/hw

**Bitmap** A possibly-infinite set of bits used for describing sets of objects such as CPUs (CPU sets) or memory nodes (Node sets). They are implemented with the <a href="https://hww.nuber

**Parent object** The object logically containing the current object, for example because its CPU set includes the CPU set of the current object.

**Ancestor object** The parent object, or its own parent object, and so on.

**Children object(s)** The object (or objects) contained in the current object because their CPU set is included in the CPU set of the current object.

Arity The number of children of an object.

**Sibling objects** Objects which have the same parent. They usually have the same type (and hence are cousins, as well), but they may not if the topology is asymmetric.


Sibling rank Index to uniquely identify objects which have the same parent, and is always in the range [0, parent arity).


Cousin objects Objects of the same type (and depth) as the current object, even if they do not have the same parent.

**Level** Set of objects of the same type and depth. All these objects are cousins.

**Depth** Nesting level in the object tree, starting from the root object. If the topology is symmetric, the depth of a child is equal to the parent depth plus one, and an object depth is also equal to the number of parent/child links between the root object and the given object. If the topology is asymmetric, the difference between some parent and child depths may be larger than one when some intermediate levels (for instance caches) are missing in only some parts of the machine.

18 Terms and Definitions





It should be noted that for PU objects, the logical index – as computed linearly by hwloc – is not the same as the OS index.

See also What happens if my topology is asymmetric? for more details.

20 **Terms and Definitions** 

# **Command-Line Tools**

hwloc comes with an extensive C programming interface and several command line utilities. Each of them is fully documented in its own manual page; the following is a summary of the available command line tools.

### 3.1 Istopo and Istopo-no-graphics

Istopo (also known as hwloc-ls) displays the hierarchical topology map of the current system. The output may be graphical or textual, and can also be exported to numerous file formats such as PDF, PNG, XML, and others. Advanced graphical outputs require the "Cairo" development package (usually cairo-devel or libcairo2-dev).

Istopo and Istopo-no-graphics accept the same command-line options. However graphical outputs are only available in Istopo. Textual outputs (those that do not depend on heavy external libraries such as Cairo) are supported in both Istopo and Istopo-no-graphics.

This command can also display the processes currently bound to a part of the machine (via the -ps option).

Note that Istopo can read XML files and/or alternate chroot filesystems and display topological maps representing those systems (e.g., use Istopo to output an XML file on one system, and then use Istopo to read in that XML file and display it on a different system).

#### 3.2 hwloc-bind

hwloc-bind binds processes to specific hardware objects through a flexible syntax. A simple example is binding an executable to specific cores (or sockets or bitmaps or ...). The hwloc-bind(1) man page provides much more detail on what is possible.

hwloc-bind can also be used to retrieve the current process' binding.

#### 3.3 hwloc-calc

hwloc-calc is generally used to create bitmap strings to pass to hwloc-bind. Although hwloc-bind accepts many forms of object specification (i.e., bitmap strings are one of many forms that hwloc-bind understands), they can be useful, compact representations in shell scripts, for example.

hwloc-calc generates bitmap strings from given hardware objects with the ability to aggregate them, intersect them, and more. hwloc-calc generally uses the same syntax than hwloc-bind, but multiple instances may be composed to generate complex combinations.

22 Command-Line Tools

Note that hwloc-calc can also generate lists of logical processors or NUMA nodes that are convenient to pass to some external tools such as taskset or numactl.

#### 3.4 hwloc-info

hwloc-info dumps information about the given objects. It is intended to be used with tools such as grep for filtering certain attribute lines. When no object is specified, hwloc-info prints a summary of the topology.

#### 3.5 hwloc-distrib

hwloc-distrib generates a set of bitmap strings that are uniformly distributed across the machine for the given number of processes. These strings may be used with hwloc-bind to run processes to maximize their memory bandwidth by properly distributing them across the machine.

## 3.6 hwloc-ps

hwloc-ps is a tool to display the bindings of processes that are currently running on the local machine. By default, hwloc-ps only lists processes that are bound; unbound process (and Linux kernel threads) are not displayed.

## 3.7 hwloc-gather-topology

hwloc-gather-topology is a Linux-specific tool that saves the relevant topology files of the current machine into a tarball (and the corresponding Istopo output). These files may be used later (possibly offline) for simulating or debugging a machine without actually running on it.

#### 3.8 hwloc-distances

hwloc-distances displays all distance matrices attached to the topology. Note that Istopo may also display distance matrices in its verbose textual output. However Istopo only prints matrices that cover the entire topology while hwloc-distances also displays matrices that ignore part of the topology.

#### 3.9 hwloc-annotate

hwloc-annotate may add object attributes such as string information (see Custom string infos for details). It reads an input topology from a XML file and outputs the annotated topology as another XML file.

## 3.10 hwloc-diff and hwloc-patch

hwloc-diff computes the difference between two topologies and outputs it to another XML file. hwloc-patch reads such a difference file and applies to another topology.

## 3.11 hwloc-compress-dir

hwloc-compress-dir compresses an entire directory of XML files by using hwloc-diff to save the differences between topologies instead of entire topologies.

#### 3.12 hwloc-assembler

hwloc-assembler combines several XML topology files into a single multi-node XML topology. It may then be used later as input with hwloc\_topology\_set\_xml() or with the HWLOC\_XMLFILE environment variable. See Multi-node Topologies for details.

#### 3.13 hwloc-assembler-remote

hwloc-assembler-remote is a frontend to hwloc-assembler. It takes care of contacting the given list of remote hosts (through ssh) and retrieving their topologies as XML before assembling them with hwloc-assembler.

24 Command-Line Tools

# **Environment Variables**

The behavior of the hwloc library and tools may be tuned thanks to the following environment variables.

HWLOC\_XMLFILE=/path/to/file.xml enforces the discovery from the given XML file as if hwloc\_topology\_set\_xml() had been called. This file may have been generated earlier with Istopo file.xml. For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, HW← LOC\_THISSYSTEM should be set 1 in the environment too, to assert that the loaded file is really the underlying system. See also Importing and exporting topologies from/to XML files.

#### HWLOC\_XML\_VERBOSE=1

- HWLOC\_SYNTHETIC\_VERBOSE=1 enables verbose messages in the XML or synthetic topology backends. hwloc XML backends (see Importing and exporting topologies from/to XML files) can emit some error messages to the error output stream. Enabling these verbose messages within hwloc can be useful for understanding failures to parse input XML topologies. Similarly, enabling verbose messages in the synthetic topology backend can help understand why the description string is invalid. See also Synthetic topologies.
- HWLOC\_FSROOT=/path/to/linux/filesystem-root/ switches to reading the topology from the specified Linux filesystem root instead of the main file-system root, as if hwloc\_topology\_set\_fsroot() had been called. Not using the main file-system root causes hwloc\_topology\_is\_thissystem() to return 0. For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, HWLO← C\_THISSYSTEM should be set 1 in the environment too, to assert that the loaded file is really the underlying system.
- HWLOC\_THISSYSTEM=1 enforces the return value of hwloc\_topology\_is\_thissystem(), as if HWLOC\_TOPOLOG 
  Y\_FLAG\_IS\_THISSYSTEM was set with hwloc\_topology\_set\_flags(). It means that it makes hwloc assume that 
  the selected backend provides the topology for the system on which we are running, even if it is not the OSspecific backend but the XML backend for instance. This means making the binding functions actually call the 
  OS-specific system calls and really do binding, while the XML backend would otherwise provide empty hooks just 
  returning success. This can be used for efficiency reasons to first detect the topology once, save it to an XML file, 
  and quickly reload it later through the XML backend, but still having binding functions actually do bind.
- **HWLOC\_HIDE\_ERRORS=0** enables or disables verbose reporting of errors. The hwloc library may issue warnings to the standard error stream when it detects a problem during topology discovery, for instance if the operating system (or user) gives contradictory topology information. Setting this environment variable to 1 removes the actual displaying of these error messages.
- **HWLOC\_GROUPING=1** enables or disables objects grouping based on distances. By default, hwloc uses distance matrices between objects (either read from the OS or given by the user) to find groups of close objects. These groups are described by adding intermediate Group objects in the topology. Setting this environment variable to 0 will disable this grouping. This variable supersedes the obsolete HWLOC IGNORE DISTANCES variable.

26 Environment Variables

HWLOC\_GROUPING\_ACCURACY=0.05 relaxes distance comparison during grouping. By default, objects may be grouped if their distances form a minimal distance graph. When setting this variable to 0.02, these distances do not have to be strictly equal anymore, they may just be equal with a 2% error. If set to try instead of a numerical value, hwloc will try to group with perfect accuracy (0, the default), then with 0.01, 0.02, 0.05 and finally 0.1. Numbers given in this environment variable should always use a dot as a decimal mark (for instance 0.01 instead of 0,01).

- **HWLOC\_GROUPING\_VERBOSE=0** enables or disables some verbose messages during grouping. If this variable is set to 1, some debug messages will be displayed during distance-based grouping of objects even if debug was not specific at configure time. This is useful when trying to find an interesting distance grouping accuracy.
- HWLOC\_<type>\_DISTANCES=index,...:X\*Y
- HWLOC\_<type>\_DISTANCES=begin-end:X\*Y\*Z
- HWLOC\_<type>\_DISTANCES=index,...:distance,... sets a distance matrix for objects of the given type and physical indexes. The type should be given as its case-sensitive stringified value (e.g. NUMANode, Socket, Cache, Core, PU). If another distance matrix already exists for the given type, either because the user specified it or because the OS offers it, it will be replaced by the given one.

If the variable value is none, the existing distance matrix for the given type is removed. Otherwise, the variable value first consists in a list of physical indexes that may be specified as a comma-separated list (e.g. 0, 2, 4, 1, 3, 5) or as a range of consecutive indexes (0-5). It is followed by a colon and the corresponding distances:

- If X\*Y is given, X groups of Y close objects are specified.
- If X\*Y\*Z is given, X groups of Y groups of Z close objects are specified.
- Otherwise, the comma-separated list of distances should be given. If N objects are considered, the i\*N+j-th value gives the distance from the i-th object to the j-th object. These distance values must use a dot as a decimal separator.

Note that distances are ignored in multi-node topologies.

- HWLOC\_PCI\_<domain>\_<bus>\_LOCALCPUS=<cpuset> changes the locality of I/O devices behind the specified PCI hostbridge. If no I/O locality information is available or if the BIOS reports incorrect information, it is possible to move a I/O device tree (the entire set of objects behind a host bridge) near a custom set of processors. domain and bus are the PCI domain and primary bus of the corresponding host bridge.
- **HWLOC\_PLUGINS\_PATH=/path/to/hwloc/plugins/:...** changes the default search directory for plugins. By default, \$libdir/hwloc is used. The variable may contain several colon-separated directories.
- **HWLOC\_PLUGINS\_VERBOSE=1** displays verbose information about plugins. List which directories are scanned, which files are loaded, and which components are successfully loaded.
- HWLOC\_COMPONENTS=list,of,components forces a list of components to enable or disable. Enable or disable the given comma-separated list of components (if they do not conflict with each other). Component names prefixed with are disabled. Once the end of the list is reached, hwloc falls back to enabling the remaining components (sorted by priority) that do not conflict with the already enabled ones, and unless explicitly disabled in the list. If stop is met, the enabling loop immediately stops, no more component is enabled. If the variable is set to an empty string, no specific component is loaded first, all components are loaded in priority order, this is strictly identical to not specifying any variable. The xml component name may be followed by a X ML file to load (xml=file.xml). The synthetic component may be followed by a basic synthetic topology description (synthetic=node:2 pu:3, see Synthetic topologies). This variable does not take precedence over the application selecting components with functions such as hwloc\_topology\_set\_xml(). See Components and plugins for details.
- **HWLOC\_COMPONENTS\_VERBOSE=1** displays verbose information about components. Display messages when components are registered or enabled. This is the recommended way to list the available components with their priority (all of them are *registered* at startup).

# **CPU and Memory Binding Overview**

Some operating systems do not systematically provide separate functions for CPU and memory binding. This means that CPU binding functions may have have effects on the memory binding policy. Likewise, changing the memory binding policy may change the CPU binding of the current thread. This is often not a problem for applications, so by default hwloc will make use of these functions when they provide better binding support.

If the application does not want the CPU binding to change when changing the memory policy, it needs to use the H← WLOC\_MEMBIND\_NOCPUBIND flag to prevent hwloc from using OS functions which would change the CPU binding. Additionally, HWLOC\_CPUBIND\_NOMEMBIND can be passed to CPU binding function to prevent hwloc from using OS functions would change the memory binding policy. Of course, using these flags will reduce hwloc's overall support for binding, so their use is discouraged.

One can avoid using these flags but still closely control both memory and CPU binding by allocating memory, touching each page in the allocated memory, and then changing the CPU binding. The already-really-allocated memory will then be "locked" to physical memory and will not be migrated. Thus, even if the memory binding policy gets changed by the CPU binding order, the already-allocated memory will not change with it. When binding and allocating further memory, the CPU binding should be performed again in case the memory binding altered the previously-selected CPU binding.

Not all operating systems support the notion of a "current" memory binding policy for the current process, but such operating systems often still provide a way to allocate data on a given node set. Conversely, some operating systems support the notion of a "current" memory binding policy and do not permit allocating data on a specific node set without changing the current policy and allocate the data. To provide the most powerful coverage of these facilities, hwloc provides:

- functions that set/get the current memory binding policies (if supported): hwloc\_set/get\_membind\_\*() and hwloc set/get\_proc\_membind()
- functions that allocate memory bound to specific node set without changing the current memory binding policy (if supported): hwloc\_alloc\_membind() and hwloc\_alloc\_membind\_nodeset().
- helpers which, if needed, change the current memory binding policy of the process in order to obtain memory binding: hwloc alloc membind policy() and hwloc alloc membind policy nodeset()

An application can thus use the two first sets of functions if it wants to manage separately the global process binding policy and directed allocation, or use the third set of functions if it does not care about the process memory binding policy.

See CPU binding and Memory binding for hwloc's API functions regarding CPU and memory binding, respectively. There are some examples under doc/examples/ in the source tree.

# I/O Devices

hwloc usually manipulates processing units and memory but it can also discover I/O devices and report their locality as well. This is useful for placing I/O intensive applications on cores near the I/O devices they use.

## 6.1 Enabling and requirements

I/O discovery is disabled by default (except in Istopo) so as not to break legacy application by adding unexpected I/O objects to the topology. It can be enabled by passing flags such as HWLOC\_TOPOLOGY\_FLAG\_IO\_DEVICES to hwloc topology set flags() before loading the topology.

Note that I/O discovery requires significant help from the operating system. The pciaccess library (the development package is usually libpciaccess-devel or libpciaccess-dev) is needed to fully detect PCI devices and bridges, and the actual locality of these devices is only currently detected on Linux. Also, some operating systems require privileges for probing PCI devices, see Does hwloc require privileged access? for details.

On Linux, PCI discovery may still be performed even if libpciaccess cannot be used. But it misses PCI device names.

## 6.2 I/O object hierarchy

When I/O discovery is enabled and supported, some additional objects (types HWLOC\_OBJ\_BRIDGE, HWLOC\_OB J\_PCI\_DEVICE and HWLOC\_OBJ\_OS\_DEVICE) are added to the topology as a child of the object they are close to. For instance, if a I/O Hub is connected to a socket, the corresponding hwloc bridge object (and its PCI bridges and devices children) is inserted as a child of the corresponding hwloc socket object.

These new objects have neither CPU sets nor node sets (NULL pointers) because they are not directly usable by the user applications. Moreover I/O hierarchies may be highly complex (asymmetric trees of bridges). So I/O objects are placed in specific levels with custom depths. Their lists may still be traversed with regular helpers such as hwloc\_get\_

next\_obj\_by\_type(). However, hwloc offers some dedicated helpers such as hwloc\_get\_next\_pcidev() and hwloc\_get

next\_osdev() for convenience (see Finding I/O objects).

An I/O hierarchy is organized as follows: A hostbridge object ( HWLOC\_OBJ\_BRIDGE object with upstream type *Host* and downstream type *PCI*) is attached below a regular object (usually the entire machine or a NUMA node). There may be multiple hostbridges in the machine, attached to different places, but all I/O devices are below one of them. Each hostbridge contains one or several children, either other bridges (usually PCI to PCI) or PCI devices (HWLOC\_OBJ\_ PCI\_DEVICE). The number of bridges between the hostbridge and a PCI device depends on the machine and on the topology flags.

30 I/O Devices

#### 6.3 Software devices

Although each PCI device is uniquely identified by its bus ID (e.g. 0000:01:02.3), the application can hardly find out which PCI device is actually used when manipulating software handle (such as the *eth0* network interface, the *sda* hard drive, or the *mlx4\_0* OpenFabrics HCA). Therefore hwloc tries to add software devices (HWLOC\_OBJ\_OS\_DEVICE, also known as OS devices) below their PCI objects.

hwloc first tries to discover the corresponding names, e.g. *eth0*, *sda* or *mlx4\_0*, from the operating system. However, this ability is currently only available on Linux for some classes of devices.

hwloc then tries to discover software devices through additional I/O components using external libraries. For instance proprietary graphics drivers do not offer any OS name, but hwloc may still create one OS object per software handle when supported. For instance the opencl and cuda components may add some *opencl0d0* and *cuda0* OS device objects.

Here is a list of OS device objects commonly created by hwloc components when I/O discovery is enabled and supported.

- Hard disks (HWLOC\_OBJ\_OSDEV\_BLOCK)
  - sda (Linux component)
- Network interfaces (HWLOC\_OBJ\_OSDEV\_NETWORK)
  - eth0, wlan0, ib0 (Linux component)
- OpenFabrics HCAs (HWLOC\_OBJ\_OSDEV\_OPENFABRICS)
  - mlx4 0, gib0 (Linux component)
- GPUs (HWLOC OBJ OSDEV GPU)
  - nvml0 for the first NVML device (NVML component, using the NVIDIA Management Library)
  - :0.0 for the first display (GL component, using the NV-CONTROL X extension library, NVCtrl)
- Co-Processors (HWLOC\_OBJ\_OSDEV\_COPROC)
  - opencl0d0 for the first device of the first OpenCL platform, opencl1d3 for the fourth device of the second
     OpenCL platform (OpenCL component)
  - cuda0 for the first NVIDIA CUDA device (CUDA component, using the NVIDIA CUDA Library)
  - mic0 for the first Intel Xeon Phi (MIC) coprocessor (Linux component)
- DMA engine channel (HWLOC\_OBJ\_OSDEV\_DMA)
  - dma0chan0 (Linux component)

When none of the above strategies is supported and enabled, hwloc cannot place any OS object inside PCI objects. Note that some PCI devices may contain multiple software devices (see the example below).

See also Interoperability With Other Software for managing these devices without considering them as hwloc objects.

## 6.4 Consulting I/O devices and binding

I/O devices may be consulted by traversing the topology manually (with usual routines such as hwloc\_get\_obj\_by\_type()) or by using dedicated helpers (such as hwloc\_get\_pcidev\_by\_busid(), see Finding I/O objects).

I/O objects do not actually contain any locality information because their CPU sets and node sets are NULL. Their locality must be retrieved by walking up the object tree (through the parent link) until an non-I/O object is found (see

6.5 Examples 31

hwloc\_get\_non\_io\_ancestor\_obj()). This regular object should have non-NULL CPU sets and node sets which describe the processing units and memory that are immediately close to the I/O device. For instance the path from a OS device to its locality may go across a PCI device parent, one or several bridges, up to a a NUMA node with the same locality.

Command-line tools are also aware of I/O devices. Istopo displays the interesting ones by default (passing -no-io disables it).


hwloc-calc and hwloc-bind may manipulate I/O devices specified by PCI bus ID or by OS device name.

- pci=0000:02:03.0 is replaced by the set of CPUs that are close to the PCI device whose bus ID is given.
- os=eth0 is replaced by CPUs that are close to the I/O device whose software handle is called eth0.

This enables easy binding of I/O-intensive applications near the device they use.

### 6.5 Examples

The following picture shows a dual-socket dual-core host whose PCI bus is connected to the first socket and NUMA node.



Six interesting PCI devices were discovered. However hwloc found some corresponding software devices (*eth0*, *eth1*, *sda*, *mlx4* 0, *ib0*, and *ib1*) for only four of these physical devices. The other ones (*PCI 102b:0532* and *PCI 8086:3a20*)

32 I/O Devices

are an unused IDE controller (no disk attached) and a graphic card (no corresponding software device reported to the user by the operating system).

On the contrary, it should be noted three different software devices were found for the last PCI device (*PCI 15b3:634a*). Indeed this OpenFabrics HCA PCI device object contains one one OpenFabrics software device (*mlx4\_0*) and two virtual network interface software devices (*ib0* and *ib1*).

PCI link speed is also reported for some bridges and devices because Istopo was privileged when it discovered the topology.

Here is the corresponding textual output:

```
Machine (24GB)
  NUMANode L#0 (P#0 12GB)
    Socket L#0 + L3 L#0 (8192KB)
      L2 L#0 (256KB) + L1 L#0 (32KB) + Core L#0 + PU L#0 (P#0)
      L2 L#1 (256KB) + L1 L#1 (32KB) + Core L#1 + PU L#1 (P#2)
    Host.Bridge
      PCIBridge
        PCI 14e4:163b
          Net "eth0"
        PCI 14e4:163b
         Net "eth1"
      PCIBridge
        PCI 1000:0060
         Block "sda"
      PCIBridge
       PCI 102b:0532
      PCI 8086:3a20
      PCI 15b3:634a
        Net "ib0"
        Net "ib1"
        Net "mlx4_0"
  NUMANode L#1 (P#1 12GB) + Socket L#1 + L3 L#1 (8192KB)
    L2 L#2 (256KB) + L1 L#2 (32KB) + Core L#2 + PU L#2 (P#1)
    L2 L#3 (256KB) + L1 L#3 (32KB) + Core L#3 + PU L#3 (P#3)
```

# **Multi-node Topologies**

hwloc is usually used for consulting and manipulating single machine topologies. This includes large systems as long as a single instance of the operating system manages the entire system. However it is sometimes desirable to have multiple independent hosts inside the same topology, for instance when applying algorithms to an entire cluster topology. hwloc therefore offers the ability to agregate multiple host topologies into a single global one.

### 7.1 Multi-node Objects Specifities

A multi-node topology contains several single-node topologies. Those are assembled by making their own root objects (usually Machine object) children of higher objects. These higher objects include at least the root of the global topology (usually a System object). Some intermediate objects may also exists, for instance to represent switches in a large fabric.

There are actually three possible types of objects that have different properties with respect to cpusets, nodesets and binding. Indeed those cpusets and nodesets were designed for execution and memory binding within a single operating system. Binding on another system or across several different systems would be meaningless.

**Local objects** Any object that corresponds to the local machine may be manipulated as usual. Obviously, if the multi-node topology does not contain the local machine topology, no such local object exists.

**Objects from other nodes** Any object that comes from inside another node is represented as usual but its cpusets and nodesets should not be used for binding since binding on another system makes no sense.

**Objects above single nodes** Any object above single-node topologies does not have any cpuset or nodeset pointer because binding across multiple systems makes no sense. This includes the glocal root object of a multi-node topology and possibly some intermediate objects between this global root and the local root of single-node topologies.

It is important to keep this in mind before binding using multi-node topologies. To make sure binding on an object is possible, one should first check that its cpuset or nodeset pointer is not NULL. Then, one should check whether the object is indeed local.

To find out which machine a given object corresponds to, one may look at the info attributes of the parent Machine object. The HostName info is usually available in Machine objects, it may be retrieved with the following code:

```
hwloc_obj_t machine_obj;
obj = hwloc_get_ancestor_obj_by_type(topology, HWLOC_OBJ_MACHINE, obj);
if (machine_obj)
  return hwloc_obj_get_info_by_name(machine_obj, "HostName");
else
  return NULL:
```

The hwloc assembler scripts (see below) also add AssemblerName and AssemblerIndex info attributes to the Machine objects to identify the corresponding host name and index during assembly.

### 7.2 Assembling topologies with command-line tools

One way to manipulate multinode topologies is to retrieve other nodes' topologies as XML files and combine them as a global XML topology. It may then be loaded with <a href="https://www.nultinode.com/hwloc\_topology\_set\_xml">hwloc\_topology\_set\_xml</a>() or with the HWLOC\_XMLFILE environment variable.

The hwloc-assembler and hwloc-assembler-remote utilities offer the ability to combine XML topologies or remote nodes' topologies (see Command-Line Tools).

### 7.3 Assembling topologies with the programming interface

The hwloc programming interface offers the ability to build multinode topologies using the *custom* interface. A new multinode topology has to be initialized with hwloc\_topology\_init() and then set to custom with hwloc\_topology\_set—custom(). Topologies and objects mat then be assembled. Later, the custom topology is finalized as usual with hwloc topology load().

A custom topology starts with a single root object of type System. It may be modified by inserting a new child object with hwloc\_custom\_insert\_group\_object\_by\_parent() or by duplicating another topology with hwloc\_custom\_insert\_custom\_insert\_custom\_insert\_custom\_insert\_custom\_insert\_start topology(). Both of these operations require to specify the parent object in the custom topology where the insertion will take place. This parent may be either the root (returned by hwloc\_get\_root\_obj()) or an already-inserted object (returned by hwloc\_custom\_insert\_group\_object\_by\_parent()).

Ideally, any existing object in the custom topology could be the parent. However, special care should be taken when traversing the topology to find such an object because most links between objects (children, siblings, cousins) are not setup until hwloc\_topology\_load() is invoked.

## 7.4 Example of assembly with the programming interface

If the topologies of two hosts have been previously gathered in XML files host1.xml and host2.xml, the global topology may be assembled with the following code.

```
hwloc_topology_t host1, host2, global;
/* initialize global topology */
hwloc_topology_init(&global);
hwloc_topology_set_custom(global);
/* insert host1 entire topology below the global topology root */
hwloc_topology_init(&host1);
hwloc_topology_load(host1);
hwloc_custom_insert_topology(global, hwloc_get_root_obj(global),
                             host1, NULL);
hwloc_topology_destroy(host1);
/* insert host2 entire topology below the global topology root */
hwloc_topology_init(&host2);
hwloc_topology_load(host2);
hwloc_custom_insert_topology(global, hwloc_get_root_obj(global),
                             host2, NULL);
hwloc_topology_destroy(host2);
/* load and play with the global topology */
```

```
hwloc_topology_load(global);
```

If a intermediate object such as a switch should be inserted above one of the host topologies:

N/IIII11	ti_nad	a lan	
wui	u-nou	ישטו ש	ologies

# **Object attributes**

#### 8.1 Normal attributes

hwloc objects have many attributes. The hwloc\_obj structure contains a common set of attributes that are available for object types, for instance their type or logical\_index.

Each object also contains an attr field that, if non NULL, points to a union hwloc\_obj\_attr\_u of type-specific attribute structures. For instance, a Cache object obj contains cache-specific information in obj->attr->cache, such as its size and associativity. See hwloc obj attr u for details.

## 8.2 Custom string infos

Aside from the name field of each object, hwloc annotates many objects with string attributes that are made of a key and a value. Each object contains a list of such pairs that may be consulted manually (looking at the object infos array field) or using the hwloc\_obj\_get\_info\_by\_name(). The user may additionally add new key-value pairs to any object using hwloc\_obj\_add\_info() or the hwloc-annotate program.

Here is a non-exhaustive list of attributes that may be automatically added by hwloc (with the usual corresponding object in parentheses). Note that these attributes heavily depend on the ability of the operating system to report them. Many of them will therefore be missing on some OS.

- OSName, OSRelease, OSVersion, HostName, Architecture (Machine object) The operating system name, release, version, the hostname and the architecture name, as reported by the Unix uname command.
- **Backend (Machine object or topology root object)** The name of the hwloc backend/component that filled the topology. If several components were combined, multiple Backend keys may exist, with different values, for instance x86, Linux and pci.
- LinuxCgroup (Machine object) The name the Linux control group where the calling process is placed.
- **SyntheticDescription (topology root object)** The description string that was given to hwloc to build this synthetic topology.
- **CPUModel (Socket or Machine)** The processor model name. Usually added to Socket objects, but can be in Machine instead if hwloc failed to discover any socket.
- CPUType (Socket) A Solaris-specific general processor type name, such as "i86pc".
- **CPUVendor, CPUModelNumber, CPUFamilyNumber (Socket or Machine)** The processor vendor name, model number, and family number. Currently available for x86 and Xeon Phi processors on most systems, and for ia64

38 Object attributes

processors on Linux. Usually added to Socket objects, but can be in Machine instead if hwloc failed to discover any socket.

**CPURevision (Socket)** A POWER/PowerPC-specific general processor revision number, currently only available on Linux.

PlatformName, PlatformModel, PlatformVendor, PlatformBoardID, PlatformRevision,

**SystemVersionRegister, ProcessorVersionRegister (Machine)** Some POWER/PowerPC-specific attributes describing the platform and processor. Currently only available on Linux. Usually added to Socket objects, but can be in Machine instead if hwloc failed to discover any socket.

PCIVendor, PCIDevice (PCI devices and bridges) The vendor and device names of the PCI device.

CoProcType (Co-Processor OS devices) The type of co-processor, for instance "MIC", "CUDA" or "OpenCL".

GPUVendor, GPUModel (GPU or Co-Processor OS devices) The vendor and model names of the GPU device.

OpenCLDeviceType, OpenCLPlatformIndex,

**OpenCLPlatformName, OpenCLPlatformDeviceIndex (OpenCL GPU OS devices)** The type of OpenCL device, the OpenCL platform index and name, and the index of the device within the platform.

**OpenCLComputeUnits, OpenCLGlobalMemorySize** The number of compute units and global memory size (in kB) of a OpenCL device.

NVIDIAUUID, NVIDIASerial (NVML GPU OS devices) The UUID and Serial of NVIDIA GPUs.

CUDAMultiProcessors, CUDACoresPerMP,

CUDAGlobalMemorySize, CUDAL2CacheSize, CUDASharedMemorySizePerMP (CUDA OS devices) The number of shared multiprocessors, the number of cores per multiprocessor, the global memory size, the (global) L2 cache size, and size of the shared memory in each multiprocessor of a CUDA device. Sizes are in kB.

**MICSerialNumber** The serial number of an Intel Xeon Phi (MIC) coprocessor. When running hwloc on the host, each hwloc OS device object that corresponds to a Xeon Phi gets such an attribute. When running hwloc inside a Xeon Phi, the root object of the topology gets this attribute. It enables easy identification of devices and topologies when multiples nodes and MICs are involved.

**MICFamily, MICSKU, MICActiveCores, MICMemorySize** The family, SKU (model), number of active cores, and memory size (in kB) of an Intel Xeon Phi (MIC) coprocessor.

**DMIBoardVendor, DMIBoardName, etc. (Machine object)** DMI hardware information such as the motherboard and chassis models and vendors, the BIOS revision, etc., as reported by Linux under /sys/class/dmi/id/.

**Address, Port (Network interface OS devices)** The MAC address and the port number of a software network interface, such as eth4 on Linux.

NodeGUID, SysImageGUID, Port1State, Port2LID, Port2LMC, Port3GID1 (OpenFabrics OS devices) The node GUID and GUID mask, the state of a port #1 (value is 4 when active), the LID and LID mask count of port #2, and GID #1 of port #3.

Here is a non-exhaustive list of user-provided info attributes that have a special meaning:

**IstopoStyle** Enforces the style of an object (background and text colors) in the graphical output of Istopo. See CUS← TOM COLORS in the Istopo(1) manpage for details.

# Importing and exporting topologies from/to XML files

hwloc offers the ability to export topologies to XML files and reload them later. This is for instance useful for loading topologies faster (see I do not want hwloc to rediscover my enormous machine topology every time I rerun a process), manipulating other nodes' topology, or avoiding the need for privileged processes (see Does hwloc require privileged access?).

Topologies may be exported to XML files thanks to <a href="https://hwloc\_topology\_export\_xml">https://hwloc\_topology\_export\_xml</a>(), or to a XML memory buffer with <a href="https://hwloc\_topology\_export\_xmlbuffer">https://hwloc\_topology\_export\_xmlbuffer</a>(). The Istopo program can also serve as a XML topology export tool.

XML topologies may then be reloaded later with hwloc\_topology\_set\_xml() and hwloc\_topology\_set\_xmlbuffer(). The XMLFILE environment variable also tells hwloc to load the topology from the given XML file.

#### Note

Loading XML topologies disables binding because the loaded topology may not correspond to the physical machine that loads it. This behavior may be reverted by asserting that loaded file really matches the underlying system with the HWLOC\_THISSYSTEM environment variable or the HWLOC\_TOPOLOGY\_FLAG\_IS\_THISSY STEM topology flag.

hwloc also offers the ability to export/import Topology differences.

XML topology files are not localized. They use a dot as a decimal separator. Therefore any exported topology can be reloaded on any other machine without requiring to change the locale.

XML exports contain all details about the platform. It means that two very similar nodes still have different X $\leftarrow$  ML exports (e.g. some serial numbers or MAC addresses are different). If a less precise exporting/importing is required, one may want to look at Synthetic topologies instead.

#### 9.1 libxml2 and minimalistic XML backends

hwloc offers two backends for importing/exporting XML.

First, it can use the libxml2 library for importing/exporting XML files. It features full XML support, for instance when those files have to be manipulated by non-hwloc software (e.g. a XSLT parser). The libxml2 backend is enabled by default if libxml2 development headers are available (the relevant development package is usually libxml2-devel or libxml2-dev).

If libxml2 is not available at configure time, or if <code>-disable-libxml2</code> is passed, hwloc falls back to a custom backend. Contrary to the aforementioned full XML backend with libxml2, this minimalistic XML backend cannot be guaranteed to work with external programs. It should only be assumed to be compatible with the same hwloc release (even if using the libxml2 backend). Its advantage is however to always be available without requiring any external dependency.

If libxml2 is available but the core hwloc library should not directly depend on it, the libxml2 support may be built as a dynamicall-loaded plugin. One should pass -enable-plugins to enable plugin support (when supported) and

build as plugins all component that support it. Or pass <code>-enable-plugins=xml\_libxml</code> to only build this libxml2 support as a plugin.

## 9.2 XML import error management

Importing XML files can fail at least because of file access errors, invalid XML syntax or non-hwloc-valid XML contents.

Both backend cannot detect all these errors when the input XML file or buffer is selected (when hwloc\_topology\_set \_ xml() or hwloc\_topology\_set\_xmlbuffer() is called). Some errors such non-hwloc-valid contents can only be detected later when loading the topology with hwloc topology load().

It is therefore strongly recommended to check the return value of both hwloc\_topology\_set\_xml() (or hwloc\_topology—set\_xml() (or hwloc\_topology\_ology\_load() to handle all these errors.

# Synthetic topologies

hwloc may load fake or remote topologies so as to consult them without having the underlying hardware available. Aside from loading XML topologies, hwloc also enables the building of *synthetic* topologies that are described by a single string listing the arity of each levels.

For instance, Istopo may create a topology made of 2 NUMA nodes, containing a single socket each, with one cache above two single-threaded cores:

```
$ lstopo -i "node:2 sock:1 cache:1 core:2 pu:1" -
Machine (2048MB)

NUMANode L#0 (P#0 1024MB) + Socket L#0 + L2 L#0 (4096KB)
Core L#0 + PU L#0 (P#0)
Core L#1 + PU L#1 (P#1)

NUMANode L#1 (P#1 1024MB) + Socket L#1 + L2 L#1 (4096KB)
Core L#2 + PU L#2 (P#2)
Core L#3 + PU L#3 (P#3)
```

Replacing - with file.xml in this command line will export this topology to XML as usual.

Note

Synthetic topologies offer a very basic way to export a topology and reimport it on another machine. It is a lot less precise than XML but may still be enough when only the hierarchy of resources matters.

## 10.1 Synthetic description string

Each item in the description string gives the type of the level and the number of such children under each object of the previous level. That is why the above topology contains 4 cores (2 cores times 2 nodes).

These type names must be written as machine, node, socket, core, cache, pu, misc, group. They do not need to be written case-sensitively, nor entirely (as long as there is no ambiguity, 2 characters such as ma select a Machine level). Type-specific attributes may also be given such as L2iCache (hwloc\_obj\_type\_sscanf() is used for parsing the type names). Note that I/O objects are not available.

The root object does not appear in the string. A Machine object is used by default, and a System object replaces it if a Machine level is specified in the string.

Cache level depths are automatically chosen by hwloc (only a L2 first, then a L1 under it, then L3 above, then L4 etc.) unless they are specified. Memory and cache sizes are also automatically chosen. The only way to modifying them is to export to XML and manually modify the file.

Each item may be followed parentheses containing a list of space-separated attributes. For instance:

42 Synthetic topologies

- L2iCache: 2 (size=32768) specifies 2 children of 32kB level-2 instruction caches.
- NUMANode: 3 (memory=16777216) specifies 3 NUMA nodes with 16MB each.
- PU:2 (indexes=0, 2, 1, 3) specifies 2 PU children and the full list of OS indexes among the entire set of 4 PU objects.
- PU:2 (indexes=numa:core) specifies 2 PU children whose OS indexes are interleaved by NUMA node first and then by socket.
- · Attributes in parentheses at the very beginning of the description apply to the root object.

## 10.2 Loading a synthetic topology

Aside from Istopo, the hwloc programming interface offers the same ability by passing the synthetic description string to hwloc\_topology\_set\_synthetic() before hwloc\_topology\_load().

Synthetic topologies are created by the synthetic component. This component may be enabled by force by setting the HWLOC\_COMPONENTS environment variable to something such as synthetic="node:2 core:3 pu:4".

Loading a synthetic topology disables binding support since the topology usually does not match the underlying hardware. Binding may be reenabled as usual by setting HWLOC\_THISSYSTEM=1 in the environment or by setting the HWLOC\_TOPOLOGY\_FLAG\_IS\_THISSYSTEM topology flag.

## 10.3 Exporting a topology as a synthetic string

The function <a href="https://hww.nct.com/hwloc\_topology\_export\_synthetic">hwloc\_topology\_export\_synthetic</a>() may export a topology as a synthetic string. It offers a convenient way to quickly describe the contents of a machine. The Istopo tool may also perform such an export by forcing the output format.

```
$ lstopo --of synthetic --no-io
Socket:1 Cache:1 Cache:2 Cache:1 Cache:1 PU:2
```

The exported string may be passed back to hwloc for recreating another similar topology. The entire tree will be similar, but some special attributes such processort types may be missing.

Such an export is only possible if the topology is totally symmetric, which means the  $symmetric\_subtree$  field of the root object is set. This usually implies that I/O objects are disabled since attaching I/O busses often cause the topology to become asymmetric. Passing -no-io to Istopo is therefore often useful to make synthetic export work (as well as not passing any I/O topology flag before exporting with hwloc\_topology\_export\_synthetic()).

# **Interoperability With Other Software**

Although hwloc offers its own portable interface, it still may have to interoperate with specific or non-portable libraries that manipulate similar kinds of objects. hwloc therefore offers several specific "helpers" to assist converting between those specific interfaces and hwloc.

Some external libraries may be specific to a particular OS; others may not always be available. The hwloc core therefore generally does not explicitly depend on these types of libraries. However, when a custom application uses or otherwise depends on such a library, it may optionally include the corresponding hwloc helper to extend the hwloc interface with dedicated helpers.

Most of these helpers use structures that are specific to these external libraries and only meaningful on the local machine. If so, the helper requires the input topology to match the current machine. Some helpers also require I/O device discovery to be supported and enabled for the current topology.

- **Linux specific features** hwloc/linux.h offers Linux-specific helpers that utilize some non-portable features of the Linux system, such as binding threads through their thread ID ("tid") or parsing kernel CPU mask files.
- **Linux libnuma** hwloc/linux-libnuma.h provides conversion helpers between hwloc CPU sets and libnuma-specific types, such as bitmasks. It helps you use libnuma memory-binding functions with hwloc CPU sets.
- **Glibc** hwloc/glibc-sched.h offers conversion routines between Glibc and hwloc CPU sets in order to use hwloc with functions such as sched\_getaffinity() or pthread\_attr\_setaffinity\_np().
- **OpenFabrics Verbs** hwloc/openfabrics-verbs.h helps interoperability with the OpenFabrics Verbs interface. For example, it can return a list of processors near an OpenFabrics device. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).
- **Myrinet Express** hwloc/myriexpress.h offers interoperability with the Myrinet Express interface. It can return the list of processors near a Myrinet board managed by the MX driver. Note that if I/O device discovery is enabled, such boards may also appear as PCI objects in the topology.
- Intel Xeon Phi (MIC) hwloc/intel-mic.h helps interoperability with Intel Xeon Phi (MIC) coprocessors by returning the list of processors near these devices. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).
- AMD OpenCL hwloc/opencl.h enables interoperability with the OpenCL interface. Only the AMD implementation currently offers locality information. It may return the list of processors near an AMD/ATI GPU given as a cl\_device\_id. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).
- **NVIDIA CUDA hwloc/cuda.h** and **hwloc/cudart.h** enable interoperability with NVIDIA CUDA Driver and Runtime interfaces. For instance, it may return the list of processors near NVIDIA GPUs. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).

- **NVIDIA Management Library (NVML)** hwloc/nvml.h enables interoperability with the NVIDIA NVML interface. It may return the list of processors near a NVIDIA GPU given as a nvmlDevice\_t. It may also return the corresponding OS device hwloc object for further information (if I/O device discovery is enabled).
- **NVIDIA displays hwloc/gl.h** enables interoperability with NVIDIA displays using the NV-CONTROL X extension (N $\leftarrow$  VCtrl library). If I/O device discovery is enabled, it may return the OS device hwloc object that corresponds to a display given as a name such as :0.0 or given as a port/device pair (server/screen).
- Taskset command-line tool The taskset command-line tool is widely used for binding processes. It manipulates CPU set strings in a format that is slightly different from hwloc's one (it does not divide the string in fixed-size subsets and separates them with commas). To ease interoperability, hwloc offers routines to convert hwloc CPU sets from/to taskset-specific string format. Most hwloc command-line tools also support the <code>-taskset</code> option to manipulate taskset-specific strings.

# **Thread Safety**

Like most libraries that mainly fill data structures, hwloc is not thread safe but rather reentrant: all state is held in a hwloc\_topology\_t instance without mutex protection. That means, for example, that two threads can safely operate on and modify two different hwloc\_topology\_t instances, but they should not simultaneously invoke functions that modify the *same* instance. Similarly, one thread should not modify a hwloc\_topology\_t instance while another thread is reading or traversing it. However, two threads can safely read or traverse the same hwloc\_topology\_t instance concurrently.

When running in multiprocessor environments, be aware that proper thread synchronization and/or memory coherency protection is needed to pass hwloc data (such as <a href="hwloc\_topology\_t">hwloc\_topology\_t</a> pointers) from one processor to another (e.g., a mutex, semaphore, or a memory barrier). Note that this is not a hwloc-specific requirement, but it is worth mentioning.

For reference, hwloc\_topology\_t modification operations include (but may not be limited to):

Creation and destruction hwloc\_topology\_init(), hwloc\_topology\_load(), hwloc\_topology← \_destroy() (see Topology Creation and Destruction) imply major modifications of the structure, including freeing some objects. No other thread cannot access the topology or any of its objects at the same time.

Also references to objects inside the topology are not valid anymore after these functions return.

Runtime topology modifications hwloc\_topology\_insert\_misc\_object\_by\_\* (see Modifying a loaded Topology) may modify the topology significantly by adding objects inside the tree, changing the topology depth, etc. hwloc\_topology\_restrict modifies the topology even more dramatically by removing some objects.

Although references to former objects may still be valid after insertion or restriction, it is strongly advised to not rely on any such guarantee and always re-consult the topology to reacquire new instances of objects.

**Locating topologies** hwloc\_topology\_ignore\*, hwloc\_topology\_set\* (see Topology Detection Configuration and Query) do not modify the topology directly, but they do modify internal structures describing the behavior of the upcoming invocation of hwloc\_topology\_load(). Hence, all of these functions should not be used concurrently.

46 **Thread Safety** 

# **Components and plugins**

hwloc is organized in components that are responsible for discovering objects. Depending on the topology configuration, some components will be used, some will be ignored. The usual default is to enable the native operating system component, (e.g. linux or solaris) and the pci miscellaneous component. If available, an architecture-specific component (such as x86) may also improve the topology detection.

If a XML topology is loaded, the xml discovery component will be used instead of all other components. It internally uses a specific class of components for the actual XML import/export routines (xml\_libxml and xml\_nolibxml) but these will not be discussed here (see libxml2 and minimalistic XML backends).

## 13.1 Components enabled by default

The hwloc core contains a list of components sorted by priority. Each one is enabled as long as it does not conflict with the previously enabled ones. This includes native operating system components, architecture-specific ones, and if available, I/O components such as pci.

Usually the native operating system component (when it exists, e.g. linux or aix) is enabled first. Then hwloc looks for an architecture specific component (e.g. x86). Finally these also exist a basic component (no\_os) that just tries to discover the number of PUs in the system.

Each component discovers as much topology information as possible. Most of them, including most native OS components, do nothing unless the topology is still empty. Some others, such as x86 and pci, can complete and annotate what other backends still earlier.

Default priorities ensure that clever components are invoked first. Native operating system components have higher priorities, and are therefore invoked first, because they likely offer very detailed topology information. If needed, it will be later extended by architecture-specific information (e.g. from the  $\times 86$  component).

If any configuration function such as <a href="https://hww.component.com/hwloc\_topology\_set\_xml">hwloc\_topology\_set\_xml</a>() is used before loading the topology, the corresponding component is enabled first. Then, as usual, hwloc enables any other component (based on priorities) that does not conflict.

Certain components that manage a virtual topology, for instance XML topology import, synthetic topology description, or custom building, conflict with all other components. Therefore, one of them may only be loaded (e.g. with hwloc\_topology\_set\_xml()) if no other component is enabled.

The environment variable HWLOC\_COMPONENTS\_VERBOSE may be set to get verbose messages about component registration (including their priority) and enabling.

## 13.2 Selecting which components to use

Once topology configuration functions such as hwloc\_topology\_set\_custom() have been taken care of, the priority order of the remaining components may be changed through the HWLOC\_COMPONENTS environment variable (component names must be separated by commas).

Specifying x86 in this variable will cause the x86 component to take precedence over any other component, including the native operating system component. It is therefore loaded first, before hwloc tries to load all remaining non-conflicting components. In this case, x86 would take care of discovering everything it supports, instead of only completing what the native OS information. This may be useful if the native component is buggy on some platforms.

It is possible to prevent some components from being loaded by prefixing their name with – in the list. For instance x86, -pci will load the x86 component, then let hwloc load all the usual components except pci.

It is possible to prevent all remaining components from being loaded by placing stop in the environment variable. Only the components listed before this keyword will be enabled.

Certain component names (xml and synthetic) accept an argument (e.g. xml=file.xml). These arguments behave exactly as if the corresponding string had been passed to hwloc\_topology\_set\_xml() or hwloc\_topology\_set\_xml().

### 13.3 Loading components from plugins

Components may optionally be built as plugins so that the hwloc core library does not directly depend on their dependencies (for instance the libpciaccess library). Plugin support may be enabled with the <code>-enable-plugins</code> configure option. All components buildable as plugins will then be built as plugins. The configure option may be given a comma-separated list of component names to specify the exact list of components to build as plugins.

Plugins are built as independent dynamic libraries that are installed in \$libdir/hwloc. All plugins found in this directory are loaded during topology\_init(). A specific list of directories (colon-separated) to scan may be specified in the HWLOC PLUGINS PATH environment variable.

Note that loading a plugin just means that the corresponding component is registered to the hwloc core. Components are then only enabled if the topology configuration requests it, as explained in the previous sections.

Also note that plugins should carefully be enabled and used when embedding hwloc in another project, see Embedding hwloc in Other Software for details.

## 13.4 Adding new discovery components and plugins

The types and functions cited below are declared in the hwloc/plugins.h header. Components are supposed to only use hwloc public headers (hwloc.h and anything under the include/hwloc subdirectory) and nothing from the include/private subdirectory in the source tree.

#### 13.4.1 Basics of discovery components

Each discovery component is defined by a hwloc\_disc\_component structure which contains an instantiate() callback. This function is invoked when this component is actually used by a topology. It fills a new hwloc\_backend structure that usually contains discover() and/or notify\_new\_object() callbacks taking care of the actual topology discovery.

Note

If two discovery components have the same name, only the highest priority one is actually made available. This offers a way for third-party plugins to override existing components.

## 13.4.2 Registering a new discovery component

Registering components to the hwloc core relies on a hwloc\_component structure. Its data field points to the previously defined hwloc\_disc\_component structure while its type should be HWLOC\_COMPONENT\_TYPE DISC. This structure should be named hwloc <name> component.

The configure script should be modified to add <name> to its hwloc\_components shell variable so that the component is actually available.

Note

The symbol name of the hwloc\_component structure is independent of the name of the discovery component mentioned in the previous section.

When the component is statically built inside the hwloc library, the symbol hwloc\_<name>\_component is added by configure to the src/static-components.h. The core then registers all components listed in this file.

If the new component may be built as a plugin, the configure script should also define the shell variable hwloc\_ < name>\_component\_maybeplugin=1. When the configure script actually enables the component as a plugin, it will set the variable hwloc\_<name>\_component to plugin. The build system may then use this variable to change the way the component is built. It should create a hwloc\_<name>.so shared object. All these files are loaded in alphabetic order, and the components they contain are registered to the hwloc core.

## 13.5 Existing components and plugins

All components distributed within hwloc are listed below. The list of actually available components may be listed at running with the HWLOC\_COMPONENTS\_VERBOSE environment variable (see Environment Variables).

- **aix, darwin, freebsd, hpux, linux, netbsd, osf, solaris, windows** Each officially supported operating system has its own native component, which is statically built when supported, and which is used by default.
- **x86** The x86 architecture (either 32 or 64 bits) has its own component that may complete or replace the previously-found CPU information. It is statically built when supported.
- bgq This component is specific to IBM BlueGene/Q compute node (running CNK). It is built and enabled by default when -host=powerpc64-bgq-linux is passed to configure (see How do I build hwloc for BlueGene/Q?).
- **no\_os** A basic component that just tries to detect the number of processing units in the system. It mostly serves on operating systems that are not natively supported. It is always statically built.
- pci PCI object discovery uses the external pciaccess library (aka libpciaccess); see I/O Devices. It may be built as a plugin.
- **linuxpci** This component can probe PCI devices on Linux without the help of external libraries such as libpciaccess. Its priority is lower than the pci component because it misses device names.
- **opencl** The OpenCL component creates co-processor OS device objects such as *opencl0d0* (first device of the first OpenCL platform) or *opencl1d3* (fourth device of the second platform). Only the AMD OpenCL implementation currently offers locality information. **It may be built as a plugin**.

- **cuda** This component creates co-processor OS device objects such as *cuda0* that correspond to NVIDIA GPUs used with CUDA library. **It may be built as a plugin**.
- **nvml** Probing the NVIDIA Management Library creates OS device objects such as *nvml0* that are useful for batch schedulers. It also detects the actual PCIe link bandwidth without depending on power management state and without requiring administrator privileges. **It may be built as a plugin**.
- **gl** Probing the NV-CONTROL X extension (NVCtrl library) creates OS device objects such as :0.0 corresponding to NVIDIA displays. They are useful for graphical applications that need to place computation and/or data near a rendering GPU. **It may be built as a plugin**.

synthetic Synthetic topology support (see Synthetic topologies) is always built statically.

custom Custom topology support (see Multi-node Topologies) is always built statically.

- xml XML topology import (see Importing and exporting topologies from/to XML files) is always built statically. It internally uses one of the XML backends (see libxml2 and minimalistic XML backends).
  - xml\_nolibxml is a basic and hwloc-specific XML import/export. It is always statically built.
  - xml\_libxml relies on the external libxml2 library for provinding a feature-complete XML import/export. It may be built as a plugin.

fake A dummy plugin that does nothing but is used for debugging plugin support.

## Chapter 14

## **Embedding hwloc in Other Software**

It can be desirable to include hwloc in a larger software package (be sure to check out the LICENSE file) so that users don't have to separately download and install it before installing your software. This can be advantageous to ensure that your software uses a known-tested/good version of hwloc, or for use on systems that do not have hwloc pre-installed.

When used in "embedded" mode, hwloc will:

- · not install any header files
- · not build any documentation files
- · not build or install any executables or tests
- not build libhwloc.\* instead, it will build libhwloc\_embedded.\*

There are two ways to put hwloc into "embedded" mode. The first is directly from the configure command line:

```
shell$ ./configure --enable-embedded-mode ...
```

The second requires that your software project uses the GNU Autoconf / Automake / Libtool tool chain to build your software. If you do this, you can directly integrate hwloc's m4 configure macro into your configure script. You can then invoke hwloc's configuration tests and build setup by calling an m4 macro (see below).

Although hwloc dynamic shared object plugins may be used in embedded mode, the embedder project will have to manually setup libltdl in its build system so that hwloc can load its plugins at run time. Also, embedders should be aware of complications that can arise due to public and private linker namespaces (e.g., if the embedder project is loaded into a private namespace and then hwloc tries to dynamically load its plugins, such loading may fail since the hwloc plugins can't find the hwloc symbols they need). The embedder project is **strongly** advised not to use hwloc's dynamically loading plugins / libltdl capability.

## 14.1 Using hwloc's M4 Embedding Capabilities

Every project is different, and there are many different ways of integrating hwloc into yours. What follows is *one* example of how to do it.

If your project uses recent versions Autoconf, Automake, and Libtool to build, you can use hwloc's embedded m4 capabilities. We have tested the embedded m4 with projects that use Autoconf 2.65, Automake 1.11.1, and Libtool 2.2.6b. Slightly earlier versions of may also work but are untested. Autoconf versions prior to 2.65 are almost certain to not work.

The following macros can then be used from your configure script (only HWLOC\_SETUP\_CORE *must* be invoked if using the m4 macros):

• HWLOC\_SETUP\_CORE(config-dir-prefix, action-upon-success, action-upon-failure, print\_banner\_or\_not): Invoke the hwloc configuration tests and setup the hwloc tree to build. The first argument is the prefix to use for AC\_OUTPUT files – it's where the hwloc tree is located relative to \$top\_srcdir. Hence, if your embedded hwloc is located in the source tree at contrib/hwloc, you should pass [contrib/hwloc] as the first argument. If HWLOC\_SETUP\_CORE and the rest of configure completes successfully, then "make" traversals of the hwloc tree with standard Automake targets (all, clean, install, etc.) should behave as expected. For example, it is safe to list the hwloc directory in the SUBDIRS of a higher-level Makefile.am. The last argument, if not empty, will cause the macro to display an announcement banner that it is starting the hwloc core configuration tests.

HWLOC\_SETUP\_CORE will set the following environment variables and AC\_SUBST them: HWLOC\_EMBEDD← ED\_CFLAGS, HWLOC\_EMBEDDED\_CPPFLAGS, and HWLOC\_EMBEDDED\_LIBS. These flags are filled with the values discovered in the hwloc-specific m4 tests, and can be used in your build process as relevant. The \_CFLAGS, \_CPPFLAGS, and \_LIBS variables are necessary to build libhwloc (or libhwloc\_embedded) itself.

HWLOC\_SETUP\_CORE also sets HWLOC\_EMBEDDED\_LDADD environment variable (and AC\_SUBSTs it) to contain the location of the libhwloc\_embedded.la convenience Libtool archive. It can be used in your build process to link an application or other library against the embedded hwloc library.

NOTE: If the HWLOC\_SET\_SYMBOL\_PREFIX macro is used, it must be invoked *before* HWLOC\_SETUP ← CORE.

- HWLOC\_BUILD\_STANDALONE: HWLOC\_SETUP\_CORE defaults to building hwloc in an "embedded" mode (described above). If HWLOC\_BUILD\_STANDALONE is invoked \*before\* HWLOC\_SETUP\_CORE, the embedded definitions will not apply (e.g., libhwloc.la will be built, not libhwloc\_embedded.la).
- HWLOC\_SET\_SYMBOL\_PREFIX(foo\_): Tells the hwloc to prefix all of hwloc's types and public symbols with "foo\_"; meaning that function hwloc\_init() becomes foo\_hwloc\_init(). Enum values are prefixed with an uppercase translation if the prefix supplied; HWLOC\_OBJ\_SYSTEM becomes FOO\_HWLOC\_OBJ\_SYSTEM. This is recommended behavior if you are including hwloc in middleware it is possible that your software will be combined with other software that links to another copy of hwloc. If both uses of hwloc utilize different symbol prefixes, there will be no type/symbol clashes, and everything will compile, link, and run successfully. If you both embed hwloc without changing the symbol prefix and also link against an external hwloc, you may get multiple symbol definitions when linking your final library or application.
- HWLOC\_SETUP\_DOCS, HWLOC\_SETUP\_UTILS, HWLOC\_SETUP\_TESTS: These three macros only apply
  when hwloc is built in "standalone" mode (i.e., they should NOT be invoked unless HWLOC\_BUILD\_STANDAL
  ONE has already been invoked).
- HWLOC\_DO\_AM\_CONDITIONALS: If you embed hwloc in a larger project and build it conditionally with Automake (e.g., if HWLOC\_SETUP\_CORE is invoked conditionally), you must unconditionally invoke HWLOC\_DCO\_AM\_CONDITIONALS to avoid warnings from Automake (for the cases where hwloc is not selected to be built). This macro is necessary because hwloc uses some AM\_CONDITIONALs to build itself, and AM\_CONDITIONALS cannot be defined conditionally. Note that it is safe (but unnecessary) to call HWLOC\_DO\_AM\_CONDITIONALS even if HWLOC\_SETUP\_CORE is invoked unconditionally. If you are not using Automake to build hwloc, this macro is unnecessary (and will actually cause errors because it invoked AM\_\* macros that will be undefined).

**NOTE:** When using the HWLOC\_SETUP\_CORE m4 macro, it may be necessary to explicitly invoke AC\_CANONIC AL\_TARGET (which requires config.sub and config.guess) and/or AC\_USE\_SYSTEM\_EXTENSIONS macros early in the configure script (e.g., after AC\_INIT but before AM\_INIT\_AUTOMAKE). See the Autoconf documentation for further information.

Also note that hwloc's top-level configure.ac script uses exactly the macros described above to build hwloc in a standalone mode (by default). You may want to examine it for one example of how these macros are used.

## 14.2 Example Embedding hwloc

Here's an example of integrating with a larger project named sandbox that already uses Autoconf, Automake, and Libtool to build itself:

```
# First, cd into the sandbox project source tree
shell$ cd sandbox
shell$ cp -r /somewhere/else/hwloc-<version> my-embedded-hwloc
shell$ edit Makefile.am
  1. Add "-Imy-embedded-hwloc/config" to ACLOCAL_AMFLAGS
  2. Add "my-embedded-hwloc" to SUBDIRS
  3. Add "$(HWLOC_EMBEDDED_LDADD)" and "$(HWLOC_EMBEDDED_LIBS)" to
     sandbox's executable's LDADD line. The former is the name of the
    Libtool convenience library that hwloc will generate. The latter
    is any dependent support libraries that may be needed by
     $ (HWLOC_EMBEDDED_LDADD) .
  4. Add "$(HWLOC_EMBEDDED_CFLAGS)" to AM_CFLAGS
  5. Add "$(HWLOC\_EMBEDDED\_CPPFLAGS)" to AM_CPPFLAGS
shell$ edit configure.ac
 1. Add "HWLOC_SET_SYMBOL_PREFIX(sandbox_hwloc_)" line
  2. Add "HWLOC_SETUP_CORE([my-embedded-hwloc], [happy=yes], [happy=no])" line
  3. Add error checking for happy=no case
shell$ edit sandbox.c
 1. Add #include <hwloc.h>
 2. Add calls to sandbox_hwloc_init() and other hwloc API functions
```

Now you can bootstrap, configure, build, and run the sandbox as normal – all calls to "sandbox\_hwloc\_\*" will use the embedded hwloc rather than any system-provided copy of hwloc.

Embedding hwle	oc in Oth	er Softwa	re

54

## **Chapter 15**

## **Frequently Asked Questions**

# 15.1 I do not want hwloc to rediscover my enormous machine topology every time I rerun a process

Although the topology discovery is not expensive on common machines, its overhead may become significant when multiple processes repeat the discovery on large machines (for instance when starting one process per core in a parallel application). The machine topology usually does not vary much, except if some cores are stopped/restarted or if the administrator restrictions are modified. Thus rediscovering the whole topology again and again may look useless.

For this purpose, hwloc offers XML import/export features. It lets you save the discovered topology to a file (for instance with the Istopo program) and reload it later by setting the HWLOC\_XMLFILE environment variable. The HWLOC\_THI

SSYSTEM environment variable should also be set to 1 to assert that loaded file is really the underlying system.

Loading a XML topology is usually much faster than querying multiple files or calling multiple functions of the operating system. It is also possible to manipulate such XML files with the C programming interface, and the import/export may also be directed to memory buffer (that may for instance be transmitted between applications through a socket). See also Importing and exporting topologies from/to XML files.

## 15.2 How many topologies may I use in my program?

hwloc lets you manipulate multiple topologies at the same time. However these topologies consume memory and system resources (for instance file descriptors) until they are destroyed. It is therefore discouraged to open the same topology multiple times.

Sharing a single topology between threads is easy (see Thread Safety) since the vast majority of accesses are read-only.

If multiple topologies of different (but similar) nodes are needed in your program, have a look at How to avoid memory waste when manipulating multiple similar topologies?.

## 15.3 How to avoid memory waste when manipulating multiple similar topologies?

hwloc does not share information between topologies. If multiple similar topologies are loaded in memory, for instance the topologies of different identical nodes of a cluster, lots of information will be duplicated.

**hwloc/diff.h** (see also Topology differences) offers the ability to compute topology differences, apply or unapply them, or export/import to/from XML. However this feature is limited to basic differences such as attribute changes. It does not support complex modifications such as adding or removing some objects.

## 15.4 Why is Istopo slow?

Istopo enables most hwloc discovery flags by default so that the output topology is as precise as possible (while hwloc disables many of them by default). This includes I/O device discovery through PCI libraries as well as external libraries such as NVML. To speed up Istopo, you may disable such features with command-line options such as -no-io.

When NVIDIA GPU probing is enabled with CUDA or NVML, one should make sure that the *Persistent* mode is enabled (with nvidia-smi -pm 1) to avoid significant GPU initialization overhead.

When AMD GPU discovery is enabled with OpenCL and hwloc is used remotely over ssh, some spurious round-trips on the network may significantly increase the discovery time. Forcing the DISPLAY environment variable to the remote X server display (usually:0) instead of only setting the COMPUTE variable may avoid this.

Also remember that these components may be disabled at build-time with configure flags such as <code>-disable-opencl</code>, <code>-disable-cuda</code> or <code>-disable-nvml</code>, and at runtime with the environment variable <code>HWLOC\_COMPONENT</code>  $\leftarrow$  <code>S=-opencl</code>, <code>cuda</code>, <code>nvml</code>.

If loading topologies is slow because the machine contains tons of processors, one should also consider using XML (see I do not want hwloc to rediscover my enormous machine topology every time I rerun a process).

## 15.5 What should I do when hwloc reports "operating system" warnings?

When the operating system reports invalid locality information (because of either software or hardware bugs), hwloc may fail to insert some objects in the topology because they cannot fit in the already built tree of resources. If so, hwloc will report a warning like the following. The object causing this error is ignored, the discovery continues but the resulting topology will miss some object and may be asymmetric (see also What happens if my topology is asymmetric?).

```
*********

* hwloc has encountered what looks like an error from the operating system.

* L3 (cpuset 0x000003f0) intersects with NUMANode (P#0 cpuset 0x0000003f) without inclusion!

* Error occurred in topology.c line 940

* Please report this error message to the hwloc user's mailing list,

* along with the output from the hwloc-gather-topology script.
```

As explained in the message, reporting this issue to the hwloc developers (by sending the tarball that is generated by the hwloc-gather-topology script on this platform) is a good way to make sure that this is a software (operating system) or hardware bug (BIOS, etc).

These errors are common on large AMD platforms because several BIOS releases fail to properly report L3 caches. In the above example, the hardware reports a L3 cache that is shared by 2 cores in the first NUMA node and 4 cores in the second NUMA node. That's wrong, it should actually be shared by all 6 cores in a single NUMA node. The resulting topology will miss some L3 caches. If your application not care about cache sharing, or if you do not plan to request cache-aware binding in your process launcher, you may likely ignore this error. The warning may be hidden by setting HWLOC HIDE ERRORS=1 in your environment.

## 15.6 Does hwloc require privileged access?

hwloc discovers the topology by querying the operating system. Some minor features may require privileged access to the operation system. For instance PCI link speed discovery on Linux is reserved to root, and the entire PCI discovery on FreeBSD requires access to the /dev/pci special file.

To workaround this limitation, it is recommended to export the topology as a XML file generated by the administrator (with the Istopo program) and make it available to all users (see Importing and exporting topologies from/to XML files). It will

offer all discovery information to any application without requiring any privileged access anymore. Only the necessary hardware characteristics will be exported, no sensitive information will be disclosed through this XML export.

This XML-based model also has the advantage of speeding up the discovery because reading a XML topology is usually much faster than querying the operating system again.

## 15.7 hwloc only has a one-dimensional view of the architecture, it ignores distances

hwloc places all objects in a tree. Each level is a one-dimensional view of a set of similar objects. All children of the same object (siblings) are assumed to be equally interconnected (same distance between any of them), while the distance between children of different objects (cousins) is supposed to be larger.

Modern machines exhibit complex hardware interconnects, so this tree may miss some information about the actual physical distances between objects. The hwloc topology may therefore be annotated with distance information that may be used to build a more realistic representation (multi-dimensional) of each level. For instance, the root object may contain a distance matrix that represents the latencies between any pairs of NUMA nodes if the BIOS and/or operating system reports them.

## 15.8 How may I ignore symmetric multithreading, hyper-threading, ...?

hwloc creates one PU (processing unit) object per hardware thread. If your machine supports symmetric multithreading, for instance Hyper-Threading, each Core object may contain multiple PU objects.

```
$ lstopo -
...
Core L#1
PU L#2 (P#1)
PU L#3 (P#3)
```

If you need to ignore symmetric multithreading, you should likely manipulate hwloc Core objects directly:

Whenever you want to bind a process or thread to a core, make sure you singlify its cpuset first, so that the task is actually bound to a single thread within this core (to avoid useless migrations).

```
/* bind on the second core */
hwloc_obj_t core = hwloc_get_obj_by_type(topology, HWLOC_OBJ_CORE, 1);
hwloc_cpuset_t set = hwloc_bitmap_dup(core->cpuset);
hwloc_bitmap_singlify(set);
hwloc_set_cpubind(topology, set, 0);
hwloc_bitmap_free(set);
```

With hwloc-calc or hwloc-bind command-line tools, you may specify that you only want a single-thread within each core by asking for their first PU object:

```
$ hwloc-calc core:4-7
0x0000ff00
$ hwloc-calc core:4-7.pu:0
0x00005500
```

When binding a process on the command-line, you may either specify the exact thread that you want to use, or ask hwloc-bind to singlify the cpuset before binding

```
$ hwloc-bind core:3.pu:0 -- echo "hello from first thread on core #3"
hello from first thread on core #3
...
$ hwloc-bind core:3 --single -- echo "hello from a single thread on core #3"
hello from a single thread on core #3"
```

## 15.9 What happens if my topology is asymmetric?

hwloc supports asymmetric topologies even if most platforms are usually symmetric. For example, there may be different types of processors in a single machine, each with different numbers of cores, symmetric multithreading, or levels of caches.

To understand how hwloc manages such cases, one should first remember the meaning of levels and cousin objects. All objects of the same type are gathered as horizontal levels with a given depth. They are also connected through the cousin pointers of the <a href="hwloc\_obj">hwloc\_obj</a> structure. Some types, such as Caches or Groups, are annotated with a depth or level attribute (for instance L2 cache or Group1). Moreover caches have a type attribute (for instance L1i or L1d). Such attributes are also taken in account when gathering objects as horizontal levels. To be clear: there will be one level for L1i caches, another level for L1d caches, another one for L2, etc.

If the topology is asymmetric (e.g., if a cache is missing in one of the processors), a given horizontal level will still exist if there exist any objects of that type. However, some branches of the overall tree may not have an object located in that horizontal level. Note that this specific hole within one horizontal level does not imply anything for other levels. All objects of the same type are gathered in horizontal levels even if their parents or children have different depths and types.

Moreover, it is important to understand that a same parent object may have children of different types (and therefore, different depths). These children are therefore siblings (because they have the same parent), but they are *not* cousins (because they do not belong to the same horizontal levels).

## 15.10 How do I annotate the topology with private notes?

Each hwloc object contains a userdata field that may be used by applications to store private pointers. This field is only valid during the lifetime of these container object and topology. It becomes invalid as soon the topology is destroyed, or as soon as the object disappears, for instance when restricting the topology. The userdata field is not exported/imported to/from XML by default since hwloc does not know what it contains. This behavior may be changed by specifying application-specific callbacks with hwloc\_topology\_set\_userdata\_export\_callback() and hwloc\_topology\_set\_userdata\_import\_callback().

Each object may also contain some *info* attributes (key name and value) that are setup by hwloc during discovery and that may be extended by the user with <a href="https://hwloc\_obj\_add\_info">hwloc\_obj\_add\_info</a>() (see also Object attributes). Contrary to the userdata field which is unique, multiple info attributes may exist for each object, even with the same name. These attributes are always exported to XML. However only character strings may be used as key names and values.

It is also possible to insert Misc objects with custom names anywhere in the topology (hwloc\_topology\_insert composed co

There is also a topology-specific userdata pointer that can be used to recognize different topologies by storing a custom pointer. It may be manipulated with  $hwloc\_topology\_set\_userdata()$  and  $hwloc\_topology\_get\_topology\_get$  userdata().

## 15.11 Why does Valgrind complain about hwloc memory leaks?

If you are debugging your application with Valgrind, you want to avoid memory leak reports that are caused by hwloc and not by your program.

hwloc itself is often checked with Valgrind to make sure it does not leak memory. However some global variables in hwloc dependencies are never freed. For instance libz allocates its global state once at startup and never frees it so that it may be reused later. Some libxml2 global state is also never freed because hwloc does not know whether it can safely ask libxml2 to free it (the application may also be using libxml2 outside of hwloc).

These unfreed variables cause leak reports in Valgrind. hwloc installs a Valgrind *suppressions* file to hide them. You should pass the following command-line option to Valgrind to use it:

```
--suppressions=/path/to/hwloc-valgrind.supp
```

## 15.12 How do I handle API upgrades?

The hwloc interface is extended with every new major release. Any application using the hwloc API should be prepared to check at compile-time whether some features are available in the currently installed hwloc distribution.

To check whether the hwloc version is at least 1.5, you should use:

```
#include <hwloc.h>
#if HWLOC_API_VERSION >= 0x00010500
...
#endif
```

One important change in hwloc 1.5 is the removal of the deprecated cpuset API, which was superseded by the new bitmap API since hwloc 1.1. If your code must work with very old hwloc releases, you should use the latest bitmap API anyway. Then, use something similar to the following code to support old cpuset-only hwloc versions:

```
#include <hwloc.h>
#if HWLOC_API_VERSION < 0x00010100
#define hwloc_bitmap_alloc hwloc_cpuset_alloc
#endif</pre>
```

hwloc 0.9 did not define any HWLOC\_API\_VERSION but this very old release probably does not deserve support from your application anymore.

## 15.13 How do I build hwloc for BlueGene/Q?

IBM BlueGene/Q machines run a standard Linux on the I/O node and a custom CNK (*Compute Node Kernel*) on the compute nodes. To run on the compute node, hwloc must be cross-compiled from the I/O node with the following configuration line:

```
./configure --host=powerpc64-bgq-linux --disable-shared --enable-static \ CPPFLAGS='-I/bgsys/drivers/ppcfloor -I/bgsys/drivers/ppcfloor/spi/include/kernel/cnk/'
```

CPPFLAGS may have to be updated if your platform headers are installed in a different directory.

## 15.14 How to get useful topology information on NetBSD?

The NetBSD (and FreeBSD) backend uses x86-specific topology discovery (through the x86 component). This implementation requires CPU binding so as to guery topology information from each individual logical processor. This means

that hwloc cannot find any useful topology information unless user-level process binding is allowed by the NetBSD kernel. The <code>security.models.extensions.user\_set\_cpu\_affinity</code> sysctl variable must be set to 1 to do so. Otherwise, only the number of logical processors will be detected.

## **Chapter 16**

## **Module Index**

## 16.1 Modules

Here is	a list of al	I modules:
1101010	a not or ar	i ilioaaloo.

API version
Object Sets (hwloc_cpuset_t and hwloc_nodeset_t)
Object Types
Object Structure and Attributes
Topology Creation and Destruction
Topology Detection Configuration and Query
Object levels, depths and types
Manipulating Object Type, Sets and Attributes as Strings
CPU binding
Memory binding
Modifying a loaded Topology
Building Custom Topologies
Exporting Topologies to XML
Exporting Topologies to Synthetic
Finding Objects inside a CPU set
Finding Objects covering at least CPU set
Looking at Ancestor and Child Objects
Looking at Cache Objects
Finding objects, miscellaneous helpers
Distributing items over a topology
CPU and node sets of entire topologies
Converting between CPU sets and node sets
Manipulating Distances
Finding I/O objects
The bitmap API
Topology differences
Components and Plugins: Discovery components
Components and Plugins: Discovery backends
Components and Plugins: Generic components
Components and Plugins: Core functions to be used by components
Components and Plugins: PCI functions to be used by components
Linux-specific helpers
Interoperability with Linux libnuma unsigned long masks
Interoperability with Linux libnuma bitmask

62 Module Index

Interoperability with glibc sched affinity
Interoperability with OpenCL
Interoperability with the CUDA Driver API
Interoperability with the CUDA Runtime API
Interoperability with the NVIDIA Management Library
Interoperability with OpenGL displays
Interoperability with Intel Xeon Phi (MIC)
Interoperability with OpenFabrics
Interoperability with Myrinet Express 166

## **Chapter 17**

## **Data Structure Index**

## 17.1 Data Structures

Here are the data structures with brief descriptions:

hwloc_backend
Discovery backend structure
hwloc_obj_attr_u::hwloc_bridge_attr_s
Bridge specific Object Attribues
hwloc_obj_attr_u::hwloc_cache_attr_s
Cache-specific Object Attributes
hwloc_component
Generic component structure
hwloc_disc_component
Discovery component structure
hwloc_distances_s
Distances between objects
hwloc_obj_attr_u::hwloc_group_attr_s
Group-specific Object Attributes
hwloc_obj
Structure of a topology object
hwloc_obj_attr_u
Object type-specific Attributes
hwloc_obj_info_s Object info
hwloc_obj_memory_s::hwloc_obj_memory_page_type_s
Array of local memory page types, NULL if no local memory and page_types is 0
hwloc obj memory s
Object memory
hwloc_obj_attr_u::hwloc_osdev_attr_s
OS Device specific Object Attributes
hwloc_obj_attr_u::hwloc_pcidev_attr_s
PCI Device specific Object Attributes
hwloc topology cpubind support
Flags describing actual PU binding support for this topology
hwloc_topology_diff_u::hwloc_topology_diff_generic_s
hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_generic_s
hwloc topology diff u::hwloc topology diff obj attr s

Data Structure Index

hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_string_s
String attribute modification with an optional name
hwloc_topology_diff_obj_attr_u
One object attribute difference
hwloc_topology_diff_obj_attr_u::hwloc_topology_diff_obj_attr_uint64_s
Integer attribute modification with an optional index
$hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_too\_complex\_s \\ \dots \\ $
hwloc_topology_diff_u
One element of a difference list between two topologies
hwloc_topology_discovery_support
Flags describing actual discovery support for this topology
hwloc_topology_membind_support
Flags describing actual memory binding support for this topology
hwloc_topology_support
Set of flags describing actual support for this topology

## **Chapter 18**

## **Module Documentation**

## 18.1 API version

#### **Macros**

- #define HWLOC\_API\_VERSION 0x00010a00
- #define HWLOC\_COMPONENT\_ABI 4

## **Functions**

unsigned hwloc\_get\_api\_version (void)

## 18.1.1 Detailed Description

## 18.1.2 Macro Definition Documentation

18.1.2.1 #define HWLOC\_API\_VERSION 0x00010a00

Indicate at build time which hwloc API version is being used.

18.1.2.2 #define HWLOC\_COMPONENT\_ABI 4

Current component and plugin ABI version (see hwloc/plugins.h)

## 18.1.3 Function Documentation

18.1.3.1 unsigned hwloc\_get\_api\_version ( void )

Indicate at runtime which hwloc API version was used at build time.

## 18.2 Object Sets (hwloc\_cpuset\_t and hwloc\_nodeset\_t)

## **Typedefs**

- typedef hwloc\_bitmap\_t hwloc\_cpuset\_t
- typedef hwloc\_const\_bitmap\_t hwloc\_const\_cpuset\_t
- typedef hwloc\_bitmap\_t hwloc\_nodeset\_t
- typedef hwloc\_const\_bitmap\_t hwloc\_const\_nodeset\_t

## 18.2.1 Detailed Description

Hwloc uses bitmaps to represent two distinct kinds of object sets: CPU sets (hwloc\_cpuset\_t) and NUMA node sets (hwloc\_nodeset\_t). These types are both typedefs to a common back end type (hwloc\_bitmap\_t), and therefore all the hwloc bitmap functions are applicable to both hwloc\_cpuset\_t and hwloc\_nodeset\_t (see The bitmap API).

The rationale for having two different types is that even though the actions one wants to perform on these types are the same (e.g., enable and disable individual items in the set/mask), they're used in very different contexts: one for specifying which processors to use and one for specifying which NUMA nodes to use. Hence, the name difference is really just to reflect the intent of where the type is used.

## 18.2.2 Typedef Documentation

18.2.2.1 typedef hwloc const bitmap thwloc const cpuset t

A non-modifiable hwloc cpuset t.

18.2.2.2 typedef hwloc\_const\_bitmap\_t hwloc\_const\_nodeset\_t

A non-modifiable hwloc nodeset t.

18.2.2.3 typedef hwloc\_bitmap\_t hwloc\_cpuset\_t

A CPU set is a bitmap whose bits are set according to CPU physical OS indexes.

It may be consulted and modified with the bitmap API as any hwloc bitmap t (see hwloc/bitmap.h).

Each bit may be converted into a PU object using hwloc get pu obj by os index().

18.2.2.4 typedef hwloc bitmap t hwloc nodeset t

A node set is a bitmap whose bits are set according to NUMA memory node physical OS indexes.

It may be consulted and modified with the bitmap API as any hwloc\_bitmap\_t (see hwloc/bitmap.h). Each bit may be converted into a NUMA node object using hwloc get numanode obj by os index().

When binding memory on a system without any NUMA node (when the whole memory is considered as a single memory bank), the nodeset may be either empty (no memory selected) or full (whole system memory selected).

See also Converting between CPU sets and node sets.

18.3 Object Types 67

## 18.3 Object Types

## **Typedefs**

- typedef enum hwloc\_obj\_cache\_type\_e hwloc\_obj\_cache\_type\_t
- typedef enum hwloc\_obj\_bridge\_type\_e hwloc\_obj\_bridge\_type\_t
- typedef enum hwloc\_obj\_osdev\_type\_e hwloc\_obj\_osdev\_type\_t

#### **Enumerations**

```
    enum hwloc_obj_type_t {
        HWLOC_OBJ_SYSTEM, HWLOC_OBJ_MACHINE, HWLOC_OBJ_NODE, HWLOC_OBJ_SOCKET,
        HWLOC_OBJ_CACHE, HWLOC_OBJ_CORE, HWLOC_OBJ_PU, HWLOC_OBJ_GROUP,
        HWLOC_OBJ_MISC, HWLOC_OBJ_BRIDGE, HWLOC_OBJ_PCI_DEVICE, HWLOC_OBJ_OS_DEVICE,
        HWLOC_OBJ_TYPE_MAX }
```

- enum hwloc\_obj\_cache\_type\_e { HWLOC\_OBJ\_CACHE\_UNIFIED, HWLOC\_OBJ\_CACHE\_DATA, HWLOC\_
   OBJ\_CACHE\_INSTRUCTION }
- enum hwloc\_obj\_bridge\_type\_e { HWLOC\_OBJ\_BRIDGE\_HOST, HWLOC\_OBJ\_BRIDGE\_PCI }
- enum hwloc\_obj\_osdev\_type\_e {
   HWLOC\_OBJ\_OSDEV\_BLOCK, HWLOC\_OBJ\_OSDEV\_GPU, HWLOC\_OBJ\_OSDEV\_NETWORK, HWLOC
   \_OBJ\_OSDEV\_OPENFABRICS,
   HWLOC\_OBJ\_OSDEV\_DMA, HWLOC\_OBJ\_OSDEV\_COPROC }
- enum hwloc\_compare\_types\_e { HWLOC\_TYPE\_UNORDERED }

## **Functions**

int hwloc\_compare\_types (hwloc\_obj\_type\_t type1, hwloc\_obj\_type\_t type2)

## 18.3.1 Detailed Description

## 18.3.2 Typedef Documentation

18.3.2.1 typedef enum hwloc\_obj\_bridge\_type\_e hwloc\_obj\_bridge\_type\_t

Type of one side (upstream or downstream) of an I/O bridge.

18.3.2.2 typedef enum hwloc obj cache type e hwloc obj cache type t

Cache type.

18.3.2.3 typedef enum hwloc\_obj\_osdev\_type\_e hwloc\_obj\_osdev\_type\_t

Type of a OS device.

## 18.3.3 Enumeration Type Documentation

18.3.3.1 enum hwloc compare types e

#### Enumerator

HWLOC\_TYPE\_UNORDERED Value returned by hwloc\_compare\_types when types can not be compared.

```
18.3.3.2 enum hwloc_obj_bridge_type_e
```

Type of one side (upstream or downstream) of an I/O bridge.

#### Enumerator

```
HWLOC_OBJ_BRIDGE_HOST Host-side of a bridge, only possible upstream.HWLOC_OBJ_BRIDGE_PCI PCI-side of a bridge.
```

```
18.3.3.3 enum hwloc_obj_cache_type_e
```

Cache type.

#### Enumerator

HWLOC\_OBJ\_CACHE\_UNIFIED Unified cache.

HWLOC\_OBJ\_CACHE\_DATA Data cache.

**HWLOC\_OBJ\_CACHE\_INSTRUCTION** Instruction cache. Only used when the HWLOC\_TOPOLOGY\_FLAG\_← ICACHES topology flag is set.

```
18.3.3.4 enum hwloc_obj_osdev_type_e
```

Type of a OS device.

### **Enumerator**

HWLOC\_OBJ\_OSDEV\_BLOCK Operating system block device. For instance "sda" on Linux.

HWLOC\_OBJ\_OSDEV\_GPU Operating system GPU device. For instance ":0.0" for a GL display, "card0" for a Linux DRM device.

HWLOC\_OBJ\_OSDEV\_NETWORK Operating system network device. For instance the "eth0" interface on Linux.

HWLOC\_OBJ\_OSDEV\_OPENFABRICS Operating system openfabrics device. For instance the "mlx4\_0" Infini← Band HCA device on Linux.

**HWLOC\_OBJ\_OSDEV\_DMA** Operating system dma engine device. For instance the "dma0chan0" DMA channel on Linux.

**HWLOC\_OBJ\_OSDEV\_COPROC** Operating system co-processor device. For instance "mic0" for a Xeon Phi (MIC) on Linux, "opencl0d0" for a OpenCL device, "cuda0" for a CUDA device.

18.3 Object Types 69

18.3.3.5 enum hwloc\_obj\_type\_t

Type of topology object.

Note

Do not rely on the ordering or completeness of the values as new ones may be defined in the future! If you need to compare types, use hwloc\_compare\_types() instead.

#### Enumerator

- **HWLOC\_OBJ\_SYSTEM** Whole system (may be a cluster of machines). The whole system that is accessible to hwloc. That may comprise several machines in SSI systems like Kerrighed.
- **HWLOC\_OBJ\_MACHINE** Machine. The typical root object type. A set of processors and memory with cache coherency.
- HWLOC\_OBJ\_NODE NUMA node. A set of processors around memory which the processors can directly access.
- **HWLOC\_OBJ\_SOCKET** Socket, physical package, or chip. In the physical meaning, i.e. that you can add or remove physically.
- HWLOC\_OBJ\_CACHE Cache. Can be L1i, L1d, L2, L3, ...
- HWLOC\_OBJ\_CORE Core. A computation unit (may be shared by several logical processors).
- HWLOC\_OBJ\_PU Processing Unit, or (Logical) Processor. An execution unit (may share a core with some other logical processors, e.g. in the case of an SMT core). Objects of this kind are always reported and can thus be used as fallback when others are not.
- HWLOC\_OBJ\_GROUP Group objects. Objects which do not fit in the above but are detected by hwloc and are useful to take into account for affinity. For instance, some operating systems expose their arbitrary processors aggregation this way. And hwloc may insert such objects to group NUMA nodes according to their distances. These objects are ignored when they do not bring any structure.
- **HWLOC\_OBJ\_MISC** Miscellaneous objects. Objects without particular meaning, that can e.g. be added by the application for its own use.

- **HWLOC\_OBJ\_OS\_DEVICE** Operating system device. These objects have neither CPU sets nor node sets. They are not added to the topology unless I/O discovery is enabled with hwloc\_topology\_set\_flags().
- HWLOC\_OBJ\_TYPE\_MAX Sentinel value

#### 18.3.4 Function Documentation

18.3.4.1 int hwloc\_compare\_types ( hwloc\_obj\_type\_t type1, hwloc\_obj\_type\_t type2 )

Compare the depth of two object types.

Types shouldn't be compared as they are, since newer ones may be added in the future. This function returns less than, equal to, or greater than zero respectively if type1 objects usually include type2 objects, are the same as type2 objects, or are included in type2 objects. If the types can not be compared (because neither is usually contained in the other), HWLOC\_TYPE\_UNORDERED is returned. Object types containing CPUs can always be compared (usually, a system contains machines which contain nodes which contain sockets which contain caches, which contain cores, which contain processors).

## Note

HWLOC\_OBJ\_PU will always be the deepest.

This does not mean that the actual topology will respect that order: e.g. as of today cores may also contain caches, and sockets may also contain nodes. This is thus just to be seen as a fallback comparison method.

## 18.4 Object Structure and Attributes

## **Data Structures**

- struct hwloc\_obj\_memory\_s
- struct hwloc\_obj\_memory\_s::hwloc\_obj\_memory\_page\_type\_s
- struct hwloc obj
- union hwloc\_obj\_attr\_u
- struct hwloc\_obj\_attr\_u::hwloc\_cache\_attr\_s
- struct hwloc\_obj\_attr\_u::hwloc\_group\_attr\_s
- struct hwloc\_obj\_attr\_u::hwloc\_pcidev\_attr\_s
- struct hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s
- struct hwloc\_obj\_attr\_u::hwloc\_osdev\_attr\_s
- struct hwloc\_distances\_s
- · struct hwloc obj info s

## **Typedefs**

• typedef struct hwloc\_obj \* hwloc\_obj\_t

## 18.4.1 Detailed Description

## 18.4.2 Typedef Documentation

18.4.2.1 typedef struct hwloc\_obj\* hwloc\_obj\_t

Convenience typedef; a pointer to a struct hwloc\_obj.

## 18.5 Topology Creation and Destruction

## **Typedefs**

typedef struct hwloc\_topology \* hwloc\_topology\_t

#### **Functions**

- int hwloc\_topology\_init (hwloc\_topology\_t \*topologyp)
- int hwloc topology load (hwloc topology t topology)
- void hwloc\_topology\_destroy (hwloc\_topology\_t topology)
- void hwloc\_topology\_check (hwloc\_topology\_t topology)

## 18.5.1 Detailed Description

## 18.5.2 Typedef Documentation

18.5.2.1 typedef struct hwloc\_topology\* hwloc\_topology\_t

Topology context.

To be initialized with hwloc topology init() and built with hwloc topology load().

#### 18.5.3 Function Documentation

18.5.3.1 void hwloc\_topology\_check ( hwloc\_topology\_t topology )

Run internal checks on a topology structure.

The program aborts if an inconsistency is detected in the given topology.

**Parameters** 

topology
----------

### Note

This routine is only useful to developers.

The input topology should have been previously loaded with <a href="https://hww.topology\_load">hwloc\_topology\_load()</a>.

18.5.3.2 void hwloc\_topology\_destroy ( hwloc\_topology\_t topology )

Terminate and free a topology context.

**Parameters** 

topology	is the topology to be freed

18.5.3.3 int hwloc\_topology\_init ( hwloc\_topology\_t \* topologyp )

Allocate a topology context.

## **Parameters**

out	topologyp	is assigned a pointer to the new allocated context.
-----	-----------	---

#### Returns

0 on success, -1 on error.

18.5.3.4 int hwloc\_topology\_load ( hwloc\_topology\_t topology )

Build the actual topology.

Build the actual topology once initialized with hwloc\_topology\_init() and tuned with Topology Detection Configuration and Query routines. No other routine may be called earlier using this topology context.

## **Parameters**

topology	is the topology to be loaded with objects.

#### Returns

0 on success, -1 on error.

### Note

On failure, the topology is reinitialized. It should be either destroyed with <a href="https://hww.commons.org/hww.commons.org/">hww.commons.org/hww.commons.org/hww.commons.org/<a href="https://hww.commons.org/">hww.commons.org/<a href="https://hww.commons.org/">hww.commons.org/<a href="https://hww.commons.org/">hww.commons.org/<a href="https://hww.commons.org/">hww.commons.org/<a href="https://hww.commons.org/">hww.commons.org/<a href="https://hww.commons.org/">hww.commons.org/<a href="https://hww.commons.org/">hww.commons.org/<a href="https://hww.commons.org/">hww.commons.org/<a href="https://hww.commons.org/">hww.commons.org/</a></a>

This function may be called only once per topology.

## See also

Topology Detection Configuration and Query

## 18.6 Topology Detection Configuration and Query

## **Data Structures**

- · struct hwloc\_topology\_discovery\_support
- struct hwloc topology cpubind support
- struct hwloc\_topology\_membind\_support
- struct hwloc\_topology\_support

#### **Enumerations**

enum hwloc\_topology\_flags\_e {
 HWLOC\_TOPOLOGY\_FLAG\_WHOLE\_SYSTEM, HWLOC\_TOPOLOGY\_FLAG\_IS\_THISSYSTEM, HWLOC\_
 TOPOLOGY\_FLAG\_IO\_DEVICES, HWLOC\_TOPOLOGY\_FLAG\_IO\_BRIDGES,
 HWLOC\_TOPOLOGY\_FLAG\_IO\_HWLOC\_TOPOLOGY\_FLAG\_ICACHES }

#### **Functions**

- int hwloc\_topology\_ignore\_type (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type)
- int hwloc\_topology\_ignore\_type\_keep\_structure (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type)
- int hwloc\_topology\_ignore\_all\_keep\_structure (hwloc\_topology\_t topology)
- int hwloc\_topology\_set\_flags (hwloc\_topology\_t topology, unsigned long flags)
- unsigned long hwloc\_topology\_get\_flags (hwloc\_topology\_t topology)
- int hwloc\_topology\_set\_pid (hwloc\_topology\_t restrict topology, hwloc\_pid\_t pid)
- int hwloc\_topology\_set\_fsroot (hwloc\_topology\_t restrict topology, const char \*restrict fsroot\_path)
- int hwloc\_topology\_set\_synthetic (hwloc\_topology\_t restrict topology, const char \*restrict description)
- int hwloc\_topology\_set\_xml (hwloc\_topology\_t restrict topology, const char \*restrict xmlpath)
- int hwloc\_topology\_set\_xmlbuffer (hwloc\_topology\_t restrict topology, const char \*restrict buffer, int size)
- int hwloc topology set custom (hwloc topology t topology)
- int hwloc\_topology\_set\_distance\_matrix (hwloc\_topology\_t restrict topology, hwloc\_obj\_type\_t type, unsigned nbobjs, unsigned \*os\_index, float \*distances)
- int hwloc topology is thissystem (hwloc topology t restrict topology)
- const struct
- hwloc\_topology\_support \* hwloc\_topology\_get\_support (hwloc\_topology\_t restrict topology)
- void hwloc\_topology\_set\_userdata (hwloc\_topology\_t topology, const void \*userdata)
- void \* hwloc\_topology\_get\_userdata (hwloc\_topology\_t topology)

## 18.6.1 Detailed Description

Several functions can optionally be called between hwloc\_topology\_init() and hwloc\_topology\_load() to configure how the detection should be performed, e.g. to ignore some objects types, define a synthetic topology, etc.

If none of them is called, the default is to detect all the objects of the machine that the caller is allowed to access.

This default behavior may also be modified through environment variables if the application did not modify it already. Setting HWLOC\_XMLFILE in the environment enforces the discovery from a XML file as if hwloc\_topology\_set\_xml() had been called. HWLOC\_FSROOT switches to reading the topology from the specified Linux filesystem root as if hwloc\_topology\_set\_fsroot() had been called. Finally, HWLOC\_THISSYSTEM enforces the return value of hwloc\_topology is thissystem().

## 18.6.2 Enumeration Type Documentation

18.6.2.1 enum hwloc topology flags e

Flags to be set onto a topology context before load.

Flags should be given to hwloc topology set flags(). They may also be returned by hwloc topology get flags().

#### Enumerator

- HWLOC\_TOPOLOGY\_FLAG\_WHOLE\_SYSTEM Detect the whole system, ignore reservations and offline settings. Gather all resources, even if some were disabled by the administrator. For instance, ignore Linux Cpusets and gather all processors and memory nodes, and ignore the fact that some resources may be offline.
- HWLOC\_TOPOLOGY\_FLAG\_IS\_THISSYSTEM Assume that the selected backend provides the topology for the system on which we are running. This forces hwloc\_topology\_is\_thissystem to return 1, i.e. makes hwloc assume that the selected backend provides the topology for the system on which we are running, even if it is not the OS-specific backend but the XML backend for instance. This means making the binding functions actually call the OS-specific system calls and really do binding, while the XML backend would otherwise provide empty hooks just returning success.

Setting the environment variable HWLOC THISSYSTEM may also result in the same behavior.

This can be used for efficiency reasons to first detect the topology once, save it to an XML file, and quickly reload it later through the XML backend, but still having binding functions actually do bind.

- HWLOC\_TOPOLOGY\_FLAG\_IO\_DEVICES Detect PCI devices. By default, I/O devices are ignored. This flag enables I/O device detection using the pci backend. Only the common PCI devices (GPUs, NICs, block devices, ...) and host bridges (objects that connect the host objects to an I/O subsystem) will be added to the topology. Uncommon devices and other bridges (such as PCI-to-PCI bridges) will be ignored.
- **HWLOC\_TOPOLOGY\_FLAG\_IO\_BRIDGES** Detect PCI bridges. This flag should be combined with HWLOC\_← TOPOLOGY\_FLAG\_IO\_DEVICES to enable the detection of both common devices and of all useful bridges (bridges that have at least one device behind them).
- **HWLOC\_TOPOLOGY\_FLAG\_WHOLE\_IO** Detect the whole PCI hierarchy. This flag enables detection of all I/O devices (even the uncommon ones) and bridges (even those that have no device behind them) using the pci backend.
- **HWLOC\_TOPOLOGY\_FLAG\_ICACHES** Detect instruction caches. This flag enables detection of Instruction caches, instead of only Data and Unified caches.

#### 18.6.3 Function Documentation

18.6.3.1 unsigned long hwloc\_topology\_get\_flags ( hwloc\_topology\_t topology )

Get OR'ed flags of a topology.

Get the OR'ed set of hwloc\_topology\_flags\_e of a topology.

Returns

the flags previously set with hwloc\_topology\_set\_flags().

18.6.3.2 const struct hwloc\_topology\_support\* hwloc\_topology\_get\_support( hwloc\_topology\_t restrict topology )

Retrieve the topology support.

18.6.3.3 void\* hwloc\_topology\_get\_userdata ( hwloc\_topology\_t topology )

Retrieve the topology-specific userdata pointer.

Retrieve the application-given private data pointer that was previously set with hwloc\_topology\_set\_userdata().

18.6.3.4 int hwloc\_topology\_ignore\_all\_keep\_structure ( hwloc\_topology\_t topology\_)

Ignore all objects that do not bring any structure.

Ignore all objects that do not bring any structure: Each ignored object should have a single children or be the only child of its parent. I/O objects may not be ignored, topology flags should be used to configure their discovery instead.

18.6.3.5 int hwloc\_topology\_ignore\_type ( hwloc\_topology\_t topology, hwloc\_obj\_type\_t type )

Ignore an object type.

Ignore all objects from the given type. The bottom-level type HWLOC\_OBJ\_PU may not be ignored. The top-level object of the hierarchy will never be ignored, even if this function succeeds. I/O objects may not be ignored, topology flags should be used to configure their discovery instead.

18.6.3.6 int hwloc topology ignore type keep structure ( hwloc topology t topology, hwloc obj type t type )

Ignore an object type if it does not bring any structure.

Ignore all objects from the given type as long as they do not bring any structure: Each ignored object should have a single children or be the only child of its parent. The bottom-level type HWLOC\_OBJ\_PU may not be ignored. I/O objects may not be ignored, topology flags should be used to configure their discovery instead.

18.6.3.7 int hwloc\_topology\_is\_thissystem ( hwloc\_topology\_t restrict topology\_)

Does the topology context come from this system?

Returns

1 if this topology context was built using the system running this program.

0 instead (for instance if using another file-system root, a XML topology file, or a synthetic topology).

18.6.3.8 int hwloc\_topology\_set\_custom ( hwloc\_topology\_t topology\_)

Prepare the topology for custom assembly.

The topology then contains a single root object. It must then be built by inserting other topologies with hwloc\_custom
\_insert\_topology() or single objects with hwloc\_custom\_insert\_group\_object\_by\_parent(). hwloc\_topology\_load() must
be called to finalize the new topology as usual.

Note

If nothing is inserted in the topology, hwloc\_topology\_load() will fail with errno set to EINVAL.

The cpuset and nodeset of the root object are NULL because these sets are meaningless when assembling multiple topologies.

On success, the custom component replaces the previously enabled component (if any), but the topology is not actually modified until hwloc\_topology\_load().

18.6.3.9 int hwloc\_topology\_set\_distance\_matrix ( hwloc\_topology\_t restrict topology, hwloc\_obj\_type\_t type, unsigned nbobjs, unsigned \* os index. float \* distances )

Provide a distance matrix.

Provide the matrix of distances between a set of objects of the given type. The set may or may not contain all the existing objects of this type. The objects are specified by their OS/physical index in the os\_index array. The distances matrix follows the same order. The distance from object i to object j in the i\*nbobjs+i.

A single latency matrix may be defined for each type. If another distance matrix already exists for the given type, either because the user specified it or because the OS offers it, it will be replaced by the given one. If nbobjs is 0, os\_index is NULL and distances is NULL, the existing distance matrix for the given type is removed.

#### Note

Distance matrices are ignored in multi-node topologies.

18.6.3.10 int hwloc topology set flags ( hwloc topology t topology, unsigned long flags )

Set OR'ed flags to non-yet-loaded topology.

Set a OR'ed set of hwloc topology flags e onto a topology that was not yet loaded.

If this function is called multiple times, the last invokation will erase and replace the set of flags that was previously set.

The flags set in a topology may be retrieved with <a href="https://hww.cc.topology\_get\_flags">https://hww.cc.topology\_get\_flags</a>()

18.6.3.11 int hwloc\_topology\_set\_fsroot ( hwloc\_topology\_t restrict topology, const char \*restrict fsroot\_path )

Change the file-system root path when building the topology from sysfs/procfs.

On Linux system, use sysfs and procfs files as if they were mounted on the given fsroot\_path instead of the main file-system root. Setting the environment variable HWLOC\_FSROOT may also result in this behavior. Not using the main file-system root causes hwloc\_topology\_is\_thissystem() to return 0.

Note that this function does not actually load topology information; it just tells hwloc where to load it from. You'll still need to invoke hwloc topology load() to actually load the topology information.

#### Returns

- -1 with errno set to ENOSYS on non-Linux and on Linux systems that do not support it.
- -1 with the appropriate errno if fsroot\_path cannot be used.

#### Note

For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, the HWLOC\_TOPOLOGY\_FLAG\_IS\_THISSYSTEM has to be set to assert that the loaded file is really the underlying system.

On success, the Linux component replaces the previously enabled component (if any), but the topology is not actually modified until hwloc\_topology\_load().

18.6.3.12 int hwloc\_topology\_set\_pid ( hwloc\_topology\_t restrict topology, hwloc\_pid\_t pid )

Change which pid the topology is viewed from.

On some systems, processes may have different views of the machine, for instance the set of allowed CPUs. By default, hwloc exposes the view from the current process. Calling <a href="hwloc\_topology\_set\_pid">hwloc\_topology\_set\_pid</a>() permits to make it expose the topology of the machine from the point of view of another process.

#### Note

hwloc\_pid\_t is pid\_t on Unix platforms, and HANDLE on native Windows platforms.
-1 is returned and errno is set to ENOSYS on platforms that do not support this feature.

18.6.3.13 int hwloc\_topology\_set\_synthetic ( hwloc\_topology\_t restrict topology, const char \*restrict description )

Enable synthetic topology.

Gather topology information from the given description, a space-separated string of numbers describing the arity of each level. Each number may be prefixed with a type and a colon to enforce the type of a level. If only some level types are enforced, hwloc will try to choose the other types according to usual topologies, but it may fail and you may have to specify more level types manually. See also the Synthetic topologies.

If description was properly parsed and describes a valid topology configuration, this function returns 0. Otherwise -1 is returned and errno is set to EINVAL.

Note that this function does not actually load topology information; it just tells hwloc where to load it from. You'll still need to invoke hwloc topology load() to actually load the topology information.

#### Note

For convenience, this backend provides empty binding hooks which just return success.

On success, the synthetic component replaces the previously enabled component (if any), but the topology is not actually modified until hwloc topology load().

18.6.3.14 void hwloc\_topology\_set\_userdata ( hwloc\_topology\_t topology, const void \* userdata )

Set the topology-specific userdata pointer.

Each topology may store one application-given private data pointer. It is initialized to NULL. hwloc will never modify it.

Use it as you wish, after <a href="hwloc\_topology\_init">hwloc\_topolog\_destroy()</a>.

This pointer is not exported to XML.

18.6.3.15 int hwloc\_topology\_set\_xml ( hwloc\_topology\_t restrict topology, const char \*restrict xmlpath )

Enable XML-file based topology.

Gather topology information from the XML file given at xmlpath. Setting the environment variable HWLOC\_XMLFILE may also result in this behavior. This file may have been generated earlier with <a href="https://hwloc\_topology\_export\_xml">hwloc\_topology\_export\_xml</a>() or Istopo file.xml.

Note that this function does not actually load topology information; it just tells hwloc where to load it from. You'll still need to invoke hwloc topology load() to actually load the topology information.

#### Returns

-1 with errno set to EINVAL on failure to read the XML file.

#### Note

See also hwloc\_topology\_set\_userdata\_import\_callback() for importing application-specific object userdata. For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, the HWLOC\_TOPOLOGY\_FLAG\_IS\_THISSYSTEM has to be set to assert that the loaded file is really the underlying system.

On success, the XML component replaces the previously enabled component (if any), but the topology is not actually modified until <a href="https://hww.noble.com/hwloc\_topology\_load">hwloc\_topology\_load</a>().

18.6.3.16 int hwloc\_topology\_set\_xmlbuffer( hwloc\_topology\_t restrict topology, const char \*restrict buffer, int size)

Enable XML based topology using a memory buffer (instead of a file, as with hwloc\_topology\_set\_xml()).

Gather topology information from the XML memory buffer given at buffer and of length size. This buffer may have been filled earlier with hwloc\_topology\_export\_xmlbuffer().

Note that this function does not actually load topology information; it just tells hwloc where to load it from. You'll still need to invoke hwloc topology load() to actually load the topology information.

### Returns

-1 with errno set to EINVAL on failure to read the XML buffer.

#### Note

See also hwloc\_topology\_set\_userdata\_import\_callback() for importing application-specific object userdata. For convenience, this backend provides empty binding hooks which just return success. To have hwloc still actually call OS-specific hooks, the HWLOC\_TOPOLOGY\_FLAG\_IS\_THISSYSTEM has to be set to assert that the loaded file is really the underlying system.

On success, the XML component replaces the previously enabled component (if any), but the topology is not actually modified until hwloc\_topology\_load().

## 18.7 Object levels, depths and types

#### **Enumerations**

enum hwloc\_get\_type\_depth\_e {
 HWLOC\_TYPE\_DEPTH\_UNKNOWN, HWLOC\_TYPE\_DEPTH\_MULTIPLE, HWLOC\_TYPE\_DEPTH\_BRIDGE,
 HWLOC\_TYPE\_DEPTH\_PCI\_DEVICE,
 HWLOC\_TYPE\_DEPTH\_OS\_DEVICE }

#### **Functions**

- unsigned hwloc\_topology\_get\_depth (hwloc\_topology\_t restrict topology)
- int hwloc\_get\_type\_depth (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type)
- static int hwloc\_get\_type\_or\_below\_depth (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type)
- static int hwloc\_get\_type\_or\_above\_depth (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type)
- hwloc\_obj\_type\_t hwloc\_get\_depth\_type (hwloc\_topology\_t topology, unsigned depth)
- unsigned hwloc\_get\_nbobjs\_by\_depth (hwloc\_topology\_t topology, unsigned depth)
- static int hwloc\_get\_nbobjs\_by\_type (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type)
- static hwloc\_obj\_t hwloc\_get\_root\_obj (hwloc\_topology\_t topology)
- hwloc\_obj\_t hwloc\_get\_obj\_by\_depth (hwloc\_topology\_t topology, unsigned depth, unsigned idx)
- static hwloc obj t hwloc get obj by type (hwloc topology t topology, hwloc obj type t type, unsigned idx)
- static hwloc\_obj\_t hwloc\_get\_next\_obj\_by\_depth (hwloc\_topology\_t topology, unsigned depth, hwloc\_obj\_t prev)
- static hwloc\_obj\_t hwloc\_get\_next\_obj\_by\_type (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type, hwloc\_obj
   \_t prev)

## 18.7.1 Detailed Description

Be sure to see the figure in Terms and Definitions that shows a complete topology tree, including depths, child/sibling/cousin relationships, and an example of an asymmetric topology where one socket has fewer caches than its peers.

## 18.7.2 Enumeration Type Documentation

```
18.7.2.1 enum hwloc_get_type_depth_e
```

### Enumerator

```
HWLOC_TYPE_DEPTH_UNKNOWN No object of given type exists in the topology.
```

HWLOC\_TYPE\_DEPTH\_MULTIPLE Objects of given type exist at different depth in the topology.

**HWLOC\_TYPE\_DEPTH\_BRIDGE** Virtual depth for bridge object level.

HWLOC\_TYPE\_DEPTH\_PCI\_DEVICE Virtual depth for PCI device object level.

HWLOC\_TYPE\_DEPTH\_OS\_DEVICE Virtual depth for software device object level.

#### 18.7.3 Function Documentation

18.7.3.1 hwloc\_obj\_type\_t hwloc\_get\_depth\_type ( hwloc\_topology\_t topology, unsigned depth )

Returns the type of objects at depth depth.

Returns

-1 if depth depth does not exist.

18.7.3.2 unsigned hwloc\_get\_nbobjs\_by\_depth ( hwloc\_topology\_t topology, unsigned depth )

Returns the width of level at depth depth.

18.7.3.3 static int hwloc\_get\_nbobjs\_by\_type ( hwloc\_topology\_t topology, hwloc\_obj\_type\_t type ) [inline], [static]

Returns the width of level type type.

If no object for that type exists, 0 is returned. If there are several levels with objects of that type, -1 is returned.

18.7.3.4 static hwloc\_obj\_t hwloc\_get\_next\_obj\_by\_depth ( hwloc\_topology\_t topology, unsigned depth, hwloc\_obj\_t prev ) [inline], [static]

Returns the next object at depth depth.

If prev is NULL, return the first object at depth depth.

18.7.3.5 static hwloc\_obj\_t hwloc\_get\_next\_obj\_by\_type ( hwloc\_topology\_t topology, hwloc\_obj\_type\_t type, hwloc\_obj\_t prev ) [inline], [static]

Returns the next object of type type.

If prev is NULL, return the first object at type type. If there are multiple or no depth for given type, return NULL and let the caller fallback to hwloc\_get\_next\_obj\_by\_depth().

18.7.3.6 hwloc\_obj\_t hwloc\_get\_obj\_by\_depth ( hwloc\_topology\_t topology, unsigned depth, unsigned idx )

Returns the topology object at logical index idx from depth depth.

18.7.3.7 static hwloc\_obj\_t hwloc\_get\_obj\_by\_type ( hwloc\_topology\_t topology, hwloc\_obj\_type\_t type, unsigned idx ) [inline], [static]

Returns the topology object at logical index idx with type type.

If no object for that type exists, NULL is returned. If there are several levels with objects of that type, NULL is returned and ther caller may fallback to  $\texttt{hwloc\_get\_obj\_by\_depth}()$ .

18.7.3.8 static hwloc\_obj\_t hwloc\_get\_root\_obj( hwloc\_topology\_t topology ) [inline], [static]

Returns the top-object of the topology-tree.

Its type is typically HWLOC OBJ MACHINE but it could be different for complex topologies.

18.7.3.9 int hwloc\_get\_type\_depth ( hwloc\_topology\_t topology, hwloc\_obj\_type\_t type )

Returns the depth of objects of type type.

If no object of this type is present on the underlying architecture, or if the OS doesn't provide this kind of information, the function returns HWLOC TYPE DEPTH UNKNOWN.

If type is absent but a similar type is acceptable, see also hwloc\_get\_type\_or\_below\_depth() and hwloc\_get\_type\_or above depth().

If some objects of the given type exist in different levels, for instance L1 and L2 caches, or L1i and L1d caches, the function returns HWLOC\_TYPE\_DEPTH\_MULTIPLE. See <a href="https://hwloc.get\_cache\_type\_depth">hwloc/helper.h</a> to better handle this case.

If an I/O object type is given, the function returns a virtual value because I/O objects are stored in special levels that are not CPU-related. This virtual depth may be passed to other hwloc functions such as hwloc\_get\_obj\_by\_depth() but it should not be considered as an actual depth by the application. In particular, it should not be compared with any other object depth or with the entire topology depth.

```
18.7.3.10 static int hwloc_get_type_or_above_depth ( hwloc_topology_t topology, hwloc_obj_type_t type ) [inline], [static]
```

Returns the depth of objects of type type or above.

If no object of this type is present on the underlying architecture, the function returns the depth of the first "present" object typically containing type.

If some objects of the given type exist in different levels, for instance L1 and L2 caches, the function returns HWLOC← TYPE DEPTH MULTIPLE.

```
18.7.3.11 static int hwloc_get_type_or_below_depth( hwloc_topology_t topology, hwloc_obj_type_t type ) [inline],
    [static]
```

Returns the depth of objects of type type or below.

If no object of this type is present on the underlying architecture, the function returns the depth of the first "present" object typically found inside type.

If some objects of the given type exist in different levels, for instance L1 and L2 caches, the function returns  $HWLOC \leftarrow TYPE\ DEPTH\ MULTIPLE$ .

18.7.3.12 unsigned hwloc\_topology\_get\_depth ( hwloc\_topology\_t restrict topology )

Get the depth of the hierarchical tree of objects.

This is the depth of HWLOC\_OBJ\_PU objects plus one.

## 18.8 Manipulating Object Type, Sets and Attributes as Strings

#### **Functions**

- const char \* hwloc\_obj\_type\_string (hwloc\_obj\_type\_t type)
- int hwloc\_obj\_type\_sscanf (const char \*string, hwloc\_obj\_type\_t \*typep, int \*depthattrp, void \*typeattrp, size\_t typeattrsize)
- int hwloc obj type snprintf (char \*restrict string, size t size, hwloc obj t obj, int verbose)
- int hwloc\_obj\_attr\_snprintf (char \*restrict string, size\_t size, hwloc\_obj\_t obj, const char \*restrict separator, int verbose)
- int hwloc obj cpuset snprintf (char \*restrict str, size t size, size t nobj, const hwloc obj t \*restrict objs)
- static const char \* hwloc obj get info by name (hwloc obj t obj, const char \*name)
- void hwloc obj add info (hwloc obj t obj, const char \*name, const char \*value)

## 18.8.1 Detailed Description

## 18.8.2 Function Documentation

18.8.2.1 void hwloc\_obj\_add\_info ( hwloc\_obj\_ t obj, const char \* name, const char \* value )

Add the given info name and value pair to the given object.

The info is appended to the existing info array even if another key with the same name already exists.

The input strings are copied before being added in the object infos.

### Note

This function may be used to enforce object colors in the Istopo graphical output by using "IstopoStyle" as a name and "Background=#rrggbb" as a value. See CUSTOM COLORS in the Istopo(1) manpage for details. If value contains some non-printable characters, they will be dropped when exporting to XML, see hwloc\_copology\_export\_xml().

18.8.2.2 int hwloc\_obj\_attr\_snprintf ( char \*restrict string, size\_t size, hwloc\_obj\_t obj, const char \*restrict separator, int verbose )

Stringify the attributes of a given topology object into a human-readable form.

Attribute values are separated by separator.

Only the major attributes are printed in non-verbose mode.

If size is 0, string may safely be NULL.

#### Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

18.8.2.3 int hwloc\_obj\_cpuset\_snprintf ( char \*restrict str, size\_t size, size\_t nobj, const hwloc\_obj\_t \*restrict objs )

Stringify the cpuset containing a set of objects.

If size is 0, string may safely be NULL.

#### Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

18.8.2.4 static const char\* hwloc\_obj\_get\_info\_by\_name( hwloc\_obj\_ t obj, const char \* name ) [inline], [static]

Search the given key name in object infos and return the corresponding value.

If multiple keys match the given name, only the first one is returned.

#### Returns

NULL if no such key exists.

18.8.2.5 int hwloc\_obj\_type\_snprintf ( char \*restrict string, size\_t size, hwloc\_obj\_t obj, int verbose )

Stringify the type of a given topology object into a human-readable form.

It differs from hwloc obj type string() because it prints type attributes such as cache depth and type.

If size is 0, string may safely be NULL.

#### Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

18.8.2.6 int hwloc\_obj\_type\_sscanf ( const char \* string, hwloc\_obj\_type\_t \* typep, int \* depthattrp, void \* typeattrp, size\_t typeattrsize )

Return an object type and attributes from a type string.

Convert strings such as "socket" or "cache" into the corresponding types. Matching is case-insensitive, and only the first letters are actually required to match.

Types that have specific attributes, for instance caches and groups, may be returned in depthattrp and typeattrp. They are ignored when these pointers are NULL.

For instance "L2i" or "L2iCache" would return type HWLOC\_OBJ\_CACHE in typep, 2 in depthattrp, and HWL $\leftarrow$  OC\_OBJ\_CACHE\_TYPE\_INSTRUCTION in typeattrp (this last pointer should point to a hwloc\_obj\_cache\_type\_t). "Group3" would return type HWLOC\_OBJ\_GROUP type and 3 in depthattrp. Attributes that are not specified in the string (for instance "Group" without a depth, or "L2Cache" without a cache type) are set to -1.

typeattrd is only filled if the size specified in typeattrsize is large enough. It is currently only used for caches, and the required size is at least the size of hwloc\_obj\_cache\_type\_t.

#### Returns

0 if a type was correctly identified, otherwise -1.

#### Note

This is an extended version of the now deprecated hwloc obj type of string()

18.8.2.7 const char\* hwloc\_obj\_type\_string ( hwloc\_obj\_type\_t type )

Return a stringified topology object type.

# 18.9 CPU binding

#### **Enumerations**

enum hwloc\_cpubind\_flags\_t { HWLOC\_CPUBIND\_PROCESS, HWLOC\_CPUBIND\_THREAD, HWLOC\_CPU
BIND\_STRICT, HWLOC\_CPUBIND\_NOMEMBIND }

# **Functions**

- int hwloc\_set\_cpubind (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, int flags)
- int hwloc get cpubind (hwloc topology t topology, hwloc cpuset t set, int flags)
- int hwloc\_set\_proc\_cpubind (hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_const\_cpuset\_t set, int flags)
- int hwloc get proc cpubind (hwloc topology t topology, hwloc pid t pid, hwloc cpuset t set, int flags)
- int hwloc\_set\_thread\_cpubind (hwloc\_topology\_t topology, hwloc\_thread\_t thread, hwloc\_const\_cpuset\_t set, int flags)
- int hwloc get thread cpubind (hwloc topology t topology, hwloc thread t thread, hwloc cpuset t set, int flags)
- int hwloc\_get\_last\_cpu\_location (hwloc\_topology\_t topology, hwloc\_cpuset\_t set, int flags)
- int hwloc get proc last cpu location (hwloc topology t topology, hwloc pid t pid, hwloc cpuset t set, int flags)

# 18.9.1 Detailed Description

It is often useful to call hwloc\_bitmap\_singlify() first so that a single CPU remains in the set. This way, the process will not even migrate between different CPUs inside the given set. Some operating systems also only support that kind of binding.

Some operating systems do not provide all hwloc-supported mechanisms to bind processes, threads, etc. hwloc\_copology\_get\_support() may be used to query about the actual CPU binding support in the currently used operating system.

When the requested binding operation is not available and the HWLOC\_CPUBIND\_STRICT flag was passed, the function returns -1. errno is set to ENOSYS when it is not possible to bind the requested kind of object processes/threads. errno is set to EXDEV when the requested cpuset can not be enforced (e.g. some systems only allow one CPU, and some other systems only allow one NUMA node).

If HWLOC\_CPUBIND\_STRICT was not passed, the function may fail as well, or the operating system may use a slightly different operation (with side-effects, smaller binding set, etc.) when the requested operation is not exactly supported.

The most portable version that should be preferred over the others, whenever possible, is the following one which just binds the current program, assuming it is single-threaded:

```
hwloc_set_cpubind(topology, set, 0),
```

If the program may be multithreaded, the following one should be preferred to only bind the current thread:

```
hwloc_set_cpubind(topology, set, HWLOC_CPUBIND_THREAD),
```

### See also

Some example codes are available under doc/examples/ in the source tree.

#### Note

To unbind, just call the binding function with either a full cpuset or a cpuset equal to the system cpuset.

On some operating systems, CPU binding may have effects on memory binding, see HWLOC\_CPUBIND\_NOMEMBIND

Running Istopo -top or hwloc-ps can be a very convenient tool to check how binding actually happened.

18.9 CPU binding 87

# 18.9.2 Enumeration Type Documentation

18.9.2.1 enum hwloc cpubind flags t

Process/Thread binding flags.

These bit flags can be used to refine the binding policy.

The default (0) is to bind the current process, assumed to be single-threaded, in a non-strict way. This is the most portable way to bind as all operating systems usually provide it.

Note

Not all systems support all kinds of binding. See the "Detailed Description" section of CPU binding for a description of errors that can occur.

#### Enumerator

HWLOC\_CPUBIND\_PROCESS Bind all threads of the current (possibly) multithreaded process.

HWLOC\_CPUBIND\_THREAD Bind current thread of current process.

HWLOC\_CPUBIND\_STRICT Request for strict binding from the OS. By default, when the designated CPUs are all busy while other CPUs are idle, operating systems may execute the thread/process on those other CPUs instead of the designated CPUs, to let them progress anyway. Strict binding means that the thread/process will \_never\_ execute on other cpus than the designated CPUs, even when those are busy with other tasks and other CPUs are idle.

Note

Depending on the operating system, strict binding may not be possible (e.g., the OS does not implement it) or not allowed (e.g., for an administrative reasons), and the function will fail in that case.

When retrieving the binding of a process, this flag checks whether all its threads actually have the same binding. If the flag is not given, the binding of each thread will be accumulated.

Note

This flag is meaningless when retrieving the binding of a thread.

HWLOC\_CPUBIND\_NOMEMBIND Avoid any effect on memory binding. On some operating systems, some CPU binding function would also bind the memory on the corresponding NUMA node. It is often not a problem for the application, but if it is, setting this flag will make hwloc avoid using OS functions that would also bind memory. This will however reduce the support of CPU bindings, i.e. potentially return -1 with errno set to ENOSYS in some cases.

This flag is only meaningful when used with functions that set the CPU binding. It is ignored when used with functions that get CPU binding information.

# 18.9.3 Function Documentation

18.9.3.1 int hwloc\_get\_cpubind ( hwloc\_topology\_t topology, hwloc\_cpuset\_t set, int flags )

Get current process or thread binding.

Writes into set the physical cpuset which the process or thread (according to flags) was last bound to.

18.9.3.2 int hwloc\_get\_last\_cpu\_location ( hwloc\_topology\_t topology, hwloc\_cpuset\_t set, int flags )

Get the last physical CPU where the current process or thread ran.

The operating system may move some tasks from one processor to another at any time according to their binding, so this function may return something that is already outdated.

flags can include either HWLOC\_CPUBIND\_PROCESS or HWLOC\_CPUBIND\_THREAD to specify whether the query should be for the whole process (union of all CPUs on which all threads are running), or only the current thread. If the process is single-threaded, flags can be set to zero to let hwloc use whichever method is available on the underlying OS.

18.9.3.3 int hwloc\_get\_proc\_cpubind ( hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_cpuset\_t set, int flags )

Get the current physical binding of process pid.

### Note

hwloc\_pid\_t is pid\_t on Unix platforms, and HANDLE on native Windows platforms.

As a special case on Linux, if a tid (thread ID) is supplied instead of a pid (process ID) and HWLOC\_CPUBIND 

\_THREAD is passed in flags, the binding for that specific thread is returned.

On non-Linux systems, HWLOC\_CPUBIND\_THREAD can not be used in flags.

18.9.3.4 int hwloc\_get\_proc\_last\_cpu\_location ( hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_cpuset\_t set, int flags )

Get the last physical CPU where a process ran.

The operating system may move some tasks from one processor to another at any time according to their binding, so this function may return something that is already outdated.

## Note

hwloc\_pid\_t is pid\_t on Unix platforms, and HANDLE on native Windows platforms.

As a special case on Linux, if a tid (thread ID) is supplied instead of a pid (process ID) and HWLOC\_CPUBIND 

\_THREAD is passed in flags, the last CPU location of that specific thread is returned.

On non-Linux systems, HWLOC\_CPUBIND\_THREAD can not be used in flags.

18.9.3.5 int hwloc\_get\_thread\_cpubind ( hwloc\_topology\_t topology, hwloc\_thread\_t thread, hwloc\_cpuset\_t set, int flags )

Get the current physical binding of thread tid.

# Note

 $\label{loc_thread_tispthread_ton Unix platforms, and HANDLE on native Windows platforms. \\ HWLOC\_CPUBIND\_PROCESS can not be used in flags. \\$ 

18.9.3.6 int hwloc\_set\_cpubind ( hwloc\_topology t topology, hwloc\_const\_cpuset\_t set, int flags )

Bind current process or thread on cpus given in physical bitmap set.

# Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

18.9 CPU binding 89

18.9.3.7 int hwloc\_set\_proc\_cpubind ( hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_const\_cpuset\_t set, int flags )

Bind a process pid on cpus given in physical bitmap set.

Note

hwloc\_pid\_t is pid\_t on Unix platforms, and HANDLE on native Windows platforms.

As a special case on Linux, if a tid (thread ID) is supplied instead of a pid (process ID) and HWLOC\_CPUBIND 

\_THREAD is passed in flags, the binding is applied to that specific thread.

On non-Linux systems, HWLOC\_CPUBIND\_THREAD can not be used in flags.

18.9.3.8 int hwloc\_set\_thread\_cpubind ( hwloc\_topology\_t topology, hwloc\_thread\_t thread, hwloc\_const\_cpuset\_t set, int flags )

Bind a thread thread on cpus given in physical bitmap set.

Note

 $hwloc\_thread\_t$  is  $pthread\_t$  on Unix platforms, and HANDLE on native Windows platforms.  $HWLOC\_CPUBIND\_PROCESS$  can not be used in flags.

# 18.10 Memory binding

### **Enumerations**

enum hwloc\_membind\_policy\_t {
 HWLOC\_MEMBIND\_DEFAULT, HWLOC\_MEMBIND\_FIRSTTOUCH, HWLOC\_MEMBIND\_BIND, HWLOC\_M
 EMBIND\_INTERLEAVE,
 HWLOC\_MEMBIND\_REPLICATE, HWLOC\_MEMBIND\_NEXTTOUCH, HWLOC\_MEMBIND\_MIXED }

enum hwloc\_membind\_flags\_t {
 HWLOC\_MEMBIND\_PROCESS, HWLOC\_MEMBIND\_THREAD, HWLOC\_MEMBIND\_STRICT, HWLOC\_ME
 MBIND\_MIGRATE,
 HWLOC\_MEMBIND\_NOCPUBIND }

## **Functions**

- int hwloc\_set\_membind\_nodeset (hwloc\_topology\_t topology, hwloc\_const\_nodeset\_t nodeset, hwloc\_
  membind\_policy\_t policy, int flags)
- int hwloc\_set\_membind (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t cpuset, hwloc\_membind\_policy\_
   t policy, int flags)
- int hwloc\_get\_membind\_nodeset (hwloc\_topology\_t topology, hwloc\_nodeset\_t nodeset, hwloc\_membind\_
   policy\_t \*policy, int flags)
- int hwloc\_get\_membind (hwloc\_topology\_t topology, hwloc\_cpuset\_t cpuset, hwloc\_membind\_policy\_t \*policy, int flags)
- int hwloc\_set\_proc\_membind\_nodeset (hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_const\_nodeset\_
   t nodeset, hwloc\_membind\_policy\_t policy, int flags)
- int hwloc\_set\_proc\_membind (hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_const\_cpuset\_t cpuset, hwloc\_membind\_policy\_t policy, int flags)
- int hwloc\_get\_proc\_membind\_nodeset (hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_nodeset\_t nodeset, hwloc\_membind\_policy\_t \*policy, int flags)
- int hwloc\_get\_proc\_membind (hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_cpuset\_t cpuset, hwloc\_
  membind\_policy\_t \*policy, int flags)
- int hwloc\_set\_area\_membind\_nodeset (hwloc\_topology\_t topology, const void \*addr, size\_t len, hwloc\_const\_ ondeset\_t nodeset, hwloc\_membind\_policy\_t policy, int flags)
- int hwloc\_set\_area\_membind (hwloc\_topology\_t topology, const void \*addr, size\_t len, hwloc\_const\_cpuset\_t cpuset, hwloc\_membind\_policy\_t policy, int flags)
- int hwloc\_get\_area\_membind\_nodeset (hwloc\_topology\_t topology, const void \*addr, size\_t len, hwloc\_nodeset
   \_t nodeset, hwloc\_membind\_policy\_t \*policy, int flags)
- int hwloc\_get\_area\_membind (hwloc\_topology\_t topology, const void \*addr, size\_t len, hwloc\_cpuset\_t cpuset, hwloc\_membind\_policy\_t \*policy, int flags)
- void \* hwloc\_alloc (hwloc\_topology\_t topology, size\_t len)
- void \* hwloc\_alloc\_membind\_nodeset (hwloc\_topology\_t topology, size\_t len, hwloc\_const\_nodeset\_t nodeset, hwloc\_membind\_policy\_t policy, int flags)
- void \* hwloc\_alloc\_membind (hwloc\_topology\_t topology, size\_t len, hwloc\_const\_cpuset\_t cpuset, hwloc\_
  membind\_policy\_t policy, int flags)
- static void \* hwloc\_alloc\_membind\_policy (hwloc\_topology\_t topology, size\_t len, hwloc\_const\_cpuset\_t set, hwloc\_membind\_policy\_t policy, int flags)
- int hwloc free (hwloc topology t topology, void \*addr, size t len)

18.10 Memory binding 91

# 18.10.1 Detailed Description

Memory binding can be done three ways:

explicit memory allocation thanks to hwloc\_alloc\_membind() and friends: the binding will have effect on the memory allocated by these functions.

- implicit memory binding through binding policy: <a href="https://hwloc\_set\_membind">hwloc\_set\_membind</a>() and friends only define the current policy of the process, which will be applied to the subsequent calls to malloc() and friends.
- migration of existing memory ranges, thanks to hwloc\_set\_area\_membind() and friends, which move alreadyallocated data.

Not all operating systems support all three ways. <a href="https://hwloc\_topology\_get\_support">hwloc\_topology\_get\_support</a>() may be used to query about the actual memory binding support in the currently used operating system.

When the requested binding operation is not available and the HWLOC\_MEMBIND\_STRICT flag was passed, the function returns -1. errno will be set to ENOSYS when the system does support the specified action or policy (e.g., some systems only allow binding memory on a per-thread basis, whereas other systems only allow binding memory for all threads in a process). errno will be set to EXDEV when the requested cpuset can not be enforced (e.g., some systems only allow binding memory to a single NUMA node).

If HWLOC\_MEMBIND\_STRICT was not passed, the function may fail as well, or the operating system may use a slightly different operation (with side-effects, smaller binding set, etc.) when the requested operation is not exactly supported.

The most portable form that should be preferred over the others whenever possible is as follows. It allocates some memory hopefully bound to the specified set. To do so, hwloc will possibly have to change the current memory binding policy in order to actually get the memory bound, if the OS does not provide any other way to simply allocate bound memory without changing the policy for all allocations. That is the difference with <a href="hwloc\_alloc\_membind">hwloc\_alloc\_membind</a>(), which will never change the current memory binding policy.

Each hwloc memory binding function is available in two forms: one that takes a CPU set argument and another that takes a NUMA memory node set argument (see Object Sets (hwloc\_cpuset\_t and hwloc\_nodeset\_t) and The bitmap API for a discussion of CPU sets and NUMA memory node sets). The names of the latter form end with \_nodeset. It is also possible to convert between CPU set and node set using hwloc\_cpuset\_to\_nodeset() or hwloc\_cpuset\_from\_nodeset().

## See also

Some example codes are available under doc/examples/ in the source tree.

Note

On some operating systems, memory binding affects the CPU binding; see HWLOC\_MEMBIND\_NOCPUBIND

18.10.2 Enumeration Type Documentation

18.10.2.1 enum hwloc\_membind\_flags\_t

Memory binding flags.

These flags can be used to refine the binding policy. All flags can be logically OR'ed together with the exception of HWLOC\_MEMBIND\_PROCESS and HWLOC\_MEMBIND\_THREAD; these two flags are mutually exclusive.

Not all systems support all kinds of binding. hwloc\_topology\_get\_support() may be used to query about the actual memory binding support in the currently used operating system. See the "Detailed Description" section of Memory binding for a description of errors that can occur.

## Enumerator

- **HWLOC\_MEMBIND\_PROCESS** Set policy for all threads of the specified (possibly multithreaded) process. This flag is mutually exclusive with HWLOC\_MEMBIND\_THREAD.
- **HWLOC\_MEMBIND\_THREAD** Set policy for a specific thread of the current process. This flag is mutually exclusive with HWLOC MEMBIND PROCESS.
- **HWLOC\_MEMBIND\_STRICT** Request strict binding from the OS. The function will fail if the binding can not be guaranteed / completely enforced.
  - This flag has slightly different meanings depending on which function it is used with.
- **HWLOC\_MEMBIND\_MIGRATE** Migrate existing allocated memory. If the memory cannot be migrated and the HWLOC\_MEMBIND\_STRICT flag is passed, an error will be returned.
- HWLOC\_MEMBIND\_NOCPUBIND Avoid any effect on CPU binding. On some operating systems, some underlying memory binding functions also bind the application to the corresponding CPU(s). Using this flag will cause hwloc to avoid using OS functions that could potentially affect CPU bindings. Note, however, that using NOCPUBIND may reduce hwloc's overall memory binding support. Specifically: some of hwloc's memory binding functions may fail with errno set to ENOSYS when used with NOCPUBIND.

18.10.2.2 enum hwloc membind policy t

Memory binding policy.

These constants can be used to choose the binding policy. Only one policy can be used at a time (i.e., the values cannot be OR'ed together).

Not all systems support all kinds of binding. hwloc\_topology\_get\_support() may be used to query about the actual memory binding policy support in the currently used operating system. See the "Detailed Description" section of Memory binding for a description of errors that can occur.

#### **Enumerator**

- HWLOC\_MEMBIND\_DEFAULT Reset the memory allocation policy to the system default.
- HWLOC\_MEMBIND\_FIRSTTOUCH Allocate memory but do not immediately bind it to a specific locality. Instead, each page in the allocation is bound only when it is first touched. Pages are individually bound to the local NUMA node of the first thread that touches it. If there is not enough memory on the node, allocation may be done in the specified cpuset before allocating on other nodes.
- **HWLOC\_MEMBIND\_BIND** Allocate memory on the specified nodes.
- HWLOC\_MEMBIND\_INTERLEAVE Allocate memory on the given nodes in an interleaved / round-robin manner.
  The precise layout of the memory across multiple NUMA nodes is OS/system specific. Interleaving can be useful when threads distributed across the specified NUMA nodes will all be accessing the whole memory range concurrently, since the interleave will then balance the memory references.
- HWLOC\_MEMBIND\_REPLICATE Replicate memory on the given nodes; reads from this memory will attempt to be serviced from the NUMA node local to the reading thread. Replicating can be useful when multiple threads from the specified NUMA nodes will be sharing the same read-only data. This policy can only be used with existing memory allocations (i.e., the hwloc\_set\_\*membind\*() functions); it cannot be used with functions that allocate new memory (i.e., the hwloc\_alloc\*() functions).
- **HWLOC\_MEMBIND\_NEXTTOUCH** For each page bound with this policy, by next time it is touched (and next time only), it is moved from its current location to the local NUMA node of the thread where the memory reference occurred (if it needs to be moved at all).
- **HWLOC\_MEMBIND\_MIXED** Returned by get\_membind() functions when multiple threads or parts of a memory area have differing memory binding policies.

18.10 Memory binding 93

## 18.10.3 Function Documentation

18.10.3.1 void\* hwloc\_alloc ( hwloc\_topology\_t topology, size\_t len )

Allocate some memory.

This is equivalent to malloc(), except that it tries to allocate page-aligned memory from the OS.

Note

The allocated memory should be freed with <a href="https://hwloc\_free">hwloc\_free</a>().

18.10.3.2 void\* hwloc\_alloc\_membind ( hwloc\_topology\_t topology, size\_t len, hwloc\_const\_cpuset\_t cpuset, hwloc\_membind\_policy\_t policy, int flags )

Allocate some memory on memory nodes near the given physical cpuset cpuset.

## Returns

NULL with errno set to ENOSYS if the action is not supported and HWLOC\_MEMBIND\_STRICT is given NULL with errno set to EXDEV if the binding cannot be enforced and HWLOC\_MEMBIND\_STRICT is given NULL with errno set to ENOMEM if the memory allocation failed even before trying to bind.

### Note

The allocated memory should be freed with hwloc free().

18.10.3.3 void\* hwloc\_alloc\_membind\_nodeset ( hwloc\_topology\_t topology, size\_t len, hwloc\_const\_nodeset\_t nodeset, hwloc\_membind\_policy\_t policy, int flags )

Allocate some memory on the given physical nodeset nodeset.

# Returns

NULL with errno set to ENOSYS if the action is not supported and HWLOC\_MEMBIND\_STRICT is given NULL with errno set to EXDEV if the binding cannot be enforced and HWLOC\_MEMBIND\_STRICT is given NULL with errno set to ENOMEM if the memory allocation failed even before trying to bind.

## Note

The allocated memory should be freed with <a href="hwloc\_free">hwloc\_free</a>().

18.10.3.4 static void\* hwloc\_alloc\_membind\_policy ( hwloc\_topology\_t topology, size\_t len, hwloc\_const\_cpuset\_t set, hwloc\_membind\_policy\_t policy, int flags ) [inline], [static]

Allocate some memory on the memory nodes near given cpuset cpuset.

This is similar to hwloc alloc membind policy nodeset, but for a given cpuset.

```
18.10.3.5 static void* hwloc_alloc_membind_policy_nodeset ( hwloc_topology_t topology, size_t len, hwloc_const_nodeset_t nodeset, hwloc_membind_policy_t policy, int flags ) [inline], [static]
```

Allocate some memory on the given nodeset nodeset.

This is similar to hwloc\_alloc\_membind except that it is allowed to change the current memory binding policy, thus providing more binding support, at the expense of changing the current state.

```
18.10.3.6 int hwloc_free ( hwloc_topology_t topology, void * addr, size_t len )
```

Free memory that was previously allocated by hwloc alloc() or hwloc alloc membind().

18.10.3.7 int hwloc\_get\_area\_membind ( hwloc\_topology\_t topology, const void \* addr, size\_t len, hwloc\_cpuset\_t cpuset, hwloc\_membind\_policy\_t \* policy, int flags )

Query the CPUs near the physical NUMA node(s) and binding policy of the memory identified by (addr, len).

This function has two output parameters: cpuset and policy. The values returned in these parameters depend on both the flags passed in and the memory binding policies and nodesets of the pages in the address range.

If HWLOC\_MEMBIND\_STRICT is specified, the target pages are first checked to see if they all have the same memory binding policy and nodeset. If they do not, -1 is returned and errno is set to EXDEV. If they are identical across all pages, the policy is returned in policy. cpuset is set to the union of CPUs near the NUMA node(s) in the nodeset.

If HWLOC\_MEMBIND\_STRICT is not specified, the union of all NUMA node(s) containing pages in the address range is calculated. cpuset is then set to the CPUs near the NUMA node(s) in this union. If all pages in the target have the same policy, it is returned in policy. Otherwise, policy is set to HWLOC\_MEMBIND\_MIXED.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

```
18.10.3.8 int hwloc_get_area_membind_nodeset ( hwloc_topology_t topology, const void * addr, size_t len, hwloc_nodeset_t nodeset, hwloc_membind_policy_t * policy, int flags )
```

Query the physical NUMA node(s) and binding policy of the memory identified by (addr, len).

This function has two output parameters: nodeset and policy. The values returned in these parameters depend on both the flags passed in and the memory binding policies and nodesets of the pages in the address range.

If HWLOC\_MEMBIND\_STRICT is specified, the target pages are first checked to see if they all have the same memory binding policy and nodeset. If they do not, -1 is returned and errno is set to EXDEV. If they are identical across all pages, the nodeset and policy are returned in nodeset and policy, respectively.

If HWLOC\_MEMBIND\_STRICT is not specified, nodeset is set to the union of all NUMA node(s) containing pages in the address range. If all pages in the target have the same policy, it is returned in policy. Otherwise, policy is set to HWLOC\_MEMBIND\_MIXED.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

18.10.3.9 int hwloc\_get\_membind ( hwloc\_topology\_t topology, hwloc\_cpuset\_t cpuset, hwloc\_membind\_policy\_t \* policy, int flags )

Query the default memory binding policy and physical locality of the current process or thread (the locality is returned in cpuset as CPUs near the locality's actual NUMA node(s)).

This function has two output parameters: cpuset and policy. The values returned in these parameters depend on both the flags passed in and the current memory binding policies and nodesets in the queried target.

18.10 Memory binding 95

Passing the HWLOC\_MEMBIND\_PROCESS flag specifies that the query target is the current policies and nodesets for all the threads in the current process. Passing HWLOC\_MEMBIND\_THREAD specifies that the query target is the current policy and nodeset for only the thread invoking this function.

If neither of these flags are passed (which is the most portable method), the process is assumed to be single threaded. This allows hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

HWLOC\_MEMBIND\_STRICT is only meaningful when HWLOC\_MEMBIND\_PROCESS is also specified. In this case, hwloc will check the default memory policies and nodesets for all threads in the process. If they are not identical, -1 is returned and errno is set to EXDEV. If they are identical, the policy is returned in policy. cpuset is set to the union of CPUs near the NUMA node(s) in the nodeset.

Otherwise, if HWLOC\_MEMBIND\_PROCESS is specified (and HWLOC\_MEMBIND\_STRICT is *not* specified), the default nodeset from each thread is logically OR'ed together. cpuset is set to the union of CPUs near the NUMA node(s) in the resulting nodeset. If all threads' default policies are the same, policy is set to that policy. If they are different, policy is set to HWLOC MEMBIND MIXED.

In the HWLOC\_MEMBIND\_THREAD case (or when neither HWLOC\_MEMBIND\_PROCESS or HWLOC\_MEMBIND — \_\_THREAD is specified), there is only one nodeset and policy. The policy is returned in policy; cpuset is set to the union of CPUs near the NUMA node(s) in the nodeset.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

```
18.10.3.10 int hwloc_get_membind_nodeset ( hwloc_topology_t topology, hwloc_nodeset_t nodeset, hwloc membind policy_t * policy, int flags )
```

Query the default memory binding policy and physical locality of the current process or thread.

This function has two output parameters: nodeset and policy. The values returned in these parameters depend on both the flags passed in and the current memory binding policies and nodesets in the queried target.

Passing the HWLOC\_MEMBIND\_PROCESS flag specifies that the query target is the current policies and nodesets for all the threads in the current process. Passing HWLOC\_MEMBIND\_THREAD specifies that the query target is the current policy and nodeset for only the thread invoking this function.

If neither of these flags are passed (which is the most portable method), the process is assumed to be single threaded. This allows hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

HWLOC\_MEMBIND\_STRICT is only meaningful when HWLOC\_MEMBIND\_PROCESS is also specified. In this case, hwloc will check the default memory policies and nodesets for all threads in the process. If they are not identical, -1 is returned and errno is set to EXDEV. If they are identical, the values are returned in nodeset and policy.

Otherwise, if HWLOC\_MEMBIND\_PROCESS is specified (and HWLOC\_MEMBIND\_STRICT is *not* specified), nodeset is set to the logical OR of all threads' default nodeset. If all threads' default policies are the same, policy is set to that policy. If they are different, policy is set to HWLOC\_MEMBIND\_MIXED.

In the HWLOC\_MEMBIND\_THREAD case (or when neither HWLOC\_MEMBIND\_PROCESS or HWLOC\_MEMBIND — \_THREAD is specified), there is only one nodeset and policy; they are returned in nodeset and policy, respectively.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

```
18.10.3.11 int hwloc_get_proc_membind ( hwloc_topology_t topology, hwloc_pid_t pid, hwloc_cpuset_t cpuset, hwloc_membind_policy_t * policy, int flags )
```

Query the default memory binding policy and physical locality of the specified process (the locality is returned in cpuset as CPUs near the locality's actual NUMA node(s)).

This function has two output parameters: cpuset and policy. The values returned in these parameters depend on both the flags passed in and the current memory binding policies and nodesets in the gueried target.

Passing the HWLOC\_MEMBIND\_PROCESS flag specifies that the query target is the current policies and nodesets for all the threads in the specified process. If HWLOC\_MEMBIND\_PROCESS is not specified (which is the most portable method), the process is assumed to be single threaded. This allows hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

Note that it does not make sense to pass HWLOC MEMBIND THREAD to this function.

If HWLOC\_MEMBIND\_STRICT is specified, hwloc will check the default memory policies and nodesets for all threads in the specified process. If they are not identical, -1 is returned and errno is set to EXDEV. If they are identical, the policy is returned in policy. cpuset is set to the union of CPUs near the NUMA node(s) in the nodeset.

Otherwise, the default nodeset from each thread is logically OR'ed together. cpuset is set to the union of CPUs near the NUMA node(s) in the resulting nodeset. If all threads' default policies are the same, policy is set to that policy. If they are different, policy is set to HWLOC\_MEMBIND\_MIXED.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

Note

hwloc\_pid\_t is pid\_t on Unix platforms, and HANDLE on native Windows platforms.

18.10.3.12 int hwloc\_get\_proc\_membind\_nodeset ( hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_nodeset\_t nodeset, hwloc\_membind\_policy\_t \* policy, int flags )

Query the default memory binding policy and physical locality of the specified process.

This function has two output parameters: nodeset and policy. The values returned in these parameters depend on both the flags passed in and the current memory binding policies and nodesets in the queried target.

Passing the HWLOC\_MEMBIND\_PROCESS flag specifies that the query target is the current policies and nodesets for all the threads in the specified process. If HWLOC\_MEMBIND\_PROCESS is not specified (which is the most portable method), the process is assumed to be single threaded. This allows hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

Note that it does not make sense to pass HWLOC\_MEMBIND\_THREAD to this function.

If HWLOC\_MEMBIND\_STRICT is specified, hwloc will check the default memory policies and nodesets for all threads in the specified process. If they are not identical, -1 is returned and errno is set to EXDEV. If they are identical, the values are returned in nodeset and policy.

Otherwise, nodeset is set to the logical OR of all threads' default nodeset. If all threads' default policies are the same, policy is set to that policy. If they are different, policy is set to HWLOC\_MEMBIND\_MIXED.

If any other flags are specified, -1 is returned and errno is set to EINVAL.

Note

hwloc\_pid\_t is pid\_t on Unix platforms, and HANDLE on native Windows platforms.

18.10.3.13 int hwloc\_set\_area\_membind ( hwloc\_topology\_t topology, const void \* addr, size\_t len, hwloc\_const\_cpuset\_t cpuset, hwloc\_membind policy t policy, int flags )

Bind the already-allocated memory identified by (addr, len) to the NUMA node(s) near physical cpuset.

18.10 Memory binding 97

### Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

```
18.10.3.14 int hwloc_set_area_membind_nodeset ( hwloc_topology_t topology, const void * addr, size_t len, hwloc_const_nodeset_t nodeset, hwloc_membind_policy_t policy, int flags )
```

Bind the already-allocated memory identified by (addr, len) to the NUMA node(s) in physical nodeset.

#### Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

```
18.10.3.15 int hwloc_set_membind ( hwloc_topology_t topology, hwloc_const_cpuset_t cpuset, hwloc membind policy t policy, int flags )
```

Set the default memory binding policy of the current process or thread to prefer the NUMA node(s) near the specified physical cpuset.

If neither HWLOC\_MEMBIND\_PROCESS nor HWLOC\_MEMBIND\_THREAD is specified, the current process is assumed to be single-threaded. This is the most portable form as it permits hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

### Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

```
18.10.3.16 int hwloc_set_membind_nodeset ( hwloc_topology_t topology, hwloc_const_nodeset_t nodeset, hwloc membind_policy_t policy, int flags )
```

Set the default memory binding policy of the current process or thread to prefer the NUMA node(s) specified by physical nodeset.

If neither HWLOC\_MEMBIND\_PROCESS nor HWLOC\_MEMBIND\_THREAD is specified, the current process is assumed to be single-threaded. This is the most portable form as it permits hwloc to use either process-based OS functions or thread-based OS functions, depending on which are available.

#### **Returns**

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced
- 18.10.3.17 int hwloc\_set\_proc\_membind ( hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_const\_cpuset\_t cpuset, hwloc\_membind\_policy\_t policy, int flags )

Set the default memory binding policy of the specified process to prefer the NUMA node(s) near the specified physical cpuset.

### Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

## Note

hwloc\_pid\_t is pid\_t on Unix platforms, and HANDLE on native Windows platforms.

18.10.3.18 int hwloc\_set\_proc\_membind\_nodeset ( hwloc\_topology\_t topology, hwloc\_pid\_t pid, hwloc\_const\_nodeset\_t nodeset, hwloc\_membind\_policy\_t policy, int flags )

Set the default memory binding policy of the specified process to prefer the NUMA node(s) specified by physical nodeset.

#### Returns

- -1 with errno set to ENOSYS if the action is not supported
- -1 with errno set to EXDEV if the binding cannot be enforced

# Note

hwloc\_pid\_t is pid\_t on Unix platforms, and HANDLE on native Windows platforms.

# 18.11 Modifying a loaded Topology

## **Enumerations**

enum hwloc\_restrict\_flags\_e { HWLOC\_RESTRICT\_FLAG\_ADAPT\_DISTANCES, HWLOC\_RESTRICT\_FLAG\_ADAPT\_DISTANCES, HWLOC\_RESTRICT\_FLAG\_ADAPT\_IO }

## **Functions**

- hwloc\_obj\_t hwloc\_topology\_insert\_misc\_object\_by\_cpuset (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t cpuset, const char \*name)
- hwloc\_obj\_t hwloc\_topology\_insert\_misc\_object\_by\_parent (hwloc\_topology\_t topology, hwloc\_obj\_t parent, const char \*name)
- int hwloc\_topology\_restrict (hwloc\_topology\_t restrict topology, hwloc\_const\_cpuset\_t cpuset, unsigned long flags)
- int hwloc\_topology\_dup (hwloc\_topology\_t \*newtopology, hwloc\_topology\_t oldtopology)

# 18.11.1 Detailed Description

# 18.11.2 Enumeration Type Documentation

18.11.2.1 enum hwloc\_restrict\_flags\_e

Flags to be given to hwloc topology restrict().

#### **Enumerator**

**HWLOC\_RESTRICT\_FLAG\_ADAPT\_DISTANCES** Adapt distance matrices according to objects being removed during restriction. If this flag is not set, distance matrices are removed.

**HWLOC\_RESTRICT\_FLAG\_ADAPT\_MISC** Move Misc objects to ancestors if their parents are removed during restriction. If this flag is not set, Misc objects are removed when their parents are removed.

**HWLOC\_RESTRICT\_FLAG\_ADAPT\_IO** Move I/O objects to ancestors if their parents are removed during restriction. If this flag is not set, I/O devices and bridges are removed when their parents are removed.

## 18.11.3 Function Documentation

18.11.3.1 int hwloc\_topology\_dup ( hwloc\_topology\_t \* newtopology, hwloc\_topology\_t oldtopology )

Duplicate a topology.

The entire topology structure as well as its objects are duplicated into a new one.

This is useful for keeping a backup while modifying a topology.

18.11.3.2 hwloc\_obj\_t hwloc\_topology\_insert\_misc\_object\_by\_cpuset ( hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t cpuset, const char \* name )

Add a MISC object to the topology.

A new MISC object will be created and inserted into the topology at the position given by bitmap <code>cpuset</code>. This offers a way to add new intermediate levels to the topology hierarchy.

cpuset and name will be copied to setup the new object attributes.

### Returns

the newly-created object.

NULL if the insertion conflicts with the existing topology tree.

#### Note

If name contains some non-printable characters, they will be dropped when exporting to XML, see hwloc\_
topology\_export\_xml().

18.11.3.3 hwloc\_obj\_t hwloc\_topology\_insert\_misc\_object\_by\_parent ( hwloc\_topology\_t topology, hwloc\_obj\_t parent, const char \* name )

Add a MISC object as a leaf of the topology.

A new MISC object will be created and inserted into the topology at the position given by parent. It is appended to the list of existing children, without ever adding any intermediate hierarchy level. This is useful for annotating the topology without actually changing the hierarchy.

name will be copied to the setup the new object attributes. However, the new leaf object will not have any cpuset.

#### Returns

the newly-created object

### Note

18.11.3.4 int hwloc\_topology\_restrict ( hwloc\_topology\_t restrict topology, hwloc\_const\_cpuset\_t cpuset, unsigned long flags )

Restrict the topology to the given CPU set.

Topology topology is modified so as to remove all objects that are not included (or partially included) in the CPU set cpuset. All objects CPU and node sets are restricted accordingly.

flags is a OR'ed set of hwloc\_restrict\_flags\_e.

### Note

This call may not be reverted by restricting back to a larger cpuset. Once dropped during restriction, objects may not be brought back, except by loading another topology with <a href="https://www.hwloc\_topology\_load">hwloc\_topology\_load</a>().

## Returns

0 on success.

- -1 with errno set to EINVAL if the input cpuset is invalid. The topology is not modified in this case.

# 18.12 Building Custom Topologies

#### **Functions**

- int hwloc\_custom\_insert\_topology (hwloc\_topology\_t newtopology, hwloc\_obj\_t newparent, hwloc\_topology\_
   t oldtopology, hwloc obj t oldroot)
- hwloc\_obj\_t hwloc\_custom\_insert\_group\_object\_by\_parent (hwloc\_topology\_t topology, hwloc\_obj\_t parent, int groupdepth)

# 18.12.1 Detailed Description

A custom topology may be initialized by calling hwloc\_topology\_set\_custom() after hwloc\_topology\_init(). It may then be modified by inserting objects or entire topologies. Once done assembling, hwloc\_topology\_load() should be invoked as usual to finalize the topology.

## 18.12.2 Function Documentation

18.12.2.1 hwloc\_obj\_t hwloc\_custom\_insert\_group\_object\_by\_parent ( hwloc\_topology\_t topology, hwloc\_obj\_t parent, int groupdepth )

Insert a new group object inside a custom topology.

An object with type HWLOC OBJ GROUP is inserted as a new child of object parent.

groupdepth is the depth attribute to be given to the new object. It may for instance be 0 for top-level groups, 1 for their children, and so on.

The custom topology newtopology must have been prepared with hwloc\_topology\_set\_custom() and not loaded with hwloc\_topology\_load() yet.

parent may be either the root of topology or an object that was added earlier through hwloc\_custom\_insert\_
group\_object\_by\_parent().

#### Note

The cpuset and nodeset of the new group object are NULL because these sets are meaningless when assembling multiple topologies.

The cpuset and nodeset of the parent object are not modified.

18.12.2.2 int hwloc\_custom\_insert\_topology ( hwloc\_topology\_t newtopology, hwloc\_obj\_t newparent, hwloc\_topology\_t oldtopology, hwloc\_obj\_t oldroot )

Insert an existing topology inside a custom topology.

Duplicate the existing topology oldtopology inside a new custom topology newtopology as a leaf of object newparent.

If oldroot is not NULL, duplicate oldroot and all its children instead of the entire oldtopology. Passing the root object of oldtopology in oldroot is equivalent to passing NULL.

The custom topology newtopology must have been prepared with hwloc\_topology\_set\_custom() and not loaded with hwloc\_topology\_load() yet.

newparent may be either the root of newtopology or an object that was added through hwloc\_custom\_insert\_
group\_object\_by\_parent().



The cpuset and nodeset of the newparent object are not modified based on the contents of oldtopology.

# 18.13 Exporting Topologies to XML

#### **Functions**

- int hwloc\_topology\_export\_xml (hwloc\_topology\_t topology, const char \*xmlpath)
- int hwloc\_topology\_export\_xmlbuffer (hwloc\_topology\_t topology, char \*\*xmlbuffer, int \*buflen)
- void hwloc\_free\_xmlbuffer (hwloc\_topology\_t topology, char \*xmlbuffer)
- void hwloc\_topology\_set\_userdata\_export\_callback (hwloc\_topology\_t topology, void(\*export\_cb)(void \*reserved, hwloc\_topology\_t topology, hwloc\_obj\_t obj))
- int hwloc\_export\_obj\_userdata (void \*reserved, hwloc\_topology\_t topology, hwloc\_obj\_t obj, const char \*name, const void \*buffer, size\_t length)
- int hwloc\_export\_obj\_userdata\_base64 (void \*reserved, hwloc\_topology\_t topology, hwloc\_obj\_t obj, const char \*name, const void \*buffer, size\_t length)
- void hwloc\_topology\_set\_userdata\_import\_callback (hwloc\_topology\_t topology, void(\*import\_cb)(hwloc\_
  topology\_t topology, hwloc\_obj\_t obj, const char \*name, const void \*buffer, size\_t length))

# 18.13.1 Detailed Description

# 18.13.2 Function Documentation

18.13.2.1 int hwloc\_export\_obj\_userdata ( void \* reserved, hwloc\_topology\_t topology, hwloc\_obj\_t obj, const char \* name, const void \* buffer, size\_t length )

Export some object userdata to XML.

This function may only be called from within the export() callback passed to hwloc\_topology\_set\_userdata\_export\_callback(). It may be invoked one of multiple times to export some userdata to XML. The buffer content of length length is stored with optional name name.

When importing this XML file, the import() callback (if set) will be called exactly as many times as hwloc\_export\_obj\_userdata() was called during export(). It will receive the corresponding name, buffer and length arguments.

reserved, topology and obj must be the first three parameters that were given to the export callback.

Only printable characters may be exported to XML string attributes. If a non-printable character is passed in name or buffer, the function returns -1 with errno set to EINVAL.

If exporting binary data, the application should first encode into printable characters only (or use <a href="https://www.nwines.com/hwloc\_export\_com/hwloc\_exp

18.13.2.2 int hwloc\_export\_obj\_userdata\_base64 ( void \* reserved, hwloc\_topology\_t topology, hwloc\_obj\_t obj, const char \* name, const void \* buffer, size\_t length )

Encode and export some object userdata to XML.

This function is similar to hwloc\_export\_obj\_userdata() but it encodes the input buffer into printable characters before exporting. On import, decoding is automatically performed before the data is given to the import() callback if any.

This function may only be called from within the export() callback passed to hwloc\_topology\_set\_userdata\_export\_callback().

The function does not take care of portability issues if the export may be reimported on a different architecture.

18.13.2.3 void hwloc\_free\_xmlbuffer ( hwloc\_topology\_t topology, char \* xmlbuffer )

Free a buffer allocated by hwloc topology export xmlbuffer()

18.13.2.4 int hwloc\_topology\_export\_xml ( hwloc\_topology\_t topology, const char \* xmlpath )

Export the topology into an XML file.

This file may be loaded later through hwloc topology set xml().

#### Returns

-1 if a failure occured.

#### Note

See also hwloc\_topology\_set\_userdata\_export\_callback() for exporting application-specific object userdata.

The topology-specific userdata pointer is ignored when exporting to XML.

Only printable characters may be exported to XML string attributes. Any other character, especially any non-ASCII character, will be silently dropped.

If name is "-", the XML output is sent to the standard output.

18.13.2.5 int hwloc\_topology\_export\_xmlbuffer ( hwloc\_topology\_t topology, char \*\* xmlbuffer, int \* buflen )

Export the topology into a newly-allocated XML memory buffer.

xmlbuffer is allocated by the callee and should be freed with hwloc free xmlbuffer() later in the caller.

This memory buffer may be loaded later through hwloc\_topology\_set\_xmlbuffer().

## Returns

-1 if a failure occured.

## Note

 $See\ also\ hwloc\_topology\_set\_userdata\_export\_callback()\ for\ exporting\ application-specific\ object\ userdata.$ 

The topology-specific userdata pointer is ignored when exporting to XML. Only printable characters may be exported to XML string attributes. Any other charact

Only printable characters may be exported to XML string attributes. Any other character, especially any non-AS← CII character, will be silently dropped.

18.13.2.6 void hwloc\_topology\_set\_userdata\_export\_callback ( hwloc\_topology\_t topology, void(\*)(void \*reserved, hwloc\_topology\_t topology, hwloc\_obj\_t obj) export\_cb )

Set the application-specific callback for exporting object userdata.

The object userdata pointer is not exported to XML by default because hwloc does not know what it contains.

This function lets applications set <code>export\_cb</code> to a callback function that converts this opaque userdata into an exportable string.

export\_cb is invoked during XML export for each object whose userdata pointer is not NULL. The callback should use hwloc\_export\_obj\_userdata() or hwloc\_export\_obj\_userdata\_base64() to actually export something to XML (possibly multiple times per object).

export\_cb may be set to NULL if userdata should not be exported to XML.

Note

The topology-specific userdata pointer is ignored when exporting to XML.

18.13.2.7 void hwloc\_topology\_set\_userdata\_import\_callback ( hwloc\_topology\_t topology, void(\*)(hwloc\_topology\_t topology, hwloc\_obj\_t obj, const char \*name, const void \*buffer, size\_t length) import\_cb )

Set the application-specific callback for importing userdata.

On XML import, userdata is ignored by default because hwloc does not know how to store it in memory.

This function lets applications set import\_cb to a callback function that will get the XML-stored userdata and store it in the object as expected by the application.

import\_cb is called during hwloc\_topology\_load() as many times as hwloc\_export\_obj\_userdata() was called during export. The topology is not entirely setup yet. Object attributes are ready to consult, but links between objects are not.

import\_cb may be NULL if userdata should be ignored during import.

## Note

buffer contains length characters followed by a null byte ('\0').

This function should be called before hwloc\_topology\_load().

The topology-specific userdata pointer is ignored when importing from XML.

# 18.14 Exporting Topologies to Synthetic

## **Enumerations**

## **Functions**

• int hwloc\_topology\_export\_synthetic (hwloc\_topology\_t topology, char \*buffer, size\_t buflen, unsigned long flags)

# 18.14.1 Detailed Description

# 18.14.2 Enumeration Type Documentation

18.14.2.1 enum hwloc\_topology\_export\_synthetic\_flags\_e

Flags for exporting synthetic topologies.

Flags to be given as a OR'ed set to hwloc\_topology\_export\_synthetic().

#### Enumerator

**HWLOC\_TOPOLOGY\_EXPORT\_SYNTHETIC\_FLAG\_NO\_EXTENDED\_TYPES** Export extended types such as L2dcache as basic types such as Cache. This is required if loading the synthetic description with hwloc < 1.9.

**HWLOC\_TOPOLOGY\_EXPORT\_SYNTHETIC\_FLAG\_NO\_ATTRS** Do not export level attributes. Ignore level attributes such as memory/cache sizes or PU indexes. This is required if loading the synthetic description with hwloc < 1.10.

## 18.14.3 Function Documentation

18.14.3.1 int hwloc\_topology\_export\_synthetic ( hwloc\_topology\_t topology, char \* buffer, size\_t buflen, unsigned long flags )

Export the topology as a synthetic string.

At most buflen characters will be written in buffer, including the terminating \0.

flags is a OR'ed set of hwloc\_topology\_export\_synthetic\_flags\_e.

# Returns

The number of characters that were written, not including the terminating \0.

-1 if the topology could not be exported, for instance if it is not symmetric.

## Note

A 1024-byte buffer should be large enough for exporting topologies in the vast majority of cases.

# 18.15 Finding Objects inside a CPU set

## **Functions**

- static hwloc\_obj\_t hwloc\_get\_first\_largest\_obj\_inside\_cpuset (hwloc\_topology\_t topology, hwloc\_const\_cpuset
  t set)
- int hwloc\_get\_largest\_objs\_inside\_cpuset (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, hwloc\_obj\_
   t \*restrict objs, int max)
- static hwloc\_obj\_t hwloc\_get\_next\_obj\_inside\_cpuset\_by\_depth (hwloc\_topology\_t topology, hwloc\_const\_
   cpuset\_t set, unsigned depth, hwloc\_obj\_t prev)
- static hwloc\_obj\_t hwloc\_get\_next\_obj\_inside\_cpuset\_by\_type (hwloc\_topology\_t topology, hwloc\_const\_
   cpuset t set, hwloc obj type t type, hwloc obj t prev)
- static hwloc\_obj\_t hwloc\_get\_obj\_inside\_cpuset\_by\_depth (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_
   t set, unsigned depth, unsigned idx)
- static hwloc\_obj\_t hwloc\_get\_obj\_inside\_cpuset\_by\_type (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, hwloc\_obj\_type\_t type, unsigned idx)
- static unsigned hwloc\_get\_nbobjs\_inside\_cpuset\_by\_depth (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, unsigned depth)
- static int hwloc\_get\_nbobjs\_inside\_cpuset\_by\_type (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, hwloc\_obj\_type\_t type)
- static int hwloc\_get\_obj\_index\_inside\_cpuset (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, hwloc\_
  obj\_t obj)

# 18.15.1 Detailed Description

## 18.15.2 Function Documentation

```
18.15.2.1 static hwloc_obj_t hwloc_get_first_largest_obj_inside_cpuset ( hwloc_topology_t topology, hwloc_const_cpuset_t set ) [inline], [static]
```

Get the first largest object included in the given couset set.

# Returns

the first object that is included in set and whose parent is not.

This is convenient for iterating over all largest objects within a CPU set by doing a loop getting the first largest object and clearing its CPU set from the remaining CPU set.

#### Note

This function cannot work if the root object does not have a CPU set, e.g. if the topology is made of different machines.

```
18.15.2.2 int hwloc_get_largest_objs_inside_cpuset ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_t *restrict objs, int max )
```

Get the set of largest objects covering exactly a given cpuset set.

#### Returns

the number of objects returned in objs.

#### Note

This function cannot work if the root object does not have a CPU set, e.g. if the topology is made of different machines.

18.15.2.3 static unsigned hwloc\_get\_nbobjs\_inside\_cpuset\_by\_depth ( hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, unsigned depth ) [inline], [static]

Return the number of objects at depth depth included in CPU set set.

#### Note

This function cannot work if objects at the given depth do not have CPU sets or if the topology is made of different machines.

18.15.2.4 static int hwloc\_get\_nbobjs\_inside\_cpuset\_by\_type ( hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, hwloc\_obj\_type\_t type ) [inline], [static]

Return the number of objects of type type included in CPU set set.

If no object for that type exists inside CPU set set, 0 is returned. If there are several levels with objects of that type inside CPU set set, -1 is returned.

# Note

This function cannot work if objects of the given type do not have CPU sets or if the topology is made of different machines.

```
18.15.2.5 static hwloc_obj_t hwloc_get_next_obj_inside_cpuset_by_depth ( hwloc_topology_t topology, hwloc_const_cpuset_t set, unsigned depth, hwloc_obj_t prev ) [inline], [static]
```

Return the next object at depth depth included in CPU set set.

If prev is NULL, return the first object at depth depth included in set. The next invokation should pass the previous return value in prev so as to obtain the next object in set.

## Note

This function cannot work if objects at the given depth do not have CPU sets or if the topology is made of different machines.

```
18.15.2.6 static hwloc_obj_t hwloc_get_next_obj_inside_cpuset_by_type ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_type_t type, hwloc_obj_t prev ) [inline], [static]
```

Return the next object of type type included in CPU set set.

If there are multiple or no depth for given type, return  $\mathtt{NULL}$  and let the caller fallback to  $\mathsf{hwloc\_get\_next\_obj\_inside\_} \leftarrow \mathsf{cpuset\_by\_depth}().$ 

Note

This function cannot work if objects of the given type do not have CPU sets or if the topology is made of different machines.

```
18.15.2.7 static int hwloc_get_obj_index_inside_cpuset ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_t obj ) [inline], [static]
```

Return the logical index among the objects included in CPU set set.

Consult all objects in the same level as obj and inside CPU set set in the logical order, and return the index of obj within them. If set covers the entire topology, this is the logical index of obj. Otherwise, this is similar to a logical index within the part of the topology defined by CPU set set.

```
18.15.2.8 static hwloc_obj_t hwloc_get_obj_inside_cpuset_by_depth ( hwloc_topology_t topology, hwloc_const_cpuset_t set, unsigned depth, unsigned idx ) [inline], [static]
```

Return the (logically) idx -th object at depth depth included in CPU set set.

Note

This function cannot work if objects at the given depth do not have CPU sets or if the topology is made of different machines.

```
18.15.2.9 static hwloc_obj_t hwloc_get_obj_inside_cpuset_by_type ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_type_t type, unsigned idx ) [inline], [static]
```

Return the idx -th object of type type included in CPU set set.

If there are multiple or no depth for given type, return NULL and let the caller fallback to hwloc\_get\_obj\_inside\_cpuset by depth().

Note

This function cannot work if objects of the given type do not have CPU sets or if the topology is made of different machines.

# 18.16 Finding Objects covering at least CPU set

#### **Functions**

 static hwloc\_obj\_t hwloc\_get\_child\_covering\_cpuset (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, hwloc obj\_t parent)

- static hwloc\_obj\_t hwloc\_get\_obj\_covering\_cpuset (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set)
- static hwloc\_obj\_t hwloc\_get\_next\_obj\_covering\_cpuset\_by\_depth (hwloc\_topology\_t topology, hwloc\_const\_
  cpuset\_t set, unsigned depth, hwloc\_obj\_t prev)
- static hwloc\_obj\_t hwloc\_get\_next\_obj\_covering\_cpuset\_by\_type (hwloc\_topology\_t topology, hwloc\_const\_couset\_t set, hwloc\_obj\_type\_t type, hwloc\_obj\_t prev)

# 18.16.1 Detailed Description

#### 18.16.2 Function Documentation

18.16.2.1 static hwloc\_obj\_t hwloc\_get\_child\_covering\_cpuset( hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set, hwloc\_obj\_t parent) [inline], [static]

Get the child covering at least CPU set set.

#### Returns

NULL if no child matches or if set is empty.

### Note

This function cannot work if parent does not have a CPU set.

```
18.16.2.2 static hwloc_obj_t hwloc_get_next_obj_covering_cpuset_by_depth ( hwloc_topology_t topology, hwloc_const_cpuset_t set, unsigned depth, hwloc_obj_t prev ) [inline], [static]
```

Iterate through same-depth objects covering at least CPU set set.

If object prev is NULL, return the first object at depth depth covering at least part of CPU set set. The next invokation should pass the previous return value in prev so as to obtain the next object covering at least another part of set.

# Note

This function cannot work if objects at the given depth do not have CPU sets or if the topology is made of different machines.

```
18.16.2.3 static hwloc_obj_t hwloc_get_next_obj_covering_cpuset_by_type ( hwloc_topology_t topology, hwloc_const_cpuset_t set, hwloc_obj_type_t type, hwloc_obj_t prev ) [inline], [static]
```

Iterate through same-type objects covering at least CPU set  $\mathtt{set}.$ 

If object prev is NULL, return the first object of type type covering at least part of CPU set set. The next invokation should pass the previous return value in prev so as to obtain the next object of type type covering at least another part of set.

If there are no or multiple depths for type type, NULL is returned. The caller may fallback to  $hwloc\_get\_next\_obj\_{\leftarrow}$  covering\\_cpuset\_by\_depth() for each depth.

#### Note

This function cannot work if objects of the given type do not have CPU sets or if the topology is made of different machines.

18.16.2.4 static hwloc\_obj\_t hwloc\_get\_obj\_covering\_cpuset( hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set )
[inline], [static]

Get the lowest object covering at least CPU set set.

# Returns

NULL if no object matches or if set is empty.

## Note

This function cannot work if the root object does not have a CPU set, e.g. if the topology is made of different machines.

# 18.17 Looking at Ancestor and Child Objects

#### **Functions**

- static hwloc\_obj\_t hwloc\_get\_ancestor\_obj\_by\_depth (hwloc\_topology\_t topology, unsigned depth, hwloc\_obj\_t obi)
- static hwloc\_obj\_t hwloc\_get\_ancestor\_obj\_by\_type (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type, hwloc-obj\_t obj)
- static hwloc\_obj\_t hwloc\_get\_common\_ancestor\_obj (hwloc\_topology\_t topology, hwloc\_obj\_t obj1, hwloc\_obj\_t obj2)
- static int hwloc obj is in subtree (hwloc topology t topology, hwloc obj t obj, hwloc obj t subtree root)
- static hwloc\_obj\_t hwloc\_get\_next\_child (hwloc\_topology\_t topology, hwloc\_obj\_t parent, hwloc\_obj\_t prev)

# 18.17.1 Detailed Description

Be sure to see the figure in Terms and Definitions that shows a complete topology tree, including depths, child/sibling/cousin relationships, and an example of an asymmetric topology where one socket has fewer caches than its peers.

## 18.17.2 Function Documentation

```
18.17.2.1 static hwloc_obj_t hwloc_get_ancestor_obj_by_depth ( hwloc_topology_t topology, unsigned depth, hwloc_obj_t obj ) [inline], [static]
```

Returns the ancestor object of obj at depth depth.

```
18.17.2.2 static hwloc_obj_t hwloc_get_ancestor_obj_by_type ( hwloc_topology_t topology, hwloc_obj_type_t type, hwloc_obj_t obj ) [inline], [static]
```

Returns the ancestor object of obj with type type.

```
18.17.2.3 static hwloc_obj_t hwloc_get_common_ancestor_obj ( hwloc_topology_t topology, hwloc_obj_t obj1, hwloc_obj_t obj2 ) [inline], [static]
```

Returns the common parent object to objects IvI1 and IvI2.

```
18.17.2.4 static hwloc_obj_t hwloc_get_next_child ( hwloc_topology_t topology, hwloc_obj_t parent, hwloc_obj_t prev
) [inline],[static]
```

Return the next child.

If prev is NULL, return the first child.

```
18.17.2.5 static int hwloc_obj_is_in_subtree ( hwloc_topology_t topology, hwloc_obj_t obj, hwloc_obj_t subtree_root )
[inline], [static]
```

Returns true if obj is inside the subtree beginning with ancestor object subtree\_root.

N	0+0

This function assumes that both  ${\tt obj}$  and  ${\tt subtree\_root}$  have a  ${\tt cpuset}.$ 

# 18.18 Looking at Cache Objects

#### **Functions**

- static int hwloc\_get\_cache\_type\_depth (hwloc\_topology\_t topology, unsigned cachelevel, hwloc\_obj\_cache\_
  type t cachetype)
- static hwloc obj t hwloc get cache covering cpuset (hwloc topology t topology, hwloc const cpuset t set)
- static hwloc\_obj\_t hwloc\_get\_shared\_cache\_covering\_obj (hwloc\_topology\_t topology, hwloc\_obj\_t obj)

# 18.18.1 Detailed Description

## 18.18.2 Function Documentation

18.18.2.1 static hwloc\_obj\_t hwloc\_get\_cache\_covering\_cpuset ( hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t set ) [inline], [static]

Get the first cache covering a cpuset set.

#### Returns

NULL if no cache matches.

#### Note

This function cannot work if the root object does not have a CPU set, e.g. if the topology is made of different machines.

```
18.18.2.2 static int hwloc_get_cache_type_depth ( hwloc_topology_t topology, unsigned cachelevel, hwloc_obj_cache_type_t cachetype ) [inline], [static]
```

Find the depth of cache objects matching cache depth and type.

Return the depth of the topology level that contains cache objects whose attributes match cachedepth and cachetype. This function intends to disambiguate the case where  $hwloc_get_type_depth()$  returns  $HWLOC_TY \leftarrow PE_DEPTH_MULTIPLE$ .

If no cache level matches, HWLOC\_TYPE\_DEPTH\_UNKNOWN is returned.

If cachetype is HWLOC\_OBJ\_CACHE\_UNIFIED, the depth of the unique matching unified cache level is returned.

If cachetype is HWLOC\_OBJ\_CACHE\_DATA or HWLOC\_OBJ\_CACHE\_INSTRUCTION, either a matching cache, or a unified cache is returned.

If cachetype is -1, it is ignored and multiple levels may match. The function returns either the depth of a uniquely matching level or HWLOC\_TYPE\_DEPTH\_MULTIPLE.

```
18.18.2.3 static hwloc_obj_t hwloc_get_shared_cache_covering_obj( hwloc_topology_t topology, hwloc_obj_t obj )
[inline], [static]
```

Get the first cache shared between an object and somebody else.

#### Returns

NULL if no cache matches or if an invalid object is given.

# 18.19 Finding objects, miscellaneous helpers

#### **Functions**

- static hwloc\_obj\_t hwloc\_get\_pu\_obj\_by\_os\_index (hwloc\_topology\_t topology, unsigned os\_index)
- static hwloc\_obj\_t hwloc\_get\_numanode\_obj\_by\_os\_index (hwloc\_topology\_t topology, unsigned os\_index)
- unsigned hwloc\_get\_closest\_objs (hwloc\_topology\_t topology, hwloc\_obj\_t src, hwloc\_obj\_t \*restrict objs, unsigned max)
- static hwloc\_obj\_t hwloc\_get\_obj\_below\_by\_type (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type1, unsigned idx1, hwloc\_obj\_type\_t type2, unsigned idx2)
- static hwloc\_obj\_t hwloc\_get\_obj\_below\_array\_by\_type (hwloc\_topology\_t topology, int nr, hwloc\_obj\_type\_
   t \*typev, unsigned \*idxv)

# 18.19.1 Detailed Description

Be sure to see the figure in Terms and Definitions that shows a complete topology tree, including depths, child/sibling/cousin relationships, and an example of an asymmetric topology where one socket has fewer caches than its peers.

#### 18.19.2 Function Documentation

18.19.2.1 unsigned hwloc\_get\_closest\_objs ( hwloc\_topology\_t topology, hwloc\_obj\_t src, hwloc\_obj\_t \*restrict objs, unsigned max )

Do a depth-first traversal of the topology to find and sort.

all objects that are at the same depth than src. Report in objs up to max physically closest ones to src.

#### Returns

the number of objects returned in objs. 0 if src is an I/O object.

#### Note

This function requires the src object to have a CPU set.

```
18.19.2.2 static hwloc_obj_t hwloc_get_numanode_obj_by_os_index ( hwloc_topology_t topology, unsigned os_index ) [inline], [static]
```

Returns the object of type HWLOC OBJ NODE with os\_index.

```
18.19.2.3 static hwloc_obj_t hwloc_get_obj_below_array_by_type ( hwloc_topology_t topology, int nr, hwloc_obj_type_t * typev, unsigned * idxv ) [inline], [static]
```

Find an object below a chain of objects specified by types and indexes.

This is a generalized version of hwloc\_get\_obj\_below\_by\_type().

Arrays typev and idxv must contain nr types and indexes.

Start from the top system object and walk the arrays typev and idxv. For each type and logical index couple in the arrays, look under the previously found object to find the index-th object of the given type. Indexes are specified within the parent, not withing the entire system.

For instance, if nr is 3, typev contains NODE, SOCKET and CORE, and idxv contains 0, 1 and 2, return the third core object below the second socket below the first NUMA node.

Note

This function requires all these objects and the root object to have a CPU set.

```
18.19.2.4 static hwloc_obj_t hwloc_get_obj_below_by_type ( hwloc_topology_t topology, hwloc_obj_type_t type1, unsigned idx1, hwloc_obj_type_t type2, unsigned idx2) [inline], [static]
```

Find an object below another object, both specified by types and indexes.

Start from the top system object and find object of type type1 and logical index idx1. Then look below this object and find another object of type type2 and logical index idx2. Indexes are specified within the parent, not withing the entire system.

For instance, if type1 is SOCKET, idx1 is 2, type2 is CORE and idx2 is 3, return the fourth core object below the third socket.

Note

This function requires these objects to have a CPU set.

```
18.19.2.5 static hwloc_obj_t hwloc_get_pu_obj_by_os_index ( hwloc_topology_t topology, unsigned os_index ) [inline], [static]
```

Returns the object of type HWLOC OBJ PU with os index.

This function is useful for converting a CPU set into the PU objects it contains. When retrieving the current binding (e.g. with <a href="https://hww.nc.get\_cpubind">hwloc\_get\_cpubind</a>()), one may iterate over the bits of the resulting CPU set with <a href="hwloc\_bitmap\_foreach\_begin">hwloc\_bitmap\_foreach\_begin</a>(), and find the corresponding PUs with this function.

# 18.20 Distributing items over a topology

# **Enumerations**

enum hwloc\_distrib\_flags\_e { HWLOC\_DISTRIB\_FLAG\_REVERSE }

# **Functions**

static int hwloc\_distrib (hwloc\_topology\_t topology, hwloc\_obj\_t \*roots, unsigned n\_roots, hwloc\_cpuset\_t \*set, unsigned n, unsigned until, unsigned long flags)

# 18.20.1 Detailed Description

# 18.20.2 Enumeration Type Documentation

18.20.2.1 enum hwloc distrib flags e

Flags to be given to hwloc\_distrib().

#### Enumerator

HWLOC\_DISTRIB\_FLAG\_REVERSE Distrib in reverse order, starting from the last objects.

## 18.20.3 Function Documentation

18.20.3.1 static int hwloc\_distrib ( hwloc\_topology\_t topology, hwloc\_obj\_t \* roots, unsigned n\_roots, hwloc\_cpuset\_t \* set, unsigned n, unsigned until, unsigned long flags ) [inline], [static]

Distribute n items over the topology under roots.

Array set will be filled with n cpusets recursively distributed linearly over the topology under objects roots, down to depth until (which can be INT MAX to distribute down to the finest level).

n\_roots is usually 1 and roots only contains the topology root object so as to distribute over the entire topology.

This is typically useful when an application wants to distribute n threads over a machine, giving each of them as much private cache as possible and keeping them locally in number order.

The caller may typically want to also call hwloc\_bitmap\_singlify() before binding a thread so that it does not move at all. flags should be 0 or a OR'ed set of hwloc distrib flags e.

## Note

This function requires the roots objects to have a CPU set.

This function replaces the now deprecated hwloc\_distribute() and hwloc\_distributev() functions.

# 18.21 CPU and node sets of entire topologies

#### **Functions**

- static hwloc\_const\_cpuset\_t hwloc\_topology\_get\_complete\_cpuset (hwloc\_topology\_t topology)
- static hwloc\_const\_cpuset\_t hwloc\_topology\_get\_topology\_cpuset (hwloc\_topology\_t topology)
- static hwloc\_const\_cpuset\_t hwloc\_topology\_get\_online\_cpuset (hwloc\_topology\_t topology)
- static hwloc\_const\_cpuset\_t hwloc\_topology\_get\_allowed\_cpuset (hwloc\_topology\_t topology)
- static hwloc\_const\_nodeset\_t hwloc\_topology\_get\_complete\_nodeset (hwloc\_topology\_t topology)
- static hwloc\_const\_nodeset\_t hwloc\_topology\_get\_topology\_nodeset (hwloc\_topology\_t topology)
- static hwloc const nodeset thwloc topology get allowed nodeset (hwloc topology t topology)

# 18.21.1 Detailed Description

# 18.21.2 Function Documentation

```
18.21.2.1 static hwloc_const_cpuset_t hwloc_topology_get_allowed_cpuset ( hwloc_topology_t topology )
[inline], [static]
```

Get allowed CPU set.

## Returns

the CPU set of allowed logical processors of the system. If the topology is the result of a combination of several systems, NULL is returned.

## Note

The returned cpuset is not newly allocated and should thus not be changed or freed, <a href="https://hww.bitmap\_dup">hwwloc\_bitmap\_dup</a>() must be used to obtain a local copy.

```
18.21.2.2 static hwloc_const_nodeset_t hwloc_topology_get_allowed_nodeset( hwloc_topology_t topology )
[inline], [static]
```

Get allowed node set.

# Returns

the node set of allowed memory of the system. If the topology is the result of a combination of several systems, NULL is returned.

## Note

The returned nodeset is not newly allocated and should thus not be changed or freed, <a href="https://hww.not.org/hwloc\_bitmap\_dup">hwloc\_bitmap\_dup</a>() must be used to obtain a local copy.

18.21.2.3 static hwloc\_const\_cpuset\_t hwloc\_topology\_get\_complete\_cpuset ( hwloc\_topology\_t topology )
[inline], [static]

Get complete CPU set.

#### Returns

the complete CPU set of logical processors of the system. If the topology is the result of a combination of several systems, NULL is returned.

## Note

The returned cpuset is not newly allocated and should thus not be changed or freed; <a href="hwloc\_bitmap\_dup">hwloc\_bitmap\_dup</a>() must be used to obtain a local copy.

18.21.2.4 static hwloc\_const\_nodeset\_t hwloc\_topology\_get\_complete\_nodeset ( hwloc\_topology\_t topology ) [inline], [static]

Get complete node set.

#### Returns

the complete node set of memory of the system. If the topology is the result of a combination of several systems, NULL is returned.

#### Note

The returned nodeset is not newly allocated and should thus not be changed or freed; <a href="hwloc\_bitmap\_dup">hwloc\_bitmap\_dup</a>() must be used to obtain a local copy.

18.21.2.5 static hwloc\_const\_cpuset\_t hwloc\_topology\_get\_online\_cpuset( hwloc\_topology\_t topology ) [inline], [static]

Get online CPU set.

#### Returns

the CPU set of online logical processors of the system. If the topology is the result of a combination of several systems, NULL is returned.

## Note

The returned cpuset is not newly allocated and should thus not be changed or freed; <a href="hwloc\_bitmap\_dup">hwloc\_bitmap\_dup</a>() must be used to obtain a local copy.

18.21.2.6 static hwloc\_const\_cpuset\_t hwloc\_topology\_get\_topology\_cpuset ( hwloc\_topology\_t topology )
[inline], [static]

Get topology CPU set.

### Returns

the CPU set of logical processors of the system for which hwloc provides topology information. This is equivalent to the cpuset of the system object. If the topology is the result of a combination of several systems, NULL is returned.

## Note

The returned cpuset is not newly allocated and should thus not be changed or freed; hwloc\_bitmap\_dup() must be used to obtain a local copy.

```
18.21.2.7 static hwloc_const_nodeset_t hwloc_topology_get_topology_nodeset ( hwloc_topology_t topology ) [inline], [static]
```

Get topology node set.

## Returns

the node set of memory of the system for which hwloc provides topology information. This is equivalent to the nodeset of the system object. If the topology is the result of a combination of several systems, NULL is returned.

#### Note

The returned nodeset is not newly allocated and should thus not be changed or freed; <a href="hwloc\_bitmap\_dup">hwloc\_bitmap\_dup</a>() must be used to obtain a local copy.

# 18.22 Converting between CPU sets and node sets

#### **Functions**

- static void hwloc\_cpuset\_to\_nodeset (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t \_cpuset, hwloc\_
   nodeset\_t nodeset)
- static void hwloc\_cpuset\_to\_nodeset\_strict (struct hwloc\_topology \*topology, hwloc\_const\_cpuset\_t \_cpuset, hwloc nodeset t nodeset)
- static void hwloc\_cpuset\_from\_nodeset (hwloc\_topology\_t topology, hwloc\_cpuset\_t \_cpuset, hwloc\_const\_

   nodeset t nodeset)
- static void hwloc\_cpuset\_from\_nodeset\_strict (struct hwloc\_topology \*topology, hwloc\_cpuset\_t\_cpuset, hwloc
   \_const\_nodeset\_t nodeset)

### 18.22.1 Detailed Description

There are two semantics for converting cpusets to nodesets depending on how non-NUMA machines are handled.

When manipulating nodesets for memory binding, non-NUMA machines should be considered as having a single NUMA node. The standard conversion routines below should be used so that marking the first bit of the nodeset means that memory should be bound to a non-NUMA whole machine.

When manipulating nodesets as an actual list of NUMA nodes without any need to handle memory binding on non-N← UMA machines, the strict conversion routines may be used instead.

### 18.22.2 Function Documentation

```
18.22.2.1 static void hwloc_cpuset_from_nodeset ( hwloc_topology_t topology, hwloc_cpuset_t _cpuset, hwloc const nodeset t nodeset ) [inline], [static]
```

Convert a NUMA node set into a CPU set and handle non-NUMA cases.

If the topology contains no NUMA nodes, the machine is considered as a single memory node, and the following behavior is used: If nodeset is empty, cpuset will be emptied as well. Otherwise cpuset will be entirely filled. This is useful for manipulating memory binding sets.

```
18.22.2.2 static void hwloc_cpuset_from_nodeset_strict ( struct hwloc_topology * topology, hwloc_cpuset_t _cpuset, hwloc_const_nodeset_t nodeset ) [inline], [static]
```

Convert a NUMA node set into a CPU set without handling non-NUMA cases.

This is the strict variant of <a href="https://hww.nc.gov.

```
18.22.2.3 static void hwloc_cpuset_to_nodeset ( hwloc_topology_t topology, hwloc_const_cpuset_t _cpuset, hwloc nodeset t nodeset ) [inline], [static]
```

Convert a CPU set into a NUMA node set and handle non-NUMA cases.

If some NUMA nodes have no CPUs at all, this function never sets their indexes in the output node set, even if a full CPU set is given in input.

If the topology contains no NUMA nodes, the machine is considered as a single memory node, and the following behavior is used: If cpuset is empty, nodeset will be emptied as well. Otherwise nodeset will be entirely filled.

18.22.2.4 static void hwloc\_cpuset\_to\_nodeset\_strict ( struct hwloc\_topology \* topology, hwloc\_const\_cpuset\_t\_cpuset, hwloc\_nodeset\_t nodeset ) [inline], [static]

Convert a CPU set into a NUMA node set without handling non-NUMA cases.

This is the strict variant of <a href="https://hww.nodeset.com/hwloc\_cpuset\_to\_nodeset">hwloc\_cpuset\_to\_nodeset</a>. It does not fix non-NUMA cases. If the topology contains some NUMA nodes, behave exactly the same. However, if the topology contains no NUMA nodes, return an empty nodeset.

Generated on Wed Sep 24 2014 16:12:37 for Hardware Locality (hwloc) by Doxygen

# 18.23 Manipulating Distances

#### **Functions**

- static const struct
   hwloc distances s \* hwloc get whole distance matrix by depth (hwloc topology t topology, unsigned depth)
- static const struct hwloc\_distances\_s \* hwloc\_get\_whole\_distance\_matrix\_by\_type (hwloc\_topology\_t topology, hwloc\_obj\_type\_t type)
- static const struct
   hwloc\_distances\_s \* hwloc\_get\_distance\_matrix\_covering\_obj\_by\_depth (hwloc\_topology\_t topology, hwloc\_cobj\_t obj, unsigned depth, unsigned \*firstp)
- static int hwloc\_get\_latency (hwloc\_topology\_t topology, hwloc\_obj\_t obj1, hwloc\_obj\_t obj2, float \*latency, float \*reverse\_latency)

# 18.23.1 Detailed Description

#### 18.23.2 Function Documentation

18.23.2.1 static const struct hwloc\_distances\_s\* hwloc\_get\_distance\_matrix\_covering\_obj\_by\_depth ( hwloc\_topology\_t topology, hwloc\_obj\_t obj, unsigned depth, unsigned \* firstp ) [static]

Get distances for the given depth and covering some objects.

Return a distance matrix that describes depth depth and covers at least object obj and all its children.

When looking for the distance between some objects, a common ancestor should be passed in obj.

firstp is set to logical index of the first object described by the matrix.

The returned structure belongs to the hwloc library. The caller should not modify or free it.

```
18.23.2.2 static int hwloc_get_latency ( hwloc_topology_t topology, hwloc_obj_t obj1, hwloc_obj_t obj2, float * latency, float * reverse_latency ) [inline], [static]
```

Get the latency in both directions between two objects.

Look at ancestor objects from the bottom to the top until one of them contains a distance matrix that matches the objects exactly.

latency gets the value from object obj1 to obj2, while reverse\_latency gets the reverse-direction value, which may be different on some architectures.

#### Returns

-1 if no ancestor contains a matching latency matrix.

```
18.23.2.3 static const struct hwloc_distances_s* hwloc_get_whole_distance_matrix_by_depth ( hwloc_topology_t topology, unsigned depth ) [static]
```

Get the distances between all objects at the given depth.

#### Returns

a distances structure containing a matrix with all distances between all objects at the given depth.

Slot i+nbobjs\*j contains the distance from the object of logical index i the object of logical index j.

#### Note

This function only returns matrices covering the whole topology, without any unknown distance value. Those matrices are available in top-level object of the hierarchy. Matrices of lower objects are not reported here since they cover only part of the machine.

The returned structure belongs to the hwloc library. The caller should not modify or free it.

#### Returns

NULL if no such distance matrix exists.

18.23.2.4 static const struct hwloc\_distances\_s\* hwloc\_get\_whole\_distance\_matrix\_by\_type( hwloc\_topology\_t topology, hwloc\_obj\_type\_t type) [static]

Get the distances between all objects of a given type.

#### Returns

a distances structure containing a matrix with all distances between all objects of the given type.

Slot i+nbobjs\*j contains the distance from the object of logical index i the object of logical index j.

## Note

This function only returns matrices covering the whole topology, without any unknown distance value. Those matrices are available in top-level object of the hierarchy. Matrices of lower objects are not reported here since they cover only part of the machine.

The returned structure belongs to the hwloc library. The caller should not modify or free it.

#### Returns

NULL if no such distance matrix exists.

# 18.24 Finding I/O objects

#### **Functions**

- static hwloc\_obj\_t hwloc\_get\_non\_io\_ancestor\_obj (hwloc\_topology\_t topology, hwloc\_obj\_t ioobj)
- static hwloc obj t hwloc get next pcidev (hwloc topology t topology, hwloc obj t prev)
- static hwloc\_obj\_t hwloc\_get\_pcidev\_by\_busid (hwloc\_topology\_t topology, unsigned domain, unsigned bus, unsigned dev, unsigned func)
- static hwloc\_obj\_t hwloc\_get\_pcidev\_by\_busidstring (hwloc\_topology\_t topology, const char \*busid)
- static hwloc\_obj\_t hwloc\_get\_next\_osdev (hwloc\_topology\_t topology, hwloc\_obj\_t prev)
- static hwloc\_obj\_t hwloc\_get\_next\_bridge (hwloc\_topology\_t topology, hwloc\_obj\_t prev)
- static int hwloc\_bridge\_covers\_pcibus (hwloc\_obj\_t bridge, unsigned domain, unsigned bus)
- static hwloc\_obj\_t hwloc\_get\_hostbridge\_by\_pcibus (hwloc\_topology\_t topology, unsigned domain, unsigned bus)

# 18.24.1 Detailed Description

## 18.24.2 Function Documentation

```
18.24.2.1 static int hwloc_bridge_covers_pcibus ( hwloc_obj_t bridge, unsigned domain, unsigned bus ) [inline], [static]
```

18.24.2.2 static hwloc\_obj\_t hwloc\_get\_hostbridge\_by\_pcibus ( hwloc\_topology\_t topology, unsigned domain, unsigned bus ) [inline], [static]

Find the hostbridge that covers the given PCI bus.

This is useful for finding the locality of a bus because it is the hostbridge parent cpuset.

```
18.24.2.3 static hwloc_obj_t hwloc_get_next_bridge ( hwloc_topology_t topology, hwloc_obj_t prev ) [inline], [static]
```

Get the next bridge in the system.

#### Returns

the first bridge if prev is NULL.

```
18.24.2.4 static hwloc_obj_t hwloc_get_next_osdev ( hwloc_topology_t topology, hwloc_obj_t prev ) [inline], [static]
```

Get the next OS device in the system.

#### Returns

the first OS device if prev is NULL.

```
18.24.2.5 static hwloc_obj_t hwloc_get_next_pcidev ( hwloc_topology_t topology, hwloc_obj_t prev ) [inline], [static]
```

Get the next PCI device in the system.

Returns

the first PCI device if prev is NULL.

```
18.24.2.6 static hwloc_obj_t hwloc_get_non_io_ancestor_obj ( hwloc_topology_t topology, hwloc_obj_t ioobj )
[inline], [static]
```

Get the first non-I/O ancestor object.

Given the I/O object ioobj, find the smallest non-I/O ancestor object. This regular object may then be used for binding because its locality is the same as ioobj.

```
18.24.2.7 static hwloc_obj_t hwloc_get_pcidev_by_busid ( hwloc_topology_t topology, unsigned domain, unsigned bus, unsigned dev, unsigned func ) [inline], [static]
```

Find the PCI device object matching the PCI bus id given domain, bus device and function PCI bus id.

```
18.24.2.8 static hwloc_obj_t hwloc_get_pcidev_by_busidstring ( hwloc_topology_t topology, const char * busid )
[inline], [static]
```

Find the PCI device object matching the PCI bus id given as a string xxxx:yy:zz.t or yy:zz.t.

18.25 The bitmap API 127

# 18.25 The bitmap API

#### **Macros**

- #define hwloc bitmap foreach begin(id, bitmap)
- #define hwloc\_bitmap\_foreach\_end()

## **Typedefs**

- typedef struct hwloc bitmap s \* hwloc bitmap t
- typedef const struct hwloc\_bitmap\_s \* hwloc\_const\_bitmap\_t

### **Functions**

- hwloc bitmap t hwloc bitmap alloc (void)
- hwloc bitmap t hwloc bitmap alloc full (void)
- void hwloc\_bitmap\_free (hwloc\_bitmap\_t bitmap)
- hwloc\_bitmap\_t hwloc\_bitmap\_dup (hwloc\_const\_bitmap\_t bitmap)
- void hwloc\_bitmap\_copy (hwloc\_bitmap\_t dst, hwloc\_const\_bitmap\_t src)
- int hwloc\_bitmap\_snprintf (char \*restrict buf, size\_t buflen, hwloc\_const\_bitmap\_t bitmap)
- int hwloc\_bitmap\_asprintf (char \*\*strp, hwloc\_const\_bitmap\_t bitmap)
- int hwloc\_bitmap\_sscanf (hwloc\_bitmap\_t bitmap, const char \*restrict string)
- int hwloc bitmap list snprintf (char \*restrict buf, size t buflen, hwloc const bitmap t bitmap)
- int hwloc\_bitmap\_list\_asprintf (char \*\*strp, hwloc\_const\_bitmap\_t bitmap)
- int hwloc bitmap list sscanf (hwloc bitmap t bitmap, const char \*restrict string)
- int hwloc bitmap taskset snprintf (char \*restrict buf, size t buflen, hwloc const bitmap t bitmap)
- int hwloc bitmap taskset asprintf (char \*\*strp, hwloc const bitmap t bitmap)
- int hwloc bitmap taskset sscanf (hwloc bitmap t bitmap, const char \*restrict string)
- · void hwloc bitmap zero (hwloc bitmap t bitmap)
- void hwloc bitmap fill (hwloc bitmap t bitmap)
- void hwloc\_bitmap\_only (hwloc\_bitmap\_t bitmap, unsigned id)
- void hwloc\_bitmap\_allbut (hwloc\_bitmap\_t bitmap, unsigned id)
- void hwloc bitmap from ulong (hwloc bitmap t bitmap, unsigned long mask)
- void hwloc\_bitmap\_from\_ith\_ulong (hwloc\_bitmap\_t bitmap, unsigned i, unsigned long mask)
- void hwloc\_bitmap\_set (hwloc\_bitmap\_t bitmap, unsigned id)
- void hwloc\_bitmap\_set\_range (hwloc\_bitmap\_t bitmap, unsigned begin, int end)
- void hwloc\_bitmap\_set\_ith\_ulong (hwloc\_bitmap\_t bitmap, unsigned i, unsigned long mask)
- void hwloc\_bitmap\_clr (hwloc\_bitmap\_t bitmap, unsigned id)
- void hwloc\_bitmap\_clr\_range (hwloc\_bitmap\_t bitmap, unsigned begin, int end)
- void hwloc\_bitmap\_singlify (hwloc\_bitmap\_t bitmap)
- unsigned long hwloc\_bitmap\_to\_ulong (hwloc\_const\_bitmap\_t bitmap)
- unsigned long hwloc bitmap to ith ulong (hwloc const bitmap t bitmap, unsigned i)
- int hwloc bitmap isset (hwloc const bitmap t bitmap, unsigned id)
- int hwloc bitmap iszero (hwloc const bitmap t bitmap)
- int hwloc bitmap isfull (hwloc const bitmap t bitmap)
- int hwloc\_bitmap\_first (hwloc\_const\_bitmap\_t bitmap)
- int hwloc\_bitmap\_next (hwloc\_const\_bitmap\_t bitmap, int prev)
- int hwloc bitmap last (hwloc const bitmap t bitmap)
- int hwloc bitmap weight (hwloc const bitmap t bitmap)

- void hwloc\_bitmap\_or (hwloc\_bitmap\_t res, hwloc\_const\_bitmap\_t bitmap\_t bitmap\_t bitmap\_t bitmap\_t
- void hwloc bitmap and (hwloc bitmap t res, hwloc const bitmap t bitmap1, hwloc const bitmap t bitmap2)
- void hwloc bitmap andnot (hwloc bitmap t res, hwloc const bitmap t bitmap1, hwloc const bitmap t bitmap2)
- void hwloc\_bitmap\_xor (hwloc\_bitmap\_t res, hwloc\_const\_bitmap\_t bitmap1, hwloc\_const\_bitmap2)
- void hwloc bitmap not (hwloc bitmap t res, hwloc const bitmap t bitmap)
- int hwloc bitmap intersects (hwloc const bitmap t bitmap1, hwloc const bitmap t bitmap2)
- int hwloc\_bitmap\_isincluded (hwloc\_const\_bitmap\_t sub\_bitmap, hwloc\_const\_bitmap\_t super\_bitmap)
- int hwloc\_bitmap\_isequal (hwloc\_const\_bitmap\_t bitmap\_t bitmap\_t bitmap\_t bitmap\_t bitmap\_t
- int hwloc bitmap compare first (hwloc const bitmap t bitmap1, hwloc const bitmap t bitmap2)
- int hwloc\_bitmap\_compare (hwloc\_const\_bitmap\_t bitmap1, hwloc\_const\_bitmap\_t bitmap2)

## 18.25.1 Detailed Description

The hwloc\_bitmap\_t type represents a set of objects, typically OS processors – which may actually be hardware threads (represented by hwloc\_cpuset\_t, which is a typedef for hwloc\_bitmap\_t) – or memory nodes (represented by hwloc\_cpuset\_t, which is also a typedef for hwloc\_bitmap\_t).

Both CPU and node sets are always indexed by OS physical number.

Note

CPU sets and nodesets are described in Object Sets (hwloc\_cpuset\_t and hwloc\_nodeset\_t).

A bitmap may be of infinite size.

Note

Several examples of using the bitmap API are available under the doc/examples/ directory in the source tree. Regression tests such as tests/hwloc bitmap\*.c also make intensive use of this API.

## 18.25.2 Macro Definition Documentation

```
18.25.2.1 #define hwloc_bitmap_foreach_begin( id, bitmap )
```

Loop macro iterating on bitmap bitmap.

index is the loop variable; it should be an unsigned int. The first iteration will set index to the lowest index in the bitmap. Successive iterations will iterate through, in order, all remaining indexes that in the bitmap. To be specific: each iteration will return a value for index such that hwloc\_bitmap\_isset(bitmap, index) is true.

The assert prevents the loop from being infinite if the bitmap is infinite.

```
18.25.2.2 #define hwloc_bitmap_foreach_end( )
```

## Value:

```
} \
} while (0)
```

#### 18.25.3 Typedef Documentation

18.25.3.1 typedef struct hwloc\_bitmap\_s\* hwloc\_bitmap\_t

Set of bits represented as an opaque pointer to an internal bitmap.

18.25 The bitmap API 129

```
18.25.3.2 typedef const struct hwloc_bitmap_s* hwloc_const_bitmap_t
a non-modifiable hwloc_bitmap_t
18.25.4 Function Documentation
18.25.4.1 void hwloc_bitmap_allbut ( hwloc_bitmap_t bitmap, unsigned id )
Fill the bitmap and clear the index id.
18.25.4.2 hwloc_bitmap_t hwloc_bitmap_alloc ( void )
Allocate a new empty bitmap.
Returns
     A valid bitmap or NULL.
The bitmap should be freed by a corresponding call to hwloc bitmap free().
18.25.4.3 hwloc_bitmap_t hwloc_bitmap_alloc_full ( void )
Allocate a new full bitmap.
18.25.4.4 void hwloc_bitmap_and ( hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t
         bitmap2)
And bitmaps bitmap1 and bitmap2 and store the result in bitmap res.
res can be the same as bitmap1 or bitmap2
18.25.4.5 void hwloc_bitmap_andnot ( hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t
         bitmap2)
And bitmap bitmap1 and the negation of bitmap2 and store the result in bitmap res.
res can be the same as bitmap1 or bitmap2
18.25.4.6 int hwloc_bitmap_asprintf ( char ** strp, hwloc_const_bitmap_t bitmap_)
Stringify a bitmap into a newly allocated string.
18.25.4.7 void hwloc_bitmap_clr ( hwloc_bitmap_t bitmap, unsigned id )
Remove index id from bitmap bitmap.
```

```
18.25.4.8 void hwloc_bitmap_clr_range ( hwloc_bitmap_t bitmap, unsigned begin, int end )
Remove indexes from begin to end in bitmap bitmap.
If end is -1, the range is infinite.
18.25.4.9 int hwloc_bitmap_compare ( hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t bitmap2 )
Compare bitmaps bitmap1 and bitmap2 using their highest index.
Higher most significant bit is higher. The empty bitmap is considered lower than anything.
18.25.4.10 int hwloc_bitmap_compare_first ( hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t bitmap2 )
Compare bitmaps bitmap1 and bitmap2 using their lowest index.
Smaller least significant bit is smaller. The empty bitmap is considered higher than anything.
18.25.4.11 void hwloc_bitmap_copy ( hwloc_bitmap_t dst, hwloc_const_bitmap_t src )
Copy the contents of bitmap src into the already allocated bitmap dst.
18.25.4.12 hwloc bitmap t hwloc_bitmap_dup ( hwloc_const_bitmap_t bitmap_)
Duplicate bitmap bitmap by allocating a new bitmap and copying bitmap contents.
If bitmap is NULL, NULL is returned.
18.25.4.13 void hwloc_bitmap_fill ( hwloc_bitmap_t bitmap )
Fill bitmap bitmap with all possible indexes (even if those objects don't exist or are otherwise unavailable)
18.25.4.14 int hwloc_bitmap_first ( hwloc_const_bitmap_t bitmap )
Compute the first index (least significant bit) in bitmap bitmap.
Returns
     -1 if no index is set.
18.25.4.15 void hwloc_bitmap_free ( hwloc_bitmap_t bitmap )
Free bitmap bitmap.
If bitmap is NULL, no operation is performed.
18.25.4.16 void hwloc_bitmap_from_ith_ulong ( hwloc_bitmap_t bitmap, unsigned i, unsigned long mask )
```

Setup bitmap bitmap from unsigned long mask used as i -th subset.

18.25 The bitmap API 131

```
18.25.4.17 void hwloc_bitmap_from_ulong ( hwloc_bitmap_t bitmap, unsigned long mask )
Setup bitmap bitmap from unsigned long mask.
18.25.4.18 int hwloc_bitmap_intersects ( hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t bitmap2 )
Test whether bitmaps bitmap1 and bitmap2 intersects.
18.25.4.19 int hwloc_bitmap_isequal ( hwloc_const_bitmap_t bitmap1, hwloc_const_bitmap_t bitmap2 )
Test whether bitmap bitmap1 is equal to bitmap bitmap2.
18.25.4.20 int hwloc_bitmap_isfull ( hwloc_const_bitmap_t bitmap_)
Test whether bitmap bitmap is completely full.
18.25.4.21 int hwloc_bitmap_isincluded ( hwloc_const_bitmap_t sub_bitmap, hwloc_const_bitmap_t super_bitmap )
Test whether bitmap sub_bitmap is part of bitmap super_bitmap.
18.25.4.22 int hwloc_bitmap_isset ( hwloc_const_bitmap_t bitmap, unsigned id )
Test whether index id is part of bitmap bitmap.
18.25.4.23 int hwloc_bitmap_iszero ( hwloc_const_bitmap_t bitmap )
Test whether bitmap bitmap is empty.
18.25.4.24 int hwloc_bitmap_last ( hwloc_const_bitmap_t bitmap_)
Compute the last index (most significant bit) in bitmap bitmap.
Returns
     -1 if no index is bitmap, or if the index bitmap is infinite.
18.25.4.25 int hwloc_bitmap_list_asprintf ( char ** strp, hwloc_const_bitmap_t bitmap )
Stringify a bitmap into a newly allocated list string.
18.25.4.26 int hwloc_bitmap_list_snprintf ( char *restrict buf, size_t buflen, hwloc_const_bitmap_t bitmap_t)
Stringify a bitmap in the list format.
Lists are comma-separated indexes or ranges. Ranges are dash separated indexes. The last range may not have a
ending indexes if the bitmap is infinite.
```

Up to buflen characters may be written in buffer buf.

```
If buflen is 0, buf may safely be NULL.
```

### Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

```
18.25.4.27 int hwloc_bitmap_list_sscanf ( hwloc_bitmap_t bitmap, const char *restrict string )
```

Parse a list string and stores it in bitmap bitmap.

```
18.25.4.28 int hwloc_bitmap_next ( hwloc_const_bitmap_t bitmap, int prev )
```

Compute the next index in bitmap bitmap which is after index prev.

If prev is -1, the first index is returned.

#### Returns

-1 if no index with higher index is bitmap.

```
18.25.4.29 void hwloc_bitmap_not ( hwloc_bitmap_t res, hwloc_const_bitmap_t bitmap )
```

Negate bitmap bitmap and store the result in bitmap res.

res can be the same as bitmap

18.25.4.30 void hwloc\_bitmap\_only ( hwloc\_bitmap\_t bitmap, unsigned id )

Empty the bitmap bitmap and add bit id.

18.25.4.31 void hwloc\_bitmap\_or ( hwloc\_bitmap\_t res, hwloc\_const\_bitmap\_t bitmap1, hwloc\_const\_bitmap\_t bitmap2 )

Or bitmaps bitmap1 and bitmap2 and store the result in bitmap res.

res can be the same as bitmap1 or bitmap2

18.25.4.32 void hwloc\_bitmap\_set ( hwloc\_bitmap\_t bitmap, unsigned id )

Add index id in bitmap bitmap.

18.25.4.33 void hwloc\_bitmap\_set\_ith\_ulong ( hwloc\_bitmap\_t bitmap, unsigned i, unsigned long mask )

Replace i -th subset of bitmap bitmap with unsigned long mask.

18.25.4.34 void hwloc\_bitmap\_set\_range ( hwloc\_bitmap\_t bitmap, unsigned begin, int end )

Add indexes from begin to end in bitmap bitmap.

If end is -1, the range is infinite.

18.25 The bitmap API 133

18.25.4.35 void hwloc\_bitmap\_singlify ( hwloc\_bitmap\_t bitmap )

Keep a single index among those set in bitmap bitmap.

May be useful before binding so that the process does not have a chance of migrating between multiple logical CPUs in the original mask.

18.25.4.36 int hwloc\_bitmap\_snprintf ( char \*restrict buf, size\_t buflen, hwloc\_const\_bitmap\_t bitmap\_)

Stringify a bitmap.

Up to buflen characters may be written in buffer buf.

If buflen is 0, buf may safely be NULL.

#### Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

18.25.4.37 int hwloc\_bitmap\_sscanf ( hwloc\_bitmap\_t bitmap, const char \*restrict string )

Parse a bitmap string and stores it in bitmap bitmap.

18.25.4.38 int hwloc\_bitmap\_taskset\_asprintf ( char \*\* strp, hwloc\_const\_bitmap\_t bitmap )

Stringify a bitmap into a newly allocated taskset-specific string.

18.25.4.39 int hwloc\_bitmap\_taskset\_snprintf ( char \*restrict buf, size\_t buflen, hwloc\_const\_bitmap\_t bitmap )

Stringify a bitmap in the taskset-specific format.

The taskset command manipulates bitmap strings that contain a single (possible very long) hexadecimal number starting with 0x.

Up to buflen characters may be written in buffer buf.

If buflen is 0, buf may safely be NULL.

## Returns

the number of character that were actually written if not truncating, or that would have been written (not including the ending \0).

18.25.4.40 int hwloc\_bitmap\_taskset\_sscanf ( hwloc\_bitmap\_t bitmap, const char \*restrict string )

Parse a taskset-specific bitmap string and stores it in bitmap bitmap.

18.25.4.41 unsigned long hwloc\_bitmap\_to\_ith\_ulong ( hwloc\_const\_bitmap\_t bitmap, unsigned i )

Convert the i -th subset of bitmap bitmap into unsigned long mask.

18.25.4.42 unsigned long hwloc\_bitmap\_to\_ulong ( hwloc\_const\_bitmap\_t bitmap )

Convert the beginning part of bitmap bitmap into unsigned long mask.

18.25.4.43 int hwloc\_bitmap\_weight ( hwloc\_const\_bitmap\_t bitmap )

Compute the "weight" of bitmap bitmap (i.e., number of indexes that are in the bitmap).

Returns

the number of indexes that are in the bitmap.

18.25.4.44 void hwloc\_bitmap\_xor ( hwloc\_bitmap\_t res, hwloc\_const\_bitmap\_t bitmap1, hwloc\_const\_bitmap\_t bitmap2 )

Xor bitmaps bitmap1 and bitmap2 and store the result in bitmap res.

res can be the same as bitmap1 or bitmap2

18.25.4.45 void hwloc\_bitmap\_zero ( hwloc\_bitmap\_t bitmap )

Empty the bitmap bitmap.

# 18.26 Topology differences

#### **Data Structures**

- union hwloc\_topology\_diff\_obj\_attr\_u
- struct hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_generic\_s
- struct hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_uint64\_s
- struct hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_string\_s
- · union hwloc\_topology\_diff\_u
- struct hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_generic\_s
- struct hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_obj\_attr\_s
- struct hwloc topology diff u::hwloc topology diff too complex s

## **Typedefs**

- typedef enum hwloc\_topology\_diff\_obj\_attr\_type\_e hwloc\_topology\_diff\_obj\_attr\_type\_t
- typedef enum hwloc\_topology\_diff\_type\_e hwloc\_topology\_diff\_type\_t
- typedef union hwloc\_topology\_diff\_u \* hwloc\_topology\_diff\_t

# **Enumerations**

- enum hwloc\_topology\_diff\_obj\_attr\_type\_e { HWLOC\_TOPOLOGY\_DIFF\_OBJ\_ATTR\_SIZE, HWLOC\_TOPO
   LOGY\_DIFF\_OBJ\_ATTR\_NAME, HWLOC\_TOPOLOGY\_DIFF\_OBJ\_ATTR\_INFO.}
- enum hwloc\_topology\_diff\_type\_e { HWLOC\_TOPOLOGY\_DIFF\_OBJ\_ATTR, HWLOC\_TOPOLOGY\_DIFF\_T
   OO\_COMPLEX }
- enum hwloc\_topology\_diff\_apply\_flags\_e { HWLOC\_TOPOLOGY\_DIFF\_APPLY\_REVERSE }

### **Functions**

- int hwloc\_topology\_diff\_build (hwloc\_topology\_t topology, hwloc\_topology\_t newtopology, unsigned long flags, hwloc\_topology\_diff\_t \*diff)
- int hwloc\_topology\_diff\_apply (hwloc\_topology\_t topology, hwloc\_topology\_diff\_t diff, unsigned long flags)
- int hwloc\_topology\_diff\_destroy (hwloc\_topology\_t topology, hwloc\_topology\_diff\_t diff)
- int hwloc\_topology\_diff\_load\_xml (hwloc\_topology\_t topology, const char \*xmlpath, hwloc\_topology\_diff\_t \*diff, char \*\*refname)
- int hwloc\_topology\_diff\_export\_xml (hwloc\_topology\_t topology, hwloc\_topology\_diff\_t diff, const char \*refname, const char \*xmlpath)
- int hwloc\_topology\_diff\_load\_xmlbuffer (hwloc\_topology\_t topology, const char \*xmlbuffer, int buflen, hwloc\_copology\_diff\_t \*diff, char \*\*refname)
- int hwloc\_topology\_diff\_export\_xmlbuffer (hwloc\_topology\_t topology, hwloc\_topology\_diff\_t diff, const char \*refname, char \*\*xmlbuffer, int \*buflen)

# 18.26.1 Detailed Description

Applications that manipulate many similar topologies, for instance one for each node of a homogeneous cluster, may want to compress topologies to reduce the memory footprint.

This file offers a way to manipulate the difference between topologies and export/import it to/from XML. Compression may therefore be achieved by storing one topology entirely while the others are only described by their differences with the former. The actual topology can be reconstructed when actually needed by applying the precomputed difference to the reference topology.

This interface targets very similar nodes. Only very simple differences between topologies are actually supported, for instance a change in the memory size, the name of the object, or some info attribute. More complex differences such as adding or removing objects cannot be represented in the difference structures and therefore return errors.

It means that there is no need to apply the difference when looking at the tree organization (how many levels, how many objects per level, what kind of objects, CPU and node sets, etc) and when binding to objects. However the difference must be applied when looking at object attributes such as the name, the memory size or info attributes.

## 18.26.2 Typedef Documentation

18.26.2.1 typedef enum hwloc topology diff obj attr type e hwloc topology diff obj attr type t

Type of one object attribute difference.

18.26.2.2 typedef union hwloc\_topology\_diff\_u \* hwloc\_topology\_diff\_t

One element of a difference list between two topologies.

18.26.2.3 typedef enum hwloc topology diff type e hwloc topology diff type t

Type of one element of a difference list.

### 18.26.3 Enumeration Type Documentation

18.26.3.1 enum hwloc topology diff apply flags e

Flags to be given to hwloc topology diff apply().

Enumerator

HWLOC TOPOLOGY DIFF APPLY REVERSE Apply topology diff in reverse direction.

18.26.3.2 enum hwloc\_topology\_diff\_obj\_attr\_type\_e

Type of one object attribute difference.

### Enumerator

**HWLOC\_TOPOLOGY\_DIFF\_OBJ\_ATTR\_SIZE** The object local memory is modified. The union is a hwloc\_
topology diff obj attr uint64 s (and the index field is ignored).

**HWLOC\_TOPOLOGY\_DIFF\_OBJ\_ATTR\_NAME** The object name is modified. The union is a hwloc\_topology diff obj attr string s (and the name field is ignored).

**HWLOC\_TOPOLOGY\_DIFF\_OBJ\_ATTR\_INFO** the value of an info attribute is modified. The union is a hwloc topology diff obj attr string s.

18.26.3.3 enum hwloc\_topology\_diff\_type\_e

Type of one element of a difference list.

#### Enumerator

HWLOC\_TOPOLOGY\_DIFF\_OBJ\_ATTR
HWLOC\_TOPOLOGY\_DIFF\_TOO\_COMPLEX

18.26.4 Function Documentation

18.26.4.1 int hwloc\_topology\_diff\_apply ( hwloc\_topology\_t topology, hwloc\_topology\_diff\_t diff, unsigned long flags )

Apply a topology diff to an existing topology.

flags is an OR'ed set of hwloc\_topology\_diff\_apply\_flags\_e.

The new topology is modified in place. hwloc topology dup() may be used to duplicate it before patching.

If the difference cannot be applied entirely, all previous applied elements are unapplied before returning.

#### Returns

0 on success.

-N if applying the difference failed while trying to apply the N-th part of the difference. For instance -1 is returned if the very first difference element could not be applied.

18.26.4.2 int hwloc\_topology\_diff\_build ( hwloc\_topology\_t topology, hwloc\_topology\_t newtopology, unsigned long flags, hwloc\_topology\_diff\_t \* diff )

Compute the difference between 2 topologies.

The difference is stored as a list of hwloc\_topology\_diff\_t entries starting at diff. It is computed by doing a depth-first traversal of both topology trees simultaneously.

If the difference between 2 objects is too complex to be represented (for instance if some objects have different types, or different numbers of children), a special diff entry of type HWLOC\_TOPOLOGY\_DIFF\_TOO\_COMPLEX is queued. The computation of the diff does not continue below these objects. So each such diff entry means that the difference between two subtrees could not be computed.

## Returns

0 if the difference can be represented properly.

0 with diff pointing to NULL if there is no difference between the topologies.

- 1 if the difference is too complex (see above). Some entries in the list will be of type HWLOC\_TOPOLOGY\_DIF ← F\_TOO\_COMPLEX.
- -1 on any other error.

Note

flags is currently not used. It should be 0.

The output diff has to be freed with hwloc\_topology\_diff\_destroy().

The output diff can only be exported to XML or passed to <a href="https://hww.nube.com/hwloc\_topology\_diff\_apply">hwloc\_topology\_diff\_apply</a>() if 0 was returned, i.e. if no entry of type HWLOC\_TOPOLOGY\_DIFF\_TOO\_COMPLEX is listed.

The output diff may be modified by removing some entries from the list. The removed entries should be freed by passing them to to <a href="https://www.hwloc\_topology\_diff\_destroy">hwloc\_topology\_diff\_destroy</a>() (possible as another list).

18.26.4.3 int hwloc\_topology\_diff\_destroy ( hwloc topology t topology, hwloc topology diff t diff )

Destroy a list of topology differences.

Note

The topology parameter must be a valid topology but it is not required that it is related to diff.

18.26.4.4 int hwloc\_topology\_diff\_export\_xml ( hwloc\_topology\_t topology, hwloc\_topology\_diff\_t diff, const char \* refname, const char \* xmlpath )

Export a list of topology differences to a XML file.

If not NULL, refname defines an identifier string for the reference topology which was used as a base when computing this difference. This identifier is usually the name of the other XML file that contains the reference topology. This attribute is given back when reading the diff from XML.

Note

The topology parameter must be a valid topology but it is not required that it is related to diff.

18.26.4.5 int hwloc\_topology\_diff\_export\_xmlbuffer ( hwloc\_topology\_t topology, hwloc\_topology\_diff\_t diff, const char \* refname, char \*\* xmlbuffer, int \* buflen )

Export a list of topology differences to a XML buffer.

If not NULL, refname defines an identifier string for the reference topology which was used as a base when computing this difference. This identifier is usually the name of the other XML file that contains the reference topology. This attribute is given back when reading the diff from XML.

Note

The XML buffer should later be freed with hwloc free xmlbuffer().

The topology parameter must be a valid topology but it is not required that it is related to diff.

18.26.4.6 int hwloc\_topology\_diff\_load\_xml ( hwloc\_topology\_t topology, const char \* xmlpath, hwloc\_topology\_diff\_t \* diff, char \*\* refname )

Load a list of topology differences from a XML file.

If not NULL, refname will be filled with the identifier string of the reference topology for the difference file, if any was specified in the XML file. This identifier is usually the name of the other XML file that contains the reference topology.

#### Note

The topology parameter must be a valid topology but it is not required that it is related to diff. the pointer returned in refname should later be freed by the caller.

18.26.4.7 int hwloc\_topology\_diff\_load\_xmlbuffer ( hwloc\_topology\_t topology, const char \* xmlbuffer, int buflen, hwloc\_topology\_diff\_t \* diff, char \*\* refname )

Load a list of topology differences from a XML buffer.

If not NULL, refname will be filled with the identifier string of the reference topology for the difference file, if any was specified in the XML file. This identifier is usually the name of the other XML file that contains the reference topology.

#### Note

The topology parameter must be a valid topology but it is not required that it is related to diff. the pointer returned in refname should later be freed by the caller.

# 18.27 Components and Plugins: Discovery components

#### **Data Structures**

· struct hwloc\_disc\_component

# **Typedefs**

typedef enum
 hwloc\_disc\_component\_type\_e hwloc\_disc\_component\_type\_t

#### **Enumerations**

# 18.27.1 Detailed Description

18.27.2 Typedef Documentation

18.27.2.1 typedef enum hwloc\_disc\_component\_type\_e hwloc\_disc\_component\_type\_t

Discovery component type.

# 18.27.3 Enumeration Type Documentation

18.27.3.1 enum hwloc\_disc\_component\_type\_e

Discovery component type.

### **Enumerator**

HWLOC\_DISC\_COMPONENT\_TYPE\_CPU CPU-only discovery through the OS, or generic no-OS support.

HWLOC\_DISC\_COMPONENT\_TYPE\_GLOBAL xml, synthetic or custom, platform-specific components such as bgq. Anything the discovers CPU and everything else. No misc backend is expected to complement a global component.

HWLOC\_DISC\_COMPONENT\_TYPE\_MISC OpenCL, Cuda, etc.

# 18.28 Components and Plugins: Discovery backends

### **Data Structures**

struct hwloc\_backend

### **Enumerations**

enum hwloc\_backend\_flag\_e { HWLOC\_BACKEND\_FLAG\_NEED\_LEVELS }

## **Functions**

- struct hwloc\_backend \* hwloc\_backend\_alloc (struct hwloc\_disc\_component \*component)
- int hwloc\_backend\_enable (struct hwloc\_topology \*topology, struct hwloc\_backend \*backend)
- int hwloc\_backends\_get\_obj\_cpuset (struct hwloc\_backend \*caller, struct hwloc\_obj \*obj, hwloc\_bitmap\_
  t cpuset)
- int hwloc\_backends\_notify\_new\_object (struct hwloc\_backend \*caller, struct hwloc\_obj \*obj)
- 18.28.1 Detailed Description
- 18.28.2 Enumeration Type Documentation
- 18.28.2.1 enum hwloc\_backend\_flag\_e

Backend flags.

#### Enumerator

**HWLOC\_BACKEND\_FLAG\_NEED\_LEVELS** Levels should be reconnected before this backend discover() is used.

#### 18.28.3 Function Documentation

18.28.3.1 struct hwloc\_backend\* hwloc\_backend\_alloc( struct hwloc\_disc\_component \* component)

Allocate a backend structure, set good default values, initialize backend->component and topology, etc. The caller will then modify whatever needed, and call <a href="https://hww.nuber.needed.needed">https://hww.nuber.needed.n

18.28.3.2 int hwloc\_backend\_enable ( struct hwloc\_topology \* topology, struct hwloc\_backend \* backend )

Enable a previously allocated and setup backend.

18.28.3.3 int hwloc\_backends\_get\_obj\_cpuset ( struct hwloc\_backend \* caller, struct hwloc\_obj \* obj, hwloc\_bitmap\_t cpuset )

Used by backends discovery callbacks to request locality information from others.

Traverse the list of enabled backends until one has a get obj cpuset() method, and call it.

18.28.3.4 int hwloc\_backends\_notify\_new\_object ( struct hwloc\_backend \* caller, struct hwloc\_obj \* obj )

Used by backends discovery callbacks to notify other backends of new objects.

Traverse the list of enabled backends (all but caller) and invoke their notify\_new\_object() method to notify them that a new object just got added to the topology.

Currently only used for notifying of new PCI device objects.

# 18.29 Components and Plugins: Generic components

### **Data Structures**

struct hwloc\_component

# **Typedefs**

typedef enum hwloc\_component\_type\_e hwloc\_component\_type\_t

### **Enumerations**

```
    enum hwloc_component_type_e { HWLOC_COMPONENT_TYPE_DISC, HWLOC_COMPONENT_TYPE_XML }
```

```
18.29.1 Detailed Description
```

# 18.29.2 Typedef Documentation

```
18.29.2.1 typedef enum hwloc_component_type_e hwloc_component_type_t
```

Generic component type.

# 18.29.3 Enumeration Type Documentation

```
18.29.3.1 enum hwloc_component_type_e
```

Generic component type.

## Enumerator

```
HWLOC_COMPONENT_TYPE_DISC The data field must point to a struct hwloc_disc_component.HWLOC_COMPONENT_TYPE_XML The data field must point to a struct hwloc_xml_component.
```

# 18.30 Components and Plugins: Core functions to be used by components

# **Typedefs**

typedef void(\* hwloc\_report\_error\_t )(const char \*msg, int line)

### **Functions**

- struct hwloc obj \* hwloc insert object by cpuset (struct hwloc topology \*topology, hwloc obj t obj)
- void hwloc\_report\_os\_error (const char \*msg, int line)
- int hwloc\_hide\_errors (void)
- struct hwloc\_obj \* hwloc\_insert\_object\_by\_cpuset (struct hwloc\_topology \*topology, hwloc\_obj\_t obj, hwloc\_
  report\_error\_t report\_error)
- void hwloc\_insert\_object\_by\_parent (struct hwloc\_topology \*topology, hwloc\_obj\_t parent, hwloc\_obj\_t obj)
- static struct hwloc\_obj \* hwloc\_alloc\_setup\_object (hwloc\_obj\_type\_t type, signed os\_index)
- int hwloc fill object sets (hwloc obj t obj)
- static int hwloc\_plugin\_check\_namespace (const char \*pluginname, const char \*symbol)

# 18.30.1 Detailed Description

# 18.30.2 Typedef Documentation

18.30.2.1 typedef void(\* hwloc\_report\_error\_t)(const char \*msg, int line)

Type of error callbacks during object insertion.

#### 18.30.3 Function Documentation

```
18.30.3.1 struct hwloc_obj* hwloc_insert_object_by_cpuset ( struct hwloc_topology * topology, hwloc_obj_t obj, hwloc_report_error_t report_error_)
```

Add an object to the topology and specify which error callback to use.

Aside from the error callback selection, this function is identical to hwloc\_insert\_object\_by\_cpuset()

```
18.30.3.2 static struct hwloc_obj* hwloc_alloc_setup_object ( hwloc_obj_type_t type, signed os_index ) [static]
```

Allocate and initialize an object of the given type and physical index.

```
18.30.3.3 int hwloc_fill_object_sets ( hwloc_obj_t obj )
```

Setup object cpusets/nodesets by OR'ing its children.

Used when adding an object late in the topology, after propagating sets up and down. The caller should use this after inserting by cpuset (which means the cpusets is already OK). Typical case: PCI backend adding a hostbridge parent.

```
18.30.3.4 int hwloc_hide_errors ( void )
```

Check whether insertion errors are hidden.

18.30.3.5 struct hwloc\_obj\* hwloc\_insert\_object\_by\_cpuset ( struct hwloc\_topology \* topology, hwloc\_obj\_t obj )

Add an object to the topology.

It is sorted along the tree of other objects according to the inclusion of cpusets, to eventually be added as a child of the smallest object including this object.

If the cpuset is empty, the type of the object (and maybe some attributes) must be enough to find where to insert the object. This is especially true for NUMA nodes with memory and no CPUs.

The given object should not have children.

This shall only be called before levels are built.

In case of error, hwloc\_report\_os\_error() is called.

Returns the object on success. Returns NULL and frees obj on error. Returns another object and frees obj if it was merged with an identical pre-existing object.

18.30.3.6 void hwloc insert object by parent ( struct hwloc topology \* topology, hwloc obj t parent, hwloc obj t obj )

Insert an object somewhere in the topology.

It is added as the last child of the given parent. The cpuset is completely ignored, so strange objects such as I/O devices should preferably be inserted with this.

The given object may have children.

Remember to call topology connect() afterwards to fix handy pointers.

```
18.30.3.7 static int hwloc_plugin_check_namespace ( const char * pluginname, const char * symbol ) [inline],
    [static]
```

Make sure that plugins can lookup core symbols.

This is a sanity check to avoid lazy-lookup failures when libhwloc is loaded within a plugin, and later tries to load its own plugins. This may fail (and abort the program) if libhwloc symbols are in a private namespace.

#### Returns

0 on success.

-1 if the plugin cannot be successfully loaded. The caller plugin init() callback should return a negative error code as well.

Plugins should call this function in their init() callback to avoid later crashes if lazy symbol resolution is used by the upper layer that loaded hwloc (e.g. OpenCL implementations using dlopen with RTLD\_LAZY).

Note

The build system must define HWLOC\_INSIDE\_PLUGIN if and only if building the caller as a plugin. This function should remain inline so plugins can call it even when they cannot find libhwloc symbols.

```
18.30.3.8 void hwloc_report_os_error ( const char * msg, int line )
```

Report an insertion error from a backend.

# 18.31 Components and Plugins: PCI functions to be used by components

#### **Functions**

- int hwloc\_insert\_pci\_device\_list (struct hwloc\_backend \*backend, struct hwloc\_obj \*first\_obj)
- unsigned hwloc\_pci\_find\_cap (const unsigned char \*config, unsigned cap)
- int hwloc\_pci\_find\_linkspeed (const unsigned char \*config, unsigned offset, float \*linkspeed)
- int hwloc\_pci\_prepare\_bridge (hwloc\_obj\_t obj, const unsigned char \*config)

# 18.31.1 Detailed Description

#### 18.31.2 Function Documentation

18.31.2.1 int hwloc\_insert\_pci\_device\_list ( struct hwloc\_backend \* backend, struct hwloc\_obj \* first\_obj )

Insert a list of PCI devices and bridges in the backend topology.

Insert a list of objects (either PCI device or bridges) starting at first\_obj (linked by next\_sibling in the topology, and ending with NULL). Objects are placed under the right bridges, and the remaining upstream bridges are then inserted in the topology by calling the get\_obj\_cpuset() callback to find their locality.

18.31.2.2 unsigned hwloc\_pci\_find\_cap ( const unsigned char \* config, unsigned cap )

Return the offset of the given capability in the PCI config space buffer.

This function requires a 256-bytes config space. Unknown/unavailable bytes should be set to 0xff.

18.31.2.3 int hwloc\_pci\_find\_linkspeed ( const unsigned char \* config, unsigned offset, float \* linkspeed )

Fill linkspeed by reading the PCI config space where PCI\_CAP\_ID\_EXP is at position offset.

Needs 20 bytes of EXP capability block starting at offset in the config space for registers up to link status.

18.31.2.4 int hwloc\_pci\_prepare\_bridge ( hwloc\_obj\_t obj, const unsigned char \* config )

Modify the PCI device object into a bridge and fill its attribute if a bridge is found in the PCI config space.

This function requires 64 bytes of common configuration header at the beginning of config.

# 18.32 Linux-specific helpers

#### **Functions**

- int hwloc\_linux\_parse\_cpumap\_file (FILE \*file, hwloc\_cpuset\_t set)
- int hwloc\_linux\_set\_tid\_cpubind (hwloc\_topology\_t topology, pid\_t tid, hwloc\_const\_cpuset\_t set)
- int hwloc\_linux\_get\_tid\_cpubind (hwloc\_topology\_t topology, pid\_t tid, hwloc\_cpuset\_t set)
- int hwloc\_linux\_get\_tid\_last\_cpu\_location (hwloc\_topology\_t topology, pid\_t tid, hwloc\_bitmap\_t set)

# 18.32.1 Detailed Description

This includes helpers for manipulating Linux kernel cpumap files, and hwloc equivalents of the Linux sched\_setaffinity and sched\_getaffinity system calls.

#### 18.32.2 Function Documentation

```
18.32.2.1 int hwloc_linux_get_tid_cpubind ( hwloc_topology_t topology, pid_t tid, hwloc_cpuset_t set )
```

Get the current binding of thread tid.

The behavior is exactly the same as the Linux sched getaffinity system call, but uses a hwloc cpuset.

Note

This is equivalent to calling hwloc\_get\_proc\_cpubind() with HWLOC\_CPUBIND\_THREAD as flags.

```
18.32.2.2 int hwloc_linux_get_tid_last_cpu_location ( hwloc_topology_t topology, pid_t tid, hwloc_bitmap_t set )
```

Get the last physical CPU where thread tid ran.

Note

This is equivalent to calling hwloc get proc last cpu location() with HWLOC CPUBIND THREAD as flags.

```
18.32.2.3 int hwloc_linux_parse_cpumap_file ( FILE * file, hwloc_cpuset_t set )
```

Convert a linux kernel cpumap file file into hwloc CPU set.

Might be used when reading CPU set from sysfs attributes such as topology and caches for processors, or local\_cpus for devices.

```
18.32.2.4 int hwloc_linux_set_tid_cpubind ( hwloc_topology_t topology, pid_t tid, hwloc_const_cpuset_t set )
```

Bind a thread tid on cpus given in cpuset set.

The behavior is exactly the same as the Linux sched\_setaffinity system call, but uses a hwloc cpuset.

Note

This is equivalent to calling hwloc set proc cpubind() with HWLOC CPUBIND THREAD as flags.

# 18.33 Interoperability with Linux libnuma unsigned long masks

#### **Functions**

static int hwloc\_cpuset\_to\_linux\_libnuma\_ulongs (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t cpuset, unsigned long \*mask, unsigned long \*maxnode)

- static int hwloc\_nodeset\_to\_linux\_libnuma\_ulongs (hwloc\_topology\_t topology, hwloc\_const\_nodeset\_t nodeset, unsigned long \*mask, unsigned long \*maxnode)
- static int hwloc\_cpuset\_from\_linux\_libnuma\_ulongs (hwloc\_topology\_t topology, hwloc\_cpuset\_t cpuset, const unsigned long \*mask, unsigned long maxnode)
- static int hwloc\_nodeset\_from\_linux\_libnuma\_ulongs (hwloc\_topology\_t topology, hwloc\_nodeset\_t nodeset, const unsigned long \*mask, unsigned long maxnode)

## 18.33.1 Detailed Description

This interface helps converting between Linux libnuma unsigned long masks and hwloc cpusets and nodesets.

It also offers a consistent behavior on non-NUMA machines or non-NUMA-aware kernels by assuming that the machines have a single NUMA node.

#### Note

Topology topology must match the current machine.

The behavior of libnuma is undefined if the kernel is not NUMA-aware. (when CONFIG\_NUMA is not set in the kernel configuration). This helper and libnuma may thus not be strictly compatible in this case, which may be detected by checking whether numa\_available() returns -1.

#### 18.33.2 Function Documentation

18.33.2.1 static int hwloc\_cpuset\_from\_linux\_libnuma\_ulongs ( hwloc\_topology\_t topology, hwloc\_cpuset\_t cpuset, const unsigned long \* mask, unsigned long maxnode ) [inline], [static]

Convert the array of unsigned long mask into hwloc CPU set.

mask is a array of unsigned long that will be read. maxnode contains the maximal node number that may be read in mask.

This function may be used after calling get\_mempolicy or any other function that takes an array of unsigned long as output parameter (and possibly a maximal node number as input parameter).

18.33.2.2 static int hwloc\_cpuset\_to\_linux\_libnuma\_ulongs ( hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t cpuset, unsigned long \* mask, unsigned long \* maxnode ) [inline], [static]

Convert hwloc CPU set cpuset into the array of unsigned long mask.

mask is the array of unsigned long that will be filled. maxnode contains the maximal node number that may be stored in mask. maxnode will be set to the maximal node number that was found, plus one.

This function may be used before calling set\_mempolicy, mbind, migrate\_pages or any other function that takes an array of unsigned long and a maximal node number as input parameter.

18.33.2.3 static int hwloc\_nodeset\_from\_linux\_libnuma\_ulongs ( hwloc\_topology\_t topology, hwloc\_nodeset\_t nodeset, const unsigned long \* mask, unsigned long maxnode ) [inline].[static]

Convert the array of unsigned long mask into hwloc NUMA node set.

mask is a array of unsigned long that will be read. maxnode contains the maximal node number that may be read in mask.

This function may be used after calling get\_mempolicy or any other function that takes an array of unsigned long as output parameter (and possibly a maximal node number as input parameter).

18.33.2.4 static int hwloc\_nodeset\_to\_linux\_libnuma\_ulongs ( hwloc\_topology\_t topology, hwloc\_const\_nodeset\_t nodeset, unsigned long \* mask, unsigned long \* maxnode ) [inline], [static]

Convert hwloc NUMA node set nodeset into the array of unsigned long mask.

mask is the array of unsigned long that will be filled. maxnode contains the maximal node number that may be stored in mask. maxnode will be set to the maximal node number that was found, plus one.

This function may be used before calling set\_mempolicy, mbind, migrate\_pages or any other function that takes an array of unsigned long and a maximal node number as input parameter.

# 18.34 Interoperability with Linux libnuma bitmask

#### **Functions**

static struct bitmask \* hwloc\_cpuset\_to\_linux\_libnuma\_bitmask (hwloc\_topology\_t topology, hwloc\_const\_
 cpuset t cpuset)

- static int hwloc\_cpuset\_from\_linux\_libnuma\_bitmask (hwloc\_topology\_t topology, hwloc\_cpuset\_t cpuset, const struct bitmask \*bitmask)
- static int hwloc\_nodeset\_from\_linux\_libnuma\_bitmask (hwloc\_topology\_t topology, hwloc\_nodeset\_t nodeset, const struct bitmask \*bitmask)

## 18.34.1 Detailed Description

This interface helps converting between Linux libnuma bitmasks and hwloc cpusets and nodesets.

It also offers a consistent behavior on non-NUMA machines or non-NUMA-aware kernels by assuming that the machines have a single NUMA node.

Note

Topology topology must match the current machine.

The behavior of libnuma is undefined if the kernel is not NUMA-aware. (when CONFIG\_NUMA is not set in the kernel configuration). This helper and libnuma may thus not be strictly compatible in this case, which may be detected by checking whether numa available() returns -1.

### 18.34.2 Function Documentation

18.34.2.1 static int hwloc\_cpuset\_from\_linux\_libnuma\_bitmask ( hwloc\_topology\_t topology, hwloc\_cpuset\_t cpuset, const struct bitmask \* bitmask \*) [inline], [static]

Convert libnuma bitmask bitmask into hwloc CPU set cpuset.

This function may be used after calling many numa\_functions that use a struct bitmask as an output parameter.

```
18.34.2.2 static struct bitmask * hwloc_cpuset_to_linux_libnuma_bitmask ( hwloc_topology_t topology, hwloc_const_cpuset_t cpuset ) [static]
```

Convert hwloc CPU set cpuset into the returned libnuma bitmask.

The returned bitmask should later be freed with numa bitmask free.

This function may be used before calling many numa\_functions that use a struct bitmask as an input parameter.

### Returns

newly allocated struct bitmask.

18.34.2.3 static int hwloc\_nodeset\_from\_linux\_libnuma\_bitmask ( hwloc\_topology\_t topology, hwloc\_nodeset\_t nodeset, const struct bitmask \* bitmask \*) [inline], [static]

Convert libnuma bitmask bitmask into hwloc NUMA node set nodeset.

This function may be used after calling many numa\_ functions that use a struct bitmask as an output parameter.

```
18.34.2.4 static struct bitmask * hwloc_nodeset_to_linux_libnuma_bitmask ( hwloc_topology_t topology, hwloc_const_nodeset_t nodeset ) [static]
```

Convert hwloc NUMA node set nodeset into the returned libnuma bitmask.

The returned bitmask should later be freed with numa\_bitmask\_free.

This function may be used before calling many numa\_functions that use a struct bitmask as an input parameter.

### Returns

newly allocated struct bitmask.

# 18.35 Interoperability with glibc sched affinity

### **Functions**

- static int hwloc\_cpuset\_to\_glibc\_sched\_affinity (hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t hwlocset, cpu\_set\_t \*schedset, size\_t schedsetsize)
- static int hwloc\_cpuset\_from\_glibc\_sched\_affinity (hwloc\_topology\_t topology, hwloc\_cpuset\_t hwlocset, const cpu\_set\_t \*schedset, size\_t schedsetsize)

## 18.35.1 Detailed Description

This interface offers ways to convert between hwloc cpusets and glibc cpusets such as those manipulated by sched\_egetaffinity() or pthread attr setaffinity np().

Note

Topology topology must match the current machine.

#### 18.35.2 Function Documentation

18.35.2.1 static int hwloc\_cpuset\_from\_glibc\_sched\_affinity ( hwloc\_topology\_t topology, hwloc\_cpuset\_t hwlocset, const cpu\_set\_t \* schedset, size\_t \* schedsetsize ) [inline], [static]

Convert glibc sched affinity CPU set schedset into hwloc CPU set.

This function may be used before calling sched\_setaffinity or any other function that takes a cpu\_set\_t as input parameter.

schedsetsize should be sizeof(cpu\_set\_t) unless schedset was dynamically allocated with CPU\_ALLOC

18.35.2.2 static int hwloc\_cpuset\_to\_glibc\_sched\_affinity ( hwloc\_topology\_t topology, hwloc\_const\_cpuset\_t hwlocset, cpu\_set\_t \* schedset, size\_t schedsetsize ) [inline], [static]

Convert hwloc CPU set toposet into glibc sched affinity CPU set schedset.

This function may be used before calling sched\_setaffinity or any other function that takes a cpu\_set\_t as input parameter

schedsetsize should be sizeof(cpu\_set\_t) unless schedset was dynamically allocated with CPU\_ALLOC

# 18.36 Interoperability with OpenCL

#### **Functions**

- static int hwloc\_opencl\_get\_device\_cpuset (hwloc\_topology\_t topology, cl\_device\_id device, hwloc\_cpuset\_t set)
- static hwloc\_obj\_t hwloc\_opencl\_get\_device\_osdev\_by\_index (hwloc\_topology\_t topology, unsigned platform\_
  index, unsigned device\_index)
- static hwloc obj t hwloc opencl get device osdev (hwloc topology t topology, cl device id device)

# 18.36.1 Detailed Description

This interface offers ways to retrieve topology information about OpenCL devices.

Only the AMD OpenCL interface currently offers useful locality information about its devices.

### 18.36.2 Function Documentation

18.36.2.1 static int hwloc\_opencl\_get\_device\_cpuset ( hwloc\_topology\_t topology, cl\_device\_id device, hwloc\_cpuset\_t set ) [inline],[static]

Get the CPU set of logical processors that are physically close to OpenCL device device.

Return the CPU set describing the locality of the OpenCL device device.

Topology topology and device device must match the local machine. I/O devices detection and the OpenCL component are not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see hwloc\_opencl\_get\_device\_osdev() and hwloc\_opencl\_get\_device\_osdev\_by\_index().

This function is currently only implemented in a meaningful way for Linux with the AMD OpenCL implementation; other systems will simply get a full cpuset.

```
18.36.2.2 static hwloc_obj_t hwloc_opencl_get_device_osdev ( hwloc_topology_t topology, cl_device_id device )
[inline], [static]
```

Get the hwloc OS device object corresponding to OpenCL device device.

Return the hwloc OS device object that describes the given OpenCL device device. Return NULL if there is none.

Topology topology and device device must match the local machine. I/O devices detection and the OpenCL component must be enabled in the topology. If not, the locality of the object may still be found using hwloc\_opencl\_component must be enabled in the topology. If not, the locality of the object may still be found using hwloc\_opencl\_component must be enabled in the topology.

#### Note

The corresponding hwloc PCI device may be found by looking at the result parent pointer.

```
18.36.2.3 static hwloc_obj_t hwloc_opencl_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned platform_index, unsigned device_index ) [inline], [static]
```

Get the hwloc OS device object corresponding to the OpenCL device for the given indexes.

Return the OS device object describing the OpenCL device whose platform index is platform\_index, and whose device index within this platform if device\_index. Return NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the OpenCL component must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

# 18.37 Interoperability with the CUDA Driver API

#### **Functions**

- static int hwloc\_cuda\_get\_device\_pci\_ids (hwloc\_topology\_t topology, CUdevice cudevice, int \*domain, int \*bus, int \*dev)
- static int hwloc\_cuda\_get\_device\_cpuset (hwloc\_topology\_t topology, CUdevice cudevice, hwloc\_cpuset\_t set)
- static hwloc\_obj\_t hwloc\_cuda\_get\_device\_pcidev (hwloc\_topology\_t topology, CUdevice cudevice)
- static hwloc\_obj\_t hwloc\_cuda\_get\_device\_osdev (hwloc\_topology\_t topology, CUdevice cudevice)
- static hwloc\_obj\_t hwloc\_cuda\_get\_device\_osdev\_by\_index (hwloc\_topology\_t topology, unsigned idx)

# 18.37.1 Detailed Description

This interface offers ways to retrieve topology information about CUDA devices when using the CUDA Driver API.

#### 18.37.2 Function Documentation

```
18.37.2.1 static int hwloc_cuda_get_device_cpuset ( hwloc_topology_t topology, CUdevice cudevice, hwloc_cpuset_t set )
[inline], [static]
```

Get the CPU set of logical processors that are physically close to device cudevice.

Return the CPU set describing the locality of the CUDA device cudevice.

Topology topology and device cudevice must match the local machine. I/O devices detection and the CUDA component are not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see hwloc cuda get device osdev() and hwloc cuda get device osdev by index().

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
18.37.2.2 static hwloc_obj_t hwloc_cuda_get_device_osdev ( hwloc_topology_t topology, CUdevice cudevice )
[inline],[static]
```

Get the hwloc OS device object corresponding to CUDA device cudevice.

Return the hwloc OS device object that describes the given CUDA device cudevice. Return NULL if there is none.

Topology topology and device cudevice must match the local machine. I/O devices detection and the NVML component must be enabled in the topology. If not, the locality of the object may still be found using hwloc\_cuda\_get ← \_\_device\_cpuset().

Note

The corresponding hwloc PCI device may be found by looking at the result parent pointer.

```
18.37.2.3 static hwloc_obj_t hwloc_cuda_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned idx ) [inline], [static]
```

Get the hwloc OS device object corresponding to the CUDA device whose index is idx.

Return the OS device object describing the CUDA device whose index is idx. Return NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the CUDA component must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

This function is identical to hwloc cudart get device osdev by index().

```
18.37.2.4 static int hwloc_cuda_get_device_pci_ids ( hwloc_topology_t topology, CUdevice cudevice, int * domain, int * bus, int * dev ) [inline], [static]
```

Return the domain, bus and device IDs of the CUDA device cudevice.

Device cudevice must match the local machine.

```
18.37.2.5 static hwloc_obj_t hwloc_cuda_get_device_pcidev ( hwloc_topology_t topology, CUdevice cudevice )
[inline], [static]
```

Get the hwloc PCI device object corresponding to the CUDA device cudevice.

Return the PCI device object describing the CUDA device cudevice. Return NULL if there is none.

Topology topology and device cudevice must match the local machine. I/O devices detection must be enabled in topology topology. The CUDA component is not needed in the topology.

## 18.38 Interoperability with the CUDA Runtime API

#### **Functions**

- static int hwloc\_cudart\_get\_device\_pci\_ids (hwloc\_topology\_t topology, int idx, int \*domain, int \*bus, int \*dev)
- · static int hwloc cudart get device cpuset (hwloc topology t topology, int idx, hwloc cpuset t set)
- static hwloc\_obj\_t hwloc\_cudart\_get\_device\_pcidev (hwloc\_topology\_t topology, int idx)
- static hwloc obj t hwloc cudart get device osdev by index (hwloc topology t topology, unsigned idx)

#### 18.38.1 Detailed Description

This interface offers ways to retrieve topology information about CUDA devices when using the CUDA Runtime API.

#### 18.38.2 Function Documentation

```
18.38.2.1 static int hwloc_cudart_get_device_cpuset ( hwloc_topology_t topology, int idx, hwloc_cpuset_t set ) [inline], [static]
```

Get the CPU set of logical processors that are physically close to device idx.

Return the CPU set describing the locality of the CUDA device whose index is idx.

Topology topology and device idx must match the local machine. I/O devices detection and the CUDA component are not needed in the topology.

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
18.38.2.2 static hwloc_obj_t hwloc_cudart_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned idx )
[inline], [static]
```

Get the hwloc OS device object corresponding to the CUDA device whose index is idx.

Return the OS device object describing the CUDA device whose index is idx. Return NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the CUDA component must be enabled in the topology. If not, the locality of the object may still be found using hwloc\_cudart\_get\_device\_cpuset().

#### Note

The corresponding PCI device object can be obtained by looking at the OS device parent object. This function is identical to hwloc cuda get device osdev by index().

```
18.38.2.3 static int hwloc_cudart_get_device_pci_ids ( hwloc_topology_t topology, int idx, int * domain, int * bus, int * dev )
[inline], [static]
```

Return the domain, bus and device IDs of the CUDA device whose index is idx.

Device index idx must match the local machine.

158 Module Documentation

**18.38.2.4** static hwloc\_obj\_t hwloc\_cudart\_get\_device\_pcidev ( hwloc\_topology\_t topology, int idx ) [inline], [static]

Get the hwloc PCI device object corresponding to the CUDA device whose index is idx.

Return the PCI device object describing the CUDA device whose index is idx. Return NULL if there is none.

Topology topology and device idx must match the local machine. I/O devices detection must be enabled in topology topology. The CUDA component is not needed in the topology.

Generated on Wed Sep 24 2014 16:12:37 for Hardware Locality (hwloc) by Doxygen

## 18.39 Interoperability with the NVIDIA Management Library

#### **Functions**

- static int hwloc\_nvml\_get\_device\_cpuset (hwloc\_topology\_t topology, nvmlDevice\_t device, hwloc\_cpuset\_t set)
- static hwloc\_obj\_t hwloc\_nvml\_get\_device\_osdev\_by\_index (hwloc\_topology\_t topology, unsigned idx)
- static hwloc\_obj\_t hwloc\_nvml\_get\_device\_osdev (hwloc\_topology\_t topology, nvmlDevice\_t device)

#### 18.39.1 Detailed Description

This interface offers ways to retrieve topology information about devices managed by the NVIDIA Management Library (NVML).

#### 18.39.2 Function Documentation

18.39.2.1 static int hwloc\_nvml\_get\_device\_cpuset ( hwloc\_topology\_t topology, nvmlDevice\_t device, hwloc\_cpuset\_t set ) [inline], [static]

Get the CPU set of logical processors that are physically close to NVML device device.

Return the CPU set describing the locality of the NVML device device.

Topology topology and device device must match the local machine. I/O devices detection and the NVML component are not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see <a href="https://www.nvml\_get\_device\_osdev">hwloc\_nvml\_get\_device\_osdev</a>, and <a href="https://www.nvml\_get\_device\_osdev">hwloc\_nvml\_get\_device\_osdev</a>.

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
18.39.2.2 static hwloc_obj_t hwloc_nvml_get_device_osdev ( hwloc_topology_t topology, nvmlDevice_t device )
[inline],[static]
```

Get the hwloc OS device object corresponding to NVML device device.

Return the hwloc OS device object that describes the given NVML device device. Return NULL if there is none.

Topology topology and device device must match the local machine. I/O devices detection and the NVML component must be enabled in the topology. If not, the locality of the object may still be found using hwloc\_nvml\_get\_device—cpuset().

Note

The corresponding hwloc PCI device may be found by looking at the result parent pointer.

```
18.39.2.3 static hwloc_obj_t hwloc_nvml_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned idx ) [inline], [static]
```

Get the hwloc OS device object corresponding to the NVML device whose index is idx.

Return the OS device object describing the NVML device whose index is idx. Returns NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the NVML component must be enabled in the topology.

160 Module Documentation

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

## 18.40 Interoperability with OpenGL displays

#### **Functions**

- static hwloc\_obj\_t hwloc\_gl\_get\_display\_osdev\_by\_port\_device (hwloc\_topology\_t topology, unsigned port, unsigned device)
- static hwloc obj t hwloc gl get display osdev by name (hwloc topology t topology, const char \*name)
- static int hwloc\_gl\_get\_display\_by\_osdev (hwloc\_topology\_t topology, hwloc\_obj\_t osdev, unsigned \*port, unsigned \*device)

### 18.40.1 Detailed Description

This interface offers ways to retrieve topology information about OpenGL displays.

Only the NVIDIA display locality information is currently available, using the NV-CONTROL X11 extension and the NVCtrl library.

#### 18.40.2 Function Documentation

```
18.40.2.1 static int hwloc_gl_get_display_by_osdev ( hwloc_topology_t topology, hwloc_obj_t osdev, unsigned * port, unsigned * device ) [inline], [static]
```

Get the OpenGL display port and device corresponding to the given hwloc OS object.

Return the OpenGL display port (server) in port and device (screen) in screen that correspond to the given hwloc OS device object. Return -1 if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the GL component must be enabled in the topology.

```
18.40.2.2 static hwloc_obj_t hwloc_gl_get_display_osdev_by_name ( hwloc_topology_t topology, const char * name )
[inline], [static]
```

Get the hwloc OS device object corresponding to the OpenGL display given by name.

Return the OS device object describing the OpenGL display whose name is name, built as ":port.device" such as ":0.0" . Return NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the GL component must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

```
18.40.2.3 static hwloc_obj_t hwloc_gl_get_display_osdev_by_port_device ( hwloc_topology_t topology, unsigned port, unsigned device ) [inline], [static]
```

Get the hwloc OS device object corresponding to the OpenGL display given by port and device index.

Return the OS device object describing the OpenGL display whose port (server) is port and device (screen) is device. Return NULL if there is none.

162 Module Documentation

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection and the GL component must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

## 18.41 Interoperability with Intel Xeon Phi (MIC)

#### **Functions**

- static int hwloc\_intel\_mic\_get\_device\_cpuset (hwloc\_topology\_t topology, int idx, hwloc\_cpuset\_t set)
- static hwloc\_obj\_t hwloc\_intel\_mic\_get\_device\_osdev\_by\_index (hwloc\_topology\_t topology, unsigned idx)

#### 18.41.1 Detailed Description

This interface offers ways to retrieve topology information about Intel Xeon Phi (MIC) devices.

#### 18.41.2 Function Documentation

```
18.41.2.1 static int hwloc_intel_mic_get_device_cpuset ( hwloc_topology_t topology, int idx, hwloc_cpuset_t set )
[inline], [static]
```

Get the CPU set of logical processors that are physically close to MIC device whose index is idx.

Return the CPU set describing the locality of the MIC device whose index is idx.

Topology topology and device index idx must match the local machine. I/O devices detection is not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see <a href="https://hww.nuc.en/beauto.com/hww.nuc.en/beauto.

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
18.41.2.2 static hwloc_obj_t hwloc_intel_mic_get_device_osdev_by_index ( hwloc_topology_t topology, unsigned idx )
[inline], [static]
```

Get the hwloc OS device object corresponding to the MIC device for the given index.

Return the OS device object describing the MIC device whose index is idx. Return NULL if there is none.

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

164 Module Documentation

## 18.42 Interoperability with OpenFabrics

#### **Functions**

- static int hwloc ibv get device cpuset (hwloc topology t topology, struct ibv device \*ibdev, hwloc cpuset t set)
- static hwloc obj t hwloc ibv get device osdev by name (hwloc topology t topology, const char \*ibname)
- static hwloc obj t hwloc ibv get device osdev (hwloc topology t topology, struct ibv device \*ibdev)

#### 18.42.1 Detailed Description

This interface offers ways to retrieve topology information about OpenFabrics devices.

#### 18.42.2 Function Documentation

```
18.42.2.1 static int hwloc_ibv_get_device_cpuset ( hwloc_topology_t topology, struct ibv_device * ibdev, hwloc_cpuset_t set ) [inline], [static]
```

Get the CPU set of logical processors that are physically close to device ibdev.

Return the CPU set describing the locality of the OpenFabrics device ibdev.

Topology topology and device ibdev must match the local machine. I/O devices detection is not needed in the topology.

The function only returns the locality of the device. If more information about the device is needed, OS objects should be used instead, see hwloc ibv get device osdev() and hwloc ibv get device osdev by name().

This function is currently only implemented in a meaningful way for Linux; other systems will simply get a full cpuset.

```
18.42.2.2 static hwloc_obj_t hwloc_ibv_get_device_osdev ( hwloc_topology_t topology, struct ibv_device * ibdev )
[inline], [static]
```

Get the hwloc OS device object corresponding to the OpenFabrics device ibdev.

Return the OS device object describing the OpenFabrics device ibdev. Returns NULL if there is none.

Topology topology and device ibdev must match the local machine. I/O devices detection must be enabled in the topology. If not, the locality of the object may still be found using  $hwloc_ibv_get_device_cpuset()$ .

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

```
18.42.2.3 static hwloc_obj_t hwloc_ibv_get_device_osdev_by_name ( hwloc_topology_t topology, const char * ibname )
[inline], [static]
```

Get the hwloc OS device object corresponding to the OpenFabrics device named ibname.

Return the OS device object describing the OpenFabrics device whose name is ibname. Returns NULL if there is none. The name ibname is usually obtained from ibv get device name().

The topology topology does not necessarily have to match the current machine. For instance the topology may be an XML import of a remote host. I/O devices detection must be enabled in the topology.

Note

The corresponding PCI device object can be obtained by looking at the OS device parent object.

166 Module Documentation

## 18.43 Interoperability with Myrinet Express

#### **Functions**

- static int hwloc\_mx\_board\_get\_device\_cpuset (hwloc\_topology\_t topology, unsigned id, hwloc\_cpuset\_t set)
- static int hwloc\_mx\_endpoint\_get\_device\_cpuset (hwloc\_topology\_t topology, mx\_endpoint\_t endpoint, hwloc\_
   cpuset t set)

#### 18.43.1 Detailed Description

This interface offers ways to retrieve topology information about Myrinet Express hardware.

#### 18.43.2 Function Documentation

18.43.2.1 static int hwloc\_mx\_board\_get\_device\_cpuset ( hwloc\_topology\_t topology, unsigned id, hwloc\_cpuset\_t set )
[inline], [static]

Get the CPU set of logical processors that are physically close the MX board id.

Return the CPU set describing the locality of the Myrinet Express board whose index is id.

Topology topology and device id must match the local machine. I/O devices detection is not needed in the topology. The function only returns the locality of the device. No additional information about the device is available.

18.43.2.2 static int hwloc\_mx\_endpoint\_get\_device\_cpuset ( hwloc\_topology\_t topology, mx\_endpoint\_t endpoint, hwloc\_cpuset\_t set ) [inline], [static]

Get the CPU set of logical processors that are physically close the MX endpoint endpoint.

Return the CPU set describing the locality of the Myrinet Express board that runs the MX endpoint endpoint.

 $\label{topology} \textbf{Topology and device id must match the local machine. I/O devices detection is not needed in the topology.}$ 

The function only returns the locality of the endpoint. No additional information about the endpoint or device is available.

## **Chapter 19**

## **Data Structure Documentation**

## 19.1 hwloc\_backend Struct Reference

```
#include <plugins.h>
```

#### **Data Fields**

- · unsigned long flags
- int is\_custom
- int is\_thissystem
- void \* private\_data
- void(\* disable )(struct hwloc\_backend \*backend)
- int(\* discover )(struct hwloc\_backend \*backend)
- int(\* get\_obj\_cpuset )(struct hwloc\_backend \*backend, struct hwloc\_backend \*caller, struct hwloc\_obj \*obj, hwloc\_bitmap\_t cpuset)
- int(\* notify\_new\_object )(struct hwloc\_backend \*backend, struct hwloc\_backend \*caller, struct hwloc\_obj \*obj)

## 19.1.1 Detailed Description

Discovery backend structure.

A backend is the instantiation of a discovery component. When a component gets enabled for a topology, its instantiate() callback creates a backend.

hwloc\_backend\_alloc() initializes all fields to default values that the component may change (except "component" and "next") before enabling the backend with hwloc\_backend\_enable().

#### 19.1.2 Field Documentation

19.1.2.1 void(\* hwloc\_backend::disable)(struct hwloc\_backend \*backend)

Callback for freeing the private data. May be NULL.

19.1.2.2 int(\* hwloc\_backend::discover)(struct hwloc\_backend \*backend)

Main discovery callback. returns > 0 if it modified the topology tree, -1 on error, 0 otherwise. May be NULL if type is HWLOC\_DISC\_COMPONENT\_TYPE\_MISC.

19.1.2.3 unsigned long hwloc\_backend::flags

Backend flags, as an OR'ed set of HWLOC BACKEND FLAG \*.

19.1.2.4 int(\* hwloc\_backend::get\_obj\_cpuset)(struct hwloc\_backend \*backend, struct hwloc\_backend \*caller, struct hwloc\_obj \*obj, hwloc\_bitmap\_t cpuset)

Callback used by the PCI backend to retrieve the locality of a PCI object from the OS/cpu backend. May be NULL.

19.1.2.5 int hwloc\_backend::is\_custom

Backend-specific 'is\_custom' property. Shortcut on !strcmp(..->component->name, "custom"). Only the custom component should touch this.

19.1.2.6 int hwloc\_backend::is\_thissystem

Backend-specific 'is\_thissystem' property. Set to 0 or 1 if the backend should enforce the thissystem flag when it gets enabled. Set to -1 if the backend doesn't care (default).

19.1.2.7 int(\* hwloc\_backend::notify\_new\_object)(struct hwloc\_backend \*backend, struct hwloc\_backend \*caller, struct hwloc\_obj \*obj)

Callback called by backends to notify this backend that a new object was added. returns > 0 if it modified the topology tree, 0 otherwise. May be NULL.

19.1.2.8 void\* hwloc\_backend::private\_data

Backend private data, or NULL if none.

The documentation for this struct was generated from the following file:

· plugins.h

## 

```
#include <hwloc.h>
```

#### **Data Fields**

union { struct hwloc\_pcidev\_attr\_s pci } upstream

```
    hwloc_obj_bridge_type_t upstream_type
    union {
        struct {
            unsigned short domain
            unsigned char secondary_bus
            unsigned char subordinate_bus
        } pci
    } downstream
```

- hwloc\_obj\_bridge\_type\_t downstream\_type
- · unsigned depth

#### 19.2.1 Detailed Description

Bridge specific Object Attribues.

#### 19.2.2 Field Documentation

```
19.2.2.1 unsigned hwloc_obj_attr_u::hwloc_bridge_attr_s::depth
```

19.2.2.2 unsigned short hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s::domain

19.2.2.3 union { ... } hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s::downstream

19.2.2.4 hwloc obj bridge type t hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s::downstream\_type

19.2.2.5 struct { ... } hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s::pci

19.2.2.6 struct hwloc\_pcidev\_attr\_s hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s::pci

19.2.2.7 unsigned char hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s::secondary\_bus

19.2.2.8 unsigned char hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s::subordinate\_bus

19.2.2.9 union { ... } hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s::upstream

19.2.2.10 hwloc\_obj\_bridge\_type\_t hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s::upstream\_type

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.3 hwloc\_obj\_attr\_u::hwloc\_cache\_attr\_s Struct Reference

```
#include <hwloc.h>
```

#### **Data Fields**

· hwloc uint64 t size

- · unsigned depth
- unsigned linesize
- · int associativity
- hwloc\_obj\_cache\_type\_t type

#### 19.3.1 Detailed Description

Cache-specific Object Attributes.

#### 19.3.2 Field Documentation

19.3.2.1 int hwloc\_obj\_attr\_u::hwloc\_cache\_attr\_s::associativity

Ways of associativity, -1 if fully associative, 0 if unknown.

19.3.2.2 unsigned hwloc\_obj\_attr\_u::hwloc\_cache\_attr\_s::depth

Depth of cache (e.g., L1, L2, ...etc.)

19.3.2.3 unsigned hwloc\_obj\_attr\_u::hwloc\_cache\_attr\_s::linesize

Cache-line size in bytes. 0 if unknown.

19.3.2.4 hwloc\_uint64\_t hwloc\_obj\_attr\_u::hwloc\_cache\_attr\_s::size

Size of cache in bytes.

19.3.2.5 hwloc\_obj\_cache\_type\_t hwloc\_obj\_attr\_u::hwloc\_cache\_attr\_s::type

Cache type.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.4 hwloc\_component Struct Reference

```
#include <plugins.h>
```

#### **Data Fields**

- unsigned abi
- int(\* init )(unsigned long flags)
- void(\* finalize )(unsigned long flags)
- hwloc\_component\_type\_t type
- · unsigned long flags
- void \* data

#### 19.4.1 Detailed Description

Generic component structure.

Generic components structure, either statically listed by configure in static-components.h or dynamically loaded as a plugin.

#### 19.4.2 Field Documentation

19.4.2.1 unsigned hwloc\_component::abi

Component ABI version, set to HWLOC\_COMPONENT\_ABI.

19.4.2.2 void\* hwloc\_component::data

Component data, pointing to a struct hwloc\_disc\_component or struct hwloc\_xml\_component.

19.4.2.3 void(\* hwloc\_component::finalize)(unsigned long flags)

Process-wide component termination callback.

This optional callback is called after unregistering the component from the hwloc core (before unloading the plugin).

flags is always 0 for now.

Note

If the component uses Itdl for loading its own plugins, it should load/unload them only in init() and finalize(), to avoid race conditions with hwloc's use of Itdl.

19.4.2.4 unsigned long hwloc\_component::flags

Component flags, unused for now.

19.4.2.5 int(\* hwloc\_component::init)(unsigned long flags)

Process-wide component initialization callback.

This optional callback is called when the component is registered to the hwloc core (after loading the plugin).

When the component is built as a plugin, this callback should call hwloc\_check\_plugin\_namespace() and return an negative error code on error.

flags is always 0 for now.

#### Returns

0 on success, or a negative code on error.

If the component uses Itdl for loading its own plugins, it should load/unload them only in init() and finalize(), to avoid race conditions with hwloc's use of Itdl.

19.4.2.6 hwloc\_component\_type\_t hwloc\_component::type

Component type.

The documentation for this struct was generated from the following file:

· plugins.h

## 19.5 hwloc\_disc\_component Struct Reference

#include <plugins.h>

#### **Data Fields**

- hwloc\_disc\_component\_type\_t type
- const char \* name
- · unsigned excludes
- struct hwloc\_backend \*(\* instantiate )(struct hwloc\_disc\_component \*component, const void \*data1, const void \*data2, const void \*data3)
- · unsigned priority

#### 19.5.1 Detailed Description

Discovery component structure.

This is the major kind of components, taking care of the discovery. They are registered by generic components, either statically-built or as plugins.

#### 19.5.2 Field Documentation

19.5.2.1 unsigned hwloc\_disc\_component::excludes

Component types to exclude, as an OR'ed set of HWLOC\_DISC\_COMPONENT\_TYPE\_\*.

For a GLOBAL component, this usually includes all other types ( $\sim$ 0).

Other components only exclude types that may bring conflicting topology information. MISC components should likely not be excluded since they usually bring non-primary additional information.

19.5.2.2 struct hwloc\_backend\*(\* hwloc\_disc\_component::instantiate)(struct hwloc\_disc\_component \*component, const void \*data1, const void \*data2, const void \*data3)

Instantiate callback to create a backend from the component. Parameters data1, data2, data3 are NULL except for components that have special enabling routines such as hwloc topology set xml().

19.5.2.3 const char\* hwloc\_disc\_component::name

Name. If this component is built as a plugin, this name does not have to match the plugin filename.

19.5.2.4 unsigned hwloc\_disc\_component::priority

Component priority. Used to sort topology->components, higher priority first. Also used to decide between two components with the same name.

Usual values are 50 for native OS (or platform) components, 45 for x86, 40 for no-OS fallback, 30 for global components (xml/synthetic/custom), 20 for pci, 10 for other misc components (opencl etc.).

19.5.2.5 hwloc\_disc\_component\_type\_t hwloc\_disc\_component::type

Discovery component type.

The documentation for this struct was generated from the following file:

plugins.h

## 19.6 hwloc distances s Struct Reference

#include <hwloc.h>

#### **Data Fields**

- · unsigned relative depth
- unsigned nbobjs
- float \* latency
- · float latency max
- · float latency base

#### 19.6.1 Detailed Description

Distances between objects.

One object may contain a distance structure describing distances between all its descendants at a given relative depth. If the containing object is the root object of the topology, then the distances are available for all objects in the machine.

If the latency pointer is not NULL, the pointed array contains memory latencies (non-zero values), as defined by the ACPI SLIT specification.

In the future, some other types of distances may be considered. In these cases, latency may be NULL.

#### 19.6.2 Field Documentation

#### 19.6.2.1 float\* hwloc\_distances\_s::latency

Matrix of latencies between objects, stored as a one-dimension array. May be NULL if the distances considered here are not latencies. Values are normalized to get 1.0 as the minimal value in the matrix. Latency from i-th to j-th object is stored in slot i\*nbobjs+j.

19.6.2.2 float hwloc\_distances\_s::latency\_base

The multiplier that should be applied to latency matrix to retrieve the original OS-provided latencies. Usually 10 on Linux since ACPI SLIT uses 10 for local latency.

19.6.2.3 float hwloc\_distances\_s::latency\_max

The maximal value in the latency matrix.

19.6.2.4 unsigned hwloc\_distances\_s::nbobjs

Number of objects considered in the matrix. It is the number of descendant objects at relative\_depth below the containing object. It corresponds to the result of hwloc\_get\_nbobjs\_inside\_cpuset\_by\_depth.

19.6.2.5 unsigned hwloc\_distances\_s::relative\_depth

Relative depth of the considered objects below the object containing this distance information.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.7 hwloc\_obj\_attr\_u::hwloc\_group\_attr\_s Struct Reference

#include <hwloc.h>

#### **Data Fields**

· unsigned depth

#### 19.7.1 Detailed Description

Group-specific Object Attributes.

#### 19.7.2 Field Documentation

19.7.2.1 unsigned hwloc\_obj\_attr\_u::hwloc\_group\_attr\_s::depth

Depth of group object.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.8 hwloc\_obj Struct Reference

#include <hwloc.h>

#### **Data Fields**

- hwloc obj type t type
- unsigned os\_index
- char \* name
- · struct hwloc obj memory s memory
- union hwloc\_obj\_attr\_u \* attr
- unsigned depth
- unsigned logical index
- · signed os\_level
- struct hwloc\_obj \* next\_cousin
- struct hwloc obj \* prev cousin
- struct hwloc\_obj \* parent
- · unsigned sibling rank
- struct hwloc\_obj \* next\_sibling
- struct hwloc obj \* prev sibling
- · unsigned arity
- struct hwloc\_obj \*\* children
- struct hwloc\_obj \* first\_child
- struct hwloc obj \* last child
- void \* userdata
- · hwloc cpuset t cpuset
- · hwloc cpuset t complete cpuset
- · hwloc\_cpuset\_t online\_cpuset
- · hwloc cpuset tallowed cpuset
- hwloc nodeset t nodeset
- hwloc\_nodeset\_t complete\_nodeset
- hwloc\_nodeset\_t allowed\_nodeset
- struct hwloc distances s \*\* distances
- · unsigned distances count
- struct hwloc obj info s \* infos
- · unsigned infos\_count
- · int symmetric subtree

#### 19.8.1 Detailed Description

Structure of a topology object.

Applications must not modify any field except hwloc\_obj.userdata.

#### 19.8.2 Field Documentation

19.8.2.1 hwloc\_cpuset\_t hwloc\_obj::allowed\_cpuset

The CPU set of allowed logical processors.

This includes the CPUs contained in this object which are allowed for binding, i.e. passing them to the hwloc binding functions should not return permission errors. This is usually restricted by administration rules. Some of them may however be offline so binding to them may still not be possible, see online\_cpuset.

Note

Its value must not be changed, hwloc\_bitmap\_dup must be used instead.

19.8.2.2 hwloc\_nodeset\_t hwloc\_obj::allowed\_nodeset

The set of allowed NUMA memory nodes.

This includes the NUMA memory nodes contained in this object which are allowed for memory allocation, i.e. passing them to NUMA node-directed memory allocation should not return permission errors. This is usually restricted by administration rules.

If there are no NUMA nodes in the machine, all the memory is close to this object, so allowed\_nodeset is full.

Note

Its value must not be changed, hwloc bitmap dup must be used instead.

19.8.2.3 unsigned hwloc\_obj::arity

Number of children.

19.8.2.4 union hwloc\_obj\_attr\_u\* hwloc\_obj::attr

Object type-specific Attributes, may be NULL if no attribute value was found.

19.8.2.5 struct hwloc obj\*\* hwloc\_obj::children

Children, children[0 .. arity -1].

19.8.2.6 hwloc\_cpuset\_t hwloc\_obj::complete\_cpuset

The complete CPU set of logical processors of this object,.

This includes not only the same as the cpuset field, but also the CPUs for which topology information is unknown or incomplete, and the CPUs that are ignored when the HWLOC\_TOPOLOGY\_FLAG\_WHOLE\_SYSTEM flag is not set. Thus no corresponding PU object may be found in the topology, because the precise position is undefined. It is however known that it would be somewhere under this object.

Note

Its value must not be changed, hwloc\_bitmap\_dup must be used instead.

19.8.2.7 hwloc\_nodeset\_t hwloc\_obj::complete\_nodeset

The complete NUMA node set of this object,.

This includes not only the same as the nodeset field, but also the NUMA nodes for which topology information is unknown or incomplete, and the nodes that are ignored when the HWLOC\_TOPOLOGY\_FLAG\_WHOLE\_SYSTEM flag is not set. Thus no corresponding NODE object may be found in the topology, because the precise position is undefined. It is however known that it would be somewhere under this object.

If there are no NUMA nodes in the machine, all the memory is close to this object, so complete\_nodeset is full.

Note

Its value must not be changed, hwloc\_bitmap\_dup must be used instead.

19.8.2.8 hwloc\_cpuset\_t hwloc\_obj::cpuset

CPUs covered by this object.

This is the set of CPUs for which there are PU objects in the topology under this object, i.e. which are known to be physically contained in this object and known how (the children path between this object and the PU objects).

If the HWLOC\_TOPOLOGY\_FLAG\_WHOLE\_SYSTEM configuration flag is set, some of these CPUs may be offline, or not allowed for binding, see online cpuset and allowed cpuset.

Note

Its value must not be changed, hwloc\_bitmap\_dup must be used instead.

19.8.2.9 unsigned hwloc\_obj::depth

Vertical index in the hierarchy. If the topology is symmetric, this is equal to the parent depth plus one, and also equal to the number of parent/child links from the root object to here.

19.8.2.10 struct hwloc\_distances\_s\*\* hwloc\_obj::distances

Distances between all objects at same depth below this object.

19.8.2.11 unsigned hwloc\_obj::distances\_count

19.8.2.12 struct hwloc\_obj\* hwloc\_obj::first\_child

First child.

19.8.2.13 struct hwloc obj info s\* hwloc\_obj::infos

Array of stringified info type=name.

19.8.2.14 unsigned hwloc\_obj::infos\_count

Size of infos array.

19.8.2.15 struct hwloc\_obj\* hwloc\_obj::last\_child

Last child.

19.8.2.16 unsigned hwloc\_obj::logical\_index

Horizontal index in the whole list of similar objects, could be a "cousin\_rank" since it's the rank within the "cousin" list below.

19.8.2.17 struct hwloc\_obj\_memory\_s hwloc\_obj::memory

Memory attributes.

19.8.2.18 char\* hwloc\_obj::name

Object description if any.

19.8.2.19 struct hwloc obj\* hwloc obj::next\_cousin

Next object of same type and depth.

19.8.2.20 struct hwloc\_obj\* hwloc\_obj::next\_sibling

Next object below the same parent.

19.8.2.21 hwloc nodeset thwloc\_obj::nodeset

NUMA nodes covered by this object or containing this object.

This is the set of NUMA nodes for which there are NODE objects in the topology under or above this object, i.e. which are known to be physically contained in this object or containing it and known how (the children path between this object and the NODE objects).

In the end, these nodes are those that are close to the current object.

If the HWLOC\_TOPOLOGY\_FLAG\_WHOLE\_SYSTEM configuration flag is set, some of these nodes may not be allowed for allocation, see allowed\_nodeset.

If there are no NUMA nodes in the machine, all the memory is close to this object, so nodeset is full.

Note

Its value must not be changed, hwloc\_bitmap\_dup must be used instead.

19.8.2.22 hwloc\_cpuset\_t hwloc\_obj::online\_cpuset

The CPU set of online logical processors.

This includes the CPUs contained in this object that are online, i.e. draw power and can execute threads. It may however not be allowed to bind to them due to administration rules, see allowed\_cpuset.

Note

Its value must not be changed, hwloc\_bitmap\_dup must be used instead.

19.8.2.23 unsigned hwloc\_obj::os\_index

OS-provided physical index number.

19.8.2.24 signed hwloc\_obj::os\_level

OS-provided physical level, -1 if unknown or meaningless.

19.8.2.25 struct hwloc\_obj\* hwloc\_obj::parent

Parent, NULL if root (system object)

19.8.2.26 struct hwloc\_obj\* hwloc\_obj::prev\_cousin

Previous object of same type and depth.

19.8.2.27 struct hwloc\_obj\* hwloc\_obj::prev\_sibling

Previous object below the same parent.

19.8.2.28 unsigned hwloc\_obj::sibling\_rank

Index in parent's children[] array.

19.8.2.29 int hwloc\_obj::symmetric\_subtree

Set if the subtree of objects below this object is symmetric, which means all children and their children have identical subtrees. If set in the topology root object, Istopo may export the topology as a synthetic string.

19.8.2.30 hwloc\_obj\_type\_t hwloc\_obj::type

Type of object.

19.8.2.31 void\* hwloc\_obj::userdata

Application-given private data pointer, initialized to NULL, use it as you wish. See <a href="https://hww.nuc.edu.nuc.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.9 hwloc\_obj\_attr\_u Union Reference

#include <hwloc.h>

#### **Data Structures**

- struct hwloc\_bridge\_attr\_s
- struct hwloc\_cache\_attr\_s
- struct hwloc\_group\_attr\_s
- struct hwloc\_osdev\_attr\_s
- · struct hwloc pcidev attr s

#### **Data Fields**

- struct hwloc\_obj\_attr\_u::hwloc\_cache\_attr\_s cache
- struct hwloc\_obj\_attr\_u::hwloc\_group\_attr\_s group
- struct hwloc\_obj\_attr\_u::hwloc\_pcidev\_attr\_s pcidev
- struct hwloc\_obj\_attr\_u::hwloc\_bridge\_attr\_s bridge
- struct hwloc obj attr u::hwloc osdev attr s osdev

#### 19.9.1 Detailed Description

Object type-specific Attributes.

#### 19.9.2 Field Documentation

```
19.9.2.1 struct hwloc_obj_attr_u::hwloc_bridge_attr_s hwloc_obj_attr_u::bridge
```

19.9.2.2 struct hwloc\_obj\_attr\_u::hwloc\_cache\_attr\_s hwloc\_obj\_attr\_u::cache

19.9.2.3 struct hwloc\_obj\_attr\_u::hwloc\_group\_attr\_s hwloc\_obj\_attr\_u::group

19.9.2.4 struct hwloc\_obj\_attr\_u::hwloc\_osdev\_attr\_s hwloc\_obj\_attr\_u::osdev

19.9.2.5 struct hwloc\_obj\_attr\_u::hwloc\_pcidev\_attr\_s hwloc\_obj\_attr\_u::pcidev

The documentation for this union was generated from the following file:

· hwloc.h

## 19.10 hwloc\_obj\_info\_s Struct Reference

```
#include <hwloc.h>
```

#### **Data Fields**

- char \* name
- char \* value

### 19.10.1 Detailed Description

Object info.

#### 19.10.2 Field Documentation

19.10.2.1 char\* hwloc\_obj\_info\_s::name

Info name.

19.10.2.2 char\* hwloc\_obj\_info\_s::value

Info value.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.11 hwloc\_obj\_memory\_s::hwloc\_obj\_memory\_page\_type\_s Struct Reference

#include <hwloc.h>

#### **Data Fields**

- hwloc\_uint64\_t size
- hwloc\_uint64\_t count

## 19.11.1 Detailed Description

Array of local memory page types, NULL if no local memory and page\_types is 0.

The array is sorted by increasing size fields. It contains page\_types\_len slots.

#### 19.11.2 Field Documentation

19.11.2.1 hwloc\_uint64\_t hwloc\_obj\_memory\_s::hwloc\_obj\_memory\_page\_type\_s::count

Number of pages of this size.

19.11.2.2 hwloc\_uint64\_t hwloc\_obj\_memory\_s::hwloc\_obj\_memory\_page\_type\_s::size

Size of pages.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.12 hwloc\_obj\_memory\_s Struct Reference

#include <hwloc.h>

#### **Data Structures**

• struct hwloc\_obj\_memory\_page\_type\_s

#### **Data Fields**

- hwloc uint64 t total memory
- hwloc\_uint64\_t local\_memory
- unsigned page\_types\_len
- struct

hwloc\_obj\_memory\_s::hwloc\_obj\_memory\_page\_type\_s \* page\_types

#### 19.12.1 Detailed Description

Object memory.

#### 19.12.2 Field Documentation

19.12.2.1 hwloc\_uint64\_t hwloc\_obj\_memory\_s::local\_memory

Local memory (in bytes)

19.12.2.2 struct hwloc\_obj\_memory\_s::hwloc\_obj\_memory\_page\_type\_s \* hwloc\_obj\_memory\_s::page\_types

19.12.2.3 unsigned hwloc\_obj\_memory\_s::page\_types\_len

Size of array page\_types.

19.12.2.4 hwloc\_uint64\_t hwloc\_obj\_memory\_s::total\_memory

Total memory (in bytes) in this object and its children.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.13 hwloc\_obj\_attr\_u::hwloc\_osdev\_attr\_s Struct Reference

```
#include <hwloc.h>
```

#### **Data Fields**

hwloc\_obj\_osdev\_type\_t type

## 19.13.1 Detailed Description

OS Device specific Object Attributes.

#### 19.13.2 Field Documentation

19.13.2.1 hwloc\_obj\_osdev\_type\_t hwloc\_obj\_attr\_u::hwloc\_osdev\_attr\_s::type

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.14 hwloc\_obj\_attr\_u::hwloc\_pcidev\_attr\_s Struct Reference

#include <hwloc.h>

#### **Data Fields**

- · unsigned short domain
- · unsigned char bus
- unsigned char dev
- · unsigned char func
- unsigned short class\_id
- · unsigned short vendor\_id
- · unsigned short device\_id
- unsigned short subvendor\_id
- · unsigned short subdevice\_id
- unsigned char revision
- · float linkspeed

#### 19.14.1 Detailed Description

PCI Device specific Object Attributes.

#### 19.14.2 Field Documentation

19.14.2.1	unsigned char hwloc_obj_attr_u::hwloc_pcidev_attr_s::bus
19.14.2.2	unsigned short hwloc_obj_attr_u::hwloc_pcidev_attr_s::class_id
19.14.2.3	unsigned char hwloc_obj_attr_u::hwloc_pcidev_attr_s::dev
19.14.2.4	unsigned short hwloc_obj_attr_u::hwloc_pcidev_attr_s::device_id
19.14.2.5	unsigned short hwloc_obj_attr_u::hwloc_pcidev_attr_s::domain
19.14.2.6	unsigned char hwloc_obj_attr_u::hwloc_pcidev_attr_s::func
19.14.2.7	float hwloc_obj_attr_u::hwloc_pcidev_attr_s::linkspeed
19.14.2.8	unsigned char hwloc_obj_attr_u::hwloc_pcidev_attr_s::revision

19.14.2.9 unsigned short hwloc\_obj\_attr\_u::hwloc\_pcidev\_attr\_s::subdevice\_id

19.14.2.10 unsigned short hwloc\_obj\_attr\_u::hwloc\_pcidev\_attr\_s::subvendor\_id

19.14.2.11 unsigned short hwloc\_obj\_attr\_u::hwloc\_pcidev\_attr\_s::vendor\_id

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.15 hwloc\_topology\_cpubind\_support Struct Reference

#include <hwloc.h>

#### **Data Fields**

- · unsigned char set thisproc cpubind
- unsigned char get\_thisproc\_cpubind
- unsigned char set\_proc\_cpubind
- · unsigned char get proc cpubind
- · unsigned char set thisthread cpubind
- unsigned char get\_thisthread\_cpubind
- unsigned char set\_thread\_cpubind
- · unsigned char get\_thread\_cpubind
- · unsigned char get thisproc last cpu location
- · unsigned char get\_proc\_last\_cpu\_location
- · unsigned char get\_thisthread\_last\_cpu\_location

#### 19.15.1 Detailed Description

Flags describing actual PU binding support for this topology.

#### 19.15.2 Field Documentation

19.15.2.1 unsigned char hwloc\_topology\_cpubind\_support::get\_proc\_cpubind

Getting the binding of a whole given process is supported.

19.15.2.2 unsigned char hwloc\_topology\_cpubind\_support::get\_proc\_last\_cpu\_location

Getting the last processors where a whole process ran is supported

19.15.2.3 unsigned char hwloc\_topology\_cpubind\_support::get\_thisproc\_cpubind

Getting the binding of the whole current process is supported.

19.15.2.4 unsigned char hwloc\_topology\_cpubind\_support::get\_thisproc\_last\_cpu\_location

Getting the last processors where the whole current process ran is supported

19.15.2.5 unsigned char hwloc\_topology\_cpubind\_support::get\_thisthread\_cpubind

Getting the binding of the current thread only is supported.

19.15.2.6 unsigned char hwloc\_topology\_cpubind\_support::get\_thisthread\_last\_cpu\_location

Getting the last processors where the current thread ran is supported

19.15.2.7 unsigned char hwloc\_topology\_cpubind\_support::get\_thread\_cpubind

Getting the binding of a given thread only is supported.

19.15.2.8 unsigned char hwloc\_topology\_cpubind\_support::set\_proc\_cpubind

Binding a whole given process is supported.

19.15.2.9 unsigned char hwloc\_topology\_cpubind\_support::set\_thisproc\_cpubind

Binding the whole current process is supported.

19.15.2.10 unsigned char hwloc\_topology\_cpubind\_support::set\_thisthread\_cpubind

Binding the current thread only is supported.

19.15.2.11 unsigned char hwloc\_topology\_cpubind\_support::set\_thread\_cpubind

Binding a given thread only is supported.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.16 hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_generic\_s Struct Reference

#include <diff.h>

#### **Data Fields**

- hwloc\_topology\_diff\_type\_t type
- union hwloc topology diff u \* next

#### 19.16.1 Field Documentation

19.16.1.1 union hwloc\_topology\_diff\_u\* hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_generic\_s::next

19.16.1.2 hwloc topology diff type t hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_generic\_s::type

The documentation for this struct was generated from the following file:

· diff.h

# 19.17 hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_generic\_s Struct Reference

#include <diff.h>

#### **Data Fields**

hwloc\_topology\_diff\_obj\_attr\_type\_t type

#### 19.17.1 Field Documentation

19.17.1.1 hwloc\_topology\_diff\_obj\_attr\_type\_t hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_generic\_s 
::type

The documentation for this struct was generated from the following file:

· diff.h

## 19.18 hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_obj\_attr\_s Struct Reference

```
#include <diff.h>
```

#### **Data Fields**

- hwloc\_topology\_diff\_type\_t type
- union hwloc topology diff u \* next
- unsigned obj\_depth
- · unsigned obj\_index
- union

hwloc\_topology\_diff\_obj\_attr\_u diff

#### 19.18.1 Field Documentation

19.18.1.1 union hwloc\_topology\_diff\_obj\_attr\_u hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_obj\_attr\_s::diff

```
19.18.1.2 union hwloc_topology_diff_u* hwloc_topology_diff_u::hwloc_topology_diff_obj_attr_s::next
```

19.18.1.3 unsigned hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_obj\_attr\_s::obj\_depth

19.18.1.4 unsigned hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_obj\_attr\_s::obj\_index

19.18.1.5 hwloc\_topology\_diff\_type\_t hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_obj\_attr\_s::type

The documentation for this struct was generated from the following file:

· diff.h

# 19.19 hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_string\_s Struct Reference

#include <diff.h>

#### **Data Fields**

- hwloc\_topology\_diff\_obj\_attr\_type\_t type
- char \* name
- char \* oldvalue
- char \* newvalue

#### 19.19.1 Detailed Description

String attribute modification with an optional name.

#### 19.19.2 Field Documentation

- 19.19.2.1 char\* hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_string\_s::name
- 19.19.2.2 char\* hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_string\_s::newvalue
- 19.19.2.3 char\* hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_string\_s::oldvalue
- 19.19.2.4 hwloc\_topology\_diff\_obj\_attr\_type\_t hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_string\_s::type

The documentation for this struct was generated from the following file:

· diff.h

## 19.20 hwloc topology diff obj attr u Union Reference

#include <diff.h>

#### **Data Structures**

- struct hwloc\_topology\_diff\_obj\_attr\_generic\_s
- struct hwloc\_topology\_diff\_obj\_attr\_string\_s
- struct hwloc\_topology\_diff\_obj\_attr\_uint64\_s

#### **Data Fields**

- struct
   hwloc topology diff obj attr u::hwloc topology diff obj attr generic s generic
- struct hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_uint64\_s uint64
- struct hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_string\_s string

#### 19.20.1 Detailed Description

One object attribute difference.

#### 19.20.2 Field Documentation

- 19.20.2.1 struct hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_generic\_s hwloc\_topology\_diff\_obj\_attr\_u::generic
- 19.20.2.2 struct hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_string\_s hwloc\_topology\_diff\_obj\_attr\_u::string
- 19.20.2.3 struct hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_uint64\_s hwloc\_topology\_diff\_obj\_attr\_u::uint64

The documentation for this union was generated from the following file:

· diff.h

# 19.21 hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_uint64\_s Struct Reference

#include <diff.h>

#### **Data Fields**

- hwloc\_topology\_diff\_obj\_attr\_type\_t type
- hwloc\_uint64\_t index
- hwloc\_uint64\_t oldvalue
- · hwloc uint64 t newvalue

#### 19.21.1 Detailed Description

Integer attribute modification with an optional index.

#### 19.21.2 Field Documentation

- 19.21.2.1 hwloc\_uint64\_t hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_uint64\_s::index
- 19.21.2.2 hwloc\_uint64\_t hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_uint64\_s::newvalue
- 19.21.2.3 hwloc\_uint64\_t hwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_uint64\_s::oldvalue
- 19.21.2.4 hwloc topology diff\_obj\_attr\_type thwloc\_topology\_diff\_obj\_attr\_u::hwloc\_topology\_diff\_obj\_attr\_uint64\_s::type

The documentation for this struct was generated from the following file:

· diff.h

## 19.22 hwloc topology diff u::hwloc topology diff too complex s Struct Reference

#include <diff.h>

#### **Data Fields**

- hwloc\_topology\_diff\_type\_t type
- union hwloc\_topology\_diff\_u \* next
- · unsigned obj depth
- · unsigned obj index

#### 19.22.1 Field Documentation

- 19.22.1.1 union hwloc\_topology\_diff\_u\* hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_too\_complex\_s::next
- 19.22.1.2 unsigned hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_too\_complex\_s::obj\_depth
- 19.22.1.3 unsigned hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_too\_complex\_s::obj\_index
- 19.22.1.4 hwloc\_topology\_diff\_type\_t hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_too\_complex\_s::type

The documentation for this struct was generated from the following file:

• diff.h

## 19.23 hwloc\_topology\_diff\_u Union Reference

#include <diff.h>

#### **Data Structures**

- struct hwloc\_topology\_diff\_generic\_s
- struct hwloc\_topology\_diff\_obj\_attr\_s
- struct hwloc\_topology\_diff\_too\_complex\_s

#### **Data Fields**

- struct hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_generic\_s generic
- struct hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_obj\_attr\_s obj\_attr
- struct hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_too\_complex\_s too\_complex

#### 19.23.1 Detailed Description

One element of a difference list between two topologies.

#### 19.23.2 Field Documentation

- 19.23.2.1 struct hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_generic\_s hwloc\_topology\_diff\_u::generic
- $19.23.2.2 \quad struct \ hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_obj\_attr\_s \ hwloc\_topology\_diff\_u::obj\_attr\_s \ hwloc\_topology\_diff\_u::$
- 19.23.2.3 struct hwloc\_topology\_diff\_u::hwloc\_topology\_diff\_too\_complex\_s hwloc\_topology\_diff\_u::too\_complex

The documentation for this union was generated from the following file:

· diff.h

## 19.24 hwloc\_topology\_discovery\_support Struct Reference

```
#include <hwloc.h>
```

#### **Data Fields**

· unsigned char pu

### 19.24.1 Detailed Description

Flags describing actual discovery support for this topology.

#### 19.24.2 Field Documentation

19.24.2.1 unsigned char hwloc\_topology\_discovery\_support::pu

Detecting the number of PU objects is supported.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.25 hwloc\_topology\_membind\_support Struct Reference

#include <hwloc.h>

#### **Data Fields**

- unsigned char set\_thisproc\_membind
- unsigned char get\_thisproc\_membind
- · unsigned char set\_proc\_membind
- unsigned char get\_proc\_membind
- · unsigned char set\_thisthread\_membind
- · unsigned char get\_thisthread\_membind
- unsigned char set\_area\_membind
- unsigned char get\_area\_membind
- unsigned char alloc\_membind
- · unsigned char firsttouch\_membind
- · unsigned char bind membind
- · unsigned char interleave\_membind
- unsigned char replicate\_membind
- unsigned char nexttouch\_membind
- unsigned char migrate\_membind

#### 19.25.1 Detailed Description

Flags describing actual memory binding support for this topology.

#### 19.25.2 Field Documentation

19.25.2.1 unsigned char hwloc\_topology\_membind\_support::alloc\_membind

Allocating a bound memory area is supported.

19.25.2.2 unsigned char hwloc\_topology\_membind\_support::bind\_membind

Bind policy is supported.

- 19.25.2.3 unsigned char hwloc\_topology\_membind\_support::firsttouch\_membind First-touch policy is supported.
- 19.25.2.4 unsigned char hwloc\_topology\_membind\_support::get\_area\_membind

  Getting the binding of a given memory area is supported.
- 19.25.2.5 unsigned char hwloc\_topology\_membind\_support::get\_proc\_membind

  Getting the binding of a whole given process is supported.
- 19.25.2.6 unsigned char hwloc\_topology\_membind\_support::get\_thisproc\_membind

  Getting the binding of the whole current process is supported.
- 19.25.2.7 unsigned char hwloc\_topology\_membind\_support::get\_thisthread\_membind
  Getting the binding of the current thread only is supported.
- 19.25.2.8 unsigned char hwloc\_topology\_membind\_support::interleave\_membind Interleave policy is supported.
- 19.25.2.9 unsigned char hwloc\_topology\_membind\_support::migrate\_membind Migration flags is supported.
- 19.25.2.10 unsigned char hwloc\_topology\_membind\_support::nexttouch\_membind

  Next-touch migration policy is supported.
- 19.25.2.11 unsigned char hwloc\_topology\_membind\_support::replicate\_membind Replication policy is supported.
- 19.25.2.12 unsigned char hwloc\_topology\_membind\_support::set\_area\_membind

  Binding a given memory area is supported.
- 19.25.2.13 unsigned char hwloc\_topology\_membind\_support::set\_proc\_membind Binding a whole given process is supported.

19.25.2.14 unsigned char hwloc\_topology\_membind\_support::set\_thisproc\_membind

Binding the whole current process is supported.

19.25.2.15 unsigned char hwloc\_topology\_membind\_support::set\_thisthread\_membind

Binding the current thread only is supported.

The documentation for this struct was generated from the following file:

· hwloc.h

## 19.26 hwloc\_topology\_support Struct Reference

#include <hwloc.h>

#### **Data Fields**

- struct hwloc\_topology\_discovery\_support \* discovery
- struct hwloc\_topology\_cpubind\_support \* cpubind
- struct hwloc\_topology\_membind\_support \* membind

## 19.26.1 Detailed Description

Set of flags describing actual support for this topology.

This is retrieved with <a href="https://www.nct.nobelogy\_get\_support(">https://www.nct.nobelogy\_get\_support()</a> and will be valid until the topology object is destroyed. Note: the values are correct only after discovery.

#### 19.26.2 Field Documentation

- 19.26.2.1 struct hwloc\_topology\_cpubind\_support\* hwloc\_topology\_support::cpubind
- 19.26.2.2 struct hwloc\_topology\_discovery\_support\* hwloc\_topology\_support::discovery
- $19.26.2.3 \quad struct \ hwloc\_topology\_membind\_support* \ hwloc\_topology\_support::membind$

The documentation for this struct was generated from the following file:

· hwloc.h

## Index

Building Custom Topologies, 101	HWLOC_DISC_COMPONENT_TYPE_GLOBAL
	Components and Plugins: Discovery components
CPU binding	140
HWLOC_CPUBIND_NOMEMBIND, 87	HWLOC_DISC_COMPONENT_TYPE_MISC
HWLOC_CPUBIND_PROCESS, 87	Components and Plugins: Discovery components
HWLOC_CPUBIND_STRICT, 87	140
HWLOC_CPUBIND_THREAD, 87	HWLOC_DISTRIB_FLAG_REVERSE
Components and Plugins: Discovery backends	Distributing items over a topology, 117
HWLOC_BACKEND_FLAG_NEED_LEVELS, 141	HWLOC MEMBIND BIND
Components and Plugins: Discovery components	Memory binding, 92
HWLOC_DISC_COMPONENT_TYPE_CPU, 140	HWLOC_MEMBIND_DEFAULT
HWLOC_DISC_COMPONENT_TYPE_GLOBAL,	Memory binding, 92
140	HWLOC_MEMBIND_FIRSTTOUCH
HWLOC_DISC_COMPONENT_TYPE_MISC, 140	Memory binding, 92
Components and Plugins: Generic components	HWLOC_MEMBIND_INTERLEAVE
HWLOC_COMPONENT_TYPE_DISC, 143	Memory binding, 92
HWLOC_COMPONENT_TYPE_XML, 143	HWLOC_MEMBIND_MIGRATE
	Memory binding, 92
Distributing items over a topology, 117	HWLOC MEMBIND MIXED
HWLOC_DISTRIB_FLAG_REVERSE, 117	Memory binding, 92
	HWLOC MEMBIND NEXTTOUCH
Exporting Topologies to Synthetic, 106	Memory binding, 92
HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_FL↔	HWLOC MEMBIND NOCPUBIND
AG_NO_ATTRS, 106	Memory binding, 92
HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_FL↔	HWLOC MEMBIND PROCESS
AG_NO_EXTENDED_TYPES, 106	Memory binding, 92
	HWLOC_MEMBIND_REPLICATE
Finding objects, miscellaneous helpers, 115	Memory binding, 92
LIMIT OO DAOMEND ELAO MEED LEMELO	HWLOC_MEMBIND_STRICT
HWLOC_BACKEND_FLAG_NEED_LEVELS	Memory binding, 92
Components and Plugins: Discovery backends, 141	HWLOC_MEMBIND_THREAD
HWLOC_COMPONENT_TYPE_DISC	Memory binding, 92
Components and Plugins: Generic components, 143	HWLOC_OBJ_BRIDGE
HWLOC_COMPONENT_TYPE_XML	Object Types, 69
Components and Plugins: Generic components, 143	HWLOC_OBJ_BRIDGE_HOST
HWLOC_CPUBIND_NOMEMBIND	
CPU binding, 87	Object Types, 68
HWLOC_CPUBIND_PROCESS	HWLOC_OBJ_BRIDGE_PCI
CPU binding, 87	Object Types, 68
HWLOC_CPUBIND_STRICT	HWLOC_OBJ_CACHE
CPU binding, 87	Object Types, 69
HWLOC_CPUBIND_THREAD	HWLOC_OBJ_CACHE_DATA
CPU binding, 87	Object Types, 68
HWLOC_DISC_COMPONENT_TYPE_CPU	HWLOC_OBJ_CACHE_INSTRUCTION
Components and Plugins: Discovery components,	Object Types, 68
140	HWLOC OBJ CACHE UNIFIED

INDEX 195

Object Types, 68 HWLOC_OBJ_CORE	HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_FLAG_↔ NO ATTRS
Object Types, 69	Exporting Topologies to Synthetic, 106
HWLOC_OBJ_GROUP	HWLOC_TOPOLOGY_EXPORT_SYNTHETIC_FLAG_↔
Object Types, 69	NO EXTENDED TYPES
HWLOC OBJ MACHINE	Exporting Topologies to Synthetic, 106
Object Types, 69	HWLOC_TOPOLOGY_FLAG_ICACHES
HWLOC_OBJ_MISC	Topology Detection Configuration and Query, 75
Object Types, 69	HWLOC_TOPOLOGY_FLAG_IO_BRIDGES
HWLOC_OBJ_NODE	Topology Detection Configuration and Query, 75
	HWLOC TOPOLOGY FLAG IO DEVICES
Object Types, 69	Topology Detection Configuration and Query, 75
HWLOC_OBJ_OS_DEVICE	HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM
Object Types, 69	Topology Detection Configuration and Query, 75
HWLOC_OBJ_OSDEV_BLOCK	HWLOC_TOPOLOGY_FLAG_WHOLE_IO
Object Types, 68	Topology Detection Configuration and Query, 75
HWLOC_OBJ_OSDEV_COPROC	HWLOC TOPOLOGY FLAG WHOLE SYSTEM
Object Types, 68	Topology Detection Configuration and Query, 75
HWLOC_OBJ_OSDEV_DMA	HWLOC_TYPE_DEPTH_BRIDGE
Object Types, 68	Object levels, depths and types, 80
HWLOC_OBJ_OSDEV_GPU	HWLOC_TYPE_DEPTH_MULTIPLE
Object Types, 68	Object levels, depths and types, 80
HWLOC_OBJ_OSDEV_NETWORK	HWLOC_TYPE_DEPTH_OS_DEVICE
Object Types, 68	Object levels, depths and types, 80
HWLOC_OBJ_OSDEV_OPENFABRICS	HWLOC_TYPE_DEPTH_PCI_DEVICE
Object Types, 68	Object levels, depths and types, 80
HWLOC_OBJ_PCI_DEVICE	HWLOC_TYPE_DEPTH_UNKNOWN
Object Types, 69	Object levels, depths and types, 80
HWLOC_OBJ_PU	HWLOC_TYPE_UNORDERED
Object Types, 69	Object Types, 68
HWLOC_OBJ_SOCKET	
Object Types, 69	Interoperability with glibc sched affinity, 152
HWLOC_OBJ_SYSTEM	Interoperability with Linux libnuma bitmask, 150
Object Types, 69	Interoperability with Linux libnuma unsigned long masks,
HWLOC_OBJ_TYPE_MAX	148
Object Types, 69	Interoperability with Myrinet Express, 166
HWLOC_RESTRICT_FLAG_ADAPT_DISTANCES	Linux anadiia halmara 147
Modifying a loaded Topology, 99	Linux-specific helpers, 147  Looking at Ancestor and Child Objects, 112
HWLOC_RESTRICT_FLAG_ADAPT_IO	•
Modifying a loaded Topology, 99	Looking at Cache Objects, 114
HWLOC_RESTRICT_FLAG_ADAPT_MISC	Manipulating Distances, 123
Modifying a loaded Topology, 99	Manipulating Object Type, Sets and Attributes as Strings,
HWLOC_TOPOLOGY_DIFF_APPLY_REVERSE	83
Topology differences, 136	Memory binding, 90
HWLOC_TOPOLOGY_DIFF_OBJ_ATTR	HWLOC MEMBIND BIND, 92
Topology differences, 137	HWLOC_MEMBIND_DEFAULT, 92
HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_INFO	HWLOC_MEMBIND_FIRSTTOUCH, 92
Topology differences, 136	HWLOC_MEMBIND_INTERLEAVE, 92
HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_NAME	HWLOC_MEMBIND_MIGRATE, 92
Topology differences, 136	HWLOC_MEMBIND_MIXED, 92
HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_SIZE	HWLOC_MEMBIND_NEXTTOUCH, 92
Topology differences, 136	HWLOC_MEMBIND_NOCPUBIND, 92
HWLOC_TOPOLOGY_DIFF_TOO_COMPLEX	HWLOC_MEMBIND_PROCESS, 92
Topology differences, 137	HWLOC_MEMBIND_REPLICATE, 92

196 INDEX

```
HWLOC_MEMBIND_STRICT, 92
                                                 HWLOC_TOPOLOGY_DIFF_OBJ_ATTR_INFO, 136
   HWLOC MEMBIND THREAD, 92
                                                 HWLOC TOPOLOGY DIFF OBJ ATTR NAME,
Modifying a loaded Topology, 99
                                                     136
   HWLOC RESTRICT FLAG ADAPT DISTANCES,
                                                 HWLOC TOPOLOGY DIFF OBJ ATTR SIZE, 136
                                                 HWLOC_TOPOLOGY_DIFF_TOO_COMPLEX, 137
   HWLOC_RESTRICT_FLAG_ADAPT_IO, 99
   HWLOC_RESTRICT_FLAG_ADAPT_MISC, 99
Object levels, depths and types, 80
   HWLOC TYPE DEPTH BRIDGE, 80
   HWLOC TYPE DEPTH MULTIPLE, 80
   HWLOC TYPE DEPTH OS DEVICE, 80
   HWLOC TYPE DEPTH PCI DEVICE, 80
   HWLOC_TYPE_DEPTH_UNKNOWN, 80
Object Structure and Attributes, 71
Object Types, 67
   HWLOC OBJ BRIDGE, 69
   HWLOC_OBJ_BRIDGE_HOST, 68
   HWLOC OBJ BRIDGE PCI, 68
   HWLOC_OBJ_CACHE, 69
   HWLOC OBJ CACHE DATA, 68
   HWLOC OBJ CACHE INSTRUCTION, 68
   HWLOC OBJ CACHE UNIFIED, 68
   HWLOC OBJ CORE, 69
   HWLOC OBJ GROUP, 69
   HWLOC_OBJ_MACHINE, 69
   HWLOC OBJ MISC, 69
   HWLOC OBJ NODE, 69
   HWLOC OBJ OS DEVICE, 69
   HWLOC OBJ OSDEV BLOCK, 68
   HWLOC_OBJ_OSDEV_COPROC, 68
   HWLOC OBJ OSDEV DMA, 68
   HWLOC OBJ OSDEV GPU, 68
   HWLOC OBJ OSDEV NETWORK, 68
   HWLOC_OBJ_OSDEV_OPENFABRICS, 68
   HWLOC OBJ PCI DEVICE, 69
   HWLOC_OBJ_PU, 69
   HWLOC OBJ SOCKET, 69
   HWLOC OBJ SYSTEM, 69
   HWLOC OBJ TYPE MAX, 69
   HWLOC_TYPE_UNORDERED, 68
Topology Creation and Destruction, 72
Topology Detection Configuration and Query, 74
   HWLOC_TOPOLOGY_FLAG_ICACHES, 75
   HWLOC_TOPOLOGY_FLAG_IO_BRIDGES, 75
   HWLOC_TOPOLOGY_FLAG_IO_DEVICES, 75
   HWLOC_TOPOLOGY_FLAG_IS_THISSYSTEM, 75
   HWLOC TOPOLOGY FLAG WHOLE IO, 75
   HWLOC_TOPOLOGY_FLAG_WHOLE_SYSTEM,
Topology differences, 135
   HWLOC TOPOLOGY DIFF APPLY REVERSE,
```

HWLOC TOPOLOGY DIFF OBJ ATTR, 137