digitals

Electronic Security Solutions

# USER MANUAL

## FG-04

TYPE : Fire Guard
(PSTN,GSM+IP Comm.)

Caution:- Please read this manual carefully before operating your product and retain it for future reference.

# Automatic Fire Detection & Alarm System




www.digitalsindia.com

digitals
Electronic Security Solutions

# Fire Detection & Alarm Systems

## Overview

An Automatic Fire Detection & Alarm System is designed to detect and alert individuals to the presence of fire, smoke, or carbon monoxide in a building. These systems are crucial in preventing fire-related injuries and property damage by providing early warnings, facilitating safe evacuation, and enabling emergency responders to act promptly.

## Contents :-


- About us
- Salient Features
- Technical Specifications
- Programming Options
- Installation Cinnections

# What is **Automatic Fire Detection & Alarm System**







A fire alarm system is a network of devices designed to detect and alert people to the presence of fire, smoke, or carbon monoxide in a building. These systems help prevent fire-related injuries and property damage by providing early warnings, allowing occupants to evacuate safely and emergency responders to take action quickly.

# Introduction

Welcome to the DISPPL family! We are thrilled you've chosen DI- FIRE FG Series. This guide will help you get the most out of your new device. Read through this quick start manual carefully to ensure safe and proper use of your device. We wish you a peaceful life and an enjoyable digitals experience.

# About us

digitals
Electronic Security Solutions

**Digitals India** is the pioneer of commercial security industry with wide range of solutions developed & deployed over the period of 39 glorious years.

With company's corporate office in NOIDA U.P., we cover the entire Nation with our sixteen (16) Regional offices & subsequent service centers in PAN India.

Our 400+ manpower with maximum on- field technicians helps us achieve the position as the leader of the industry.

For becoming the choice for end users, our innovation team has innovated & launched more than 100 + customized products. From 'Analog Door Alarm Systems' to the most advanced 'IP based Security Panels', We provide comprehensive security solutions to cover the security gaps for the customers & mitigate risks.



# **Salient** Features

digitals
Electronic Security Solutions

- Microcontroller controlled 2/4/8/16 hardwired zones & 8 wireless zones(optional).
- Built-in GSM module can SMS alarm in English.
- Can be used with SMS Alarm Center to control the alarm unit.
- Inbuilt IP Module and can send alarm to CMS center using external CMS module (NG) using CONTACT ID protocol.
- Easy programming using by SMS (Admin. Phone)/Onboard keypad (Phone ID & Password protected).
- 30 operators for Reset or Alarm through SMS or RF remote with Phone ID & password protection.
- Automatic isolation of faulty (OPEN/SHORT) zones on reset.
- SMS messages for each zone can be programmed.
- LED indications for GSM Network, Isolated zone, Alarm, System Status.
- Users can inquire about the working state of the alarm unit through SMS.
- Built-in MIC for Monitoring site voice.
- 24V Hooter output for Alarm.
- Relay Alarm output for Alarm.
- In built RTC for time accuracy.
- SMPS power supply for universal voltage operation (90V to 270V AC).
- All zones are programmable for Single/double trigger, cross zone.
- Inbuilt solar charger (recommended 20W, 24V panel).
- Thermal printer support for log events.
- Smart battery charger for better life of battery.
- Complies to all BIS standards (all variants).

*Features may vary depending on the variant.

# Technical Specifications



| | |
|---|---|
| **Electrical Specifications** | |
| Operating Voltage | 24 volts DC |
| Stand by Batteries | 24 volts DC (2X12 volt DC) |
| Stand by Current | 100 mA |
| **Power** | |
| Mains | 90-270 Volts 50 Hz to the internal SMPS for high voltage fluctuation tolerance |
| Input | 24-28 volt from internal SMPS |
| Output | 24 volt DC |
| Charging Voltage | 28 V (DC) |
| EOL Resistance | 4.7K Ohms |
| Standby Current | 1. <100mA @ 24Volt Battery with GSM/IP module & EOL resistance 4.7k ohms (standby mode)<br><br>2. <130mA @ 24V with backlight LCD ON |
| **MISC.** | |
| Protection | Built-in Surge Protector for high voltage spikes |
| Ext. Output | 1 Relay output, Hooter outputs |
| Indication | LED, Onboard LCD & Audio Indications for various functions |

# Programming



**Fire Guard FG 04 IP**

**IP+GSM+PSTN Auto Dialer**



**Fire Guard FG 04 D**

**GSM+PSTN Auto Dialer**

## 1. Entering the programming menu

Code for entering the programming mode of the system:

Step 1: Press 'ENTER'
Step 2: Enter your '2-Digit User No.'
Step 3: Enter your '4-Digit Pass Code'
Step 4: Press '*'
Step 5: Press '55'
Step 6: Press 'Enter'

e.g. <ENTER> 00 1234 * 55 <ENTER> )
where 00 is user ID, 1234 is password & *55 is programming code.

## 2. **Explanation of Menu options with their purpose**

The menu options of the device are very easy to understand. No Coding is required for the programming of the system. Simple programming options help installers to easily programming the system within seconds.

Please see the below table to understand the purpose of each setting:

- Baud Rate
- Protection Mode
- Date /Time Set
- Evacuate
- Voice Monitor
- Dialer
- CMS Number
- Alarm Duration
- Zones Setting
- Users Setting
- Passcode Edit
- System Log
- Default Settings
- System Mode
- Product ID
- Product Address

# INSTALLATION CONNECTIONS

digitals
Electronic Security Solutions

| Sr.No. | Name:- | Connection |
|---|---|---|
| 1 | 220v AC<br>E. P. N. | Connect the AC 220V,50Hz, for Input. |
| 2 | SOL(+,-) | For Solar Input (20 W, 24V). |
| 3 | BAT.(+,-) | Input 24v 7Ah DC (2x12V Battery). |
| 4 | ON/OFF | For manually panel off. |
| 5 | 24v | 24V DC Output. |
| 6 | Zones<br>(4/8/16) | Connect the sensors (heat detector, smoke detector, flame detector, multicriteria detector, manual call point) you can connect the all types of heat & smoke (fire) sensors on the zones with 4.7k ohms EOL Resistance. |
| 7 | H1,GND,H | Connect the (24V) 2- Fire Hooters. |
| 8 | NO, C, NC | Relay output for other device triggering. |
| 9 | Sig (+,-) | To trigger for External Device. |
| 10 | A, B, +, - | A,B- Signal For external key-pad, (+,- for 12V |
| 11 | RX, TX | Connect the Thermal Printer. |
| 12 | GSM SIM slot | Insert the SIM Card. |
| 13 | GSM Antenna connector | Connect the GSM Antenna. |

digitals
Electronic Security Solutions

# YOUR SAFETY IS OUR RESPONSIBILITY!!



# Thank You

MAKE IN INDIA

**STRONG ROOTING IN TECHNOLOGY**

*Contact for Channel Sales : +91 9212787332*
*sales1@digitalsindia.com*
*C-22, Sector 63, Noida, UP-201301*

www.digitalsindia.com