



1. Apply loctite 290, Item 60, to all of the threads where the screw exits the Pem fastener on the back of the plate.



