
# Physical Layer: Theory

Kameswari Chebrolu

## Recap

- Nodes generate data (bits: 1's and 0's)
- Links carry signals in the form of electromagnetic waves
- Task on hand: Convert data into signals
  - Process termed: Encoding/Modulation
- First: Some Theory



### **Link Characteristics**


- Data Rate: How many bits per second can be transferred on the link? (expressed in bps,kbps,Mbps,Gbps)
- Loss rate: What is the probability of packet error (or bit error) rate on the link?
- Delay: How much time does it take for the bits to reach other end?

# Simple Encoding

Data: 101111011


Your Friend (Far Away)
Wire Pair
I will follow the wire, reach other
end and convey the data in person

How would you send the data over the wires?





# Signals and Bandwidth


 Fourier Analysis shows that any signal can be decomposed to sinusoids of different amplitude, frequency and phases



$$s(t) = A \times \frac{4}{\pi} \times \sum_{k \text{ odd}, k=1}^{\infty} \frac{\sin(2\pi k f t)}{k}$$








**Fourier Transform** 

### NRZ bandwidth


- Spectrum of a signal:
   Range of frequencies it contains
- Bandwidth: width of the spectrum
  - First Null Bandwidth = 1/T




Spectrum of a random NRZ signal

### **Link Bandwidth**

 How much link bandwidth do I need to recover signal?




Random NRZ Signal Bandwidth



## Nyquist Rate

- The number of independent pulses that could be put through a channel per unit time is limited to twice the bandwidth of the channel
- $f_p <= 2B$ 
  - $f_p$  is pulse rate (number of pulses/sec)
  - B is bandwidth of the channel
- Example: Binary pulse with rate 2000 bps needs link bandwidth of at least 1000 Hz

## **Effect of Noise**



### Shannon's Theorem

- Provides an upper bound to the capacity (bps) of a link
- $C = B \log_2 (1 + S/N)$  bits/sec
  - C: capacity (bps), B: channel bandwidth (Hz), S/N: signal to noise ratio
  - S/N often expressed in dB, 10log<sub>10</sub>(S/N)
    - E.g. 30dB corresponds to a ratio of 1000
- Example: Data over telephone line calculation
- B = 3300Hz 300Hz = 3000Hz; S/N = 1000 (30db); C ~ 30kbps

# **Implications**


- If R < C, there exists a coding technique which permits transmission of data with arbitrary small error
  - The theorem does not specify how to reach this bound
  - Real systems rarely achieve this upper bound
  - E.g. WiFi: 64-QAM Modulation operating in 20Mhz bandwidth needs SNR of 27dB for packet error rate under 10% to provide 54Mbps
    - R is 54Mbps rate, B is 20Mhz band,, C is 124Mbps
- If R > C, the probability of error increases without bound

#### **Error Rate**

- What is the probability of bit error on a link?
- Function of received SNR and type of modulation
- For a given modulation, charts of SNR vs BER are often provided

## Bit Error Rate (BER)

- Packet Error Rate
   (PER) = 1-(1-BER)<sup>N</sup>,
   where N is the size of
   packet in bits
  - BER 10<sup>-8</sup>, PER = 0.008%
- Typical BERs:
  - Wireless ~ 10<sup>-6</sup>,
     Twisted Pair ~ 10<sup>-8</sup>,
     Fiber-optics ~ 10<sup>-9</sup> to 10<sup>-12</sup>



## **Propagation Delay**

- Time required for a bit to propagate from beginning of link to end of the link
  - Depends on speed of light in the medium (S) & distance
     (D)
    - speed of light: 2\* 10<sup>8</sup> to 3 \* 10<sup>8</sup> m/s
  - Formula: D/S
- Note that Transmission delay(TD) is different from propagation delay
  - TD(sec) = Length of the packet (bits)/Data rate(bps)

Tx 
$$= 1 \text{Mbps} = 10^6 \text{ bps}$$
 $P = 1000 \text{ bits}$ 
 $P = 1000 \text{ bits$ 


RX

TX

1) = 2000 Km = 2 x 10 m

### Goals of Modulation

- Bandwidth Efficiency: Data-rate/bandwidth-required, bps/Hz
  - Goal: Try to reach Shannon limit
  - Real Systems: Ranges from 0.001 to 16
- Power Efficiency: Energy per bit/N<sub>o</sub>
  - N<sub>o</sub> is noise power spectral density
  - Goal: Minimize SNR required for a given BER
- Tradeoff bandwidth efficiency and power efficiency
  - Can achieve high BW only at the expense of more energy per bit



## Summary

- Signals and frequency domain representation (bandwidth they occupy)
- How many bits per sec can be sent on a link?
  - Upper bounded by Shannon theorem
  - In reality, depends on medium and modulation
- What is the packet error rate?
  - Function of BER which is determined by SNR and modulation
- Signal corresponding to a bit takes time to propagate
  - Propagation delay is function of speed of light in medium and distance
- Goals of Modulation