
## **LOGSIM 2.0 USER GUIDE**



Change how much of the signal trace you can see at one time (for both modes) **Terminal Controls** View list of help commands Toggle 3D Mode

1 Reset view (both modes)

3D MODE

- 2 Reset signal trace plots (both modes)
- Continue execution of circuit

- 4 Run circuit
- 5 Zap Monitor (only 2D)
- 6 Add Monitor (only 2D)