



01 / COLUMN SECTION A-A



02 / LINK + CROSS-TIE FORMS




R10 / PERIMETER



INTERNAL TIE

03 / CAGE ELEVATION




LINK ZONES / INDICATIVE

REINFORCEMENT KEY

- R09 / Longitudinal bars
- R10 / Perimeter links
- Internal ties shown as a separate layer.
- c / Cover dimension - project specific.

CONNECTION AT FLOOR LEVEL



SECTION CONTEXT / FLOOR + COLUMN

DRAWING NOTES

- Section dimensions are illustrative only.
- Bar counts do not represent a design.
- Cover and tie spacing require verification.
- Read the cage elevation with section A-A.

COLUMN SECTION STUDY

REINFORCEMENT / SCHEMATIC / NOT TO SCALE

PURPOSE

COMMUNICATION
STUDY ONLY

SHEET / REVISION

FW-S05 / 01