Nulaxy C900 Webcam User Manual

1 Introduction

The Nulaxy C900 webcam is a high-definition webcam designed for various applications such as video chatting, conferencing, webinars, and more. With advanced video processing technology and built-in features, it offers users a seamless experience for both video and audio communication.

2 Features

- Full HD 1080P Resolution: Capture sharp and clear images at 30fps for high-quality video.
- Plug & Play: Simply plug the USB cable into your computer's USB port; no drivers required.
- Rotation and Adjustable Clip: Enjoy a wide 92° view angle, 360° rotating head, and adjustable clip for optimal viewing angles and compatibility with laptops, monitors, PCs, or tripods.
- Built-in Stereo Microphone: Equipped with high sensitivity and echo-canceling technology, the built-in omnidirectional microphone captures clear sound in rich stereo audio from different angles.
- Privacy Shutter: The webcam includes a privacy cover to control what you want to show, protecting your privacy when not in use. Slide the cover to close when needed to block potential hackers.
- Universal Compatibility: Works with PC, notebooks, and laptops, compatible with Windows 7, 8, 10 and above, Linux 2.6.24, Mac OS 10.6, Android 5.1, and other operating systems. Supports major platforms such as Skype, OBS, Twitch, YouTube, FaceTime, Xbox, Xsplit, Twitter, WhatsApp, and more.
- Power Requirement: Working power of 200mA/5V.
- F23 Sensor: Includes F23 sensor for enhanced functionality.

3 Installation

- 1. Connect the webcam's USB cable to an available USB port on your computer.
- 2. Adjust the webcam's position using the rotating head and adjustable clip for optimal viewing angles.
- 3. If necessary, install any drivers or software provided by your operating system or preferred video conferencing platform (although typically not required).

4 Usage

- To start using the webcam, launch your preferred video conferencing or recording software.
- Ensure the webcam is selected as the video input device within the software settings.
- Adjust settings such as resolution, frame rate, and microphone sensitivity as needed within the software.

5 Maintenance

- Keep the webcam clean by wiping it with a soft, dry cloth.
- Avoid exposing the webcam to extreme temperatures, moisture, or direct sunlight.
- Store the webcam in a safe and dry location when not in use.

6 Troubleshooting

- If the webcam is not recognized by your computer, try connecting it to a different USB port or restarting your computer.
- Ensure that no other applications are currently using the webcam.
- Check for any updates to your operating system or video conferencing software that may resolve compatibility issues.

7 Warranty Information

For warranty information or technical support, please contact Nulaxy Customer Service at support@nulaxy.com.

8 Compliance and Safety

- This device complies with FCC regulations and CE standards.
- For safety reasons, do not disassemble or modify the webcam.
- Keep the webcam away from children and pets to avoid potential hazards.

9 Legal Notice

- All trademarks mentioned in this document belong to their respective owners.
- Nulaxy reserves the right to make changes to the product specifications or user manual without prior notice.

10 Feedback

We value your feedback! If you have any suggestions or comments regarding the Nulaxy C900 webcam, please contact us at feedback@nulaxy.com.

11 Disclaimer

Nulaxy is not liable for any damages or losses resulting from the use of this webcam beyond what is covered under the warranty. Users are responsible for ensuring compliance with local laws and regulations regarding privacy and data protection.