

STANDARD OPERATING PROCEDURE: PUMP P-101

Section: 1. Purpose & Scope

Document ID: SOP-101 | Version: v3.0 (Approved)

Effective Date: 15 January 2023 | Review Date: 15 January 2027

Applies to: P-101 and P-102 Centrifugal Pumps in Unit 2

Mandatory PPE: Safety Glasses, Steel-Toe Boots, Hearing Protection, Nomex Coveralls

STANDARD OPERATING PROCEDURE: PUMP P-101

Section: 2. Pre-Start Checks & Safety LOTO

Step 1: Verify Lockout/Tagout (LOTO) isolation status before opening casing.

Step 2: Inspect bearing housing oil level in sight glass (center of red mark).

Step 3: Confirm lubricant is clean ISO VG 46 oil free from moisture emulsification.

Step 4: Rotate pump shaft by hand to verify smooth rotation without binding.

Step 5: Ensure suction isolation valve is 100% OPEN before motor energization.

STANDARD OPERATING PROCEDURE: PUMP P-101

Section: 3. Alignment Verification Procedure

Step 6: Use dial indicators or laser alignment tool across flexible coupling.

Step 7: Maximum allowable radial angular misalignment: 0.05 mm.

Step 8: Check casing soft foot before tightening foundation anchor bolts.

Step 9: Monitor initial vibration for 30 minutes following restart. Stop if > 4.5 mm/s.