

GENERAL INDUSTRIAL PUMP LUBRICATION & MAINTENANCE GUIDELINES

Document Purpose: General Safety & Operating Best Practices

Target Audience: All Plant Maintenance Technicians

Document Code: GEN-SOP-LUBE-2026

General Guidelines:

1. Always de-energize and lock out equipment prior to entering pump volute or bearing housing.
2. Ensure clean grease gun tips to avoid introducing particulate contamination into ball or roller bearings.
3. Monitor casing skin temperature using infrared thermography during initial two hours after startup.
4. Replace mechanical seal face gaskets whenever the gland plate is loosened.

This is a general guideline document and does not specify any particular equipment asset.