Working with Fleets

> Access to the Fleets module is restricted to users with the **Admin**, **Project Manager, Mission Manager** and **Pilot** user role**s**. Other users will not be able to view or access this module.

The **Fleets** module is where you can manage your Drones, Payloads, and Pilots. Fleets also allows you to create teams that can be assigned individual projects for execution.

To access the **Fleets** module:

- On the **Modules** page, click **Fleets**.

Fleets on the Module page

OR

In the left navigation pane, click the **Applications** icon and then under **Quick Links**, click **Fleets**.

Fleets from Quick Links

The **Fleet** module main page is opened.

Learn more about

- **Resource Management**
- **Teams**

Previous Managing your Account on SkyDeck	Next Resource Management