
2 CPU Architecture: Fetch-Execute Cycle


2.1 CPU, Main memory, I/O units

Any modern digitcal computer can be described as having only three major **functional hardware units**:



(For now, we will ignore *secondary memory*, like hard disk drives.)

PC motherboard (Intel Pentium)



Bus

The functional units are interconnected to enable data transport (e.g., write CPU register **data** content to a certain **address** in memory)


- The unit ←→ unit interconnections are referred to as a busses
 - Bus: a bundle of conductors (wires/tracks) layed out on the motherboard (bus width = number of conductors in bundle)
- Data and addresses are communicated on separate data and address
 busses (history: e.g., Intel 8086 used shared data/address bus)

Examples

CPU	Address bus width	Data bus width
Intel Pentium IV	32	64
Intel Itanium	44	64

Bus

- Bus types:
 - ① data bus (move data)
 - ② address bus (select address in memory, select port in I/O unit)
 - (3) control bus (synchronize units, request action from unit, unit state)



Bus vs. point-to-point


• Point-to-point (p2p) interconnections may seem a viable alternative to the system bus concept

A fully wired motherboard with n units, however, would need $\frac{n \times (n-1)}{2}$ interconnections. Unmanageable.

Example: n = 30 units, data bus width 32, control bus width 6:

#wires =
$$\frac{30 \times 29}{2} \times (32+6)$$
 = 16530

Example: p2p interconnections for n = 2...6 units (and bus with 6 units):



The bus bottleneck

- **Note:** the bus architecture comes with a serious disadvantage:
 - An electronic bus can transfer only **one item at a time** (e.g., one data word, one address)
- The bus transmission speed thus poses a limit on the overall performance of the system (this phenomenon is known as the **bus bottleneck**)
 - Bus transmission speed is limited by physical characteristics (the capacitance and inductance of the bus wires)
 - Note that advances in CPU speed do not help here: the faster the CPU operates internally, the slower the bus transfers appear to be
 - While the CPU waits for a bus transfer to complete, the CPU is stalled

The CPU fetch-execute cycle

2.2 The CPU fetch—execute cycle

- A (non-parallel) CPU executes **one instruction at a time** (sequentially); a sequence of instructions is also referred to as a **program**
- On today's computers, data as well as programs reside in memory (this is known as the **von Neumann architecture**), the CPU thus iterates the following steps over and over:
 - ① Compute the **address of the next instruction**, advise main memory unit to read the data (= instruction) at the selected address (address/control bus)
 - (2) **Fetch the instruction** into the CPU (data bus)
 - (3) **Decode and execute** the instruction inside the CPU

Instruction decoding

 In a von Neumann computer, instructions are like any other data items stored in memory³

Example (decoding a Pentium instruction):

- Memory contents:

10111000 00000000 00000001

- This encodes the Pentium instruction MOV AX, 0x100:

(**mov**e value 0x100 into CPU register AX)


One equivalent instruction in C:

$$i = 256;$$

³Question: This is potential hazard and beneficial opportunity at the same time. How?

Fetch-execute cycle in detail

• The following units interact during the fetch—execute cycle:



- CPU registers:
 - accumulator AX, instruction pointer IP, instruction register IR
- Main memory:
 - memory address register MAR, main memory stores the instruction(s)

Fetch phase (identical for all instructions)

The address in the CPU register IP is transmitted via the address bus to the memory unit's MAR:

$$IP \rightarrow MAR$$


② IP is incremented to point at the next program instruction, ready for the next cycle (IP points at individual **bytes** [= 8 bits] in memory):

Memory selects addressed location and copies its contents onto the data bus; CPU loads received data into IR:

$$(MAR) \rightarrow IR$$

(4) CPU starts decoding the instruction in IR

Fetch phase (identical for all instructions)



Note:

- only the the instruction code (here: 1 byte) is copied into IR
- The actions on the control bus are not shown here

Execution phase (varies with instruction type)

This illustrates the execution phase of the MOV AX, c (move constant value c into register AX) instruction:

(1) IP is transferred via address bus into MAR of main memory

$$IP \rightarrow MAR$$


(2) IP is incremented

$$IP ++; IP ++;$$

The contents of the selected memory location is copied into CPU register AX (Pentium: actually EAX)

$$(MAR) \rightarrow AX$$

Execution phase (varies with instruction type)



Note:

- This time 16 bits (2 bytes) are copied via the data bus (the byte width of the data to be copied is encoded in the MOV instruction)
- Accordingly, IP is incremented twice to point after the data


Synchronous system bus

- One of the control bus lines is the **system clock**, whose signal is generated by a high-frequency crystal oscillator
- Normally, the CPU starts an operation by sending signals to other units (e.g., main memory) over the control bus
- The triggered unit may then take control of the system bus for a while (e.g., main memory transmits requested data over the data bus)
- Obviously, bus usage must follow a precise timing pattern (otherwise two units may want to use the bus simultaneously)



• If this timing pattern is completely locked into the system clock, the system is operating with a synchronous bus

Synchronous bus trace




Notes:

- Clock cycle 10 ns: all units run at 100 MHz, three cycles shown here
- The R/\overline{W} (read/write) signal is part of the control bus
- The bus contents are considered valid at times A, B, C (falling edges)
- The trace shows a *memory-to-memory* move instruction
- The CPU can only run as fast as the **slowest** unit on the bus

Instruction cycle timing

• As we have seen, a single instruction cycle (or fetch-execute cycle) itself is comprised of a number of distinct phases, the **micro-cycles**:



• **Example:** A current motherboard with a 100 MHz clock runs with a micro-cycle period of 10 ns (period = $\frac{1}{\text{frequency}}$):

$$t_{
m micro} = rac{1}{100 imes 10^6} {
m s} = rac{1}{100} \mu {
m s} = rac{1000}{100} {
m ns} = 10 {
m ns}$$


– Internally, Pentiums quadruple the motherboard system clock; the resulting micro-cycle period of 2.5 ns exceeds main memory speed (memory access time $\approx 50\,\mathrm{ns}$)

Asynchronous system bus

- The operation of an **asynchronous bus** is a bit more complicated but also more flexible
- The system uses two new control bus lines to adapt the CPU to the speed of the unit it is actively communicating with:
 - ALE (Address Latch Enable): controlled by CPU, set when valid address signal is on address bus
 - DTA (Data Transfer Acknowledge): controlled by unit, indicates that data has been written/read successfully
- Together, the ALE and DTA signals are said to implement a handshake
 protocol

(this is a widely used "trick" in computer science in general, e.g., in networking)

Asynchronous bus trace




Notes:

- \bigcirc CPU puts address value on address bus, then activates ALE (time A)
- ② Memory unit copies requested data (here: instruction code) onto data bus, then activates DTA (time B)
- ③ CPU recognizes DTA and copies instruction code into IR, then deactivates ALE (time C)
- In the time span A-B, the CPU is **stalled** (waiting for DTA)

High clock frequencies


- Electrical effects like the resistance and capacitance of the bus wiring
 pose limits on the achievable system clock frequency
- The edges of a real pulse are "round", pulse tails may not interfere with the rising of the next pulse:



- Power supply of current motherboards: 3.5 V
 - Voltage $< 0.8 V \Rightarrow logic 0$
 - Voltage > 2.5 V ⇒ logic 1
- Other limits: CPU heat problems (\Rightarrow cooling equipment, e.g., fans)

Pre-fetching by the CPU


- The faster CPUs are clocked, the slower main memory accesses appear to be (the CPU spends more micro-cycles waiting for the DTA signal)
- There are, however, phases during the fetch—execute cycle which do *not* involve any bus activity:
 - (1) decode instruction
 - (2) execute instruction
- **Pre-fetching CPUs** use these periods of "bus silence" to *read* instructions ahead from main memory and store them for later use:



 Instructions are stored in a queue, a tabular structure that is written to/read from using two independent circulating pointers

Parallelism in the CPU

 In pre-prefetching CPUs, the fetch and execute phases for two instructions may overlap:




- Whenever the program contains a conditional jump instruction, the pre-fetcher unit has to decide to follow *one of the two possible* branches
 - The contents of the pre-fetch queue may be useless if the CPU follows the other branch
 - Modern CPUs try to "guess" which branch will be followed
 (observations from previous outcomes of the same conditional branch)

Memory size and address width

2.3 Memory size and address width

- Note that the address bus width determines how much memory a CPU can use: each address bus wire represents a single bit of the address value
- Similarly, CPU address registers (e.g., IP) are of a specific register width
 (= number of bits in the register):⁴



 $^{^{4}1 \, \}text{K} = 1024, \quad 1 \, \text{M} = 1024 \, \text{K}, \quad 1 \, \text{G} = 1024 \, \text{M}$

Bottom and top memory addresses


• **Example** (memory addressing with address width of 8 bits):

Address bits	Address (decimal)	
00000000	0	bottom
0000001	1	
0000010	2	
00000011	3	
00000100	4	
00000101	5	
:	:	
10000000	128	
10000001	129	
:	:	
11111110	254	
11111111	255	top

- With an address width of n bits, a CPU can access 2^n memory locations
- The bottom address is 0, the top address is $2^n 1 = \underbrace{1111 \cdots 111_2}$

Hexadecimal address notation

- Especially for large address widths (e.g., 32 bits or soon 64 bits), handling memory addresses in binary notation is error-prone (at least for humans)
- It is common practice to "pack" 4 binary digits (bits) into a single hexadecimal digit
 - **Example** (a 32 bit address in binary and hexadecimal notation):



Dec	Bin	Hex
0	0000	0
1	0001	1
2	0010	2
3	0011	3
4	0100	4
5	0101	5
6	0110	6
7	0111	7

Dec	Bin	Hex
8	1000	8
9	1001	9
10	1010	Α
11	1011	В
12	1100	C
13	1101	D
14	1110	Е
15	1111	F

Hexadecimal address notation

