The Memory System

Overview

Memo rv

What is memory?


- Electronic circuitry that holds data and program instructions
- Often called the *primary storage* or store, which creates the confusion with disk storage
- Memory has direct link to the CPU
- Storage refers to disk storage communicating with the CPU over the system bus

Some basic concepts

Memo ry

To build a memory -- a logical $k \times m$ array of stored bits.

Address Space: number of locations (usually a power of 2)






Basic Concepts


- The maximum size of the memory that can be used in any computer is determined by the addressing scheme.

 16-bit addresses = 2^{16} = 64K memory locations
 - Most modern computers are byte addressable.



Some basic concepts

- Maximum size of the Main Memory
- byte-addressable
- CPU-Main Memory Connection





Some basic concepts(Contd.,)

- Measures for the speed of a memory:
 - memory access time.
 - memory cycle time.
- An important design issue is to provide a computer system with as large and fast a memory as possible, within a given cost target.
- Several techniques to increase the effective size and speed of the memory:
 - Cache memory (to increase the effective speed).
 - Virtual memory (to increase the effective size).

Memory

Types of memory?

- RAM
- Cache
- Virtual
- ROM
- CMOS



Semiconductor RAM memories


The Memory System

Internal organization of memory chips

- Each memory cell can hold one bit of information.
- Memory cells are organized in the form of an array.
- One row is one memory word.
- All cells of a row are connected to a common line, known as the "word line".
- Word line is connected to the address decoder.
- Sense/write circuits are connected to the data input/output lines of the memory chip.



Internal organization of memory chips (Contd.,)



Internal organization of memory chips (Contd.,)

- 16 words of 8 bits each: 16x8 memory org..
- It has 16 external connections: addr. 4, data 8, control: 2, power/ground: 2
- IK memory cells: 128x8 memory, external connections: ? 19(7+8+2+2)
- 1Kx1:? 15 (10+1+2+2)



A Memory Chip





Figure 5.3. Organization of a $1K \times 1$ memory chip.

SRAM Cell

- Two transistor inverters are cross connected to implement a basic flip-flop.
- The cell is connected to one word line and two bits lines by transistors T1 and T2
- When word line is at ground level, the transistors are turned off and the latch retains its state
- Read operation: In order to read state of SRAM cell, the word line is activated to close switches T1 and T2. Sense/Write circuits at the bottom monitor the state of b and b'





A Dynamic Memory Chip

Static RAMs are fast, but they cost more area and are more expensive.

 Dynamic RAMs (DRAMs) are cheap and area efficient, but they can not retain their state indefinitely – need to be periodically refreshed Rit line




Figure 5.6. A single-transistor dynamic memory cell

SRAM vs DRAM

Static RAMs (SRAMs):

- Consist of circuits that are capable of retaining their state as long as the power is applied.
- Volatile memories, because their contents are lost when power is interrupted.
- Access times of static RAMs are in the range of few nanoseconds.
- However, the cost is usually high.

Dynamic RAMs (DRAMs):

- Do not retain their state indefinitely.
- Contents must be periodically refreshed.
- Contents may be refreshed while accessing them for real

Asynchronous DRAMs




Figure 5.7. Internal organization of a(16 megabit) $2M \times 8$ dynamic memory chip.


Fast Page Mode

Suppose if we want to access the consecutive bytes in the selected row.

This can be done without having to reselect the row.

- Add a latch at the output of the sense circuits in each row.
- All the latches are loaded when the row is selected.
- Different column addresses can be applied to select and place different bytes on the data lines.
- Consecutive sequence of column addresses can be applied under the control signal CAS, without reselecting the row.
 - Allows a block of data to be transferred at a much faster rate than random accesses.
 - A small collection/group of bytes is usually referred to as a block
- This transfer capability is referred to as the fast page mode feature.

Synchronous DRAMs



Synchronous DRAMs




Figure 5.9. Burst read of length 4 in an SDRAM.

Synchronous DRAMs

- No CAS pulses is needed in burst operation.
- Refresh circuits are included (every 64ms).
- Clock frequency > 100 MHz
- Intel PC100 and PC133


Latency and Bandwidth

- The speed and efficiency of data transfers among memory, processor, and disk have a large impact on the performance of a computer system.
- Memory latency the amount of time it takes to transfer a word of data to or from the memory.
- Memory bandwidth the number of bits or bytes that can be transferred in one second. It is used to measure how much time is needed to transfer an entire block of data.
- Bandwidth is not determined solely by memory. It is the product of the rate at which data are transferred (and accessed) and the width of the data bus.

DDR SDRAM


- Double-Data-Rate SDRAM
- Standard SDRAM performs all actions on the rising edge of the clock signal.
- DDR SDRAM accesses the cell array in the same way, but transfers the data on both edges of the clock.
- The cell array is organized in two banks. Each can be accessed separately.
- DDR SDRAMs and standard SDRAMs are most efficiently used in applications where block transfers are prevalent.

Static memories




MAIN MEMORY

Typical RAM chip



(CS1	CS2	RD	WR	Memory function	State of data bus
	0	0	X	Х	Inhibit	High-impedence
	0	1	X	X	Inhibit	High-impedence
	1	0	0	0	Inhibit	High-impedence
	1	0	0	1	Write	Input data to RAM
	1	0	1	X	Read	Output data from RAM
	1	1	Х	Х	Inhibit	High-impedence

Typical ROM chip



MEMORY ADDRESS MAP Address space assignment to each memory chip


Example: 512 bytes RAM and 512 bytes ROM

	Hexa	Address bus									
Component	address	10	9	8	7	6	5	4	3	2	1
RAM 1 RAM 2 RAM 3 RAM 4 ROM	0000 - 007F 0080 - 00FF 0100 - 017F 0180 - 01FF 0200 - 03FF	0 0 0	0 1 1	1 0 1	X X X	X X X	X X X	X X X X	X X X	X X X	X X X

Memory Connection to CPU

- RAM and ROM chips are connected to a CPU through the data and address buses
- The low-order lines in the address bus select the byte within the chips and other lines in the address bus select a particular chip through its chip select inputs

CONNECTION OF MEMORY TO CPU




Dynamic memories

- Large dynamic memory systems can be implemented using DRAM chips in a similar way to static memory systems.
- Placing large memory systems directly on the motherboard will occupy a large amount of space.
 - Also, this arrangement is inflexible since the memory system cannot be expanded easily.
- Packaging considerations have led to the development of larger memory units known as SIMMs (Single In-line Memory Modules) and DIMMs (Dual In-line Memory Modules).
- Memory modules are an assembly of memory chips on a small board that plugs vertically onto a single socket on the motherboard.
 - Occupy less space on the motherboard.
 - Allows for easy expansion by replacement.

Memory controller

- Recall that in a dynamic memory chip, to reduce the number of pins, multiplexed addresses are used.
- Address is divided into two parts:
 - High-order address bits select a row in the array.
 - They are provided first, and latched using RAS signal.
 - Low-order address bits select a column in the row.
 - They are provided later, and latched using CAS signal.
- However, a processor issues all address bits at the same time.
- In order to achieve the multiplexing, memory controller circuit is inserted between the process and memory.

Memory controller (contd..)




Read-Only Memories (ROMs)

The Memory System

Read-Only Memories (ROMs)

- SRAM and SDRAM chips are volatile:
 - Lose the contents when the power is turned off.
- Many applications need memory devices to retain contents after the power is turned off.
 - For example, computer is turned on, the operating system must be loaded from the disk into the memory.
 - Store instructions which would load the OS from the disk.
 - Need to store these instructions so that they will not be lost after the power is turned off.
 - We need to store the instructions into a non-volatile memory.
- Non-volatile memory is read in the same manner as volatile memory.
 - Separate writing process is needed to place information in this memory.
 - Normal operation involves only reading of data, to of memory is called Read-Only memory (ROM).

Read-Only-Memory



Read-Only Memories (Contd.,)

- Read-Only Memory:
 - Data are written into a ROM when it is manufactured.
- Programmable Read-Only Memory (PROM):
 - Allow the data to be loaded by a user.
 - Process of inserting the data is irreversible.
 - Storing information specific to a user in a ROM is expensive.
 - Providing programming capability to a user may be better.
- Erasable Programmable Read-Only Memory (EPROM):
 - Stored data to be erased and new data to be loaded.
 - Flexibility, useful during the development phase of digital systems.
 - Erasable, reprogrammable ROM.
 - Erasure requires exposing the ROM to UV light.


Read-Only Memories (Contd.,)

- Electrically Erasable Programmable Read-Only Memory (EEPROM):
 - To erase the contents of EPROMs, they have to be exposed to ultraviolet light.
 - Physically removed from the circuit.
 - EEPROMs the contents can be stored and erased electrically.
- Flash memory:
 - Has similar approach to EEPROM.
 - Read the contents of a single cell, but write the contents of an entire block of cells.
 - Flash devices have greater density.
 - Higher capacity and low storage cost per bit.
 - Power consumption of flash memory is very low, making it attractive for use in equipment that is battery-driven.
 - Single flash chips are not sufficiently large, so larger memory modules are implemented using flash cards and flash drives.

Speed, Size, and Cost

- A big challenge in the design of a computer system is to provide a sufficiently large memory, with a reasonable speed at an affordable cost.
- Static RAM:
 - Very fast, but expensive, because a basic SRAM cell has a complex circuit making it impossible to pack a large number of cells onto a single chip.
- Dynamic RAM:
 - Simpler basic cell circuit, hence are much less expensive, but significantly slower than SRAMs.
- Magnetic disks:
 - Storage provided by DRAMs is higher than SRAMs, but is still less than what is necessary.
 - Secondary storage such as magnetic disks provide a large and of storage, but is much slower than DRAMs.

Memory Hierarchy



Cache Memories

The Memory System


Cache Memories

- Processor is much faster than the main memory.
 - As a result, the processor has to spend much of its time waiting while instructions and data are being fetched from the main memory.
 - Major obstacle towards achieving good performance.
- Speed of the main memory cannot be increased beyond a certain point.
- Cache memory is an architectural arrangement which makes the main memory appear faster to the processor than it really is.
- Cache memory is based on the property of computer programs known as "locality reference".

Locality of Reference

- Analysis of programs indicates that many instructions in localized areas of a program are executed repeatedly during some period of time, while the others are accessed relatively less frequently.
 - These instructions may be the ones in a loop, nested loop or few procedures calling each other repeatedly.
 - This is called <u>"locality of reference".</u>
- Temporal locality of reference:
 - Recently executed instruction is likely to be executed again very soon.
- Spatial locality of reference:
 - Instructions with addresses close to a recently instruction are likely to be executed soon.

Cache memories



- Processor issues a Read request, a block of words is transferred from the main memory to the cache, one word at a time. Subsequent references to the data in this block of words are found
- in the cache.
- At any given time, only some blocks in the main memory are held in the cache. Which blocks in the main memory are in the cache is determined by a "<u>mapping function".</u> When the cache is full, and a block of words needs to be transferred
- from the main memory, some block of words in the cache must be replaced. This is determined by a "replacement algorithm".

Cache hit

- Existence of a cache is transparent to the processor. The processor issues Read and Write requests in the same manner.
- If the data is in the cache it is called a Read or Write hit.
- Read hit:
 - The data is obtained from the cache.
- Write hit:
 - Cache has a replica of the contents of the main memory.
 - Contents of the cache and the main memory may be updated simultaneously. This is the <u>write-through</u> protocol.
 - Update the contents of the cache, and mark it as updated by setting a bit known as the <u>dirty bit or modified</u> bit. The contents of the main memory are updated when this block is replaced. This is <u>write-back or copy-back</u> protocol.

Cache miss

- If the data is not present in the cache, then a <u>Read miss or</u> <u>Write miss</u> occurs.
- Read miss:
 - Block of words containing this requested word is transferred from the memory.
 - After the block is transferred, the desired word is forwarded to the processor.
 - The desired word may also be forwarded to the processor as soon as it is transferred without waiting for the entire block to be transferred. This is called <u>load-through or early-restart.</u>
- Write-miss:
 - Write-through protocol is used, then the contents of the main memory are updated directly.
 - If write-back protocol is used, the block containing the addressed word is first brought into the cache. The desired word is overwritten with new information.

Cache Coherence Problem

- A bit called as "valid bit" is provided for each block.
- If the block contains valid data, then the bit is set to 1, else it is 0.
- Valid bits are set to 0, when the power is just turned on. When a block is loaded into the cache for the first time, the valid bit is set to 1.
- Data transfers between main memory and disk occur directly bypassing the cache.
- When the data on a disk changes, the main memory block is also updated.
- However, if the data is also resident in the cache, then the valid bit is set to 0.
- What happens if the data in the disk and main memory changes and the write-back protocol is being used?
- In this case, the data in the cache may also have changed and is indicated by the dirty bit.
- The copies of the data in the cache, and the main memory are different. This is called the <u>cache coherence problem</u>.
- One option is to force a write-back before the main memor updated from the disk.

Mapping functions

Mapping functions determine how memory blocks are placed in the cache.

A simple processor example:


- Cache consisting of 128 blocks of 16 words each.
- Total size of cache is 2048 (2K) words.
- Main memory is addressable by a 16-bit address.
- Main memory has 64K words.
- Main memory has 4K blocks of 16 words each.

Three mapping functions:


- Direct mapping
- Associative mapping
- Set-associative mapping.




Direct mapping



Associative mapping



Set-Associative mapping



Performance considerations

The Memory System

Performance considerations


- A key design objective of a computer system is to achieve the best possible performance at the lowest possible cost.
 - Price/performance ratio is a common measure of success.
- Performance of a processor depends on:
 - How fast machine instructions can be brought into the processor for execution.
 - How fast the instructions can be executed.




Interleaving

- Divides the memory system into a number of memory modules. Each module has its own address buffer register (ABR) and data buffer register (DBR).
 Arranges addressing so that successive
- Arranges addressing so that successive words in the address space are placed in different modules.
- When requests for memory access involve consecutive addresses, the access will be to different modules.
- Since parallel access to these modules is possible, the average rate of fetching words from the Main Memory can be increased.

Methods of address layouts





- Consecutive words are placed in a module.
- High-order k bits of a memory address determine the module.
- Low-order m bits of a memory address determine the word within a module.
- When a block of words is transferred from main memory to cache, only one module is busy at a time.

- •Consecutive words are located in consecutive modules.
- •Consecutive addresses can be located in consecutive modules.
- •While transferring a block of data, several memory module can be kept busy at the same time.

Hit Rate and Miss Penalty

- Hit rate
- Miss penalty
- Hit rate can be improved by increasing block size, while keeping cache size constant
- Block sizes that are neither very small nor very large give best results.
- Miss penalty can be reduced if load-through approach is used when loading new blocks into cache.



Caches on the processor chip

- In high performance processors 2 levels of caches are normally used.
- Avg access time in a system with 2 levels of caches is

$$T_{ave} = h1c1+(1-h1)h2c2+(1-h1)(1-h2)M$$



Other Performance Enhancements

Write buffer

- Write-through:
- Each write operation involves writing to the main memory.
- If the processor has to wait for the write operation to be complete, it slows down the processor.
- Processor does not depend on the results of the write operation.
- Write buffer can be included for temporary storage of write requests.
- Processor places each write request into the buffer and continues execution.
- If a subsequent Read request references data which is still in the write buffer, then this data is referenced in the write buffer.
- Write-back:
- Block is written back to the main memory when it is replaced.
- If the processor waits for this write to complete, before reading the new block, it is slowed down.
- Fast write buffer can hold the block to be written, and the new block can be read first.

Other Performance Enhancements (Contd.,)

Prefetching

- New data are brought into the processor when they are first needed.
- Processor has to wait before the data transfer is complete.
- Prefetch the data into the cache before they are actually needed, or a before a Read miss occurs.
- Prefetching can be accomplished through software by including a special instruction in the machine language of the processor.
 - Inclusion of prefetch instructions increases the length of the programs.
- Prefetching can also be accomplished using hardware:
 - Circuitry that attempts to discover patterns in memory references and then prefetches according to this pattern.

Other Performance Enhancements (Contd.,)

Lockup-Free Cache

- Prefetching scheme does not work if it stops other accesses to the cache until the prefetch is completed.
- A cache of this type is said to be "locked" while it services a miss.
- Cache structure which supports multiple outstanding misses is called a lockup free cache.
- Since only one miss can be serviced at a time, a lockup free cache must include circuits that keep track of all the outstanding misses.
- Special registers may hold the necessary information about these misses.

Virtual Memory

The Memory System

Virtual memories

- Recall that an important challenge in the design of a computer system is to provide a large, fast memory system at an affordable cost.
- Architectural solutions to increase the effective speed and size of the memory system.
- Cache memories were developed to increase the effective speed of the memory system.
- Virtual memory is an architectural solution to increase the effective size of the memory system.

Virtual memories (contd..)

- Recall that the addressable memory space depends on the number of address bits in a computer.
 - For example, if a computer issues 32-bit addresses, the addressable memory space is 4G bytes.
- Physical main memory in a computer is generally not as large as the entire possible addressable space.
 - Physical memory typically ranges from a few hundred megabytes to 1G bytes.
- Large programs that cannot fit completely into the main memory have their parts stored on secondary storage devices such as magnetic disks.
 - Pieces of programs must be transferred to the main memory from second storage before they can be executed.


Virtual memories (contd..)

- When a new piece of a program is to be transferred to the main memory, and the main memory is full, then some other piece in the main memory must be replaced.
 - Recall this is very similar to what we studied in case of cache memories.
- Operating system automatically transfers data between the main memory and secondary storage.
 - Application programmer need not be concerned with this transfer
 - Also, application programmer does not need to be aware of limitations imposed by the available physical memory.

Virtual memories (contd..)

- Techniques that automatically move program and data between main memory and secondary storage when they are required for execution are called <u>virtual-memory</u> techniques.
- Programs and processors reference an instruction or data independent of the size of the main memory.
- Processor issues binary addresses for instructions and data.
 - These binary addresses are called logical or virtual addresses.
- Virtual addresses are translated into physical addresses by a combination of hardware and software subsystems.
 - If virtual address refers to a part of the program that is currently in the main memorit is accessed immediately.
 - If the address refers to a part of the program that is not currently in the man period it is first transferred to the main memory before it can be used.

Virtual memory organization



Address translation

Assume that program and data are composed of fixed-length units called pages.

A page consists of a block of words that occupy contiguous locations in the main

memory.

Page is a basic unit of information that is transferred between secondary storage and main memory.

Size of a page commonly ranges from 2K to

16K bytes.

Pages should not be too small, because the access time of a secondary storage device is much larger than the main memory.

Pages should not be too large, else a large portion of the page nused, and it will occupy valuable space in the main memory.


- Concepts of virtual memory are similar to the concepts of cache memory.
- Cache memory:
 - Introduced to bridge the speed gap between the processor and the main memory.
 - Implemented in hardware.
- Virtual memory:
 - Introduced to bridge the speed gap between the main memory and secondary storage.
 - Implemented in part by software.

Each virtual or logical address generated by a processor is interpreted as a virtual page number (high-order bits) plus an offset (loworder bits) that specifies the location of a particular byte within that page.

Information about the main memory location of each page is kept in the page table.

- Main memory address where the page is stored.
- Current status of the page.
- Area of the main memory that can hold a page is called as <u>page frame</u>.
- Starting address of the page table is kept in a page table base register.

- Virtual page number generated by the processor is added to the contents of the page table base register.
 - This provides the address of the corresponding entry in the page table.
- The contents of this location in the page table give the starting address of the page if the page is currently in the main memory.




- Page table entry for a page also includes some control bits which describe the status of the page while it is in the main memory.
- One bit indicates the validity of the page.
 - Indicates whether the page is actually loaded into the main memory.
 - Allows the operating system to invalidate the page without actually removing it.
- One bit indicates whether the page has been modified during its residency in the main memory.
 - This bit determines whether the page should be written back to the disk when it is removed from the main memory.
 - Similar to the dirty or modified bit in case of cache memory.

- Other control bits for various other types of restrictions that may be imposed.
 - For example, a program may only have read permission for a page, but not write or modify permissions.



- Where should the page table be located?
- Recall that the page table is used by the MMU for every read and write access to the memory.
 - Ideal location for the page table is within the MMU.
- Page table is quite large.
- MMU is implemented as part of the processor chip.
- Impossible to include a complete page table on the chip.
- Page table is kept in the main memory.
- A copy of a small portion of the page table can be accommodated within the MMU.
 - Portion consists of page table entries that correspond to the most recent accessed pages.

- A small cache called as Translation Lookaside Buffer (TLB) is included in the MMU.
 - TLB holds page table entries of the most recently accessed pages.
- Recall that cache memory holds most recently accessed blocks from the main memory.
 - Operation of the TLB and page table in the main memory is similar to the operation of the cache and main memory.
- Page table entry for a page includes:
 - Address of the page frame where the page resides in the main memory.
 - Some control bits.
- In addition to the above for each page, TLB must hold the virtual page number for each page.



How to keep the entries of the TLB coherent with the contents of the page table in the main memory?

Operating system may change the contents of the page table in the main memory.

- Simultaneously it must also invalidate the corresponding entries in the TLB.
- A control bit is provided in the TLB to invalidate an entry.
- If an entry is invalidated, then the TLB gets the information for that entry from the page table.
 - Follows the same process that it would follow if the entry is not found in the TLB or if a "miss" occurs.

- what nappens if a program generates an access to a page that is not in the main memory?
- In this case, a page fault is said to occur.
 - Whole page must be brought into the main memory from the disk, before the execution can proceed.
- Upon detecting a page fault by the MMU, following actions occur:
 - MMU asks the operating system to intervene by raising an exception.
 - Processing of the active task which caused the page fault is interrupted.
 - Control is transferred to the operating system.
 - Operating system copies the requested page from secondary storage to the main memory.
 - Once the page is copied, control is returned to the task which was interrupted.

- Servicing of a page fault requires transferring the requested page from secondary storage to the main memory.
- This transfer may incur a long delay.
- While the page is being transferred the operating system may:
 - Suspend the execution of the task that caused the page fault.
 - Begin execution of another task whose pages are in the main memory.
- Enables efficient use of the processor.

- How to ensure that the interrupted task can continue correctly when it resumes execution?
- There are two possibilities:
 - Execution of the interrupted task must continue from the point where it was interrupted.
 - The instruction must be restarted.
- Which specific option is followed depends on the design of the processor.

- When a new page is to be brought into the main memory from secondary storage, the main memory may be full.
 - Some page from the main memory must be replaced with this new page.
- How to choose which page to replace?
 - This is similar to the replacement that occurs when the cache is full.
 - The principle of locality of reference (?) can also be applied here.
 - A replacement strategy similar to LRU can be applied.
- Since the size of the main memory is relatively larger compared to cache, a relatively large amount of programs and data can be held in the main memory.
 - Minimizes the frequency of transfers between secondary storage and memory.

- A page may be modified during its residency in the main memory.
- When should the page be written back to the secondary storage?
- Recall that we encountered a similar problem in the context of cache and main memory:
 - Write-through protocol(?)
 - Write-back protocol(?)
- Write-through protocol cannot be used, since it will incur a long delay each time a small amount of data is written to the

Memory Management

The Memory System

Memory management

- Operating system is concerned with transferring programs and data between secondary storage and main memory.
- Operating system needs memory routines in addition to the other routines.
- Operating system routines are assembled into a virtual address space called system space.
- System space is separate from the space in which user application programs reside.
 - This is user space.
- Virtual address space is divided into one system space + several user spaces.



Memory management (contd..)

- Recall that the Memory Management Unit (MMU) translates logical or virtual addresses into physical addresses.
- MMU uses the contents of the page table base register to determine the address of the page table to be used in the translation.
 - Changing the contents of the page table base register can enable us to use a different page table, and switch from one space to another.
- At any given time, the page table base register can point to one page table.
 - Thus, only one page table can be used in the translation process at a given time.
 - Pages belonging to only one space are accessible at given time.


Memory management (contd..)

- When multiple, independent user programs coexist in the main memory, how to ensure that one program does not modify/destroy the contents of the other?
- Processor usually has two states of operation:
 - Supervisor state.
 - User state.
- Supervisor state:
 - Operating system routines are executed.
- User state:
 - User programs are executed.
 - Certain privileged instructions cannot be executed in user state.
 - These privileged instructions include the ones which change page table base register.
 - Prevents one user from accessing the space of other user

Secondary Storage

The Memory System

Magnetic Hard Disks



Organization of Data on a Disk




Figure 5.30. Organization of one surface of a disk.



Access Data on a Disk

- Sector header
- Following the data, there is an error-correction code (ECC).
- Formatting process
- Difference between inner tracks and outer tracks
- Access time seek time / rotational delay (latency time)
- Data buffer/cache

Disk Controller




Figure 5.31. Disks connected to the system bus.

Disk Controller


- Seek
- Read
- Write
- Error checking




RAID Disk Arrays


- Redundant Array of Inexpensive Disks
- Using multiple disks makes it cheaper for huge storage, and also possible to improve the reliability of the overall system.
- RAID0 data striping
- RAID1 identical copies of data on two disks
- RAID2, 3, 4 increased reliability
- RAID5 parity-based error-recovery

Optical Disks





(b) Transition from pit to land



Optical Disks

- CD-ROM
- CD-Recordable (CD-R)
- CD-ReWritable (CD-RW)
- DVD
- DVD-RAM



Magnetic Tape Systems




Figure 5.33. Organization of data on magnetic tape.

