
MODEL NO. BO5031



SPARE PARTS LIST

MODEL NO. BO5031

A03 416063-0 DUST BAG NOZZLE
A04 416064-8 DUST NOZZLE
A05 794544-7 ABRASIVE DISC 125 #120

ITEM	1 PART NO.	DESCRIPTION	QTY	NOTE
001	265995-6	TAPPING SCREW 4X18	3	
002	450810-9	TOP COVER	1	
003	265995-6	TAPPING SCREW 4X18	2	
004	645105-5	NOISE SUPPRESSOR	1	
005	687052-4	STRAIN RELIEF	1	
006	682502-4	CORD GUARD 8-85	1	
007	665383-1	POWER SUPPLY CORD 1.0-2-2.0	1	
800	191962-4	CARBON BRUSH CB-419	1	
009	643995-0	BRUSH HOLDER	2	
010	654532-5	TERMINAL BLOCK 1P	1	
011	651527-9	SWITCH	1	
012	424039-3	SWITCH COVER	1	
013	450809-4	MOTOR HOUSING	1	
014	866159-1	BO5031 NAME PLATE	1	
015	633674-8	FIELD 240V	1	
016	266147-2	TAPPING SCREW 4X55	2	
017	210017-7	BALL BEARING 607DDW	1	
018	681652-2	INSULATION WASHER	1	
019	515734-7	ARMATURE ASS'Y 240V	1	
		INC. 17,18,20,21		
020	267806-1	WASHER 9	1	
021	211092-6	BALL BEARING 629DDW	1	
022	450672-5	BRACKET	1	
023	265995-6	TAPPING SCREW 4X18	4	
024	241673-2	FAN 88	1	
025	267164-5	FLAT WASHER 15	1	
026	188579-2	SKIRT L/R SET	1	
		INC. 28		
027	265995-6	TAPPING SCREW 4X18	2	
028	188579-2	SKIRT L/R SET	1	
		INC. 26		
029	318304-9	BEARING BOX	1	
030	211228-7	BALL BEARING 6202DDW	1	
031	424131-5	BRAKE RING	1	
032	318303-1	BEARING BOX COVER	1	
033	253739-6	FLAT WASHER 4	1	
034	911128-8	PAN HEAD SCREW M4X16	1	
035	743081-8	PAD 123	1	
036	911128-8	PAN HEAD SCREW M4X16	3	
037	631832-0	CONTROLLER	1	
A01	166078-4	DUST BAG	1	
A02	257202-1	RING 25	1	
4.00	440000	D. 107 D. 4 C. 110 771 F		

PAGE 1