Maximum Rate of Diversion

The maximum rate you will divert the water measured in m3/sec. Note that the total volume extracted on a per second rate may NOT exceed the total annual quantity applied for.

- If water is being used continuously year-round (i.e. 24 hrs/day, 365 days/year), calculate the maximum rate of diversion, from the total annual quantity using the Online Unit Converter Tool;
- For all other water usage durations, calculate the maximum rate of diversion manually by using the following calculations:
- If the Total Annual Quantity is in m3/year then take the total annual quantity divide it by the number of days you will extract (i.e. every day for 365 or only 5 days per week for 52 weeks [260 days per year]), divide that by number of hours per day you plan to withdraw water, and then divide it by 3600.
- If the Total Annual Quantity is in m3/day then take the total annual quantity and divide by number of hours per day you plan to withdraw water, and then divide it by 3600
- If water is being used seasonally or intermittently, such as an irrigation system, use the BC Ag Calculator to calculate peak flow. BC Agriculture Water Calculator find your parcel, input the area being irrigated, adjust the dates from April 1 to September 30, and then show monthly amounts. Use the highest demand month (July) and divide by 31 days, 24 hours, then 3600 to get m3/s. This is the highest water demand based on peak ET (evapotranspiration).