

WizFi360

Quick Start Guide

Version 1.0
WIZnet Co.,Ltd
Copyright© 2019



History

Ver	Date	Description
1.0	Aug.2019	Initial version




Contents

1.	Environment setting	4
2.	Using Serial command	
3.	History	



1. Environment setting



WizFi360EVB can use the AT command through UART1 and it also can consist that be used as an Arduino Pin. When it use Arduino Pin or USB of WizFi360EVB, the setting of WizFi360 is as below.

	SW1(RXD1/TXD1)	SW2(RTS/CTS)	JP3(TXD),JP2,JP1(RXD)
Arduino Pin	OFF	ON	JP3<->D0, JP1<->D1
		OFF	
WizFi360 Pin and USB	ON	(RTS: 15pin of WizFi360,	X
		CTS: 7pin of WizFi360)	

WizFi360io can use the AT command through UART and there are two types of module, wizFi360io-C and WizFi360io-H.



2. Using Serial command

A brief AT command describe for operating of WizFi360 as below. If you need AT command example of another mode, see the documentation called "AT command examples".

- Station Mode

AT command	Terminal	
AT	AT <cr><lf></lf></cr>	
47 01/14005 01/0 4	<pre><cr><lf> 0K<cr><lf></lf></cr></lf></cr></pre>	
AT+CWMODE_CUR=1	AT+CWMODE CUR=1 <cr><lf></lf></cr>	
AT+CWDHCP CUR=1,1	<cr><lf></lf></cr>	
	OK <cr><lf></lf></cr>	
AT+CWLAP	AT+CWDHCP_CUR=1,1 <cr><lf></lf></cr>	
AT+CWJAP CUR="wizms1","maker0701"	<cr><lf></lf></cr>	
ATTEMORIZED TO MIZITIST , MIRKETO/OT	OK <cr><lf> AT+CWLAP<cr><lf></lf></cr></lf></cr>	
AT+CIPSTA_CUR?	+CWLAP:(4,"DIR-815 Wiznet",-59," 7",1) <cr><lf></lf></cr>	
	+CWLAP: (0, "ESP 574935", -71," ",1) <cr><lf></lf></cr>	
	+CWLAP:(3,"##WIZnet irina",-46," ,1) <cr><lf></lf></cr>	
	+CWLAP: (3, "Matthew2.4", -63, " ",2) < CR>< LF>	
	+CWLAP: (3, "rena", -46, "", 3) < CR > < LF >	
	+CWLAP: (0, "iptime", -67," ",4) <cr><lf></lf></cr>	
	+CWLAP:(3,"Dap",-63,"	
	+CWLAP:(0, ESP_5/7CC/,-07,,0) <cr><lf></lf></cr>	
	+CWLAP:(0,"Wizfi360",-69,"	
	+CWLAP: (4, "DLINK-IPv6", -55, " ",10) < CR> < LF>	
	+CWLAP:(0,"iptime",-59," ",11) <cr><lf></lf></cr>	
	+CWLAP:(3,"WIZnet_Scott",-51,"",11) <cr><lf></lf></cr>	
	+CWLAP:(0,"WizFi360_A1B2D1",-69," ,11) <cr><lf></lf></cr>	
	+CWLAP: (3,"Teddy_AP", -57," ",13) <cr><lf></lf></cr>	
	OK <cr><lf></lf></cr>	
	AT+CWJAP CUR="wizms1","maker0701" <cr><lf></lf></cr>	
	WIFI DISCONNECT <cr><lf></lf></cr>	
	WIFI CONNECTED <cr><lf></lf></cr>	
	WIFI GOT IP <cr><lf></lf></cr>	
	<pre><cr><lf> 0K<cr><lf></lf></cr></lf></cr></pre>	
	AT+CIPSTA CUR? <cr><lf></lf></cr>	
	+CIPSTA CUR:ip:"192.168.1.120" <cr><lf></lf></cr>	
	+CIPSTA CUR:gateway:"192.168.1.1" <cr><lf></lf></cr>	
	+CIPSTA_CUR:netmask:"255.255.255.0" <cr><lf></lf></cr>	
	<cr><lf></lf></cr>	
	OK <cr><lf></lf></cr>	



- TCP Client / Command mode

AT command	Terminal
AT+CIPSTART="TCP","192.168.1.74",5000	AT+CIPSTART="TCP","192.168.1.74",5000 <cr><lf> CONNECT<cr><lf></lf></cr></lf></cr>
AT+CIPSENDBUF=10	<pre><cr><lf></lf></cr></pre>
0123456789 => 10byte data	
AT+CIPSENDEX=10	
012₩0 =>3byte data	<cr><lf> 0K<cr><lf></lf></cr></lf></cr>
	> 0123456789 <cr><lf> Recv 10 bytes<cr><lf> <cr><lf> 1,SEND 0K<cr><lf> AT+CIPSENDEX=10<cr><lf> <cr><lf> 0K<cr><lf> > 0K<cr><lf> > CR><lf> SEND 0K<cr><lf> SEND 0K<cr><lf></lf></cr></lf></cr></lf></lf></cr></lf></cr></lf></cr></lf></cr></lf></cr></lf></cr></lf></cr></lf></cr>