WizFi360 Datasheet (Version 1.02)







Document Revision History

Date	Revision	Changes	
2019-07-26	V0.9	Temporary Release	
		Edited "5. Pin Definitions"	
2019-09-02	V1.0	Added "5.1 Initial Value of GPIO Pins"	
		Added "Figure3. WizFi360 Pinout"	
	V1.01	Edited "Figure3. WizFi360 Pinout"	
		Edited "Table4. WizFi360 Pin Function"	
2019-09-19		Added "7. Peripheral Circuit Reference Design"	
		Added "8. Recommended PCB Land Pattern"	
		Added "9. Reflow Condition"	
2019-10-10	V1.02	Edited "Table 1. Description on Power Consumption"	



Table of Contents

1.	Over	view	4
2.	Feat	ures	4
3.		meters	
4.	Pack	age Information	7
	4.1.	WizFi360-PA	7
	4.2.	WizFi360-CON	7
5.	Pin [Definitions	8
	5.1.	Initial Value of GPIO Pins	9
6.	Phys	ical Dimensions	10
	6.1.	WizFi360-PA Dimensions	10
	6.2.	WizFi360-CON Dimensions	11
7.	Perip	oheral Circuit Reference Design	12
8.	Reco	mmended PCB Land Pattern	13
9.	Reflo	ow Profile	14
10.	Impo	ortant Notice	15



1. Overview

WizFi360 is a low cost and low-power consumption industrial-grade WiFi module. It is c ompatible with IEEE802.11 b/g/n standard and supports SoftAP, Station and SoftAP+Stati on modes. The serial port baud rate can be up to 2Mbps, which can meet the require ment of various applications.

2. Features

- WiFi 2.4G, 802.11 b/g/n
- Support Station / SoftAP / SoftAP+Station operation modes
- Support "Data pass-through" and "AT command data transfer" mode
- Support serial AT command configuration
- Support TCP Server / TCP Client / UDP operating mode
- Support configuration of operating channel 0 ~ 13
- Support auto 20MHz / 40MHz bandwidth
- Support WPA_PSK / WPA2_PSK encryption
- Serial port baud rate up from 600bps to 2Mbps with 16 common values
- Support up to 5 TCP / UDP links
- Obtaining IP address automatically from the DHCP server (Station mode)
- DHCP service for Wireless LAN clients (AP mode)
- Support DNS for communication with servers by domain name
- Support "Keep-Alive" to monitor TCP connection
- Support "Ping" for monitoring network status
- Built-in SNTP client for receiving the network time
- Support built-in unique MAC address and user configurable
- Support firmware upgrade by UART Download / OTA (via WLAN)
- Industrial grade (operating temperature range: -40 ° C ~ 85 ° C)
- CE, FCC, KC certification



3. Parameters

Categories	Items	Values	
Wireless	Wireless Standard	802.11 b/g/n	
vvireiess	Frequency Range	2.4GHz-2.5GHz (2400MHz~2483.5MHz)	
	Serial Data Interface	3.3V TTL×1 : TXD、RXD、CTS、RTS、GND	
Hardware	Operating Voltage	3.0~3.6V (Typical 3.3V)	
	Operating Temperature	-40°C ~85°C	
	WiFi Operation Modes	Station / SoftAP / SoftAP + Station	
	Encryption Method	WPA_PSK/WPA2_PSK	
Software	Operation Modes	TCP Server/TCP Client/UDP	
	Configuration Mode	AT commend set	
	Firmware Upgrade	UART Download / OTA (via WLAN) upgrade	
Certification Report		CE, FCC, KC	

Table 2. Parameters

Parameter	Typical value	Unit						
Input Frequency	2400~2484	MHz						
	Output Power							
PA Output Power at 72.2Mbps	12	dBm						
PA Output Power in 802.11b	19	dBm						
	Sensitivity							
DSSS,1 Mbps	-95	dBm						
CCK,11 Mbps	-86	dBm						
OFDM,6 Mbps	-89	dBm						
OFDM,54 Mbps	-73	dBm						
HT20, MCS0	-89	dBm						
HT20, MCS7	-71	dBm						
Adjacent-channel interference (ACI)								
OFDM,6 Mbps	32	dB						
OFDM,54 Mbps	15	dB						
HT20, MCS0	29	dB						
HT20, MCS7	10	dB						

Table 3. Receiver Sensitivity

WizFi360 Datasheet 5 / 16



Mode	Typical	Max	Unit
Send IEEE802.11b, CCK 11Mbps, POUT = +19 dBm	230	290	mA
Send IEEE802.11g, OFDM 54Mbps, POUT = +13.5 dBm	210	-	mA
Send IEEE802.11n, OFDM MCS7, POUT = +12 dBm	210	-	mA
Receive IEEE802.11 b/g/n	100-110		mA
Standby Mode	135		uA
Modem Sleep Mode	20		mA
Light Sleep Mode	13		mA

Table 4. Description on Power Consumption

- Standby mode
 - MCU will shut down all the peripherals and CPU will be powered down too. CPU can be wake up by external WP(WAKEUP) PIN or internal Timer.
- Modem Sleep mode
 - All peripherals of the MCU will operate.
- Light Sleep mode
 - Shutdown peripheral except for UART, TIMER, RFCFG GPSED



4. Package Information

4.1. WizFi360-PA




Figure 1. WizFi360-PA

- Onboard PCB antenna
- Onboard LED light, TX/RX LED
- Dimension: $24 \times 16 \times 3.2$ (mm)

4.2. WizFi360-CON




Figure 2. WizFi360-CON

- Onboard IPEX connector for connecting antenna
- ANT pin for external antenna
- Dimension: $17 \times 16 \times 3.2$ (mm)

WizFi360 Datasheet 7 / 16



5. Pin Definitions




Figure 3. WizFi360 Pinout

No	Pin Name	Туре	Pin Function		
1	RST	I	Module Reset Pin (Active Low)		
2	NC	-	WizFi360-PA Reserved		
	ANT	0	WizFi360-CON	ANT pin for external antenna	
			BOOT Pin (Active low)		
3	PA0	I/O	When power on or reset is low, it operates in Boot mode.		
	1710		In the normal operating mode, this pin can be controlled by AT		
			command.		
		WP I	WAKE-UP Pin (Active High)		
4	WP		If the wake-up pin is high in Standby mode, the WizFi360 is reset to the		
			normal operating mode.		
			Pull down over 3s for taking effect.		
5	PA1	I	UART1's current parameter changes to default value (please refer to		
			the AT+UART_CUR command in WizFi360 AT command manual).		
6	PB6	I/O	This pin can be controlled by AT command.		
7	PB9	I	CTS Pin of UART1		
7			If you don't use the CTS function, this pin can be controlled by AT		



			command.	
8	VCC	Р	Power Pin (Typical Value 3.3V)	
9	PB15	I/O	This pin can be controlled by AT command.	
10	PB18	I/O	This pin can be controlled by AT command.	
11	PB13	I/O	This pin can be controlled by AT command.	
12	PB14	I/O	This pin can be controlled by AT command.	
13	PB17	I/O	This pin can be controlled by AT command.	
14	PB16	I/O	This pin can be controlled by AT command.	
15	GND	I/O	Ground Pin	
16	PB10	0	RTS Pin of UART1 If you don't use the RTS function, this pin can be controlled by AT command.	
17	TXD0	0	TXD Pin of UART0	
18	RXD0	1	RXD Pin of UART0	
19	PB7	0	LED Light output (Active low). Go to Low while each TX/RX packet and then back to high. Note: It has been connected to onboard LED for WizFi360-PA	
20	PB8	I/O	This pin can be controlled by AT command.	
21	RXD1	ı	RXD Pin of UART1	
22	TXD1	0	TXD Pin of UART1	

Table 5. WizFi360 Pin Function

*Note: UART1 is used for AT command and data communication. UART0 is used for debugging and firmware upgrade.

5.1. Initial Value of GPIO Pins

This is the initial value of GPIO when using AT command to use GPIO on the WizFi360.

Pin Name	Туре	Value	Pull up / Pull down
PA0	I/O	High	Pull up
PB6	I/O	Low	Pull down
PB9	I/O	Low	Pull down
PB15	I/O	High	Pull down
PB18	I/O	High	Pull down
PB13	I/O	High	Pull down
PB14	I/O	High	Pull down

WizFi360 Datasheet 9 / 16



PB17	I/O	High	Pull down
PB16	I/O	High	Pull down
PB10	I/O	Low	Pull down
PB07	I/O	High	Pull down
PB08	I/O	High	Pull down

Table 6. Initial Value of GPIO Pins

6. Physical Dimensions

6.1. WizFi360-PA Dimensions

24(L) x 16(W) x 3.2(H) (\pm 0.1), (unit: mm)




Figure 4. WizFi360-PA Physical Dimensions



6.2. WizFi360-CON Dimensions

 $17(L) \times 16(W) \times 3.2(H) (\pm 0.1)$, (unit: mm)




Figure 5. WizFi360-CON Physical Dimensions

WizFi360 Datasheet 11 / 16



7. Peripheral Circuit Reference Design




Figure 6. WizFi360 Circuit Reference Design



8. Recommended PCB Land Pattern




Figure 7. Recommended PCB Land Pattern of WizFi360

WizFi360 Datasheet 13 / 16



9. Reflow Condition




Figure 8. Reflow Condition



10. Important Notice

WIZnet reserves the right to make corrections, modifications, enhancements, improvements and other changes to its products and services at any time, and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders, and should verify that such information is current and complete. All products are sold subject to WIZnet's terms and conditions of sale, supplied at the time of order acknowledgment. Information relating to device applications, and the like, is intended as suggestion only and may be superseded by updates. It is the customer's responsibility to ensure that their application meets their own specifications. WIZnet makes no representation and gives no warranty relating to advice, support or customer product design.

WIZnet assumes no responsibilities or liabilities for the use of any of its products, conveys no license or title under any patent, copyright or mask work rights to these products, and makes no representations or warranties that these products are free from patent, copyright or mask work infringement, unless otherwise specified.

WIZnet products are not intended for use in life support systems/appliances or any systems where product malfunction can reasonably be expected to result in personal injury, death, severe property damage or environmental damage. WIZnet customers using or selling WIZnet products for use in such applications do so at their own risk and agree to fully indemnify WIZnet for any damages resulting from such use.

All trademarks are the property of their respective owners.

WizFi360 Datasheet 15 / 16



Copyright Notice

Copyright 2019 WIZnet Co., Ltd. All Rights Reserved.

Technical Support: https://forum.wiznet.io/

Sales & Distribution: sales@wiznet.io

For more information, visit our website at http://www.wiznet.io/