
entry_493.xml | entry point: MainTree
?* FallbackStar
root_AutoLocalization
initialPoseReceived
→* SequenceStar
doSelfLocalization
RetryUntilSuccesful
retry_client_request
num_attempts=5
globalLocalizationServiceRequest
RetryUntilSuccesful
retry_localization
num_attempts=10
→ Sequence
? Fallback
IsLocalized
IsLocalized
→* SequenceStar
Spin
BackUp
Spin