
entry_256.xml | entry point: BehaviorTree
Repeat
num_cycles={num_cycles}
→ Sequence
Action
LTLPreCheck
ltl_state_current={ltl_state_current}
ltl_state_desired_sequence={ltl_state_desired_sequence}
Action
MoveAction
action={action}
move_base_finished={move_base_finished}
move_base_idle={move_base_idle}
nav_goal={nav_goal}
Action
UpdateLTL
action_sequence={action_sequence}
ltl_state_desired_sequence={ltl_state_desired_sequence}
nav_goal={nav_goal}