# EUROPEAN ORGANISATION FOR THE SAFETY OF AIR NAVIGATION



# **EUROCONTROL STANDARD DOCUMENT**

# **FOR**

# SURVEILLANCE DATA EXCHANGE

# Part 2b

**Transmission of Monoradar Service Messages** 

SUR.ET1.ST05.2000-STD-02b-01

Edition : 1.27
Edition Date : May 2007
Status : Released Issue
Class : General Public

# **DOCUMENT IDENTIFICATION SHEET**

DOCUMENT DESCRIPTION										
			Docume	ent Title						
	;	Surveilla	ance Data I	Exchange	- Part 2b	)				
Transmission of Monoradar Service Messages										
EWP DELIVERABLE RE	FEREN	CE NUN	/IBER							
PROGRAMME RE	FEREN	CE INDI	ΞX	EDITION	:		1.27			
SUR.ET1.ST05.2	2000-STE	0-02b-0	1	EDITION	DATE :	M	ay 2007			
			Abs	tract						
This document describes the application of ASTERIX to the transmission of monoradar service messages.										
			Keyw	vords						
Monoradar Data	ASTER		•	Service N	∕lessage	es				
Data Item	Catego	ry 34		UAP						
			•			1				
CONTACT PERSON:	A. E	ngel	TEL : +3	32-2-729 3355 <b>UNIT</b> : DAP/SUR						
	I	OOCU	MENT STA	ATUS AN	D TYPE	<b>=</b>				
STATUS			CATE	GORY		CLASSII	FICATION			
Working Draft		Exec	utive Tasl	k		General Public	c ⊻	1		
Draft		Spec	ialist Task	<		EATMP		]		
Proposed Issue		Lowe	er Layer T	ask		Restricted		]		
Released Issue	$\checkmark$		,							
		EL	ECTRON	IC BACK	UP					
INTERNAL REFERENCE	CE NAM	IE:								
HOST SYSTEM			ME	DIA		SOFTW	VARE(S)			
Microsoft Window	'S	Туре	: Hard dis	k			-			

Media Identification:

#### **DOCUMENT APPROVAL**

The following table identifies all management authorities who have successively approved the present issue of this document.

AUTHORITY	NAME AND SIGNATURE	DATE
ASTERIX		
Manager	D. Doukas	
SUR Domain		
Manager	J. Berends	
SURT		
Chairman	M. Rees	
EATM/DAP		
Director	G. Kerkhofs	

#### **DOCUMENT CHANGE RECORD**

The following table records the complete history of the successive editions of the present document.

EDITION	DATE	REASON FOR CHANGE	SECTIONS PAGES AFFECTED
Released Ed 1.0	November 1997	Adoption by the Eurocontrol Permanent Commission	
Working Draft Ed 1.1	May 1998	<ul><li>I034/070 renamed, types added;</li><li>I034/110 types added.</li></ul>	See respective Data Items
Draft Ed 1.2	October 1998	<ul> <li>Introduction modified to keep in line with Part 1;</li> <li>Two sentences added in General Principles;</li> <li>The title of the document amended by replacing Radar with Surveillance;</li> </ul>	1. 4.2 & 4.3  ALL  See respective
Draft Ed 1.21	January 1999	<ul> <li>I034/050 &amp; I034/060 shortened.</li> <li>1.1.3 and 1.2 suppressed;</li> <li>Editorial corrections;</li> <li>Reserved Expansion Indicator added in UAP.</li> </ul>	Data Items ALL 5.3
Draft Ed 1.22	February 1999	<ul><li>Editorial corrections;</li><li>I034/070 &amp; I034/110 types reviewed.</li></ul>	See respective Data Item
Draft Ed 1.23	March 1999	Correction in I034/090 LSB	See respective Data Item
Proposed Ed 1.24	September 1999	<ul> <li>Editorial corrections;</li> <li>Modifications in encoding rules and notes of I034/050, I034/060, I034/100, I034/110;</li> <li>Coding modifications of I034/070 and I034/110.</li> </ul>	See respective Data Item
Proposed Ed 1.26	November 2000	<ul> <li>Sector Crossing Messages made optional.</li> <li>Items 050 and 060 made optional.</li> </ul>	4.3 See respective Data Items
1.27	May 2007	<ul> <li>Document ID-sheet updated</li> <li>Signature Page updated</li> <li>Reference to ASTERIX website added</li> </ul>	ID-Sheet Sign. Page 5.2.2

# **TABLE OF CONTENTS**

DOCUME	ENT IDENTIFICATION SHEET	ii
DOCUME	ENT APPROVAL	iii
DOCUME	ENT CHANGE RECORD	iv
1.	INTRODUCTION	1
1.1	Scope	1
2.	REFERENCES	3
2.1	General	3
2.2	Reference Documents	3
3.	DEFINITIONS, ACRONYMS AND ABBREVIATIONS	5
3.1	Definitions	5
3.2	Acronyms and Abbreviations	6
4.	GENERAL PRINCIPLES	7
4.1	General	7
4.2	Time Management	7
4.2.1	Definition	7
4.2.2	Requirements for Time Stamping	7
4.3	North Marker and Sector Crossing Messages	7
4.4	Unused Bits in Data Items	7
4.5	Definitions and Addressing Concepts	8
4.5.1	Radar Sensor	8
4.5.2	Radar System	8
4.5.3	Combination of Target Reports	8
4.5.4	Addressing Concepts: Assigning SAC/SIC Codes	9
4.6	Radar Service Messages	9
4.6.1	Types of Radar Service Messages	9
4.6.2	User Application Profile and Data Block	10
4.7	Composition of Messages	10

5.	LAYOUT OF RADAR SERVICE MESSAGES	11
5.1	Standard Data Items	11
5.2	Description of Standard Data Items	12
5.2.1	Data Item I034/000, Message Type	12
5.2.2	Data Item I034/010, Data Source Identifier	14
5.2.3	Data Item I034/020, Sector Number	14
5.2.4	Data Item I034/030, Time of Day	15
5.2.5	Data Item I034/041, Antenna Rotation Speed	16
5.2.6	Data Item I034/050, System Configuration and Status	17
5.2.7	Data Item I034/060, System Processing Mode	22
5.2.8	Data Item I034/070, Message Count Values	27
5.2.9	Data Item I034/090, Collimation Error	28
5.2.10	Data Item I034/100, Generic Polar Window	29
5.2.11	Data Item I034/110 Data Filter	30
5.2.12	Data Item I034/120 3D-Position Of Data Source.	31
5.3	Standard User Application Profile	32

#### 1. INTRODUCTION

# 1.1 Scope

- 1.1.1 This document describes the message structure for the transmission of monoradar service messages, from a radar station (conventional Secondary Surveillance Radar (SSR), monopulse, Mode S, conventional primary radar or primary radar using Moving Target Detection (MTD) processing), to one or more Surveillance Data Processing (SDP) Systems.
- **1.1.2** Monoradar service messages are data out of Data Category 034.

This page is intentionally left blank

#### 2. REFERENCES

#### 2.1 General

The following Documents and Standards contain provisions which, through references in this text, constitute provisions of this Eurocontrol Standard Document.

At the time of publication of this Eurocontrol Standard Document, the editions indicated for the referenced documents and standards were valid.

Any revision of the referenced ICAO Documents shall be immediately taken into account to revise this Eurocontrol Standard Document.

Revisions of the other referenced documents shall not form part of the provisions of this Eurocontrol Standard Document until they are formally reviewed and incorporated into this Eurocontrol Standard Document.

In the case of a conflict between the requirements of this Eurocontrol Standard Document and the contents of the other referenced documents, this Eurocontrol Standard Document shall take precedence.

#### 2.2 Reference Documents

- 1. Eurocontrol Standard 000-1-92. Directives for the Uniform Drafting and Presentation of Eurocontrol Standard Documents. 1992.
- 2. Eurocontrol Standard SUR.ET1.ST05.2000-STD-01-01. All Purpose Structured Eurocontrol Surveillance Information Exchange ASTERIX. Edition 1.26, Proposed, November 2000
- 3. Eurocontrol Standard SUR.ET1.1000-STD-01-01. Radar Surveillance in En-Route Airspace and Major Terminal Areas.

This page is intentionally left blank

# 3. DEFINITIONS, ACRONYMS AND ABBREVIATIONS

3.1	Definitions	
	For the purposes o apply:	f this Eurocontrol Document, the following definitions shall
3.1.1	Catalogue of Data Items:	List of all the possible Data Items of each Data Category describing the Data Items by their reference, structure, size and units (where applicable).
3.1.2	Data Block:	Unit of information seen by the application as a discrete entity by its contents. A Data Block contains one or more Record(s) containing data of the same Category.
3.1.3	Data Category:	Classification of the data in order to permit inter alia an easy identification.
3.1.4	Data Field:	Physical implementation for the purpose of communication of a Data Item, it is associated with a unique Field Reference Number and is the smallest unit of transmitted information.
3.1.5	Data Item:	The smallest unit of information in each Data Category.
3.1.6	Record:	A collection of transmitted Data Fields of the same Category preceded by a Field Specification field, signalling the presence/absence of the various Data Fields
3.1.7	User Application Profile:	The mechanism for assigning Data Items to Data Fields, and containing all necessary information which needs to be standardised for the successful encoding and decoding of the messages.

#### 3.2 Acronyms and Abbreviations

For the purposes of this Eurocontrol Document the following shall apply:

**ASTERIX** All Purpose STructured Eurocontrol suRveillance Information

**EXchange** 

**CAT** Data Category

**COMT** Communications Team (EATMP)

**EATMP** European Air Traffic Control Management Programme

FRN Field Reference Number

**FSPEC** Field Specification

**FX** Field Extension Indicator

ICAO International Civil Aviation Organization

LEN Length Indicator
LSB Least Significant Bit

MSSR Monopulse Secondary Surveillance Radar

MTD Moving Target Detection

NM Nautical Mile, unit of distance (1852 metres)

**PSR** Primary Surveillance Radar

RDP Radar Data Processing (System)
RDPC Radar Data Processing Chain
REP Field Repetition Indicator

s second, unit of time SAC System Area Code

**SDP** Surveillance Data Processing (system)

SICSystem Identification CodeSPSpecial Purpose IndicatorSSRSecondary Surveillance Radar

**STFRDE** Surveillance Task Force on Radar Data Exchange

**SURT** Surveillance Team (EATMP)

**UAP** User Application Profile (see Definitions)

**UTC** Co-ordinated Universal Time

#### 4. GENERAL PRINCIPLES

#### 4.1 General

The transmission of monoradar information shall require the transmission of two types of messages:

- data messages or radar target reports containing plot or track information (not covered by this document);
- radar service messages used to signal status information of the radar station to the user systems.

#### 4.2 Time Management

Time Management principles apply only to conventional rotating antennas.

#### 4.2.1 Definition

The sector time stamp shall be consistent with the reported sector azimuth.

#### 4.2.2 Requirements for Time Stamping

The timestamping shall comply with the Coordinated Universal Time (UTC) as specified in ICAO Annex 5. It shall be used to time stamp radar data.

#### 4.3 North Marker and Sector Crossing Messages

This paragraph only applies to conventional rotating antennas.

At every north crossing one and only one North Marker Message shall be transmitted. The highest priority shall be given to the transmission of the North Marker Message; this shall not be delayed by the plot processing activities.

Sector Crossing Messages are optional messages. When used, they shall always be thirty-two per revolution.

#### 4.4 Unused Bits in Data Items.

Decoders of ASTERIX data **shall never assume and rely on** specific settings of spare or unused bits. However in order to improve the readability of binary dumps of ASTERIX records, it is recommended to set all spare bits to zero.

#### 4.5 Definitions and Addressing Concepts

In order to address radar sources in an unambiguous way, a simple abstract model for concepts like sensors or radar systems has been designed.

#### 4.5.1 Radar Sensor

In the framework of Category 034 a Radar Sensor is a detection/measurement device, either of the Primary (PSR) or Secondary Surveillance Radar (SSR, MSSR) type, which uses a single rotating antenna assembly.

#### 4.5.2 Radar System

In the framework of Category 034 a Radar System is a construction, consisting of either **one single** sensor or a **combination of two** sensors of different types. In the case of combined sensors it is assumed that the respective antenna subsystems are configured, such that:

- a coincidence in target detection is guaranteed;
- a single co-ordinate reference point is used.

#### 4.5.3 Combination of Target Reports

The Radar Data Combiner is a function which combines (merges) the digitized target reports (plots) from two sensors constituting one Radar System.

#### 4.5.4 Addressing Concepts: Assigning SAC/SIC Codes

By convention a dedicated and unambiguous SAC/SIC code shall be assigned to every Radar System.

#### **EXAMPLES**

- A back-to-back configuration of two PSRs with an on-mounted SSR antenna each, is considered as two Radar Systems, being addressed via two SAC/SIC codes.
- 2. A main tower carrying a combined PSR/SSR radar station, supplemented with a standby tower at several hundreds of meters from the main tower and supporting a single back-up SSR station, shall be considered as two independent Radar Systems. It is irrelevant whether both radar systems are synchronized or not, and in addition whether only one Radar System at a time transmits its data or both Radar Systems simultaneously.
- 3. Two distinct radar heads, located at close distance, whose data is processed in a time-exclusive way by the same plot processor equipment may be considered as a single Radar System, using a single SAC/SIC address, provided that:
  - the same geographical reference point is used, irrespective of whether the data of head#1 or head#2 is selected;
  - the access lines to the site carry only the data of one head at a time.

Where the above conditions are not simultaneously met, it is imperative to assign two SAC/SIC codes.

## 4.6 Radar Service Messages

#### 4.6.1 Types of Radar Service Messages

Four types of radar service messages have been identified:

- Sector Crossing Messages;
- North Marker Messages;
- Geographical Filtering Messages;
- Jamming Strobe Messages.

#### 4.6.1.1 Sector Crossing Messages

- **4.6.1.1.1** When Sector Crossing messages are used, the transmission of 32 messages shall be synchronised (possibly with some delay) with the antenna rotation.
- **4.6.1.1.2** Sector crossing messages shall be time-stamped. The time information should be the time at which the antenna has crossed the azimuth defining the beginning of the sector, and not the time of transmission of the message.
- **4.6.1.1.3** By convention, the sector 0 crossing message shall signal the crossing of the North azimuth. It may contain more information than other sector crossing messages.

#### 4.6.1.2 North Marker Messages

- **4.6.1.2.1** These messages shall signal, independently of the sector crossing messages and as quickly as possible, the crossing of the local geographical North azimuth by the antenna.
- **4.6.1.2.2** The North marker message shall not replace the sector 0 crossing message. The transmission of the sector 0 crossing messages can be delayed like other sector crossing messages.

#### 4.6.1.3 Geographical Filtering Messages

These messages shall be sent to inform the user system(s) on the activation and the de-activation of geographical selective plots or tracks filtering processes.

#### 4.6.1.4 Jamming Strobe Messages

These messages shall be sent to indicate an area where jamming strobe has been detected.

#### 4.6.2 User Application Profile and Data Block

- **4.6.2.1** A single UAP has been standardised and shall be used to transmit service messages from a radar station to user RDP systems.
- **4.6.2.2** Data Blocks containing radar service messages shall have the following layout:

CAT = 034	LEN	FSPEC	Items of the first record	FSPEC	Items of the last record

#### Where:

- CAT = 034 is a one-octet field indicating that the Data Block contains service messages;
- LEN is a two-octet field indicating the total length in octets of the Data Block, including the CAT and LEN fields;
- FSPEC is the Field Specification.

#### 4.7 Composition of Messages

- **4.7.1** Messages shall be composed of Data Items assembled in the order defined by the Field Reference Number (FRN) in the associated UAP.
- **4.7.2** When sent, items shall always be transmitted in a Record with the corresponding FSPEC bits set to one.

# 5. LAYOUT OF RADAR SERVICE MESSAGES

#### 5.1 Standard Data Items

The standardised Data Items which shall be used for the transmission of radar service messages are defined in Table 4 and described in the following pages.

Table 4 - Standard Data Items of Category 034

Data Item Ref. No.	Description	System Units
1034/000	Message Type	N.A.
1034/010	Data Source Identifier	N.A.
1034/020	Sector Number	360°/(2 <sup>8</sup> )
1034/030	Time of Day	1/128 s
1034/041	Antenna Rotation Period	1/128 s
1034/050	System Configuration & Status	N.A.
1034/060	System Processing Mode	N.A.
1034/070	Message Count Values	N.A.
1034/090	Collimation Error	Range: 1/128 NM Azimuth: 360°/(2 <sup>14</sup> )
1034/100	Generic Polar Window	RHO: 1/256 NM THETA: 360°/(2 <sup>16</sup> )
1034/110	Data Filter	N.A.
1034/120	3D-position of source	Height : 1 m Latitude: 180°/(2 <sup>23</sup> ) Longitude: 180°/(2 <sup>23</sup> )

#### 5.2 Description of Standard Data Items

## 5.2.1 Data Item I034/000, Message Type


**Definition:** This Data Item allows for a more convenient handling of the

messages at the receiver side by further defining the type of

transaction.

**Format :** One-octet fixed length Data Item.

Structure:



bits-8/1 Message Type

#### **Encoding Rule:**

This data item shall be present in every ASTERIX record.

#### **NOTES**

- 1. In applications where transactions of various types are exchanged, the Message Type Data Item facilitates the proper message handling at the receiver side.
- 2. All Message Type values are reserved for common standard use.
- 3. The following set of Message Types are standardised for Category 034 records:
  - 001 North Marker message
  - 002 Sector crossing message
  - 003 Geographical filtering message
  - 004 Jamming Strobe message
- 4. The list of items present for the four message types is defined in the following table.

M stands for mandatory, O for optional, X for never present.

Table 1 Message Types


Type Item	001 North Marker	002 Sector Crossing	003 Geographical Filtering	004 Jamming Strobe
I034/000 Message Type	М	М	М	М
I034/010 Data Source Identifier	М	М	М	М
I034/020 Sector Number	Х	М	Х	Х
I034/030 Time of Day	М	М	0	0
I034/041 Antenna Rotation Period	0	Х	Х	Х
I034/050 System Configuration & Status	0	0	Х	Х
I034/060 System Processing Mode	0	0	Х	Х
I034/070 Message Count Values	0	0	Х	Х
I034/090 Collimation Error	0	0	Х	Х
I034/100 Generic Polar Window	Х	Х	0	М
I034/110 Data Filter	Х	Х	М	Х
I034/120 3D-position of source	0	Х	Х	Х

#### 5.2.2 Data Item 1034/010, Data Source Identifier

**Definition:** Identification of the radar station from which the data are received.

**Format :** Two-octet fixed length Data Item.

Structure:



#### **Encoding Rule:**

See table in I034/000.

**NOTE** - The up-to-date list of SACs is published on the Eurocontrol Web Site (<a href="http://www.eurocontrol.int/asterix">http://www.eurocontrol.int/asterix</a>).


#### 5.2.3 Data Item I034/020, Sector Number

Definition: Eight most significant bits of the antenna azimuth defining a

particular azimuth sector.

Format: One-octet fixed length Data Item.

Structure:



#### **Encoding Rule:**


See Table in I034/000.


# 5.2.4 Data Item 1034/030, Time of Day

**Definition:** Absolute time stamping expressed as UTC time.

**Format :** Three-octet fixed length Data Item.

Structure:





#### **Encoding Rule:**

See Table in 1034/000.

For the message types where this data item is mandatory, it shall be sent, except in case of failure of all sources of time stamping. Every radar station using ASTERIX shall be equipped with at least one synchronised time source. The time information, coded in three octets, shall reflect the exact time of an event (crossing of the azimuth defining the beginning of a sector by the antenna), expressed as a number of 1/128 s elapsed since last midnight.

#### **NOTES**

1. The time of day value is reset to zero each day at midnight.


#### 5.2.5 Data Item I034/041, Antenna Rotation Speed

**Definition:** Antenna rotation period as measured between two consecutive

North crossings or as averaged during a period of time.

**Format :** Two-octet fixed length Data Item.

Structure:



#### **Encoding Rule:**

See table in I034/000.

**NOTE** - This item represents the antenna rotation period as measured by the radar station between two consecutive North crossings, or a calculated antenna rotation speed as averaged during a period of time, or during a number of antenna rotation scans.

## 5.2.6 Data Item I034/050, System Configuration and Status

**Definition:** Information concerning the configuration and status of a System. **Format:** Compound Data Item, comprising an extensible primary subfield

(initially and patterns) followed by a variable

(initially one octet; one octet extents), followed by a variable

number of secondary subfields.

# Structure of Primary Subfield:

noid.										
		C	Octet	no.	1					
8	7	6	5	4	3	2	1			
СОМ	0	0	PSR	SSR	MDS	0	FX			
bit-8				(CC	OM)			Subfield #1: Common Part  0 Absence of Subfield #1  1 Presence of Subfield #1		
bit-7				(Sp	are)		=	Subfield #2: Spare Subfield  O Absence of Subfield #2  The Presence of Subfield #2		
bit-6				(Sp	are)		Subfield #3: Spare Subfield = 0 Absence of Subfield #3 = 1 Presence of Subfield #3			
bit-5				(PS	SR)		F =	Subfield #4: Specific Status for PSR Sensor = 0 Absence of Subfield #4 = 1 Presence of Subfield #4		
bit-4					SR)		=	Subfield #5: Specific Status for SSR Sensor = 0 Absence of Subfield #5 = 1 Presence of Subfield #5		
bit-3	Mode S = 0 Abs				Subfield #6: Specific Status for Mode S Sensor = 0 Absence of Subfield #6 = 1 Presence of Subfield #6					
bit-2				(Sp	are)		Subfield #7: Spare Subfield # = 0 Absence of Subfield # = 1 Presence of Subfield #			
bit-1				(FX	()			= 0 End of Primary Subfield = 1 Extension of Primary Subfield into next octet		

# Structure of COM Subfield:

The first Secondary Subfield (COM) contains the status of the common elements of a System.

			(	Octet	no.	1			•				
	8	7	6	5	4	3	2	1					
1	NOGO	RDPC	RDPR	OVL RDP	OVL XMT	MSC	TSV	0					
k	oit-8	3				OGC stem		(	Operational Release Status of the				
								=	<ul> <li>System is released for operational use</li> </ul>				
								=	= 1 Operational use of System is inhibited, i.e. the data shall be discarded by an operational SDPS				
k	bit-7 (RDPC)						)	=	Radar Data Processor Chain Selection Status = 0 RDPC-1 selected = 1 RDPC-2 selected				
k	bit-6 (RDPR)				OPR.	)	i r =	Event to signal a reset/restart of the selected Radar Data Processor Chair i.e. expect a new assignment of track numbers = 0 Default situation = 1 Reset of RDPC					
k	oit-5	5		(OVL RDP)					Radar Data Processor Overload ndicator = 0 Default, no overload = 1 Overload in RDP				
k	bit-4 (OVL XMT)						MT)	=	Fransmission Subsystem Overload Status = 0 Default, no overload = 1 Overload in transmission subsystem				
k	oit-3	3			(MS	SC)		=	Monitoring System Connected Status  O Monitoring system connected  Monitoring system disconnected				
k	oit-2	2			(TS	SV)		=	Fime Source Validity = 0 valid = 1 invalid				
k	oit-1				(Sp	are)	)	5	Set to zero				

#### **NOTES**

- 1. A time source is considered as valid when either externally synchronised or running on a local oscillator within the required accuracy of UTC.
- 2. Bit-6 (RDPR) is sent only once after the event.

# Structure of PSR Subfield: Specific Status information for a PSR sensor

Octet no. 1

_													
	8	7	6	5	4	3	2	1					
4	ANT	CH-	A/B	OVL	MSC	0	0	0					
k	oit-8				(AN	IT)		=	Selected antenna = 0 antenna 1 = 1 antenna 2				
k	oits-	7/6		(CH-A/B)				:	Channel A/B selection status = 00 No channel selected = 01 Channel A only selected = 10 Channel B only selected = 11 Diversity mode; Channel A and B selected				
k	oit-5	;			(OVL)				Overload condition = 0 No overload = 1 Overload				
ţ	oit-4				(MS	SC)		=	Monitoring System Connected Status:  0 Monitoring system connected  1 Monitoring system disconnected				
k	oits-	3/1			(Sp	are)		5	Spare bit set to 0				

Monitoring System Connected Status:

# Structure of SSR Subfield: Specific Status information for a SSR sensor

bit-4

	_	(	Octet	no.	1	_	_	
8	7	6	5	4	3	2	1	
ANT	CH-	A/B	OVL	MSC	0	0	0	
bit-8	3			(AN	IT)		=	Selected antenna : 0 antenna 1 : 1 antenna 2
bits-	7/6			(CF	I-A/I	В)	=	Channel A/B selection status  00 No channel selected  01 Channel A only selected  10 Channel B only selected  11 Invalid combination
bit-5 (OVL)				/L)		=	Overload condition : 0 No overload : 1 Overload	

(MSC)

# Structure of MDS Subfield: Specific Status information for a Mode S sensor

		(	Octet	no.	1					(	Octet	no.	2	ā		
16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	
ANT	СН	-A/B	OVL SUR		SCF	DLF	OVL SCF	OVL DLF	0	0	0	0	0	0	0	
bit-	16			(A)	<b>VT</b> )		=	Seled = 0 a = 1 a	nten	na 1						
bits	-15/ <i>*</i>	14		(Ch	<b>H-A</b> /I	В)	=	Chan surve = 00 = 01 = 10 = 11	illan No Cha Cha	ice char anne anne	nnel el A d	sele only only	ctec sele sele	l cted	Ī	
bit-	13			(O)	/LS	UR)	=	Overl = 0	o ol	verl	oad	n				
bit-	12			(MS	SC)		=	Monit = 0 N = 1 N	∕loni	torir	ng sy	/ster	n co	nne	cted	
bit-	11			(SC	CF)		=	Chan Surve = 0 ( = 1 (	eillar Char	nce ( nnel	Co-c A in	rdin use	atior			on
bit-	10		(DLF)					Channel A/B selection status for Data Link Function = 0 Channel A in use = 1 Channel B in use							for	
bit-9	bit-9				(OVL SCF)				Overload in Surveillance Co-ordination Function = 0 No overload = 1 Overload							
bit-8	3			(O)	/L D	LF)	=	Overl = 0	o ol	verl	oad	Link	Fur	nctio	n	
bits	7/1			(Sp	are)	)	5	Spare	e bit	set	to 0					

# **Encoding Rule:**

See Table in I034/000.

#### 5.2.7 Data Item I034/060, System Processing Mode

**Definition:** Status concerning the processing options, in use during the last

antenna revolution, for the various Sensors, composing the

System.

Format: Compound Data Item, comprising an extensible primary subfield

(initially one octet; one octet extents), followed by a variable

number of secondary subfields.

# Structure of Primary Subfield:

#### Octet no. 1

				110.				•
8	7	6	5	4	3	2	1	
СОМ	0	0	PSR	SSR	MDS	0	FX	
bit-8				(CC	OM)		=	Subfield #1: Common Part  Output On the Common Part  Output Outpu
bit-7				(Sp	are)		=	Subfield #2: Spare Subfield  : 0 Absence of Subfield #2  : 1 Presence of Subfield #2
bit-6				(Sp	are)		=	Subfield #3: Spare Subfield  : 0 Absence of Subfield #3  : 1 Presence of Subfield #3
bit-5				(PS	SR)		N =	Subfield #4: Specific Processing Mode information for PSR Sensor  0 Absence of Subfield #4  1 Presence of Subfield #4
bit-4				(SS	SR)		N =	Subfield #5: Specific Processing  Mode information for SSR Sensor  0 Absence of Subfield #5  1 Presence of Subfield #5
bit-3				(MI	OS)		ii =	Subfield #6: Specific Processing Mode information for Mode S Sensor  0 Absence of Subfield #6 1 Presence of Subfield #6
bit-2				(Sp	are)		=	Subfield #7: Spare Subfield  Output On the Control of the Control of Subfield #7  The Control of Subfield #7
bit-1				(FX	()			<ul><li>0 End of Primary Subfield</li><li>1 Extension of Primary Subfield into next octet</li></ul>

# Structure of COM Subfield:

The first Secondary Subfield (COM) defines the processing modes of the common elements of a System.

Octet no. 1

		`			<u> </u>			_	
8	7	6	5	4	3	2	1		
0	RI	ED-RI	OP	RE	ED-XN	ΛT	0		
bit-8	}			(Sp	are)	)		Fixed	setting to zero
bits7	7/5			(RE	D-F	RDP)		overlo = 000 = 001 = 010 = 011 = 100 = 101	ction Steps in use for an pad of the RDP No reduction active Reduction step 1 active Reduction step 2 active Reduction step 3 active Reduction step 4 active Reduction step 5 active Reduction step 6 active Reduction step 7 active
bits-	4/2			(RE	D-X	(MT)		overlosubsy = 000 = 001 = 010 = 011 = 100 = 101 = 110	ction Steps in use for an ead of the Transmission stem  No reduction active Reduction step 1 active Reduction step 2 active Reduction step 3 active Reduction step 4 active Reduction step 5 active Reduction step 6 active Reduction step 7 active Reduction step 7 active
bit-1				(Sp	are)	)		= 0 Sp	pare bit, fixed set to zero

# Structure of PSR Subfield: Specific Processing Mode information for a PSR sensor

bits-2/1

		C	Octet	no.	1			
8	7	6	5	4	3	2	1	
POL	RI	ED-RA	AD	Sī	ГС	0	0	
bit-8				(PC	DL)		=	Polarization in use by PSR  O Linear polarization  Circular polarization
bits-	7/5			(RE	ED-F	RAD)	=======================================	Reduction Steps in use as result of an overload within the PSR subsystem 1000 No reduction active 1001 Reduction step 1 active 1010 Reduction step 2 active 1011 Reduction step 3 active 1010 Reduction step 4 active 1011 Reduction step 5 active 1110 Reduction step 6 active 1111 Reduction step 7 active
bits-	bits-4/3			/3 (STC)				Sensitivity Time Control Map in use = 00 STC Map-1 = 01 STC Map-2 = 10 STC Map-3 = 11 STC Map-4

Spare bits; fixed set to zero

(Spare)

## Structure of SSR Subfield: Specific Processing Mode information for a SSR sensor

Octet no. 1

8	7	6	5	4	3	2	1
RI	ED-RA	۸D	0	0	0	0	0

bits-8/6 (RED-RAD) Reduction Steps in use as result of an

overload within the SSR subsystem

= 000 No reduction active

= 001 Reduction step 1 active

= 010 Reduction step 2 active

= 011 Reduction step 3 active

= 100 Reduction step 4 active

= 101 Reduction step 5 active

= 110 Reduction step 6 active = 111 Reduction step 7 active

bits-5/1 (Spare) Spare bits; fixed set to zero

### Structure of MDS Subfield: Specific Processing Mode information for a Mode S Sensor

_			Octet	no.	1	_	
8	7	6	5	4	3	2	1
RI	ED-RA	\D	CLU	0	0	0	0

bits-8/6 (RED-RAD) Reduction Steps in use as result of an

overload within the Mode S subsystem

= 000 No reduction active

= 001 Reduction step 1 active

= 010 Reduction step 2 active

= 011 Reduction step 3 active

= 100 Reduction step 4 active = 101 Reduction step 5 active

= 101 Reduction step 5 active

= 110 Reduction step 6 active

= 111 Reduction step 7 active

bit-5 (CLU) Cluster State

= 0 Autonomous

= 1 Not autonomous

bits-4/1 (Spare) Spare bits; fixed set to zero

#### **Encoding Rule:**

See Table in I034/000.

**NOTE -** Applicable to all defined secondary subfields. The actual mapping between the up to seven data reduction steps and their associated data reduction measures is not subject to standardisation.

#### 5.2.8 Data Item 1034/070, Message Count Values

**Definition:** Message Count values, according the various types of messages,

for the last completed antenna revolution, counted between two


North crossings


Format: Repetitive Data Item, starting with a one-octet Field Repetition

Indicator (REP) followed by at least one message counter of two-

octet length.

Structure:





\_\_\_\_

Prime Interest

D. . I .

bits-11/1

(COUNTER)

11-bit counter value

+ all SSR/Mode S data

+ SSR/Mode S data not in Area of

= 16 Filter for PSR+Enhanced Surveillance

#### **Encoding Rule:**

See Table in 1034/000.

#### 5.2.9 Data Item I034/090, Collimation Error


**Definition:** Averaged difference in range and in azimuth for the primary target

position with respect to the SSR target position as calculated by

the radar station.

**Format :** Two-octet fixed length Data Item.

Structure:



## **Encoding Rule:**

See Table in I034/000.


NOTE - Negative values are coded in two's complement form.


#### 5.2.10 Data Item I034/100, Generic Polar Window


**Definition:** Geographical window defined in polar co-ordinates.

**Format :** Eight-octet fixed length Data Item.

Structure:







		(	Octe	t no.	7			Octet no. 8								
16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	
		1	1		I	THI	ETA-E	ND	ı	ı			ı	ı	LSB	
bit-	49		(LSB) = 1/256 NM. Max. Range = 256 NM													
bit-	33			(LS	SB)		=	-	256 ax. F			256	NN	1		
bit-	17			(LS	SB)		=	36	60°/(2	2 <sup>16</sup> ) :	= ap	prox	c. 0.0	0055	°	
bit-	1			(LS	SB)		=	: 36	0°/(2	2 <sup>16</sup> )=	= ap	orox	. 0.0	055	0	

#### Examples of Geographical windows:

Polar Cell	Rho_start	Rho_end	Theta_start	Theta_end
Azimuth Sector	0	256 NM	Theta_start	Theta_end
Range Ring	Rho_start	Rho_end	0	360°
Total Coverage	0	256 NM	0	360°

#### **Encoding Rule:**

See Table in I034/000.

This data item shall be sent when:


- indicating a geographical filtering,
- indicating a jamming strobe area.

#### 5.2.11 Data Item I034/110 Data Filter

**Definition:** Data Filter, which allows suppression of individual data types.

**Format :** One octet fixed length Data Item.

Structure: Structure:



bits 8/1 (TYP)

- 0 invalid value
- = 1 Filter for Weather data
- = 2 Filter for Jamming Strobe
- = 3 Filter for PSR data
- = 4 Filter for SSR/Mode S data
- = 5 Filter for SSR/Mode S + PSR data
- = 6 Enhanced Surveillance data
- = 7 Filter for PSR+Enhanced Surveillance data
- 8 Filter for PSR+Enhanced Surveillance+ SSR/Mode S data not in Area ofPrime Interest
- = 9 Filter for PSR+Enhanced Surveillance
  - + all SSR/Mode S data

#### **Encoding Rule:**

See Table in 1034/000.

See also encoding rules for I034/100.

#### **NOTES**


- 1. This Data Item is often used in conjunction with I034/100 and represents a Data Filter for a specific geographical subarea. A Data Source may have zero, one or multiple data filters active at any time.
- 2. If I034/110 is not accompanied with I034/100, then the Data Filter is valid throughout the total area of coverage.


#### 5.2.12 Data Item 1034/120 3D-Position Of Data Source.

**Definition:** 3D-Position of Data Source in WGS 84 Co-ordinates.

**Format :** Eight-octet fixed length Data Item.

Structure:





	Octet no. 5										(	Octe	no.6	3		
3	32 31 30 29 28 27 26							25	24	23	22	21	20	19	18	17
								LSB								

			(	Octe	t no.	7		Octet no.8								
	16 15 14 13 12 11 10 9									7	6	5	4	3	2	1
	Longitude in								WGS	84						LSB
hits-64/49 (Height of																

	Longitude	IN VVGS 84
bits-64/49	(Height of Data Source)	Signed Height of the Data Source, expressed in meters above WGS 84 reference ellipsoid.
Bit-49	(LSB)	= 1 metre
Bits-48/25	(Latitude)	Latitude in WGS 84 expressed in two's complement Range: -90<= latitude<= 90degrees
Bit 25	(LSB)	= 180/2 <sup>23</sup> degrees = 2.145767*10 <sup>-05</sup> degrees This corresponds to an accuracy of at least 2.3844 metres
Bits-24/1	(Longitude)	Longitude in WGS 84 expressed in two complement Range: -180 < = longitude<180 degree
Bit-1	(LSB)	= 180/2 <sup>23</sup> degrees = 2.145767*10 <sup>-05</sup> degrees This corresponds to an accuracy of at

least 2.3844 metres

## **Encoding Rule:**

See Table in I034/000.

# 5.3 Standard User Application Profile

**5.3.1** The following standard UAP shown in Table 5 shall be used for the transmission of radar service messages:

**Table 5 - Standard UAP for Radar Service Messages** 

FRN	Data Item	Data Item Description	Length in Octets
1	1034/010	Data Source Identifier	2
2	1034/000	Message Type	1
3	1034/030	Time-of-Day	3
4	1034/020	Sector Number	1
5	1034/041	Antenna Rotation Period	2
6	1034/050	System Configuration and Status	1+
7	1034/060	System Processing Mode	1+
FX	N/A.	Field Extension Indicator	N/A.
8	1034/070	Message Count Values	(1+2*N)
9	1034/100	Generic Polar Window	8
10	1034/110	Data Filter	1
11	1034/120	3D-Position of Data Source	8
12	1034/090	Collimation Error	2
13	RE-Data Item	Reserved Expansion Field	1+1+
14	SP-Data Item	Special Purpose Field	1+1+
FX	N/A.	Field Extension Indicator	n.a.

#### where:

- the first column indicates the FRN associated to each Data Item used in the UAP;
- the fourth column gives the format and the length of each item, a stand-alone figure indicates the octet count of a fixed-length Data Item, 1+ indicates a variable-length Data Item comprising a first part of one-octet followed by n-octets extent as necessary.