# 224- Transport Management Commands

224.1 Transport Management Command Tree 224.2 IP Net-to-media Management Command

224-7290 224-7291

Issue: 01 3HH-08079-FCEH-TCZZA 7289

## 224.1 Transport Management Command Tree

## **Description**

This chapter gives an overview of nodes that are handled by "Transport Management Commands".

### **Command Tree**

```
----admin
----transport
----ip-net-to-media
- (interface-name)
- network-addr
- phy-addr
- (delete)
```

7290 3HH-08079-FCEH-TCZZA Issue: 01

## 224.2 IP Net-to-media Management Command

### **Command Description**

This command allows the operator to delete the IP address out of the ARP table.

#### **User Level**

The command can be accessed by operators with transport privileges, and executed by operators with transport privileges.

## **Command Syntax**

The command has the following syntax:

> admin transport ip-net-to-media (interface-name) network-addr <Ip::V4AddressHex> phy-addr <Sys::MacAddr> [ (delete) ]

#### **Command Parameters**

Table 224.2-1 "IP Net-to-media Management Command" Resource Parameters

Resource Identifier	Type	Description
(interface-name)	Format:	name of the interface
	eth1	
	Possible values:	
	- eth1 : control interface	
network-addr	Parameter type: <ip::v4addresshex></ip::v4addresshex>	ip addr corresponding to
	Format:	media-dependent physical addr
	- IPv4-address	
phy-addr	Parameter type: <sys::macaddr></sys::macaddr>	media-dependent physical addr
	Format:	
	- a mac-address (example: 01:02:03:04:05:06)	
	- length: 6	

#### Table 224.2-2 "IP Net-to-media Management Command" Command Parameters

Parameter	Type	Description
(delete)	Format:	optional parameter
	delete	delete a ip-net-to-media
	Possible values:	-
	- delete : delete a ip-net to media entry	

Issue: 01 3HH-08079-FCEH-TCZZA 7291