41- Voice Ont Configuration Commands

| 11.1 Voice Ont Configuration Command Tree | 41-1362 |
|---|----------|
| 11.2 Voice ONT Service Configuration Command | 41-1369 |
| 11.3 Performance Monitoring configuration command for | 41-1374 |
| /OIP service | |
| 11.4 Voice ONT POTS Configuration Command | 41-1376 |
| 11.5 Voice ONT Voice-Port Configuration Command | 41-1380 |
| 11.6 GPON Authentication Security Profile Configuration | 41-1384 |
| Command | |
| 11.7 Voice ONT Secure URI profile Configuration | 41-1386 |
| command | |
| 11.8 GPON URI Profile Configuration Command | 41-1388 |
| 11.9 GPON Tone Pattern Profile Configuration Command | 41-1389 |
| 11.10 GPON Tone Pattern Sequence Profile Configuration | 41-1391 |
| Command | |
| 11.11 Tone Event Profile Configuration Command | 41-1395 |
| 11.12 GPON Busy Tone Event Profile Configuration | 41-1396 |
| Command | |
| 11.13 GPON First Call Wait Tone Event Profile | 41-1398 |
| Configuration Command | |
| 11.14 GPON Second Call Wait Tone Event Profile | 41-1400 |
| Configuration Command | |
| 11.15 GPON Third Call Wait Tone Event Profile | 41-1402 |
| Configuration Command | |
| 11.16 GPON Fourth Call Wait Tone Event Profile | 41-1404 |
| Configuration Command | 44 4 400 |
| 41.17 GPON Alert Tone Event Profile Configuration | 41-1406 |
| Command 11.18 GPON Special Dial Tone Event Profile Configuration | 41-1408 |
| Command | 41-1400 |
| 11.19 GPON Special Info Tone Event Profile Configuration | 41-1410 |
| Command | 41-1410 |
| 11.20 GPON Release Tone Event Profile Configuration | 41-1412 |
| Command | 71 1712 |
| 11.21 GPON Congest Tone Event Profile Configuration | 41-1414 |
| Command | 41 1414 |
| 11.22 GPON Confirm Tone Event Profile Configuration | 41-1416 |
| Command | |
| 11.23 GPON Dial Tone Event Profile Configuration | 41-1418 |
| Command | |
| 11.24 GPON Message Wait Tone Event Profile | 41-1420 |
| Configuration Command | |
| 11.25 GPON Reorder Tone Event Profile Configuration | 41-1422 |
| Command | |
| 11.26 GPON Ring Back Tone Event Profile Configuration | 41-1424 |
| Command | |
| 11.27 GPON Roh Tone Event Profile Configuration | 41-1426 |
| Command | |
| 11.28 GPON Stutter Tone Event Profile Configuration | 41-1428 |
| Command | |
| 11 29 GPON Intrusion Tone Event Profile Configuration | 41-1430 |

| Command | |
|--|---------|
| 41.30 GPON Dead Tone Event Profile Configuration | 41-1432 |
| Command | |
| 41.31 GPON First User Defined Tone Event Profile | 41-1434 |
| Configuration Command | |
| 41.32 GPON Second User Defined Tone Event Profile | 41-1436 |
| Configuration Command | |
| 41.33 GPON Third User Defined Tone Event Profile | 41-1438 |
| Configuration Command | |
| 41.34 GPON Fourth User Defined Tone Event Profile | 41-1440 |
| Configuration Command | |
| 41.35 GPON Network Dial Plan Profile Configuration | 41-1442 |
| Command | |
| 41.36 Create a RTP profile | 41-1444 |
| 41.37 Create a Voice Service profile | 41-1446 |
| 41.38 Create a VOIP Application Service Profile | 41-1449 |
| 41.39 Create a VOIP media profile | 41-1454 |
| 41.40 GPON Ringing Pattern Profile Configuration | 41-1460 |
| Command | |
| 41.41 GPON Ringing Pattern Sequence Profile | 41-1462 |
| Configuration Command | |
| 41.42 GPON Ring Event Profile Configuration Command | 41-1465 |
| 41.43 GPON VOIP Feature Access Codes Profile | 41-1468 |
| Configuration Command | |
| 41.44 GPON Common VOIP Configuration Command | 41-1471 |
| 41.45 GPON Voice ONT POTS Rtp PM Mode Configuration | 41-1473 |
| Command | |
| 41.46 GPON ONT SIP Configuration Command | 41-1475 |
| 41.47 Voice Ont SIP Agent PM Mode Configuration | 41-1479 |
| Command | |
| 41.48 Voice Ont SIP Agent Call PM Mode Configuration | 41-1481 |
| Command | |
| 41.49 Configure ont POT SIP | 41-1483 |
| 41.50 Voice ONT MGC Configuration command | 41-1487 |
| 41.51 Voice ONT MGC PM monitoring command | 41-1491 |
| 41.52 Voice Ont Pots Call PM Mode Configuration | 41-1493 |
| Command | |

41.1 Voice Ont Configuration Command Tree

Description

This chapter gives an overview of nodes that are handled by "Voice Ont Configuration Commands".

Command Tree

```
----configure
    ----voice
         ----ont
             ----[no] service
                  - (voip-index)
                  - [no] label
                  - [no] ip-address
                  - [no] net-mask
                  - [no] default-router
                  - [no] mgc-ip-addr
                  - [no] sec-mgc-ip-addr
                  - [no] ftp-serv-ip-addr
                  - [no] dhcp
                  - [no] mgc-udp-port
                  - [no] voip-dscp
                  - [no] voip-mode
                  - conf-file-name
                  - [no] client-id
                  - [no] secret-id
                  - [no] secret-k
                  - [no] ipsec-enable
                  - [no] conf-method
                  - [no] spg-prof
                  - [no] spg-user-name
                  - [no] spg-passwd
                  - [no] spg-realm
                  - [no] ftp-user-name
                  - [no] ftp-passwd
                  - vlan
                  - [no] admin-state
                  - [no] uncond-omci-dnld
                  ----tc-layer
                       - [no] pm-collect
             ----pots
                  - (uni-idx)
                  - [no] custinfo
                  - [no] voip-serv
                  - [no] termination-id
                  - [no] pots-pwr-timer
                  - [no] call-hist
                  - [no] pwr-override
                  - [no] sip-msg-tot-th
```

1362 3HH-08079-FCEH-TCZZA Issue: 01

[no] brr-pkt-loss-th [no] excess-jitter-th [no] rx-gain

- [no] tx-gain
- [no] pots-dscp
- [no] veip-ptr
- [no] admin-state
- [no] transmit-path
- [no] nominal-feed-vol

----voice-port

- (uni-idx)
- [no] custinfo
- [no] voipconfig
- [no] pots-pwr-timer
- [no] call-hist
- [no] pwr-override
- [no] rx-gain
- [no] tx-gain
- [no] impedance
- [no] voip-media-prof
- [no] ne-file-name
- [no] admin-state

----[no] auth-sec-prof

- (index)
- name
- [no] validation-scheme
- [no] user-name
- [no] password
- [no] realm

----[no] sec-uri-profile

- (index)
- name
- [no] auth-securi-prof
- uri-prof

----[no] uri-prof

- (index)
- name
- [no] address
- [no] version

----[no] tone-seg-profile

- (index)
- name
- freq1
- power1
- freq2
- power2
- freq3
- power3
- freq4
- power4
- modulation-freq
- modulation-power
- duration

----[no] tone-seq-profile

- (index)
- name
- pattern-prof1
- [no] pattern-prof2
- [no] pattern-prof3
- [no] pattern-prof4
- [no] pattern-prof5
- [no] pattern-prof6

- [no] pattern-prof7
- [no] pattern-prof8

----[no] tone-event-prof

- (index)
- name

----busy-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----callwait1-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----callwait2-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----callwait3-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----callwait4-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----alert-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----special-dial-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----special-info-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----release-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----congest-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----confirm-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----dial-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----msg-wait-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----reorder-tone

- [no] tone-seq-prof

- [no] file-prof
- [no] repeat

----ringback-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----roh-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----stutter-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----intrusion-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----dead-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----userdef1-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----userdef2-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----userdef3-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----userdef4-tone

- [no] tone-seq-prof
- [no] file-prof
- [no] repeat

----[no] nwdial-plan-prof

- (index)

- name
- [no] critical-timeout
- [no] partial-timout
- [no] format
- digitmap1
- digitmap2
- digitmap3
- digitmap4

----[no] rtp-profile

- (index)
- name
- [no] local-port-min
- [no] local-port-max
- [no] dscp
- [no] piggy-back-event
- [no] tone-event
- [no] dtmf-event
- [no] cas-event

----[no] voice-serv-prof

- (index)

- name
- [no] securi-prof
- [no] toneset-prof
- [no] ringingset-prof
- [no] announce-type
- [no] jitter-target
- [no] jitter-max
- [no] echo-cancel
- [no] dtmf-level
- [no] dtmf-duration
- [no] hook-flash-min
- [no] hook-flash-max
- [no] pstn-variant

----[no] voip-app-service

- (index)
 - name
 - [no] calling-number
 - [no] calling-name
 - [no] caller-id-block
 - [no] caller-id-number
 - [no] caller-id-name
 - [no] anonymous-block
 - [no] call-waiting
 - [no] callerid-announce
 - [no] three-way-calling
 - [no] call-transfer
 - [no] call-hold
 - [no] call-park
 - [no] do-not-disturb
 - [no] flash-on-emer-cal
 - [no] masn-on-emer-ear
 - [no] emer-ser-org-hold
 - [no] six-way-calling
 - [no] mwi-splash-ring
 - [no] mwi-spl-dialtone
 - [no] mwi-visual-indi
 - [no] call-fwd-indicate
 - [no] dir-conn-feature [no] dialtone-dely-opt
 - [no] dir-conn-prof
 - [no] bridge-prof
 - [no] conf-prof

----[no] voip-media-prof

- (index)
- name
- [no] voiceserviceprof
- [no] rtp-prof
- [no] fax-mode
- [no] codec1st
- [no] pkt-period1st
- [no] silence1st
- [no] codec2nd
- [no] pkt-period2nd
- [no] silence2nd
- [no] codec3rd
- [no] pkt-period3rd
- [no] silence3rd
- [no] codec4th

- [no] pkt-period4th
- [no] silence4th
- [no] outofband-dtmf

----[no] ring-seg-prof

- (index)
- name
- [no] profile-ring
- ring-duration

----[no] ring-seq-prof

- (index)
- name
- pattern1
- [no] pattern2
- [no] pattern3
- [no] pattern4
- [no] pattern5

----[no] ringing-profile

- (index)
- name
- [no] ringing-seq-prof
- [no] ringing-file-prof
- [no] ringing-repeat
- [no] splash-seq-prof
- [no] splash-file-prof
- [no] splash-repeat

----[no] feat-acccode-prof

- (index)
- name
- [no] cancel-call-wait
- [no] hold
- [no] park
- [no] act-caller-id
- [no] deact-caller-id
- [no] act-dnd
- [no] deact-dnd
- [no] dnd-pin
- [no] emergency
- [no] intercom
- [no] attend-call-trans
- [no] blind-call-trans

----[no] voip-config

- (voip-index)
- protocol
- [no] conf-method
- [no] securi-prof

----pots-rtp

- (uni-index)
- [no] pm-collect

----[no] sip-config

- (sip-index)
- [no] proxyserv-prof
- [no] outproxyserv-prof
- [no] primary-dns
- [no] secondary-dns
- [no] reg-expire-time
- [no] re-reg-head-start
- [no] aor-host-prt-prof
- [no] registrar-prof
- [no] soft-sw-vendor

- [no] opt-tx-cntrl
- [no] uri-format
- [no] dscp
- [no] udp-port

----sip-agent

- (ont-index)
- [no] pm-collect

----sip-call

- (ont-index)
- [no] pm-collect

----voice-sip-port

- (pots-index)
- [no] user-aor
- [no] display-name
- [no] val-scheme
- [no] user-name
- [no] password
- [no] realm
- [no] voice-mail-prof
- [no] voice-mail-to
- [no] ntwk-dp-prof
- [no] app-serv-prof
- [no] ac-code-prof
- [no] rlstimer
- [no] rohtimer

----[no] mgc-config

- (if-index)
- pri-mgcuri-profid
- sec-mgcuri-profid
- [no] protocol-ver
- [no] msg-format
- [no] max-retry-time
- [no] max-retries
- [no] status-delay-time
- base-termid
- [no] sig-dscp
- [no] udp-port
- [no] sw-vendor
- [no] cnf-msg-profid

----mgc-agent

- (voip-index)
- [no] pm-collect

----pots-call

- (uni-idx)
- [no] pm-collect

41.2 Voice ONT Service Configuration Command

Command Description

This command is to configure the service related paramters for ONT.

NOTE: OLT prohibits the entry of the following range of well-known IP addresses:

224.0.0.0 to 239.255.255.255 (multicast)

127.0.0.0 to 127.255.255.255 (loopback)

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no service (voip-index)) | (service (voip-index) [no label | label <Gpon::Label>] [no ip-address | ip-address <Gpon::Ipaddr>] [no net-mask | net-mask <Gpon::Ipaddr>] [no default-router | default-router <Gpon::Ipaddr>] [no mgc-ip-addr | mgc-ip-addr <Gpon::Ipaddr>] [no sec-mgc-ip-addr | sec-mgc-ip-addr <Gpon::Ipaddr>] [no dhcp | dhcp <Gpon::Dhcp>] [no mgc-udp-port | mgc-udp-port <Gpon::PortSignalling>] [no voip-dscp | voip-dscp <Gpon::DscpSetting>] [no voip-mode | voip-mode <Gpon::GWMode>] conf-file-name <Gpon::ConfName> [no client-id | client-id <Gpon::ClientID>] [no secret-id | secret-id <Gpon::SecretID>] [no secret-k | secret-k <Gpon::SecretK>] [no ipsec-enable | ipsec-enable <Gpon::IpSec>] [no conf-method | conf-method <Gpon::SrvConfMethod>] [no spg-prof | spg-prof <Gpon::UriProfileName>] [no spg-user-name | spg-user-name <Gpon::SippingAuthUserName>] [no spg-passwd | spg-passwd <Gpon::AuthPasswd>] [no spg-realm | spg-realm <Gpon::Realm>] [no ftp-user-name | ftp-user-name <Gpon::FtpAuth>] [no ftp-passwd | ftp-passwd <Security::Password5>] vlan <Vlan::Index> [no admin-state | admin-state <Gpon::AdminState>] [[no] uncond-omci-dnld])

Command Parameters

Table 41.2-1 "Voice ONT Service Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---|--------------------------|
| (voip-index) | Format: | a unique interface index |
| | (<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <eqpt::ponid> / <eqpt::ontid> / 1</eqpt::ontid></eqpt::ponid> | |
| | ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup> | |
| | <ng2::ontid> / 1)</ng2::ontid> | |
| | Possible values: | |
| | - ng2 : ngpon2 style identification | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |

| Resource Identifier | Type | Description |
|----------------------------|--|-------------|
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Possible values: | |
| | - 1 : Gpon voip Port | |
| | Field type <ng2::channelgroup></ng2::channelgroup> | |
| | - channel group number | |
| | Field type <ng2::subchannelgroup></ng2::subchannelgroup> | |
| | - subchannel group number | |
| | Field type <ng2::ontid></ng2::ontid> | |
| | - the ONT identifier | |
| | Possible values: | |
| | - 1 : Gpon voip Port | |

Table 41.2-2 "Voice ONT Service Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------------------|---|---|
| [no] label | Parameter type: <gpon::label></gpon::label> | optional parameter with default |
| | Format: | value: "" |
| | - char string | label used to identify service |
| | - length: x<=80 | |
| [no] ip-address | Parameter type: <gpon::ipaddr></gpon::ipaddr> | optional parameter with default |
| | Format: | value: "0.0.0.0" |
| | - IPv4-address | The parameter is not visible |
| | | during modification. |
| | | ip Address of the ONT VoIP |
| | | Client |
| [no] net-mask | Parameter type: <gpon::ipaddr></gpon::ipaddr> | optional parameter with default |
| | Format: | value: "0.0.0.0" |
| | - IPv4-address | The parameter is not visible |
| | | during modification. |
| | | subnet mask for the VoIP client's |
| [] 1.C. 1 | December 11 and | subnet |
| [no] default-router | Parameter type: <gpon::ipaddr> Format:</gpon::ipaddr> | optional parameter with default value: "0.0.0.0" |
| | - IPv4-address | |
| | - IPV4-address | The parameter is not visible during modification. |
| | | default next hop IP Address used |
| | | by the VoIP Client |
| [no] mgc-ip-addr | Parameter type: <gpon::ipaddr></gpon::ipaddr> | optional parameter with default |
| [110] mgc-ip-addi | Format: | value: "0.0.0.0" |
| | - IPv4-address | The parameter is not visible |
| | ii v+ address | during modification. |
| | | IP Address of the Network Media |
| | | Gateway |
| [no] sec-mgc-ip-addr | Parameter type: <gpon::ipaddr></gpon::ipaddr> | optional parameter with default |
| [] Br -F | Format: | value: "0.0.0.0" |
| | - IPv4-address | The parameter is not visible |
| | | during modification. |
| | | IP Address of the secondary |
| | | Network Media Gateway |
| [no] ftp-serv-ip-addr | Parameter type: <gpon::ipaddr></gpon::ipaddr> | optional parameter with default |
| | Format: | value: "0.0.0.0" |
| | - IPv4-address | The parameter is not visible |
| | | during modification. |

| Parameter Type | default visible CP is |
|---|---------------------------------------|
| [no] dhcp | default visible CP is default visible |
| [no] dhcp | default visible CP is default visible |
| [no] dhcp | visible CP is default visible |
| Format: (enabled disabled) Possible values: - enabled : DHCP is enabled - disabled : DHCP is disabled [no] mgc-udp-port Parameter type: <gpon::portsignalling> Format: - TCP or UDP port used for signalling (L2 only) - range: [065535] [no] voip-dscp Parameter type: <gpon::dscpsetting> Parameter type: <gpon::dscpsetting> Format: - to set the DSCP value that the Voip Client will use - range: [063] Format: - to set the DSCP value to the D</gpon::dscpsetting></gpon::dscpsetting></gpon::portsignalling> | visible CP is default visible |
| (enabled disabled) Possible values: - enabled : DHCP is enabled - disabled : DHCP is disabled [no] mgc-udp-port Parameter type: <gpon::portsignalling> Format: - TCP or UDP port used for signalling (L2 only) - range: [065535] [no] voip-dscp Parameter type: <gpon::dscpsetting> Format: - to set the DSCP value that the Voip Client will use - range: [063] The parameter is not during modification. UDP port of the Media Government optional parameter with value: 24L The parameter with value: 24L The parameter with value: 24L The parameter is not during modification. The parameter is not during modification. The parameter is not during modification. To set the DSCP value that the Voip Client will use - range: [063]</gpon::dscpsetting></gpon::portsignalling> | CP is default visible |
| disabled) Possible values: - enabled : DHCP is enabled - disabled : DHCP is disabled Parameter type: <gpon::portsignalling> optional parameter with value: 2944L TCP or UDP port used for signalling (L2 only) The parameter is not during modification. UDP port of the Media Government: value: 24L To set the DSCP value that the Voip Client will use range: [063] optional parameter is not during modification. </gpon::portsignalling> | CP is default visible |
| Possible values: - enabled: DHCP is enabled - disabled: DHCP is disabled [no] mgc-udp-port Parameter type: <gpon::portsignalling> Format: - TCP or UDP port used for signalling (L2 only) - range: [065535] [no] voip-dscp Parameter type: <gpon::dscpsetting> Format: - to set the DSCP value that the Voip Client will use - range: [063] designate whether DH enabled optional parameter with value: 2944L The parameter is not during modification. value: 24L The parameter is not during modification. to set the DSCP value that to set the DSCP value that to set the DSCP value the during modification. to set the DSCP value the designate whether DH enabled optional parameter with value: 2944L The parameter is not during modification. to set the DSCP value the during modification.</gpon::dscpsetting></gpon::portsignalling> | default visible |
| - enabled : DHCP is enabled - disabled : DHCP is disabled [no] mgc-udp-port Parameter type: <gpon::portsignalling> Format: - TCP or UDP port used for signalling (L2 only) - range: [065535] [no] voip-dscp Parameter type: <gpon::dscpsetting> Format: - to set the DSCP value that the Voip Client will use - range: [063] enabled optional parameter with value: 2944L The parameter is not during modification. UDP port of the Media G Controller used for signaling optional parameter with value: 24L The parameter is not during modification. to set the DSCP value the</gpon::dscpsetting></gpon::portsignalling> | default visible |
| - disabled : DHCP is disabled [no] mgc-udp-port Parameter type: <gpon::portsignalling> Format: - TCP or UDP port used for signalling (L2 only) - range: [065535] [no] voip-dscp Parameter type: <gpon::dscpsetting> Format: - to set the DSCP value that the Voip Client will use - range: [063] - disabled - optional parameter with value: 2944L - to set the DSCP value that the Voip Client will use - disabled - optional parameter with value: 24L - to set the DSCP value that the Voip Client will use - range: [063] - optional parameter is not during modification to set the DSCP value that the Voip Client will use - range: [063]</gpon::dscpsetting></gpon::portsignalling> | visible |
| [no] mgc-udp-port Parameter type: <gpon::portsignalling> Format: - TCP or UDP port used for signalling (L2 only) - range: [065535] [no] voip-dscp Parameter type: <gpon::dscpsetting> Format: - to set the DSCP value that the Voip Client will use - range: [063] Parameter type: <gpon::dscpsetting> aptional parameter with value: 24L The parameter is not during modification. The parameter with value: 24L The parameter with value: 24L The parameter is not during modification. to set the DSCP value to set the DSCP v</gpon::dscpsetting></gpon::dscpsetting></gpon::portsignalling> | visible |
| Format: - TCP or UDP port used for signalling (L2 only) - range: [065535] Parameter type: <gpon::dscpsetting> Format: - to set the DSCP value that the Voip Client will use - range: [063] Format: - to set the DSCP value that the Voip Client will use - range: [063] Value: 2944L The parameter is not during modification. To set the DSCP value that the Voip Client will use - range: [063]</gpon::dscpsetting> | visible |
| - TCP or UDP port used for signalling (L2 only) - range: [065535] The parameter is not during modification. UDP port of the Media Government of th | |
| - range: [065535] - range: [065535] - during modification. UDP port of the Media Government o | |
| UDP port of the Media G Controller used for signalia [no] voip-dscp Parameter type: <gpon::dscpsetting> Format: - to set the DSCP value that the Voip Client will use - range: [063] Optional parameter with value: 24L The parameter is not during modification. to set the DSCP value the during modification.</gpon::dscpsetting> | ateway |
| [no] voip-dscp Parameter type: <gpon::dscpsetting> optional parameter with value: 24L - to set the DSCP value that the Voip Client will use - range: [063] The parameter is not during modification. to set the DSCP value to</gpon::dscpsetting> | aicwav |
| [no] voip-dscp Parameter type: <gpon::dscpsetting> optional parameter with value: 24L - to set the DSCP value that the Voip Client will use - range: [063] to set the DSCP value t</gpon::dscpsetting> | |
| Format: - to set the DSCP value that the Voip Client will use - range: [063] rough in the Voip Client will use - range: [063] value: 24L The parameter is not during modification. to set the DSCP value the during modification. | |
| - to set the DSCP value that the Voip Client will use - range: [063] The parameter is not during modification. to set the DSCP value that the Voip Client will use | |
| - range: [063] during modification. to set the DSCP value t | visible |
| to set the DSCP value t | |
| | hat the |
| Voip Client will use | |
| [no] voip-mode Parameter type: <gpon::gwmode> optional parameter with</gpon::gwmode> | default |
| Format: value: "sip1" | |
| (gr303-h248 The parameter is not | visible |
| v5.x-h248 during modification. | |
| softswitch-h248 Used to set Voice G | ateway |
| signalling mode. | |
| sip2 Possible values: | |
| - gr303-h248 : GR303-H248 | |
| - v5.x-h248 : V5.x-H248 | |
| - softswitch-h248 : Softswitch-H248 | |
| - sip1 : Mode 1 SIP | |
| - sip2 : Mode 2 SIP | |
| conf-file-name Parameter type: <gpon::confname> mandatory parameter</gpon::confname> | |
| | Planned |
| - name of the Planned Configuration File that the VoIP Configuration File that th | e VoIP |
| Client must use for VoIP configuration. Client must use for | VoIP |
| - length: x<=49 configuration. | |
| [no] client-id Parameter type: <gpon::clientid> optional parameter with</gpon::clientid> | default |
| Format: value: "" | |
| | clientid |
| - length: x<=25 associated with the VoIPs | |
| [no] secret-id Parameter type: <gpon::secretid> optional parameter with value: ""</gpon::secretid> | аејаин |
| Format: - DHCP Option 90 Secret ID for VoIP Service. Up to 8 The parameter is not | visible |
| hexadecimal characters (example 01:02:03:04). | visibie |
| - length: x<=4 Consider the control of the contr | ID for |
| VoIP Service. Up | to 8 |
| | ^ |
| | w 8 |
| hexadecimal characters. | |
| | |
| hexadecimal characters. [no] secret-k Parameter type: <gpon::secretk> optional parameter with value: ""</gpon::secretk> | default |
| hexadecimal characters. [no] secret-k Parameter type: <gpon::secretk> optional parameter with value: ""</gpon::secretk> | default |

41 Voice Ont Configuration Commands

| Parameter | Туре | Description |
|-----------------------|---|---|
| | - length: x<=16 | VoIP Service. Up to 32 hexadecimal characters. |
| [no] ipsec-enable | Parameter type: <gpon::ipsec></gpon::ipsec> | optional parameter with default |
| | Format: | value: "disabled" |
| | (enabled | The parameter is not visible |
| | disabled) | during modification. |
| | Possible values: | Used to designate whether IPSEC |
| | - enabled : IPSEC is enabled | is enabled or disabled. |
| | - disabled : IPSEC is disabled | |
| [no] conf-method | Parameter type: <gpon::srvconfmethod></gpon::srvconfmethod> | optional parameter with default |
| | Format: | value: "ftp" |
| | (ftp | Used to determine the primary |
| | sipping | method the ONT uses to obtain |
| | omci) | VoIP configuration information. |
| | Possible values: | |
| | - ftp: FTP Server | |
| | - sipping : Sipping Server, editing to and from sipping is not | |
| | allowed | |
| | - omci : Omci ftp | |
| [no] spg-prof | Parameter type: <gpon::uriprofilename></gpon::uriprofilename> | optional parameter with default |
| | Format: | value: "" |
| | (none | URI profile that contains the |
| | <gpon:uriprofileptr></gpon:uriprofileptr> | address for acquiring the |
| | name : <asamprofilename>)</asamprofilename> | SIPPING Server. |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon:uriprofileptr></gpon:uriprofileptr> | |
| | - Index of the URI profile that contains the IP address of the | |
| | server | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] spg-user-name | Parameter type: <gpon::sippingauthusername></gpon::sippingauthusername> | optional parameter with default |
| | Format: | value: "" |
| | - user name required for sipping authentication | Username required for |
| | - length: x<=25 | authentication with the SIPPING |
| | | Server OR for PPPoE |
| [no] and neggyd | Parameter type: Chany Auth Daggyid | authentication. |
| [no] spg-passwd | Parameter type: <gpon::authpasswd></gpon::authpasswd> | optional parameter with default value: "" |
| | Format: | |
| | password required for authenticationlength: x<=25 | Password required for authentication with the SIPPING |
| | - length. X<-25 | Server OR for PPPoE |
| | | authentication. |
| [no] spg-realm | Parameter type: <gpon::realm></gpon::realm> | optional parameter with default |
| [110] spg-1callii | Format: | value: "" |
| | - realm required for authentication | Realm for authentication with the |
| | - length: x<=25 | SIPPING Server OR for the |
| | iongui. A\—23 | PPPoE access concentrator name. |
| [no] ftp-user-name | Parameter type: <gpon::ftpauth></gpon::ftpauth> | optional parameter with default |
| [110] Ttp-usor-Hallic | Format: | value: "" |
| | - authentication string | the Username required for |
| | - length: x<=25 | authentication with the FTP |
| | - Iongin. A\—23 | Server. |
| | | Berver. |

| Parameter | Type | Description |
|-----------------------|--|-----------------------------------|
| [no] ftp-passwd | Parameter type: <security::password5></security::password5> | optional parameter with default |
| | Format: | value: "plain : " |
| | (prompt | password required for |
| | plain : <security::plainpassword5>)</security::plainpassword5> | authentication with the FTP |
| | Possible values: | Server. |
| | - prompt : prompts the operator for a password | |
| | - plain : the password in plain text | |
| | Field type <security::plainpassword5></security::plainpassword5> | |
| | - authentication string | |
| | - length: x<=25 | |
| vlan | Parameter type: <vlan::index></vlan::index> | mandatory parameter |
| , 1411 | Format: | The parameter is not visible |
| | (<vlan::uvlanindex></vlan::uvlanindex> | during modification. |
| | stacked : <vlan::svlanindexstacked> :</vlan::svlanindexstacked> | vlan id |
| | <vlan::cvlanindex>)</vlan::cvlanindex> | Vidir id |
| | Possible values: | |
| | - stacked : stacked vlan identity | |
| | Field type <vlan::uvlanindex></vlan::uvlanindex> | |
| | - unstacked vlan identity | |
| | - range: [14093,4096] | |
| | Field type <vlan::svlanindexstacked></vlan::svlanindexstacked> | |
| | - service vlan identity | |
| | | |
| | - range: [14093] | |
| | Field type <vlan::cvlanindex></vlan::cvlanindex> | |
| | - customer vlan identity | |
| | - range: [04093] | |
| [no] admin-state | Parameter type: <gpon::adminstate></gpon::adminstate> | optional parameter with default |
| | Format: | value: "unlocked" |
| | (locked | Setting it to 'locked' causes OLT |
| | unlocked) | to block upstream traffic on this |
| | Possible values: | service |
| | - locked: Setting it to 'locked' causes OLT to block | |
| | upstream traffic on this service | |
| | - unlocked : Setting it to 'unlocked' causes OLT to allow | |
| | upstream traffic on this service | |
| [no] uncond-omci-dnld | Parameter type: boolean | optional parameter |
| | | The parameter is not visible |
| | | during creation. |
| | | download Voip XML |
| | | unconditionally |

41.3 Performance Monitoring configuration command for VOIP service

Command Description

configures the PM Mode of ONT-side TC-layer counters.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont service (voip-index) tc-layer [no pm-collect | pm-collect <Gpon::PmEnable>]

Command Parameters

Table 41.3-1 "Performance Monitoring configuration command for VOIP service" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---|--------------------------|
| (voip-index) | Format: | a unique interface index |
| | (<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <eqpt::ponid> / <eqpt::ontid> / 1</eqpt::ontid></eqpt::ponid> | |
| | ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup> | |
| | <ng2::ontid> / 1)</ng2::ontid> | |
| | Possible values: | |
| | - ng2 : ngpon2 style identification | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Possible values: | |
| | - 1 : Gpon voip Port | |
| | Field type <ng2::channelgroup></ng2::channelgroup> | |
| | - channel group number | |
| | Field type <ng2::subchannelgroup></ng2::subchannelgroup> | |
| | - subchannel group number | |
| | Field type <ng2::ontid></ng2::ontid> | |

| Resource Identifier | Type | Description |
|----------------------------|----------------------|-------------|
| | - the ONT identifier | |
| | Possible values: | |
| | - 1 : Gpon voip Port | |

Table 41.3-2 "Performance Monitoring configuration command for VOIP service" Command Parameters

| Parameter | Type | Description |
|-----------------|---|------------------------------------|
| [no] pm-collect | Parameter type: <gpon::pmenable></gpon::pmenable> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | indicates whether to layer counter |
| | enable) | Performance Monitors should be |
| | Possible values: | collected for this VOIP Service |
| | - disable : disable the collection | |
| | - enable : enable the collection | |

41.4 Voice ONT POTS Configuration Command

Command Description

This command allows the operator to configure pots specific data associated with an ont.

Parameter Termination ID is a case insensitive string up to 25 characters long. Only the following characters are allowed:

```
['a'..'z', 'A'..'Z', '0'..'9', '*', '/', '-', '_', '$', '@', or '.'].
```

The first character must be alphabetic. The string 'ROOT' is not allowed.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont pots (uni-idx) [no custinfo | custinfo | Copon::CustInfo>] [no voip-serv | voip-serv | Copon::VoipSrvIndex>] [no termination-id | termination-id | Copon::TerminationId>] [no pots-pwr-timer | pots-pwr-timer | Copon::PotsPwrTimer>] [no call-hist | call-hist | Call-hist | Call-hist | Call-hist | Copon::CallHist>] [no pwr-override | pwr-override | Copon::PotsPwrShedOverride>] [no sip-msg-tot-th | sip-msg-tot-th | copon::SipMsgTimeOutThreshold>] [no brr-pkt-loss-th | brr-pkt-loss-th | Copon::BrrPktLossThreshold>] [no excess-jitter-th | excess-jitter-th | copon::ExcessJitterThreshold>] [no rx-gain | rx-gain | copon::RxGain>] [no tx-gain | tx-gain | Copon::TxGain>] [no pots-dscp | pots-dscp | Copon::PotsDscpSetting>] [no veip-ptr | veip-ptr | Copon::OntSpIndexOrZero>] [no admin-state | admin-state | Copon::PotsAdminState>] [no transmit-path | transmit-path | Copon::Transmission>] [no nominal-feed-vol | nominal-feed-vol | Copon::NominalFeedVoltage>]

Command Parameters

Table 41.4-1 "Voice ONT POTS Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|--|---------------------------------|
| (uni-idx) | Format: | interface index of the pots uni |
| | (<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <pre><eqpt::ponid> / <eqpt::ontid> / <gpon::ontslotid> /</gpon::ontslotid></eqpt::ontid></eqpt::ponid></pre> | |
| | <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup> | |
| | <ng2::ontid> / <gpon::ontslotid> /</gpon::ontslotid></ng2::ontid> | |
| | <gpon::ontpotsportid>)</gpon::ontpotsportid> | |
| | Possible values: | |
| | - ng2 : ngpon2 style identification | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |

| Resource Identifier | Туре | Description |
|----------------------------|--|-------------|
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Field type <ng2::channelgroup></ng2::channelgroup> | |
| | - channel group number | |
| | Field type <ng2::subchannelgroup></ng2::subchannelgroup> | |
| | - subchannel group number | |
| | Field type <ng2::ontid></ng2::ontid> | |
| | - the ONT identifier | |
| | Field type <gpon::ontslotid></gpon::ontslotid> | |
| | - Gpon Ont Slot | |
| | - range: [114] | |
| | Field type <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | - Gpon Ont Pots Port | |
| | - range: [124] | |

Table 41.4-2 "Voice ONT POTS Configuration Command" Command Parameters

| Parameter | Туре | Description |
|----------------------|---|-----------------------------------|
| [no] custinfo | Parameter type: <gpon::custinfo></gpon::custinfo> | optional parameter with default |
| | Format: | value: "" |
| | - a printable string | information about pots port |
| | - length: x<=80 | |
| [no] voip-serv | Parameter type: <gpon::voipsrvindex></gpon::voipsrvindex> | optional parameter with default |
| | Format: | value: "1" |
| | - service number of the voip client service | service number of the voip client |
| | - range: [1] | service |
| [no] termination-id | Parameter type: <gpon::terminationid></gpon::terminationid> | optional parameter with default |
| | Format: | value: "" |
| | - identifies the POTS port in H248 VoIP signalling | identifies the POTS port in H248 |
| | messages. The first character must be alphabetic. The string | VoIP signalling messages |
| | 'ROOT' is not allowed. | |
| | - range: [a-zA-Z0-9*/\$@.] | |
| | - length: x<=25 | |
| [no] pots-pwr-timer | Parameter type: <gpon::potspwrtimer></gpon::potspwrtimer> | optional parameter with default |
| | Format: | value: "0" |
| | - time during which pots loop voltage is held up | time during which pots loop |
| | - range: [065535] | voltage is held up |
| [no] call-hist | Parameter type: <gpon::callhist></gpon::callhist> | optional parameter with default |
| | Format: | value: "disable" |
| | (enable | indicates whether or not a call |
| | disable) | history to be maintained for this |
| | Possible values: | line. |
| | - enable : enable PM collection | |
| | - disable : disable PM collection | |
| [no] pwr-override | Parameter type: <gpon::potspwrshedoverride></gpon::potspwrshedoverride> | optional parameter with default |
| | Format: | value: "false" |
| | (true | voice class power shedding |
| | false) | |
| | Possible values: | |
| | - true : port excluded from voice class power shedding | |
| | - false : port included in voice class power shedding | |
| [no] sip-msg-tot-th | Parameter type: <gpon::sipmsgtimeoutthreshold></gpon::sipmsgtimeoutthreshold> | optional parameter with default |
| | Format: | value: "0" |
| | - threshold for raising the SIP message timeout tca alarm | threshold for raising the SIP |
| | - range: [065535] | message timeout tca alarm |
| [no] brr-pkt-loss-th | Parameter type: <gpon::brrpktlossthreshold></gpon::brrpktlossthreshold> | optional parameter with default |

41 Voice Ont Configuration Commands

| Parameter | Туре | Description |
|-----------------------|---|---|
| | Format: | value: "0" |
| | - threshold for raising the bearer packet loss tca alarm | threshold for raising the bearer |
| | - unit: 1/256ths | packet loss tca alarm |
| | - range: [0255] | |
| [no] excess-jitter-th | Parameter type: <gpon::excessjitterthreshold></gpon::excessjitterthreshold> | optional parameter with default |
| | Format: | value: "0" |
| | - threshold for raising the jitter tca alarm in milliseconds | excessive jitter threshold in |
| | - unit: milliseconds | milliseconds |
| | - range: [065535] | |
| [no] rx-gain | Parameter type: <gpon::rxgain></gpon::rxgain> | optional parameter with default |
| | Format: | value: 0 |
| | - gain value for the received signal in 0.1db increments | gain value for the received signal |
| | - unit: db | in 0.1db increments |
| | - range: [-126] | |
| [no] tx-gain | Parameter type: <gpon::txgain></gpon::txgain> | optional parameter with default |
| | Format: | value: 0 |
| | - gain value for the transmit signal in 0.1db increments | gain value for the transmit signal |
| | - unit: db | in 0.1db increments |
| | - range: [-126] | |
| [no] pots-dscp | Parameter type: <gpon::potsdscpsetting></gpon::potsdscpsetting> | optional parameter with default |
| | Format: | value: 46 |
| | - dscp value for use in outgoing voip bearer packets (L3 | dscp value for use in outgoing |
| | only) | voip bearer packets |
| | - range: [063] | |
| [no] veip-ptr | Parameter type: <gpon::ontspindexorzero></gpon::ontspindexorzero> | optional parameter with default |
| | Format: | value: "none" |
| | (<gpon::ontslotid2> / <gpon::ontportid2></gpon::ontportid2></gpon::ontslotid2> | interface index of the veip uni |
| | none) | |
| | Possible values: | |
| | - none : default value | |
| | Field type <gpon::ontslotid2></gpon::ontslotid2> | |
| | - Gpon Ont Slot | |
| | - range: [014] | |
| | Field type <gpon::ontportid2></gpon::ontportid2> | |
| | - Gpon Ont Port | |
| | - range: [016] | |
| [no] admin-state | Parameter type: <gpon::potsadminstate></gpon::potsadminstate> | optional parameter with default |
| | Format: | value: "locked" |
| | (unlocked | administrative state of pptp pots |
| | locked) | uni |
| | Possible values: | |
| | - unlocked: activates the pots port | |
| [m.] (m. m. m.) | - locked : deactivates the pots port | |
| [no] transmit-path | Parameter type: <gpon::transmission></gpon::transmission> | optional parameter with default |
| | Format: | value: "not-supported" |
| | (full-time | allows setting the POTS UNI |
| | part-time | either to full-time onhook transmission |
| | not-supported) Possible values: | u ansinission |
| | | |
| | - full-time : full-time on-hook transmission | |
| | - part-time : part-time on-hook transmission | |
| [no] nominal food vol | - not-supported : do not care and do not send any OMCI | ontional nanameter with J-f14 |
| [no] nominal-feed-vol | Parameter type: <gpon::nominalfeedvoltage></gpon::nominalfeedvoltage> | optional parameter with default |
| | Format: | value: "not-supported" |
| | (not-supported | indicates the designed nominal |
| | < Gpon::NominalFeedVoltage>) | feed voltage of the POTS loop |
| | Possible values: | |

| Parameter | Type | Description |
|-----------|--|-------------|
| | - not-supported : do not care and do not send any OMCI | |
| | Field type <gpon::nominalfeedvoltage></gpon::nominalfeedvoltage> | |
| | - indicates the designed nominal feed voltage of the POTS | |
| | loop | |
| | - unit: Volts | |
| | - range: [1255,65535] | |

Command Output

Table 41.4-3 "Voice ONT POTS Configuration Command" Display parameters

| Specific Information | | |
|----------------------|---|----------------------------------|
| name | Type | Description |
| oper-state | Parameter type: <gpon::potsoperstate></gpon::potsoperstate> | operational state of the service |
| | (enabled | This element is always shown. |
| | disabled | |
| | unknown) | |
| | Possible values: | |
| | - enabled : enable the service | |
| | - disabled : disable the service | |
| | - unknown : unknown state | |

41.5 Voice ONT Voice-Port Configuration Command

Command Description

This command allows the operator to configure the voice port specific data associated with an ont.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont voice-port (uni-idx) [no custinfo | custinfo < Gpon::CustInfo>] [no voipconfig | voipconfig < Gpon::VoipConfig>] [no pots-pwr-timer | pots-pwr-timer < Gpon::PotsPwrTimer>] [no call-hist | call-hist < Gpon::CallHist>] [no pwr-override | pwr-override < Gpon::PotsPwrShedOverride>] [no rx-gain | rx-gain < Gpon::RxGain>] [no tx-gain | tx-gain < Gpon::TxGain>] [no impedance | impedance < Gpon::Impedance>] [no voip-media-prof | voip-media-prof < Gpon::VoipMediaProfilePointer>] [no ne-file-name | ne-file-name < Gpon::NEFileName>] [no admin-state | admin-state < Gpon::PotsAdminState>]

Command Parameters

Table 41.5-1 "Voice ONT Voice-Port Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|--|---------------------------------|
| (uni-idx) | Format: | interface index of the pots uni |
| | (<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <pre><eqpt::ponid> / <eqpt::ontid> / <gpon::ontslotid> /</gpon::ontslotid></eqpt::ontid></eqpt::ponid></pre> | |
| | <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup> | |
| | <ng2::ontid> / <gpon::ontslotid> /</gpon::ontslotid></ng2::ontid> | |
| | <gpon::ontpotsportid>)</gpon::ontpotsportid> | |
| | Possible values: | |
| | - ng2 : ngpon2 style identification | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Field type <ng2::channelgroup></ng2::channelgroup> | |

| Resource Identifier | Туре | Description |
|----------------------------|--|-------------|
| | - channel group number | |
| | Field type <ng2::subchannelgroup></ng2::subchannelgroup> | |
| | - subchannel group number | |
| | Field type <ng2::ontid></ng2::ontid> | |
| | - the ONT identifier | |
| | Field type <gpon::ontslotid></gpon::ontslotid> | |
| | - Gpon Ont Slot | |
| | - range: [114] | |
| | Field type <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | - Gpon Ont Pots Port | |
| | - range: [124] | |

Table 41.5-2 "Voice ONT Voice-Port Configuration Command" Command Parameters

| Parameter | Type | Description |
|---------------------|---|------------------------------------|
| [no] custinfo | Parameter type: <gpon::custinfo></gpon::custinfo> | optional parameter with default |
| | Format: | value: "" |
| | - a printable string | information about pots port |
| | - length: x<=80 | |
| [no] voipconfig | Parameter type: <gpon::voipconfig></gpon::voipconfig> | optional parameter with default |
| | Format: | value: "none" |
| | (none | associates pots port with sip or |
| | mgc | mgc agent |
| | sip) | |
| | Possible values: | |
| | - none : no association with sip or megaco | |
| | - mgc : associates with mgc agent | |
| | - sip: associates with sip agent | |
| [no] pots-pwr-timer | Parameter type: <gpon::potspwrtimer></gpon::potspwrtimer> | optional parameter with default |
| | Format: | value: "0" |
| | - time during which pots loop voltage is held up | time during which pots loop |
| | - range: [065535] | voltage is held up |
| [no] call-hist | Parameter type: <gpon::callhist></gpon::callhist> | optional parameter with default |
| | Format: | value: "disable" |
| | (enable | indicates whether or not a call |
| | disable) | history to be maintained for this |
| | Possible values: | line. |
| | - enable : enable PM collection | |
| | - disable : disable PM collection | |
| [no] pwr-override | Parameter type: <gpon::potspwrshedoverride></gpon::potspwrshedoverride> | optional parameter with default |
| • | Format: | value: "false" |
| | (true | voice class power shedding |
| | false) | |
| | Possible values: | |
| | - true : port excluded from voice class power shedding | |
| | - false : port included in voice class power shedding | |
| [no] rx-gain | Parameter type: <gpon::rxgain></gpon::rxgain> | optional parameter with default |
| 0 | Format: | value: 0 |
| | - gain value for the received signal in 0.1db increments | gain value for the received signal |
| | - unit: db | in 0.1db increments |
| | - range: [-126] | |
| [no] tx-gain | Parameter type: <gpon::txgain></gpon::txgain> | optional parameter with default |
| | Format: | value: 0 |
| | - gain value for the transmit signal in 0.1db increments | gain value for the transmit signal |
| | - unit: db | in 0.1db increments |
| | - range: [-126] | |
| [no] impedance | Parameter type: <gpon::impedance></gpon::impedance> | optional parameter with default |
| | Format: | value: "unspecified" |

| Parameter | Type | Description |
|----------------------|---|-----------------------------------|
| | (600 | standard impedance settings for |
| | 900 | the pots line |
| | 750 | |
| | 820 | |
| | 1050 | |
| | unspecified) | |
| | Possible values: | |
| | - 600 : 600 0hms | |
| | - 900 : 900 0hms | |
| | - 750 : 750 0hms + 150 nF + 270 ohms | |
| | - 820 : 820 0hms + 115 nF + 220 ohms | |
| | - 1050 : 1050 ohms + 230 nF + 320 ohms | |
| | - unspecified : the impedance of the line will be handled by | |
| | the ont internally | |
| [no] voip-media-prof | Parameter type: <gpon::voipmediaprofilepointer></gpon::voipmediaprofilepointer> | optional parameter with default |
| [no] voip media proi | Format: | value: "none" |
| | (none | voip media profile |
| | <gpon::voipmediaprofilepointer></gpon::voipmediaprofilepointer> | voip media prome |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::voipmediaprofilepointer></gpon::voipmediaprofilepointer> | |
| | - profile index | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] ne-file-name | Parameter type: <gpon::nefilename></gpon::nefilename> | optional parameter with default |
| [HO] He-IHE-Hame | Format: | value: "" |
| | | |
| | - file name used to supplement the network extension file | file name used to supplement the |
| | pointer in voice service profile | network extension file pointer in |
| [nol admin state | - length: x<=50 | voice service profile |
| [no] admin-state | Parameter type: <gpon::potsadminstate></gpon::potsadminstate> | optional parameter with default |
| | Format: | value: "locked" |
| | (unlocked | administrative state of pptp pots |
| | locked) | uni |
| | Possible values: | |
| | - unlocked : activates the pots port | |
| | - locked : deactivates the pots port | |

Command Output

Table 41.5-3 "Voice ONT Voice-Port Configuration Command" Display parameters

| Specific Information | | |
|----------------------|---|----------------------------------|
| name | Type | Description |
| oper-state | Parameter type: <gpon::potsoperstate></gpon::potsoperstate> | operational state of the service |
| | (enabled | This element is always shown. |
| | disabled | |
| | unknown) | |
| | Possible values: | |
| | - enabled : enable the service | |
| | - disabled : disable the service | |
| | - unknown : unknown state | |

41.6 GPON Authentication Security Profile Configuration Command

Command Description

This command creates the profile for accessing the server storing authentication security information for contacting network addresses. These profiles are normally associated with Voip Services that must reference common authentication information.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no auth-sec-prof (index) ) | ( auth-sec-prof (index) name <AsamProfileName> [ no validation-scheme | validation-scheme <Gpon::AuthSecValScheme> ] [ no user-name | user-name <Gpon::AuthUserName> ] [ no password | password <Security::Password5> ] [ no realm | realm <Gpon::Realm> ] )
```

Command Parameters

Table 41.6-1 "GPON Authentication Security Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|-----------------|---------------|
| (index) | Format: | profile index |
| | - profile index | |
| | - range: [120] | |

Table 41.6-2 "GPON Authentication Security Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|------------------------|---|---------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | profile name |
| | - length: 1<=x<=32 | |
| [no] validation-scheme | Parameter type: <gpon::authsecvalscheme></gpon::authsecvalscheme> | optional parameter with default |
| | Format: | value: "md5-digest" |
| | (disabled | The parameter is not visible |
| | md5-digest | during modification. |
| | basic-authentic) | validation scheme required for |
| | Possible values: | authentication |
| | - disabled : Validation disabled | |

41 Voice Ont Configuration Commands

| Parameter | Type | Description |
|----------------|---|---|
| | - md5-digest : validate using md5 digest authentication - basic-authentic : Validate using basic authentication | |
| [no] user-name | Parameter type: <gpon::authusername> Format: - user name required for authentication - length: x<=50</gpon::authusername> | optional parameter with default value: "" The parameter is not visible during modification. user name required for authentication |
| [no] password | Parameter type: <security::password5> Format: (prompt plain : <security::plainpassword5>) Possible values: - prompt : prompts the operator for a password - plain : the password in plain text Field type <security::plainpassword5> - authentication string - length: x<=25</security::plainpassword5></security::plainpassword5></security::password5> | optional parameter with default value: "plain: " The parameter is not visible during modification. password required for authentication |
| [no] realm | Parameter type: <gpon::realm> Format: - realm required for authentication - length: x<=25</gpon::realm> | optional parameter with default value: "" The parameter is not visible during modification. realm required for authentication |

41.7 Voice ONT Secure URI profile Configuration command

Command Description

This command creates a Secure URI Profile.

It provides (via pointers to other profiles) both the URI for accessing information plus the security information necessary to access the information

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no sec-uri-profile (index)) | (sec-uri-profile (index) name <AsamProfileName> [no auth-securi-prof | auth-securi-prof <Gpon::AuthProfileName>] uri-prof <Gpon::UriProfileName>)

Command Parameters

Table 41.7-1 "Voice ONT Secure URI profile Configuration command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|-----------------|------------------------|
| (index) | Format: | a unique profile index |
| | - profile index | |
| | - range: [150] | |

Table 41.7-2 "Voice ONT Secure URI profile Configuration command" Command Parameters

| Parameter | Type | Description |
|-----------------------|---|----------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | A string 132 characters long |
| | - length: 1<=x<=32 | which uniquely identifies this |
| | | Secure URI Profile |
| [no] auth-securi-prof | Parameter type: <gpon::authprofilename></gpon::authprofilename> | optional parameter with default |
| | Format: | value: "none" |
| | (none | The parameter is not visible |
| | <gpon:authprofptr></gpon:authprofptr> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | Authentication security profile |
| | Possible values: | that contains network address of |
| | - none : no profile to associate | the security server |
| | - name : profile name | |
| | Field type <gpon:authprofptr></gpon:authprofptr> | |

| Parameter | Type | Description |
|-----------|--|-----------------------------------|
| | - Index of the Authentication security profile | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| uri-prof | Parameter type: <gpon::uriprofilename></gpon::uriprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | (none | during modification. |
| | < Gpon: UriProfilePtr> | uri profile that contains network |
| | name : <asamprofilename>)</asamprofilename> | address of the configuration |
| | Possible values: | server |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon:uriprofileptr></gpon:uriprofileptr> | |
| | - Index of the URI profile that contains the IP address of the | |
| | server | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |

Command Output

Table 41.7-3 "Voice ONT Secure URI profile Configuration command" Display parameters

| Specific Information | | |
|-----------------------------|--|---|
| name | Type | Description |
| auth-securi-prof-name | Parameter type: <gpon::ignoredprintablestring> - ignored printable string</gpon::ignoredprintablestring> | name of the authentication security uri profile This element is only shown in detail mode. |
| uri-prof-name | Parameter type: <gpon::ignoredprintablestring> - ignored printable string</gpon::ignoredprintablestring> | name of the uri profile This element is only shown in detail mode. |

41.8 GPON URI Profile Configuration Command

Command Description

This command creates the URI profile for accessing the configuration server. These profiles are normally associated with Voip Services.

User Level

The command can be accessed by operators with equipment privileges, and executed by operators with equipment privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no uri-prof (index)) | (uri-prof (index) name < AsamProfileName> [no address | address < Gpon::UriProfileAddress>] [no version | version < Gpon::UriProfileVersionNbr>])

Command Parameters

Table 41.8-1 "GPON URI Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|-----------------|---------------|
| (index) | Format: | profile index |
| | - profile index | |
| | - range: [1100] | |

Table 41.8-2 "GPON URI Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------|---|-------------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | profile name |
| | - length: 1<=x<=32 | |
| [no] address | Parameter type: <gpon::uriprofileaddress></gpon::uriprofileaddress> | optional parameter with default |
| | Format: | value: "" |
| | - uri profile address | uri profile address that contains a |
| | - length: x<=100 | Fully Qualified Domain Name |
| | | (FQDN) or an IP Address (in dot |
| | | notation) |
| [no] version | Parameter type: <gpon::uriprofileversionnbr></gpon::uriprofileversionnbr> | optional parameter with default |
| | Format: | value: 1L |
| | - uri profile version number | uri profile version number |
| | - range: [12147483647] | |

41.9 GPON Tone Pattern Profile Configuration Command

Command Description

This command creates a profile that defines a tone (multi-frequency is supported) segment including duration and power. Multiple tone segment profiles are used to specify a tone that will be applied to the analog signal to the handset when a particular call event/condition occurs, such as sending a busy tone when the called party is busy.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no tone-seg-profile (index) ) | ( tone-seg-profile (index) name <AsamProfileName> freq1
<Gpon::ToneSegFrequency> power1
                                   <Gpon::ToneSegPower> freq2 <Gpon::ToneSegFrequency> power2
<Gpon::ToneSegPower>
                        freq3
                                <Gpon::ToneSegFrequency>
                                                            power3
                                                                      <Gpon::ToneSegPower>
                                    power4
<Gpon::ToneSegFrequency>
                                                     <Gpon::ToneSegPower>
                                                                                     modulation-freq
<Gpon::ToneSegModulationFrequency>
                                         modulation-power
                                                                <Gpon::ToneSegPower>
                                                                                            duration
<Gpon::ToneSegDuration>)
```

Command Parameters

Table 41.9-1 "GPON Tone Pattern Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|-----------------|---------------|
| (index) | Format: | profile index |
| | - profile index | |
| | - range: [150] | |

Table 41.9-2 "GPON Tone Pattern Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------|---|------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | profile name |
| | - length: 1<=x<=32 | |
| freq1 | Parameter type: <gpon::tonesegfrequency></gpon::tonesegfrequency> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - frequency | during modification. |
| | - unit: Hz | frequency of one of the tone |
| | - range: [04000] | components |
| power1 | Parameter type: <gpon::tonesegpower></gpon::tonesegpower> | mandatory parameter |
| | Format: | The parameter is not visible |

41 Voice Ont Configuration Commands

| Parameter | Type | Description |
|------------------|---|-------------------------------|
| | - power level | during modification. |
| | - unit: dBm | power level of freq1 |
| | - range: [-25.50.0] | |
| freq2 | Parameter type: <gpon::tonesegfrequency></gpon::tonesegfrequency> | mandatory parameter |
| 1- | Format: | The parameter is not visible |
| | - frequency | during modification. |
| | - unit: Hz | frequency of one of the tone |
| | - range: [04000] | components |
| power2 | Parameter type: <gpon::tonesegpower></gpon::tonesegpower> | mandatory parameter |
| powerz | Format: | The parameter is not visible |
| | - power level | during modification. |
| | - power level | power level of freq2 |
| | | power level of freq2 |
| <u> </u> | - range: [-25.50.0] | |
| freq3 | Parameter type: <gpon::tonesegfrequency></gpon::tonesegfrequency> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - frequency | during modification. |
| | - unit: Hz | frequency of one of the tone |
| | - range: [04000] | components |
| power3 | Parameter type: <gpon::tonesegpower></gpon::tonesegpower> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - power level | during modification. |
| | - unit: dBm | power level of freq3 |
| | - range: [-25.50.0] | |
| freq4 | Parameter type: <gpon::tonesegfrequency></gpon::tonesegfrequency> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - frequency | during modification. |
| | - unit: Hz | frequency of one of the tone |
| | - range: [04000] | components |
| power4 | Parameter type: <gpon::tonesegpower></gpon::tonesegpower> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - power level | during modification. |
| | - unit: dBm | power level of freq4 |
| | - range: [-25.50.0] | |
| modulation-freq | Parameter type: <gpon::tonesegmodulationfrequency></gpon::tonesegmodulationfrequency> | mandatory parameter |
| 1 | Format: | The parameter is not visible |
| | - frequency | during modification. |
| | - unit: Hz | modulation frequency for the |
| | - range: [02000] | tone segment |
| modulation-power | Parameter type: <gpon::tonesegpower></gpon::tonesegpower> | mandatory parameter |
| modulation-power | Format: | The parameter is not visible |
| | - power level | during modification. |
| | - power lever - unit: dBm | |
| | | modulation power for the tone |
| dynation | - range: [-25.50.0] | segment |
| duration | Parameter type: <gpon::tonesegduration></gpon::tonesegduration> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - duration | during modification. |
| | - unit: milliseconds | duration of the tone segment |
| | - range: [065535] | |

41.10 GPON Tone Pattern Sequence Profile Configuration Command

Command Description

This command creates a profile that defines a tone sequence by serially identifying tone segment profiles to associate for a sequence.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no tone-seq-profile (index)) | (tone-seq-profile (index) name <AsamProfileName> pattern-prof1 <Gpon::ZeroToneSegProfile> [no pattern-prof2 | pattern-prof2 <Gpon::ZeroToneSegProfile>] [no pattern-prof3 | pattern-prof3 <Gpon::ZeroToneSegProfile>] [no pattern-prof4 | pattern-prof4 <Gpon::ZeroToneSegProfile>] [no pattern-prof5 <Gpon::ZeroToneSegProfile>] [no pattern-prof6 | pattern-prof6 <Gpon::ZeroToneSegProfile>] [no pattern-prof7 | pattern-prof7 <Gpon::ZeroToneSegProfile>] [no pattern-prof8 | patter

Command Parameters

Table 41.10-1 "GPON Tone Pattern Sequence Profile Configuration Command" Resource
Parameters

| Resource Identifier | Type | Description |
|---------------------|-----------------|---------------|
| (index) | Format: | profile index |
| | - profile index | |
| | - range: [150] | |

Table 41.10-2 "GPON Tone Pattern Sequence Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|---------------|---|------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | profile name |
| | - length: 1<=x<=32 | |
| pattern-prof1 | Parameter type: <gpon::zerotonesegprofile></gpon::zerotonesegprofile> | mandatory parameter |
| | Format: | The parameter is not visible |
| | (none | during modification. |
| | < Gpon::ZeroToneSegProfilePointer> | tone segment profile |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |

41 Voice Ont Configuration Commands

| Parameter | Type | Description |
|--------------------|---|---|
| | - none : no profile to associate | _ |
| | - name : profile name | |
| | Field type <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] pattern-prof2 | Parameter type: <gpon::zerotonesegprofile></gpon::zerotonesegprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | The parameter is not visible |
| | < Gpon::ZeroToneSegProfilePointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | tone segment profile |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] pattern-prof3 | Parameter type: <gpon::zerotonesegprofile></gpon::zerotonesegprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | The parameter is not visible |
| | <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | tone segment profile |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| [no] nottom mof4 | The currently allowed values can be shown with online-help. Parameter type: <gpon::zerotonesegprofile></gpon::zerotonesegprofile> | antiqual nangurator with default |
| [no] pattern-prof4 | Format: | optional parameter with default value: "none" |
| | (none | The parameter is not visible |
| | | The Darameier is not visible |
| | | |
| | <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | during modification. |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>)</asamprofilename></gpon::zerotonesegprofilepointer> | |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values:</asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate</asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name</asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer></asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::zerotonesegprofilepointer> - profile index</gpon::zerotonesegprofilepointer></asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::zerotonesegprofilepointer> - profile index - range: [050]</gpon::zerotonesegprofilepointer></asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::zerotonesegprofilepointer> - profile index - range: [050] Data driven field type</gpon::zerotonesegprofilepointer></asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::zerotonesegprofilepointer> - profile index - range: [050] Data driven field type Possible values are depending on the actual configuration</gpon::zerotonesegprofilepointer></asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |
| | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::zerotonesegprofilepointer> - profile index - range: [050] Data driven field type Possible values are depending on the actual configuration and software.</gpon::zerotonesegprofilepointer></asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |
| [no] pattern-prof5 | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::zerotonesegprofilepointer> - profile index - range: [050] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.</gpon::zerotonesegprofilepointer></asamprofilename></gpon::zerotonesegprofilepointer> | during modification. tone segment profile |
| [no] pattern-prof5 | <gpon::zerotonesegprofilepointer> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::zerotonesegprofilepointer> - profile index - range: [050] Data driven field type Possible values are depending on the actual configuration and software.</gpon::zerotonesegprofilepointer></asamprofilename></gpon::zerotonesegprofilepointer> | during modification. |

| Parameter | Type | Description |
|--------------------|--|---------------------------------|
| | <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | during modification. |
| | name: <asamprofilename>)</asamprofilename> | tone segment profile |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] pattern-prof6 | Parameter type: <gpon::zerotonesegprofile></gpon::zerotonesegprofile> | optional parameter with default |
| r . J r | Format: | value: "none" |
| | (none | The parameter is not visible |
| | <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | during modification. |
| | name: <asamprofilename>)</asamprofilename> | tone segment profile |
| | Possible values: | 1-8 F |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] pattern-prof7 | Parameter type: <gpon::zerotonesegprofile></gpon::zerotonesegprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | The parameter is not visible |
| | < Gpon::ZeroToneSegProfilePointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | tone segment profile |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] pattern-prof8 | Parameter type: <gpon::zerotonesegprofile></gpon::zerotonesegprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | The parameter is not visible |
| | < Gpon::ZeroToneSegProfilePointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | tone segment profile |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::zerotonesegprofilepointer></gpon::zerotonesegprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |

Command Output

Table 41.10-3 "GPON Tone Pattern Sequence Profile Configuration Command" Display parameters

| Specific Information | | |
|----------------------|---|----------------------------------|
| name | Type | Description |
| pattern-prof1-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the tone segment profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| pattern-prof2-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the tone segment profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| pattern-prof3-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the tone segment profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| pattern-prof4-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the tone segment profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| pattern-prof5-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the tone segment profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| pattern-prof6-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the tone segment profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| pattern-prof7-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the tone segment profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| pattern-prof8-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the tone segment profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |

41.11 Tone Event Profile Configuration Command

Command Description

This command is used to create a profile that contains the associations of tone sequence profiles or file ids to call event/conditions.

Note, this profile supports either method for making this association (use of the tone sequence profile or identifying a file on the ONT where a bit map of the tone is located).

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no tone-event-prof (index)) | (tone-event-prof (index) name < AsamProfileName>)

Command Parameters

Table 41.11-1 "Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.11-2 "Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------|---|---------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | profile name |
| | - a profile name | |
| | - range: [a-zA-Z0-9] | |
| | - length: 1<=x<=32 | |

41.12 GPON Busy Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Busy tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) busy-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.12-1 "GPON Busy Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.12-2 "GPON Busy Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | The currently allowed values can be shown with online-help. | _ |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| _ | Format: | value: "none" |
| | (none | uri profile |
| | < Gpon::FileProfPtr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| _ | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.13 GPON First Call Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of the first Call Wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) callwait1-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.13-1 "GPON First Call Wait Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.13-2 "GPON First Call Wait Tone Event Profile Configuration Command" Command Parameters

| | Description |
|---|--|
| Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| Format: | value: "none" |
| (none | tone sequence profile |
| <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| name : <asamprofilename>)</asamprofilename> | |
| Possible values: | |
| - none : no profile to associate | |
| - name : profile name | |
| Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| - profile index | |
| - range: [050] | |
| | (none <gpon::toneseqprofptr> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::toneseqprofptr> - profile index</gpon::toneseqprofptr></asamprofilename></gpon::toneseqprofptr> |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | uri profile |
| | < Gpon::FileProfPtr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.14 GPON Second Call Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of the second Call Wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) callwait2-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.14-1 "GPON Second Call Wait Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.14-2 "GPON Second Call Wait Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |

| Parameter | Туре | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | uri profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.15 GPON Third Call Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of the third Call Wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) callwait3-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.15-1 "GPON Third Call Wait Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.15-2 "GPON Third Call Wait Tone Event Profile Configuration Command" Command Parameters

| | Description |
|---|--|
| Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| Format: | value: "none" |
| (none | tone sequence profile |
| <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| name : <asamprofilename>)</asamprofilename> | |
| Possible values: | |
| - none : no profile to associate | |
| - name : profile name | |
| Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| - profile index | |
| - range: [050] | |
| | (none <gpon::toneseqprofptr> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::toneseqprofptr> - profile index</gpon::toneseqprofptr></asamprofilename></gpon::toneseqprofptr> |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | uri profile |
| | < Gpon::FileProfPtr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.16 GPON Fourth Call Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a fourth Call Wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) callwait4-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.16-1 "GPON Fourth Call Wait Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.16-2 "GPON Fourth Call Wait Tone Event Profile Configuration Command" Command Parameters

| | Description |
|---|--|
| Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| Format: | value: "none" |
| (none | tone sequence profile |
| <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| name : <asamprofilename>)</asamprofilename> | |
| Possible values: | |
| - none : no profile to associate | |
| - name : profile name | |
| Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| - profile index | |
| - range: [050] | |
| | (none <gpon::toneseqprofptr> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon::toneseqprofptr> - profile index</gpon::toneseqprofptr></asamprofilename></gpon::toneseqprofptr> |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | Data driven field type | • |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.17 GPON Alert Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Alert tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) alert-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.17-1 "GPON Alert Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.17-2 "GPON Alert Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | The currently allowed values can be shown with online-help. | - |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| _ | Format: | value: "none" |
| | (none | URI profile |
| | < Gpon::FileProfPtr> | _ |
| | name: <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.18 GPON Special Dial Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Special Dial tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) special-dial-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.18-1 "GPON Special Dial Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.18-2 "GPON Special Dial Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |

| Parameter | Туре | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.19 GPON Special Info Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Special Info tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) special-info-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.19-1 "GPON Special Info Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.19-2 "GPON Special Info Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.20 GPON Release Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Release tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) release-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr>]
```

Command Parameters

Table 41.20-1 "GPON Release Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.20-2 "GPON Release Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |

| Parameter | Туре | Description |
|----------------|---|----------------------------------|
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.21 GPON Congest Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a congest tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) congest-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.21-1 "GPON Congest Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.21-2 "GPON Congest Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |

| Parameter | Туре | Description |
|----------------|---|----------------------------------|
| | Possible values are depending on the actual configuration | _ |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.22 GPON Confirm Tone Event Profile

Configuration Command

Command Description

This command is used to change or configure the definition of a Confirm tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) confirm-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr> ]
```

Command Parameters

Table 41.22-1 "GPON Confirm Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.22-2 "GPON Confirm Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |

| Parameter | Туре | Description |
|----------------|---|----------------------------------|
| | Possible values are depending on the actual configuration | - |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | uri profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.23 GPON Dial Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of the Dial tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) dial-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.23-1 "GPON Dial Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.23-2 "GPON Dial Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | The currently allowed values can be shown with online-help. | - |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | uri profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| _ | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.24 GPON Message Wait Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Message wait tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) msg-wait-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.24-1 "GPON Message Wait Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.24-2 "GPON Message Wait Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | uri profile |
| | < Gpon::FileProfPtr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.25 GPON Reorder Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Reorder tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) reorder-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr>]
```

Command Parameters

Table 41.25-1 "GPON Reorder Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.25-2 "GPON Reorder Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |

| Parameter | Туре | Description |
|----------------|---|----------------------------------|
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | uri profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.26 GPON Ring Back Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Ring Back tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) ringback-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.26-1 "GPON Ring Back Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.26-2 "GPON Ring Back Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | uri profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.27 GPON Roh Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Roh tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) roh-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.27-1 "GPON Roh Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.27-2 "GPON Roh Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | The currently allowed values can be shown with online-help. | _ |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| _ | Format: | value: "none" |
| | (none | uri profile |
| | < Gpon::FileProfPtr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| _ | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.28 GPON Stutter Tone Event Profile

Configuration Command

Command Description

This command is used to change or configure the definition of a Stutter tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont tone-event-prof (index) stutter-tone [ no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile> ] [ no file-prof | file-prof <Gpon::FileProfile> ] [ no repeat | repeat <Gpon::RepetitionNbr>]
```

Command Parameters

Table 41.28-1 "GPON Stutter Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.28-2 "GPON Stutter Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone sequence profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | uri profile |
| | < Gpon::FileProfPtr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: 0L |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.29 GPON Intrusion Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Intrusion tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) intrusion-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.29-1 "GPON Intrusion Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.29-2 "GPON Intrusion Tone Event Profile Configuration Command" Command Parameters

| er with default |
|-----------------|
| |
| |
| file |
| |
| |
| |
| |
| |
| |
| |
| |
| |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | Data driven field type | • |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.30 GPON Dead Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Dead tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) dead-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.30-1 "GPON Dead Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.30-2 "GPON Dead Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone segment profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | The currently allowed values can be shown with online-help. | - |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| - | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.31 GPON First User Defined Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a First User Defined tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) userdef1-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.31-1 "GPON First User Defined Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.31-2 "GPON First User Defined Tone Event Profile Configuration Command" Command Parameters

| Parameter | Туре | Description | |
|--------------------|---|---------------------------------|--|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default | |
| | Format: | value: "none" | |
| | (none | tone segment profile | |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | | |
| | name : <asamprofilename>)</asamprofilename> | | |
| | Possible values: | | |
| | - none : no profile to associate | | |
| | - name : profile name | | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | | |
| | - profile index | | |
| | - range: [050] | | |
| | | | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.32 GPON Second User Defined Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Second User Defined tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) userdef2-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.32-1 "GPON Second User Defined Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.32-2 "GPON Second User Defined Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone segment profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |

| Parameter | Type | Description |
|----------------|---|----------------------------------|
| | Data driven field type | • |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.33 GPON Third User Defined Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Third User Defined tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) userdef3-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.33-1 "GPON Third User Defined Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Туре | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.33-2 "GPON Third User Defined Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone segment profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |

| Parameter | Туре | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.34 GPON Fourth User Defined Tone Event Profile Configuration Command

Command Description

This command is used to change or configure the definition of a Fourth User Defined tone within the tone set.

As noted in the Tone Event Profile configuration command, the selection of the tone can be either via pointing to a Tone Sequence Profile, or by referencing a file on the ONT.

This command supports either mechanism.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont tone-event-prof (index) userdef4-tone [no tone-seq-prof | tone-seq-prof <Gpon::ToneSeqProfile>] [no file-prof | file-prof <Gpon::FileProfile>] [no repeat | repeat <Gpon::RepetitionNbr>]

Command Parameters

Table 41.34-1 "GPON Fourth User Defined Tone Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|----------------------------|---------------|
| (index) | Format: | profile index |
| | - tone event profile index | |
| | - range: [15] | |

Table 41.34-2 "GPON Fourth User Defined Tone Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| [no] tone-seq-prof | Parameter type: <gpon::toneseqprofile></gpon::toneseqprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | tone segment profile |
| | <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneseqprofptr></gpon::toneseqprofptr> | |
| | - profile index | |
| | - range: [050] | |

| Parameter | Туре | Description |
|----------------|---|----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] file-prof | Parameter type: <gpon::fileprofile></gpon::fileprofile> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile |
| | <gpon::fileprofptr></gpon::fileprofptr> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::fileprofptr></gpon::fileprofptr> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] repeat | Parameter type: <gpon::repetitionnbr></gpon::repetitionnbr> | optional parameter with default |
| | Format: | value: "0" |
| | - repitition number | number of times the tone file is |
| | - range: [010] | repeated |

41.35 GPON Network Dial Plan Profile Configuration Command

Command Description

This command creates a profile that defines a Network Dial Plan.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

 $> configure\ voice\ ont\ (\ no\ nwdial-plan-prof\ (index)\)\ |\ (\ nwdial-plan-prof\ (index)\ name\ < AsamProfileName\ [\ no\ critical-timeout\ |\ critical-timeout\ < Gpon::TimeOut\)\ [\ no\ partial-timout\ |\ partial-timout\ < Gpon::TimeOut\)\ [\ no\ format\ |\ format\ |\ Gpon::PlanFormat\)\ [\ digitmap1\ < Gpon::Digit\)\ [\ digitmap2\ < Gpon::Digit\)\ [\ digitmap3\ < Gpon::Digit\)\]\ [\ digitmap4\ < Gpon::Digit\)\]$

Command Parameters

Table 41.35-1 "GPON Network Dial Plan Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|-----------------|---------------------------|
| (index) | Format: | network dial plan profile |
| | - profile index | |
| | - range: [120] | |

Table 41.35-2 "GPON Network Dial Plan Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------------------|---|----------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | name of profile |
| | - length: 1<=x<=32 | |
| [no] critical-timeout | Parameter type: <gpon::timeout></gpon::timeout> | optional parameter with default |
| | Format: | value: 4L |
| | - dial timeout | The parameter is not visible |
| | - unit: sec | during modification. |
| | - range: [1.00040.000] | critical dial timeout in seconds |
| [no] partial-timout | Parameter type: <gpon::timeout></gpon::timeout> | optional parameter with default |
| | Format: | value: 16L |
| | - dial timeout | The parameter is not visible |
| | - unit: sec | during modification. |
| | - range: [1.00040.000] | partial dial timeout in seconds |
| [no] format | Parameter type: <gpon::planformat></gpon::planformat> | optional parameter with default |

| Parameter | Type | Description |
|-----------|---|--|
| | Format: (not-def h248 nsc) Possible values: - not-def: not defined - h248: h.248 format using dial plan tokens | value: "h248" The parameter is not visible during modification. specifies the dial plan format |
| digitmap1 | - nsc : nsc format Parameter type: <gpon::digit> Format: - ASCII character string - length: x<=256</gpon::digit> | optional parameter The parameter is not visible during modification. specifies part 1 of the actual digit map ascii symbols with delimiter |
| digitmap2 | Parameter type: <gpon::digit> Format: - ASCII character string - length: x<=256</gpon::digit> | optional parameter The parameter is not visible during modification. specifies part 2 of the actual digit map ascii symbols with delimiter '1' |
| digitmap3 | Parameter type: <gpon::digit> Format: - ASCII character string - length: x<=256</gpon::digit> | optional parameter The parameter is not visible during modification. specifies part 3 of the actual digit map ascii symbols with delimiter '1' |
| digitmap4 | Parameter type: <gpon::digit> Format: - ASCII character string - length: x<=256</gpon::digit> | optional parameter The parameter is not visible during modification. specifies part 4 of the actual digit map ascii symbols with delimiter '1' |

41.36 Create a RTP profile

Command Description

This command creates a RTP profile which provides information required by Real Time Protocol.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no rtp-profile (index)) | (rtp-profile (index) name <Gpon::RtpProfileName> [no local-port-min | local-port-min | Gpon::LocalPortMin>] [no local-port-max | local-port-max | Gpon::LocalPortMax>] [no dscp | dscp <Gpon::Dscp>] [no piggy-back-event | piggy-back-event <Gpon::PiggyBackEvent>] [no tone-event | tone-event <Gpon::ToneEvent>] [no dtmf-event | dtmf-event <Gpon::DtmfEvent>] [no cas-event | cas-event <Gpon::CasEvent>])

Command Parameters

Table 41.36-1 "Create a RTP profile" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---------------------|----------------------------------|
| (index) | Format: | access identifier of rtp profile |
| | - access identifier | |
| | - range: [110] | |

Table 41.36-2 "Create a RTP profile" Command Parameters

| Parameter | Type | Description |
|---------------------|---|------------------------------------|
| name | Parameter type: <gpon::rtpprofilename></gpon::rtpprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - unique rtp profile name | during modification. |
| | - length: 1<=x<=32 | unique rtp profile name |
| [no] local-port-min | Parameter type: <gpon::localportmin></gpon::localportmin> | optional parameter with default |
| | Format: | value: 50000L |
| | - Local port | The parameter is not visible |
| | - range: [500065000] | during modification. |
| | | base rtp port for voice traffic |
| [no] local-port-max | Parameter type: <gpon::localportmax></gpon::localportmax> | optional parameter with default |
| | Format: | value: 60000L |
| | - Local port | The parameter is not visible |
| | - range: [500065000] | during modification. |
| | | highest rtp port for voice traffic |
| [no] dscp | Parameter type: <gpon::dscp></gpon::dscp> | optional parameter with default |
| | Format: | value: 46L |
| | - dscp setting | The parameter is not visible |
| | - range: [063] | during modification. |

| Parameter | Type | Description |
|-----------------------|---|---|
| | | value of dscp setting to use in ip header |
| [no] piggy-back-event | Parameter type: <gpon::piggybackevent> Format:</gpon::piggybackevent> | optional parameter with default |
| | 1 0111140 | value: "disabled" |
| | (disabled | The parameter is not visible |
| | enabled) Possible values: | during modification. |
| | 1 obbiete (araes. | handling of rtp piggy back events |
| | disabled : disabled rtp piggyback eventsenabled : enabled rtp poggyback events | |
| [no] tone-event | Parameter type: <gpon::toneevent></gpon::toneevent> | optional parameter with default |
| [no] tone event | Format: | value: "disabled" |
| | (disabled | The parameter is not visible |
| | enabled) | during modification. |
| | Possible values: | handling tones via rtp tones |
| | - disabled : disabled rtp tone events | |
| | - enabled : enabled rtp tone events | |
| [no] dtmf-event | Parameter type: <gpon::dtmfevent></gpon::dtmfevent> | optional parameter with default |
| | Format: | value: "disabled" |
| | (disabled | The parameter is not visible |
| | enabled) | during modification. |
| | Possible values: | handling dtmf via rtp dtmf |
| | - disabled : disabled rtp dtmf events | |
| | - enabled : enabled rtp dtmf events | |
| [no] cas-event | Parameter type: <gpon::casevent></gpon::casevent> | optional parameter with default |
| | Format: | value: "disabled" |
| | (disabled | The parameter is not visible |
| | enabled) | during modification. |
| | Possible values: | handling cas via rtp cas |
| | - disabled : disabled rtp cas events | |
| | - enabled : enabled rtp cas events | |

41.37 Create a Voice Service profile

Command Description

This command creates a Voice Service profile which provides information required voice service function.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no voice-serv-prof (index) ) | ( voice-serv-prof (index) name <Gpon::VoiceServiceProfileName> [ no securi-prof | securi-prof <Gpon::SecureUriProfilePointer> ] [ no toneset-prof | toneset-prof | toneset-prof | considered | indicated |
```

Command Parameters

Table 41.37-1 "Create a Voice Service profile" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---------------------|------------------------------------|
| (index) | Format: | access identifier of voice service |
| | - access identifier | profile |
| | - range: [110] | |

Table 41.37-2 "Create a Voice Service profile" Command Parameters

| Parameter | Type | Description |
|------------------|---|-----------------------------------|
| name | Parameter type: <gpon::voiceserviceprofilename></gpon::voiceserviceprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - unique voip media profile name | during modification. |
| | - length: 1<=x<=32 | unique voice service profile name |
| [no] securi-prof | Parameter type: <gpon::secureuriprofilepointer></gpon::secureuriprofilepointer> | optional parameter with default |
| | Format: | value: 0L |
| | (none | The parameter is not visible |
| | < Gpon::SecureUriProfilePointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | voice service security profile |
| | Possible values: | pointer |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::secureuriprofilepointer></gpon::secureuriprofilepointer> | |
| | - profile index | |
| | - range: [050] | |

| Parameter | Type | Description |
|----------------------|---|-----------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] toneset-prof | Parameter type: <gpon::toneeventprofilepointer></gpon::toneeventprofilepointer> | optional parameter with default |
| [] F | Format: | value: 0L |
| | (none | The parameter is not visible |
| | <gpon::toneeventprofilepointer></gpon::toneeventprofilepointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | tone set profile it contains tone |
| | Possible values: | definitions |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::toneeventprofilepointer></gpon::toneeventprofilepointer> | |
| | - profile index | |
| | - range: [05] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] ringingset-prof | Parameter type: <gpon::ringeventprofilepointer></gpon::ringeventprofilepointer> | optional parameter with default |
| [mo] imgingset prof | Format: | value: 0L |
| | (none | The parameter is not visible |
| | <gpon::ringeventprofilepointer></gpon::ringeventprofilepointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | ringing set profile |
| | Possible values: | inging set prome |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::ringeventprofilepointer></gpon::ringeventprofilepointer> | |
| | - profile index | |
| | - range: [05] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] announce-type | Parameter type: <gpon::announcetype></gpon::announcetype> | optional parameter with default |
| 1 1 1 1 1 1 1 1 1 1 | Format: | value: 255L |
| | (silence | The parameter is not visible |
| | recorder-tone | during modification. |
| | fast-busy | treatment when subscriber goes |
| | voice | off-hook |
| | not-applicable) | |
| | Possible values: | |
| | - silence : silence | |
| | - recorder-tone : recorder type | |
| | - fast-busy : fast busy | |
| | - voice : voice | |
| | - not-applicable : not applicable | |
| [no] jitter-target | Parameter type: <gpon::jittertarget></gpon::jittertarget> | optional parameter with default |
| | Format: | value: 0L |
| | - jitter target | The parameter is not visible |
| | - range: [065535] | during modification. |
| | | target value of jitter buffer in |
| | | msec |
| [no] jitter-max | Parameter type: <gpon::jittermax></gpon::jittermax> | optional parameter with default |
| • | Format: | value: 0L |
| | - jitter max | The parameter is not visible |
| | - range: [065535] | during modification. |

| Parameter | Type | Description |
|----------------------|---|--|
| | | max buffer value of jitter buffer |
| | | in msec |
| [no] echo-cancel | Parameter type: <gpon::echocancel></gpon::echocancel> | optional parameter with default |
| | Format: | value: 1L |
| | (disabled | The parameter is not visible |
| | enabled) | during modification. |
| | Possible values: | enable or disable echo |
| | - disabled : disabled echo cancellation | cancellation |
| | - enabled : enabled echo cancellation | |
| [no] dtmf-level | Parameter type: <gpon::dtmflevel></gpon::dtmflevel> | optional parameter with default |
| | Format: | value: 0L |
| | - dtmf level | The parameter is not visible |
| | - range: [-253,0] | during modification. |
| F 11 C1 4 | D C D C | power level of dtmf tone |
| [no] dtmf-duration | Parameter type: <gpon::dtmfduration></gpon::dtmfduration> | optional parameter with default |
| | Format: | value: 0L |
| | - dtmf duration | The parameter is not visible |
| | - range: [065535] | during modification. |
| | | duration the tone being sent to subscriber |
| [no] hook-flash-min | Parameter type: <gpon::hookflashmin></gpon::hookflashmin> | optional parameter with default |
| [HO] HOOK-Hash-Hilli | Format: | value: 0L |
| | - hook flash min | The parameter is not visible |
| | - range: [065535] | during modification. |
| | Tange. [003333] | minimum duration to determine a |
| | | hook flash event |
| [no] hook-flash-max | Parameter type: <gpon::hookflashmax></gpon::hookflashmax> | optional parameter with default |
| [no] noon mass mass | Format: | value: 0L |
| | - hook flash max | The parameter is not visible |
| | - range: [065535] | during modification. |
| | | maximum duration to determine a |
| | | hook flash event |
| [no] pstn-variant | Parameter type: <gpon::pstnvariant></gpon::pstnvariant> | optional parameter with default |
| - | Format: | value: 0L |
| | - country code for the pots line | The parameter is not visible |
| | - range: [0999] | during modification. |
| | | current country code for pots line |

Command Output

Table 41.37-3 "Create a Voice Service profile" Display parameters

| Specific Information | | |
|----------------------|---|-----------------------------------|
| name | Type | Description |
| securi-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | security profile pointer |
| | - ignored printable string | This element is always shown. |
| toneset-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | tone event profile pointer |
| | - ignored printable string | This element is always shown. |
| ringingset-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | ringing set event profile pointer |
| | - ignored printable string | This element is always shown. |

41.38 Create a VOIP Application Service Profile

Command Description

This command creates a VOIP Application service profile which provides configuration information regarding calling features.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

configure voice ont (no voip-app-service (index)) | (voip-app-service (index) name <Gpon::VoipAppProfileName> [no calling-number | calling-number | calling-number | calling-number |] [no calling-name <Gpon::CidCallingName>] [no caller-id-block | caller-id-block <Gpon::CidCidBlock>] [no caller-id-number | caller-id-number <Gpon::CidCidNumber>] [no caller-id-name | caller-id-name <Gpon::CidCidName>] [no anonymous-block | anonymous-block <Gpon::CidAcr>] [no <Gpon::CwaitIdAnnounce>] [no three-way-calling | three-way-calling <Gpon::Ctrans3WayCalling>] [no call-transfer | call-transfer call-park | call-park <Gpon::CtransCallPark>] [no do-not-disturb | do-not-disturb <Gpon::CtransDoNotDisturb>] [no flash-on-emer-cal | flash-on-emer-cal <Gpon::CtransFlashOnEmergency>] [no emer-ser-org-hold emer-ser-org-hold <Gpon::CtransEmergencyServiceOrginateHold> | [no six-way-calling | six-way-calling <Gpon::Ctrans6WayCalling>] [no mwi-splash-ring | mwi-splash-ring <Gpon::CpresentMwiSplashRing>] [no mwi-spl-dialtone | mwi-spl-dialtone | Gpon::CpresentMwiSpecialDialtone | no mwi-visual-indi mwi-visual-indi <Gpon::CpresentMwiVisualInidcation>] [no call-fwd-indicate | call-fwd-indicate <Gpon::CpresentCallFwdIndicate>] [no dir-conn-feature | dir-conn-feature <Gpon::DirConnFeature>] [no dialtone-dely-opt | dialtone-dely-opt <Gpon::DialtoneDelayOpt>] [no dir-conn-prof | dir-conn-prof <Gpon::DirConnectProfilePointer>] [no bridge-prof | bridge-prof <Gpon::BridgeProfilePointer>] [no conf-prof | conf-prof <Gpon::ConfProfilePointer>])

Command Parameters

Table 41.38-1 "Create a VOIP Application Service Profile" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|---------------------|----------------------------|
| (index) | Format: | an access identifier index |
| | - access identifier | |
| | - range: [120] | |

Table 41.38-2 "Create a VOIP Application Service Profile" Command Parameters

| Parameter | Type | Description |
|-----------|---|---------------------------------|
| name | Parameter type: <gpon::voipappprofilename></gpon::voipappprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - unique voip app profile name | during modification. |
| | - length: 1<=x<=32 | unique voip app service profile |

| Parameter | Туре | Description |
|------------------------|---|-----------------------------------|
| | | name |
| [no] calling-number | Parameter type: <gpon::cidcallingnumber></gpon::cidcallingnumber> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | caller id supports calling number |
| | - disable : disable | |
| | - enable : enable | |
| [no] calling-name | Parameter type: <gpon::cidcallingname></gpon::cidcallingname> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | caller id supports calling name |
| | - disable : disable | |
| | - enable : enable | |
| [no] caller-id-block | Parameter type: <gpon::cidcidblock></gpon::cidcidblock> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | block both cid number and name |
| | - disable : disable | |
| | - enable : enable | |
| [no] caller-id-number | Parameter type: <gpon::cidcidnumber></gpon::cidcidnumber> | optional parameter with default |
| | Format: | value: "public" |
| | (public | The parameter is not visible |
| | private) | during modification. |
| | Possible values: | permanent presentation status for |
| | - public : disable | number |
| | - private : enable | |
| [no] caller-id-name | Parameter type: <gpon::cidcidname></gpon::cidcidname> | optional parameter with default |
| | Format: | value: "public" |
| | (public | The parameter is not visible |
| | private) | during modification. |
| | Possible values: | permanent presentation status for |
| | - public : disable | name |
| | - private : enable | |
| [no] anonymous-block | Parameter type: <gpon::cidacr></gpon::cidacr> | optional parameter with default |
| . , , | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | anonymous cid blocking |
| | - disable : disable | , |
| | - enable : enable | |
| [no] call-waiting | Parameter type: <gpon::cwaitcallwaiting></gpon::cwaitcallwaiting> | optional parameter with default |
| [no] can waring | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | call waiting feature supported |
| | - disable : disable | tan arang reatare supported |
| | - enable : enable | |
| [no] callerid-announce | Parameter type: <gpon::cwaitidannounce></gpon::cwaitidannounce> | optional parameter with default |
| [] carrotta announce | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable | during modification. |
| | Possible values: | caller id announcement feature |
| | - disable : disable | |
| | - disable : disable - enable : enable | supported |
| | - CHAUIC . CHAUIC | |

| Parameter | Туре | Description |
|------------------------|--|--|
| [no] three-way-calling | Parameter type: <gpon::ctrans3waycalling></gpon::ctrans3waycalling> | optional parameter with default |
| , | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | 3 way calling |
| | - disable : disable | 2 may curing |
| | - enable : enable | |
| [no] call-transfer | Parameter type: <gpon::ctranscalltransfer></gpon::ctranscalltransfer> | optional parameter with default |
| [no] can-transfer | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | | |
| | enable) | during modification. |
| | Possible values: | call transfer supported |
| | - disable : disable | |
| | - enable : enable | |
| [no] call-hold | Parameter type: <gpon::ctranscallhold></gpon::ctranscallhold> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | call hold |
| | - disable : disable | |
| | - enable : enable | |
| [no] call-park | Parameter type: <gpon::ctranscallpark></gpon::ctranscallpark> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | call park |
| | - disable : disable | our puri |
| | - enable : enable | |
| [no] do-not-disturb | Parameter type: <gpon::ctransdonotdisturb></gpon::ctransdonotdisturb> | optional parameter with default |
| [no] do not distaro | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | do not disturb |
| | - disable : disable | do not disturb |
| | - enable : enable | |
| [no] flock on amor col | | antional nanamatan with default |
| [no] flash-on-emer-cal | Parameter type: <gpon::ctransflashonemergency></gpon::ctransflashonemergency> | optional parameter with default value: "disable" |
| | Format: | |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | flash on emergency call |
| | - disable : disable | |
| | - enable : enable | |
| [no] emer-ser-org-hold | Parameter type | |
| | <pre><gpon::ctransemergencyserviceorginatehold></gpon::ctransemergencyserviceorginatehold></pre> | value: "disable" |
| | Format: | The parameter is not visible |
| | (disable | during modification. |
| | enable) | emergency service originate hold |
| | Possible values: | |
| | - disable : disable | |
| | - enable : enable | |
| [no] six-way-calling | Parameter type: <gpon::ctrans6waycalling></gpon::ctrans6waycalling> | optional parameter with default |
| [.] | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | 6 way calling |
| | - disable : disable | o way cannig |
| | - enable : enable | |
| | - CHADIC . CHADIC | |

| Parameter | Type | Description |
|------------------------|---|-------------------------------------|
| [no] mwi-splash-ring | Parameter type: <gpon::cpresentmwisplashring></gpon::cpresentmwisplashring> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | message waiting indication |
| | - disable : disable | splash ring |
| | - enable : enable | |
| [no] mwi-spl-dialtone | Parameter type: <gpon::cpresentmwispecialdialtone></gpon::cpresentmwispecialdialtone> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | message waiting indication |
| | - disable : disable | special dial tone |
| | - enable : enable | |
| [no] mwi-visual-indi | Parameter type: <gpon::cpresentmwivisualinidcation></gpon::cpresentmwivisualinidcation> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | message waiting indication visual |
| | - disable : disable | indication |
| | - enable : enable | |
| [no] call-fwd-indicate | Parameter type: <gpon::cpresentcallfwdindicate></gpon::cpresentcallfwdindicate> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | call forwarding indication |
| | - disable : disable | |
| | - enable : enable | |
| [no] dir-conn-feature | Parameter type: <gpon::dirconnfeature></gpon::dirconnfeature> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | direct connect feature |
| | - disable : disable | |
| | - enable : enable | |
| [no] dialtone-dely-opt | Parameter type: <gpon::dialtonedelayopt></gpon::dialtonedelayopt> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | The parameter is not visible |
| | enable) | during modification. |
| | Possible values: | dial tone delay option |
| | - disable : disable | |
| [] 1 | - enable : enable | |
| [no] dir-conn-prof | Parameter type: <gpon::dirconnectprofilepointer></gpon::dirconnectprofilepointer> | optional parameter with default |
| | Format: | value: 0L |
| | (none | The parameter is not visible |
| | <gpon::dirconnectprofilepointer></gpon::dirconnectprofilepointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | secure uri profile that contains ip |
| | Possible values: | of address of direct connect |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::dirconnectprofilepointer></gpon::dirconnectprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |

| Parameter | Type | Description |
|------------------|---|-------------------------------------|
| [no] bridge-prof | Parameter type: <gpon::bridgeprofilepointer></gpon::bridgeprofilepointer> | optional parameter with default |
| | Format: | value: 0L |
| | (none | The parameter is not visible |
| | <gpon::bridgeprofilepointer></gpon::bridgeprofilepointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | secure uri profile that contains ip |
| | Possible values: | address of bridge line agent |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::bridgeprofilepointer></gpon::bridgeprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] conf-prof | Parameter type: <gpon::confprofilepointer></gpon::confprofilepointer> | optional parameter with default |
| | Format: | value: 0L |
| | (none | The parameter is not visible |
| | <gpon::confprofilepointer></gpon::confprofilepointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | secure uri profile that contains ip |
| | Possible values: | address of conference factory |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::confprofilepointer></gpon::confprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |

Command Output

Table 41.38-3 "Create a VOIP Application Service Profile" Display parameters

| Specific Information | | |
|----------------------|---|--------------------------------|
| name | Type | Description |
| dir-conn-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the secure uri profile |
| | - ignored printable string | pointer |
| | | This element is always shown. |
| bridge-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the secure uri profile |
| | - ignored printable string | pointer |
| | | This element is always shown. |
| conf-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the secure uri profile |
| | - ignored printable string | pointer |
| | | This element is always shown. |

41.39 Create a VOIP media profile

Command Description

This command creates a VOIP media profile which provides information pertaining to voice encoding.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no voip-media-prof (index)) | (voip-media-prof (index) name <Gpon::VoipMediaProfileName> [no voiceserviceprof | voiceserviceprof <Gpon::VoiceServiceProfilePointer>] [no rtp-prof | rtp-prof <Gpon::RtpProfilePointer>] [no fax-mode | fax-mode <Gpon::FaxMode>] [no codec1st | codec1st <Gpon::CodecOrder>] [no pkt-period1st | pkt-period1st <Gpon::PktPeriodOrd>] [no silence1st | silence1st <Gpon::SilenceOrder>] [no codec2nd | codec2nd <Gpon::CodecOrder>] [no pkt-period2nd | pkt-period2nd <Gpon::PktPeriodOrd>] [no silence2nd | silence2nd <Gpon::PktPeriodOrd>] [no silence3rd | silence3rd <Gpon::SilenceOrder>] [no codec4th | codec4th <Gpon::CodecOrder>] [no pkt-period4th | pkt-period4th <Gpon::PktPeriodOrd>] [no silence4th | silence4th <Gpon::SilenceOrder>] [no outofband-dtmf | outofband-dtmf <Gpon::OutOfBand>])

Command Parameters

Table 41.39-1 "Create a VOIP media profile" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|---------------------|---------------------------------|
| (index) | Format: | access identifier of voip media |
| | - access identifier | profile |
| | - range: [110] | |

Table 41.39-2 "Create a VOIP media profile" Command Parameters

| Parameter | Type | Description |
|-----------------------|---|---------------------------------|
| name | Parameter type: <gpon::voipmediaprofilename></gpon::voipmediaprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - unique voip media profile name | during modification. |
| | - length: 1<=x<=32 | unique voip media profile name |
| [no] voiceserviceprof | Parameter type: <gpon::voiceserviceprofilepointer></gpon::voiceserviceprofilepointer> | optional parameter with default |
| | Format: | value: 0L |
| | (none | The parameter is not visible |
| | < Gpon:: VoiceServiceProfilePointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | voice service profile pointer |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::voiceserviceprofilepointer></gpon::voiceserviceprofilepointer> | |

| Parameter | Туре | Description |
|------------------|---|---------------------------------|
| | - profile index | * |
| | - range: [010] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] rtp-prof | Parameter type: <gpon::rtpprofilepointer></gpon::rtpprofilepointer> | optional parameter with default |
| L of Tr | Format: | value: 0L |
| | (none | The parameter is not visible |
| | <gpon::rtpprofilepointer></gpon::rtpprofilepointer> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | rtp profile |
| | Possible values: | Top prome |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::rtpprofilepointer></gpon::rtpprofilepointer> | |
| | - profile index | |
| | - range: [010] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] fax-mode | Parameter type: <gpon::faxmode></gpon::faxmode> | optional parameter with default |
| [IIO] Tax-IIIOdc | Format: | value: "passthru" |
| | (passthru | The parameter is not visible |
| | t.38) | during modification. |
| | Possible values: | defines how to handle fax calls |
| | - passthru : passthru mode | defines now to handle fax cans |
| | - t.38 : t.38 mode | |
| [no] codec1st | Parameter type: <gpon::codecorder></gpon::codecorder> | optional parameter with default |
| [HO] COUCCISE | Format: | value: "pcmu" |
| | (pcmu | The parameter is not visible |
| | unknown | during modification. |
| | unknown | codec selection option |
| | gsm | codec selection option |
| | g723 | |
| | div4.8 | |
| | div4.16 | |
| | lpc | |
| | pcma | |
| | g722 | |
| | 116.2 | |
| | 116.1 | |
| | qcelp | |
| | qeeip cn | |
| | mpa | |
| | g728 | |
| | div4.11 | |
| | div4.22 | |
| | g729) | |
| | Possible values: | |
| | - pcmu : pcmu | |
| | - unknown : reserved | |
| | - unknown : reserved | |
| | - gsm : gsm | |
| | - gsiii . gsiii - g723 : g723 | |
| | - g723 . g723 - div4.8 : div4.8 | |
| | - div4.8 : div4.8 | |
| | - 4174.10 . 4174.10 | |

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| | - lpc : lpc | 2000.00 |
| | - pcma : pcma | |
| | - g722 : g722 | |
| | - 116.2 : 116.2 | |
| | - 116.1 : 116.1 | |
| | - qcelp : qcelp | |
| | - cn : cn | |
| | - mpa : mpa | |
| | - g728 : g728 | |
| | - div4.11 : div4.11 | |
| | - div4.22 : div4.22 | |
| | - g729 : g729 | |
| [no] pkt-period1st | Parameter type: <gpon::pktperiodord></gpon::pktperiodord> | optional parameter with default |
| | Format: | value: 10L |
| | - packet period order | The parameter is not visible |
| | - range: [1030] | during modification. |
| | | packet period selection option |
| [no] silence1st | Parameter type: <gpon::silenceorder></gpon::silenceorder> | optional parameter with default |
| | Format: | value: "off" |
| | (off | The parameter is not visible |
| | on) | during modification. |
| | Possible values: | silence suppression selection |
| | - off : off | mode |
| | - on : on | |
| [no] codec2nd | Parameter type: <gpon::codecorder></gpon::codecorder> | optional parameter with default |
| | Format: | value: "pcmu" |
| | (pcmu | The parameter is not visible |
| | unknown | during modification. |
| | unknown | codec selection option |
| | gsm | |
| | g723 | |
| | div4.8 | |
| | div4.16 | |
| | lpc | |
| | pema | |
| | g722 | |
| | 116.2 | |
| | 116.1 | |
| | qcelp | |
| | cn | |
| | mpa | |
| | g728 div4.11 | |
| | div4.11 | |
| | g729) | |
| | Possible values: | |
| | - pcmu : pcmu | |
| | - unknown : reserved | |
| | - unknown : reserved | |
| | - gsm : gsm | |
| | - gsiii . gsiii - g723 : g723 | |
| | - div4.8 : div4.8 | |
| | - div4.16 : div4.16 | |
| | - lpc : lpc | |
| | - pcma : pcma | |
| | - g722 : g722 | |
| | - g/22 : g/22 - 116.2 : 116.2 | |
| | 110.2 . 110.2 | |

| Parameter | Туре | Description |
|--------------------|---|---------------------------------|
| 1 41 4110001 | - 116.1 : 116.1 | 2 escription |
| | - qcelp : qcelp | |
| | - qccip : qccip | |
| | | |
| | - mpa : mpa | |
| | - g728 : g728 | |
| | - div4.11 : div4.11 | |
| | - div4.22 : div4.22 | |
| | - g729 : g729 | |
| [no] pkt-period2nd | Parameter type: <gpon::pktperiodord></gpon::pktperiodord> | optional parameter with default |
| | Format: | value: 10L |
| | - packet period order | The parameter is not visible |
| | - range: [1030] | during modification. |
| | | packet period selection option |
| [no] silence2nd | Parameter type: <gpon::silenceorder></gpon::silenceorder> | optional parameter with default |
| | Format: | value: "off" |
| | (off | The parameter is not visible |
| | on on | during modification. |
| | Possible values: | |
| | | |
| | - off : off | mode |
| | - on : on | |
| [no] codec3rd | Parameter type: <gpon::codecorder></gpon::codecorder> | optional parameter with default |
| | Format: | value: "pcmu" |
| | (pcmu | The parameter is not visible |
| | unknown | during modification. |
| | unknown | codec selection option |
| | gsm | |
| | g723 | |
| | div4.8 | |
| | div4.16 | |
| | lpc | |
| | pcma | |
| | g722 | |
| | 116.2 | |
| | 116.1 | |
| | · | |
| | qcelp | |
| | cn | |
| | mpa | |
| | g728 | |
| | div4.11 | |
| | div4.22 | |
| | g729) | |
| | Possible values: | |
| | - pcmu : pcmu | |
| | - unknown : reserved | |
| | - unknown : reserved | |
| | - gsm : gsm | |
| | - g723 : g723 | |
| | - div4.8 : div4.8 | |
| | - div4.16 : div4.16 | |
| | - lpc : lpc | |
| | 1 1 | |
| | - pcma : pcma | |
| | | |
| | - g722 : g722 | |
| | - g722 : g722 - 116.2 : 116.2 | |
| | - g722 : g722 - 116.2 : 116.2 - 116.1 : 116.1 | |
| | - g722 : g722 - 116.2 : 116.2 | |
| | - g722 : g722 - 116.2 : 116.2 - 116.1 : 116.1 | |

| Parameter | Type | Description |
|--------------------|---|---------------------------------|
| | - g728 : g728 | |
| | - div4.11 : div4.11 | |
| | - div4.22 : div4.22 | |
| | - g729 : g729 | |
| [no] pkt-period3rd | Parameter type: <gpon::pktperiodord></gpon::pktperiodord> | optional parameter with default |
| | Format: | value: 10L |
| | - packet period order | The parameter is not visible |
| | - range: [1030] | during modification. |
| | | packet period selection option |
| [no] silence3rd | Parameter type: <gpon::silenceorder></gpon::silenceorder> | optional parameter with default |
| | Format: | value: "off" |
| | (off | The parameter is not visible |
| | on) | during modification. |
| | Possible values: | silence suppression selection |
| | - off : off | mode |
| | - on : on | |
| [no] codec4th | Parameter type: <gpon::codecorder></gpon::codecorder> | optional parameter with default |
| | Format: | value: "pcmu" |
| | (pcmu | The parameter is not visible |
| | unknown | during modification. |
| | unknown | codec selection option |
| | gsm | T. |
| | g723 | |
| | div4.8 | |
| | div4.16 | |
| | lpc | |
| | pcma | |
| | g722 | |
| | 116.2 | |
| | 116.1 | |
| | qcelp | |
| | decip | |
| | | |
| | mpa g728 | |
| | g726 div4.11 | |
| | div4.11 | |
| | div4.22 g729) | |
| | Possible values: | |
| | | |
| | - pcmu : pcmu | |
| | - unknown : reserved | |
| | - unknown : reserved | |
| | - gsm : gsm | |
| | - g723 : g723 | |
| | - div4.8 : div4.8 | |
| | - div4.16 : div4.16 | |
| | - lpc : lpc | |
| | - pcma : pcma | |
| | - g722 : g722 | |
| | - 116.2 : 116.2 | |
| | - 116.1 : 116.1 | |
| | - qcelp : qcelp | |
| | - cn : cn | |
| | - mpa : mpa | |
| | - g728 : g728 | |
| | - div4.11 : div4.11 | |
| | - div4.22 : div4.22 | |
| | - g729 : g729 | |

| Parameter | Type | Description |
|---------------------|---|-----------------------------------|
| [no] pkt-period4th | Parameter type: <gpon::pktperiodord></gpon::pktperiodord> | optional parameter with default |
| | Format: | value: 10L |
| | - packet period order | The parameter is not visible |
| | - range: [1030] | during modification. |
| | | packet period selection option |
| [no] silence4th | Parameter type: <gpon::silenceorder></gpon::silenceorder> | optional parameter with default |
| | Format: | value: "off" |
| | (off | The parameter is not visible |
| | on) | during modification. |
| | Possible values: | silence suppression selection |
| | - off : off | mode |
| | - on : on | |
| [no] outofband-dtmf | Parameter type: <gpon::outofband></gpon::outofband> | optional parameter with default |
| | Format: | value: "enabled" |
| | (disabled | The parameter is not visible |
| | enabled) | during modification. |
| | Possible values: | selects out of band dtmf carriage |
| | - disabled : dtmf are carried in pcm streams | |
| | - enabled : dtmf signals are carried out of band | |

Command Output

Table 41.39-3 "Create a VOIP media profile" Display parameters

| Specific Information | | |
|-----------------------|---|-------------------------------|
| name | Type | Description |
| voiceserviceprof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | voice service profile pointer |
| | - ignored printable string | This element is always shown. |
| rtp-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | rtp profile pointer |
| | - ignored printable string | This element is always shown. |

41.40 GPON Ringing Pattern Profile Configuration Command

Command Description

This command creates a profile that defines a ringing segment including duration or whether it is silent. Multiple ringing segment profiles are used to specify the ringing that will be applied to the analog line to ring the phone. Only two types of ringing are supported ("normal" or "splash") are supported via this method..

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no ring-seg-prof (index)) | (ring-seg-prof (index) name <AsamProfileName> [no profile-ring | profile-ring <Gpon::ProfileRing>] ring-duration <Gpon::RingDuration>)

Command Parameters

Table 41.40-1 "GPON Ringing Pattern Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|-----------------|------------------|
| (index) | Format: | index of profile |
| | - profile index | |
| | - range: [120] | |

Table 41.40-2 "GPON Ringing Pattern Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|-------------------|---|-----------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | name of profile |
| | - length: 1<=x<=32 | |
| [no] profile-ring | Parameter type: <gpon::profilering></gpon::profilering> | optional parameter with default |
| | Format: | value: "ringing" |
| | (ringing | The parameter is not visible |
| | silent) | during modification. |
| | Possible values: | Ringing sequence profile. |
| | - ringing : supplies ringing | |
| | - silent : specifies a silent period | |
| ring-duration | Parameter type: <gpon::ringduration></gpon::ringduration> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - duration of the tone segment in (msec). | during modification. |
| | - unit: msec | Valid values are 0 to 65535 (0 to |

| Parameter | Type | Description |
|-----------|-------------------|-----------------------------------|
| | - range: [065535] | 65.535 seconds) A value of 0 |
| | | means ring indefinitely until a |
| | | call event occurs causing ringing |
| | | to be removed from the |
| | | lineDuration of the tone segment |
| | | (in msec) |

41.41 GPON Ringing Pattern Sequence Profile Configuration Command

Command Description

This command creates a profile that defines a ringing sequence by serially identifying ring segment profiles to associate for a ringing sequence

NOTE: Segment 1 is mandatory to be entered. The remainders are optional. Other than the zero value (profile ID), the same Ring pattern cannot be referenced more than twice within the same profile. To cause a repeating sequence, reuse the profile ID from pattern1 or name from that first profile reference to define the looping of ring segments. These patterns represent the play order of the ring segments

User Level

The command can be accessed by operators with sip, megaco privileges, and executed by operators with sip, megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no ring-seq-prof (index)) | (ring-seq-prof (index) name <AsamProfileName> pattern1 <Gpon::RingingProf> [no pattern2 | pattern2 <Gpon::RingingProfPointer>] [no pattern3 | pattern3 <Gpon::RingingProfPointer>] [no pattern4 | pattern4 <Gpon::RingingProfPointer>] [no pattern5 | pattern5 <Gpon::RingingProfPointer>])

Command Parameters

Table 41.41-1 "GPON Ringing Pattern Sequence Profile Configuration Command " Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|-----------------|------------------|
| (index) | Format: | index of profile |
| | - profile index | |
| | - range: [120] | |

Table 41.41-2 "GPON Ringing Pattern Sequence Profile Configuration Command "Command Parameters

| Parameter | Type | Description |
|-----------|---|------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | name of profile |
| | - length: 1<=x<=32 | _ |
| pattern1 | Parameter type: <gpon::ringingprof></gpon::ringingprof> | mandatory parameter |
| | Format: | The parameter is not visible |
| | (< Gpon::RingingSetProfilePtr> | during modification. |

| Parameter | Type | Description |
|----------------|--|---|
| | name : <asamprofilename>)</asamprofilename> | ring segment profile |
| | Possible values: | |
| | - name : profile name | |
| | Field type <gpon::ringingsetprofileptr></gpon::ringingsetprofileptr> | |
| | - profile index | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] pattern2 | Parameter type: <gpon::ringingprofpointer></gpon::ringingprofpointer> | optional parameter with default |
| r .11 | Format: | value: "none" |
| | (none | The parameter is not visible |
| | <gpon::ringingsetprofileptr></gpon::ringingsetprofileptr> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | ring segment profile |
| | Possible values: | ing segment prome |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::ringingsetprofileptr></gpon::ringingsetprofileptr> | |
| | - profile index | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] pattern3 | Parameter type: <gpon::ringingprofpointer></gpon::ringingprofpointer> | optional parameter with default |
| [no] patterns | Format: | value: "none" |
| | (none | The parameter is not visible |
| | <gpon::ringingsetprofileptr></gpon::ringingsetprofileptr> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | ring segment profile |
| | Possible values: | ring segment prome |
| | | |
| | none : no profile to associatename : profile name | |
| | | |
| | Field type <gpon::ringingsetprofileptr> - profile index</gpon::ringingsetprofileptr> | |
| | | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration and software. | |
| | | |
| [mal mattamy 4 | The currently allowed values can be shown with online-help. | antiqual nanguratan with default |
| [no] pattern4 | Parameter type: <gpon::ringingprofpointer></gpon::ringingprofpointer> | optional parameter with default value: "none" |
| | Format: | |
| | (none | The parameter is not visible |
| | <gpon::ringingsetprofileptr></gpon::ringingsetprofileptr> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | ring segment profile |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name Field type (Grony Pinging Set Profile Pty) | |
| | Field type <gpon::ringingsetprofileptr></gpon::ringingsetprofileptr> | |
| | - profile index | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] pattern5 | Parameter type: <gpon::ringingprofpointer></gpon::ringingprofpointer> | optional parameter with default |
| | Format: | value: "none" |

| Parameter | Type | Description |
|-----------|--|------------------------------|
| | (none | The parameter is not visible |
| | <gpon::ringingsetprofileptr></gpon::ringingsetprofileptr> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | ring segment profile |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::ringingsetprofileptr></gpon::ringingsetprofileptr> | |
| | - profile index | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |

41.42 GPON Ring Event Profile Configuration Command

Command Description

This command can be used to create a profile that contains the associations of ringing sequence profiles or file ids to ringing selections. Note, this profile supports either method for making this association (use of the ringing sequence profile or identifying a file on the ONT that defines the ringing).

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no ringing-profile (index)) | (ringing-profile (index) name <AsamProfileName> [no ringing-seq-prof | ringing-seq-prof <Gpon::RingingseqPointer>] [no ringing-file-prof | ringing-file-prof | ringing-repeat | ringing-repeat <Gpon::RingRepeat>] [no splash-seq-prof | splash-seq-prof <Gpon::RingingseqPointer>] [no splash-file-prof | splash-file-prof <Gpon::RingingfilePointer>] [no splash-repeat | s

Command Parameters

Table 41.42-1 "GPON Ring Event Profile Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|-----------------|------------------|
| (index) | Format: | index of profile |
| | - profile index | |
| | - range: [15] | |

Table 41.42-2 "GPON Ring Event Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------------------|---|---------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | name of profile |
| | - length: 1<=x<=32 | |
| [no] ringing-seq-prof | Parameter type: <gpon::ringingseqpointer></gpon::ringingseqpointer> | optional parameter with default |
| | Format: | value: "none" |
| | (none | The parameter is not visible |
| | <gpon::ringingfileprofpoint></gpon::ringingfileprofpoint> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | ringing sequence profile |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |

| Parameter | Type | Description |
|----------------------------|--|---|
| | Field type <gpon::ringingfileprofpoint></gpon::ringingfileprofpoint> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| In all vive in a file woof | The currently allowed values can be shown with online-help. | |
| [no] ringing-file-prof | Parameter type: <gpon::ringingfilepointer> Format:</gpon::ringingfilepointer> | optional parameter with default value: "none" |
| | (none | The parameter is not visible |
| | <gpon::ringingfileprofpoint></gpon::ringingfileprofpoint> | during modification. |
| | name : <asamprofilename>)</asamprofilename> | uri profile that contains the |
| | Possible values: | location of the file that contains |
| | - none : no profile to associate | the ringing definition |
| | - name : profile name | the ringing derintion |
| | Field type <gpon::ringingfileprofpoint></gpon::ringingfileprofpoint> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] ringing-repeat | Parameter type: <gpon::ringrepeat></gpon::ringrepeat> | optional parameter with default |
| | Format: | value: 0L |
| | - Specifies how many times the ringing file is to be repeated | The parameter is not visible |
| | for a ringing event | during modification. |
| | - range: [010] | Specifies how many times the |
| | | ringing file is to be repeated for a |
| | | ringing event. Valid range is |
| | | 010. Default of 0 means repeats |
| [mal anlash are most | Domentos testos (ConsulPinnings and Painter) | until the end of the tone event. |
| [no] splash-seq-prof | Parameter type: <gpon::ringingseqpointer> Format:</gpon::ringingseqpointer> | optional parameter with default value: "none" |
| | (none | The parameter is not visible |
| | Concord Conc | during modification. |
| | name : <asamprofilename>)</asamprofilename> | Splash ringing sequence profile |
| | Possible values: | spinish ringing sequence prome |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::ringingfileprofpoint></gpon::ringingfileprofpoint> | |
| | - profile index | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] splash-file-prof | Parameter type: <gpon::ringingfilepointer></gpon::ringingfilepointer> | optional parameter with default |
| | Format: | value: "none" |
| | (none | The parameter is not visible |
| | <gpon::ringingfileprofpoint></gpon::ringingfileprofpoint> | during modification. |
| | name : <asamprofilename>) Possible values:</asamprofilename> | Splash ringing sequence profile |
| | - none : no profile to associate | |
| | - none : no prome to associate - name : profile name | |
| | Field type <gpon::ringingfileprofpoint></gpon::ringingfileprofpoint> | |
| | - profile index | |
| | - range: [0100] | |
| | 1411.50. [01.1100] | |

| Parameter | Type | Description |
|--------------------|---|--------------------------------------|
| | Data driven field type | |
| | Possible values are depending on the actual configuration and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] splash-repeat | Parameter type: <gpon::splashrepeat></gpon::splashrepeat> | optional parameter with default |
| | Format: | value: 0L |
| | - Specifies how many times the ringing file is to be repeated | The parameter is not visible |
| | for a ringing event. | during modification. |
| | - range: [010] | Specifies how many times the |
| | | ringing file is to be repeated for a |
| | | ringing event. Valid range is |
| | | 010. Default of 0 means repeats |
| | | until the end of the tone event. |

Command Output

Table 41.42-3 "GPON Ring Event Profile Configuration Command" Display parameters

| Specific Information | | |
|------------------------|---|---------------------------------|
| name | Type | Description |
| ringing-seq-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the default uri profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| ringing-file-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the default uri profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| splash-seq-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the default uri profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| splash-file-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the default uri profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |

41.43 GPON VOIP Feature Access Codes Profile Configuration Command

Command Description

This command creates a profile that defines a set of Feature Access Codes.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

```
> configure voice ont ( no feat-acccode-prof (index) ) | ( feat-acccode-prof (index) name < AsamProfileName> [ no cancel-call-wait | cancel-call-wait < Gpon::Accesscode> ] [ no hold | hold < Gpon::Accesscode> ] [ no park | park < Gpon::Accesscode> ] [ no act-caller-id | act-caller-id < Gpon::Accesscode> ] [ no deact-caller-id | deact-caller-id < Gpon::Accesscode> ] [ no deact-dnd | deact-dnd < Gpon::Accesscode> ] [ no dnd-pin | dnd-pin < Gpon::Accesscode> ] [ no emergency | emergency < Gpon::Accesscode> ] [ no intercom | intercom < Gpon::Accesscode> ] [ no attend-call-trans | attend-call-trans < Gpon::Accesscode> ] [ no blind-call-trans | blind-call-trans blind-call-tra
```

Command Parameters

Table 41.43-1 "GPON VOIP Feature Access Codes Profile Configuration Command" Resource Parameters

| Resource Identifier | Туре | Description |
|----------------------------|-----------------|-------------------------------|
| (index) | Format: | feature access codes profile. |
| | - profile index | _ |
| | - range: [120] | |

Table 41.43-2 "GPON VOIP Feature Access Codes Profile Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------------------|---|---------------------------------|
| name | Parameter type: <asamprofilename></asamprofilename> | mandatory parameter |
| | Format: | The parameter is not visible |
| | - a profile name | during modification. |
| | - range: [a-zA-Z0-9] | name of profile |
| | - length: 1<=x<=32 | |
| [no] cancel-call-wait | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to cancel call |
| | | waiting. |

| Parameter | Type | Description |
|------------------------|---|---|
| [no] hold | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to hold a call |
| [no] park | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to park a call |
| [no] act-caller-id | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to activate caller id. |
| [no] deact-caller-id | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to deactivate caller |
| | | id. |
| [no] act-dnd | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| [] | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to activate do not |
| | | disturb |
| [no] deact-dnd | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| [no] deact and | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to de-activate do not |
| | length. A <= 5 | disturb |
| [no] dnd-pin | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| [no] und pm | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to to change the do |
| | | not disturb pin. |
| [no] emergency | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| [no] emergency | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to set the emergency |
| | - length. A\-5 | service number. |
| [no] intercom | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| [HO] HICICOIII | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - access code - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to enable intercom |
| | iongui. A\-J | service |
| [no] attand coll tuons | Doromotor type: «Chany Apacacada» | |
| [no] attend-call-trans | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default value: "" |
| | Format: | |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: x<=5 | access code to select attended call |
| | | transfer behavior. |

| Parameter | Type | Description |
|-----------------------|---|---------------------------------|
| [no] blind-call-trans | Parameter type: <gpon::accesscode></gpon::accesscode> | optional parameter with default |
| | Format: | value: "" |
| | - access code | The parameter is not visible |
| | - range: [0-9*#] | during modification. |
| | - length: $x \le 5$ | select unattended call transfer |
| | | behavior. |

41.44 GPON Common VOIP Configuration Command

Command Description

This command creates the common VoIP configuration for the ONT. It must be created after creating an IP Host on the ONT. It ties directly to the IP Host via the AID. Note, only one VoIP client can be supported in an ONT at this time.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no voip-config (voip-index)) | (voip-config (voip-index) protocol <Gpon::VoipProtocol> [no conf-method | conf-method <Gpon::ConfMethod>] [no securi-prof | securi-prof <Gpon::SecuriProf>])

Command Parameters

Table 41.44-1 "GPON Common VOIP Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---|--------------------------|
| (voip-index) | Format: | a unique interface index |
| | (ont : <eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <eqpt::ponid> / <eqpt::ontid> / <gpon::iphostid></gpon::iphostid></eqpt::ontid></eqpt::ponid> | |
| | ont:ng2 : <eqpt::channelgroupid> /</eqpt::channelgroupid> | |
| | <eqpt::subchannelgroupid> / <eqpt::ng2ontid> /</eqpt::ng2ontid></eqpt::subchannelgroupid> | |
| | <ng2::iphostid>)</ng2::iphostid> | |
| | Possible values: | |
| | - ont:ng2 : ngpon2 ont | |
| | - ont : ont | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Field type <eqpt::channelgroupid></eqpt::channelgroupid> | |
| | - the channel group identifier | |
| | Field type <eqpt::subchannelgroupid></eqpt::subchannelgroupid> | |

| Resource Identifier | Type | Description |
|----------------------------|--|-------------|
| | - the subchannel group identifier | |
| | Field type <eqpt::ng2ontid></eqpt::ng2ontid> | |
| | - the NG2 ONT identifier | |
| | Field type <gpon::iphostid></gpon::iphostid> | |
| | - iphost id | |
| | Field type <ng2::iphostid></ng2::iphostid> | |
| | - iphost id (ngpon2) | |

Table 41.44-2 "GPON Common VOIP Configuration Command" Command Parameters

| Parameter | Type | Description |
|------------------|--|---------------------------------|
| protocol | Parameter type: <gpon::voipprotocol></gpon::voipprotocol> | mandatory parameter |
| | Format: | protocol |
| | (sip | |
| | h248) | |
| | Possible values: | |
| | - sip : sip signalling protocol | |
| | - h248 : h248 signalling protocol | |
| [no] conf-method | Parameter type: <gpon::confmethod></gpon::confmethod> | optional parameter with default |
| | Format: | value: "omci" |
| | (omci | configuration method |
| | ftp) | |
| | Possible values: | |
| | - omci : FTP Server | |
| | - ftp: FTP Server | |
| [no] securi-prof | Parameter type: <gpon::securiprof></gpon::securiprof> | optional parameter with default |
| | Format: | value: "none" |
| | (none | securi prof |
| | < Gpon::SecuriProfilePointer> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::securiprofilepointer></gpon::securiprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |

41.45 GPON Voice ONT POTS Rtp PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of ONT POTS Rtp monitoring.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont pots-rtp (uni-index) [no pm-collect | pm-collect < Gpon::OntPmCollect>]

Command Parameters

Table 41.45-1 "GPON Voice ONT POTS Rtp PM Mode Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---|---------------------|
| (uni-index) | Format: | gpon ont port index |
| | (<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <eqpt::ponid> / <eqpt::ontid> / <gpon::ontslotid> /</gpon::ontslotid></eqpt::ontid></eqpt::ponid> | |
| | <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup> | |
| | <ng2::ontid> / <gpon::ontslotid> /</gpon::ontslotid></ng2::ontid> | |
| | <gpon::ontpotsportid>)</gpon::ontpotsportid> | |
| | Possible values: | |
| | - ng2 : ngpon2 style identification | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Field type <ng2::channelgroup></ng2::channelgroup> | |
| | - channel group number | |
| | Field type <ng2::subchannelgroup></ng2::subchannelgroup> | |
| | - subchannel group number | |
| | Field type <ng2::ontid></ng2::ontid> | |

| Resource Identifier | Type | Description |
|----------------------------|--|-------------|
| | - the ONT identifier | |
| | Field type <gpon::ontslotid></gpon::ontslotid> | |
| | - Gpon Ont Slot | |
| | - range: [114] | |
| | Field type <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | - Gpon Ont Pots Port | |
| | - range: [124] | |

Table 41.45-2 "GPON Voice ONT POTS Rtp PM Mode Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------------|---|---------------------------------|
| [no] pm-collect | Parameter type: <gpon::ontpmcollect></gpon::ontpmcollect> | optional parameter with default |
| | Format: | value: "disable" |
| | (enable | ONT POTS Rtp performance |
| | disable) | monitoring |
| | Possible values: | |
| | - enable : enable PM | |
| | - disable : disable PM | |

41.46 GPON ONT SIP Configuration Command

Command Description

This command creates the SIP configuration for the ONT. It must be created after creating a VOIP Configuration on the ONT. Note, only one VoIP client can be supported in an ONT at this time.

NOTE:

OLT prohibits the entry of the following range of well-known IP addresses for the parameters primary-dns and secondary-dns:

224.0.0.0 to 239.255.255.255 (multicast)

127.0.0.0 to 127.255.255.255 (loopback)

255.255.255.255 (broadcast)

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no sip-config (sip-index)) | (sip-config (sip-index) [no proxyserv-prof | proxyserv-prof < Gpon::UriProfileName>] [no outproxyserv-prof | outproxyserv-prof < Gpon::UriProfileName>] [no primary-dns | primary-dns < Gpon::IpAddress>] [no secondary-dns | secondary-dns < Gpon::IpAddress>] [no reg-expire-time | reg-expire-time < Gpon::RegExpireTime>] [no re-reg-head-start | re-reg-head-start < Gpon::ReRegHeadStart>] [no aor-host-prt-prof | aor-host-prt-prof < Gpon::UriProfileName>] [no registrar-prof | registrar-prof < Gpon::SecuriProf>] [no soft-sw-vendor | soft-sw-vendor < Gpon::SwVendor>] [no opt-tx-cntrl | opt-tx-cntrl < Gpon::OpticalTxCntrl>] [no uri-format | uri-format < Gpon::UriFormat>] [no dscp | dscp < Gpon::SigDscp>] [no udp-port | udp-port < Gpon::SipUdpPort>])

Command Parameters

Table 41.46-1 "GPON ONT SIP Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---|---------------|
| (sip-index) | Format: | SIP ONT index |
| | (ont : <eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <eqpt::ponid> / <eqpt::ontid> / <gpon::iphostid></gpon::iphostid></eqpt::ontid></eqpt::ponid> | |
| | ont:ng2 : <eqpt::channelgroupid> /</eqpt::channelgroupid> | |
| | <eqpt::subchannelgroupid> / <eqpt::ng2ontid> /</eqpt::ng2ontid></eqpt::subchannelgroupid> | |
| | <ng2::iphostid>)</ng2::iphostid> | |
| | Possible values: | |
| | - ont:ng2 : ngpon2 ont | |
| | - ont : ont | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |

| Resource Identifier | Type | Description |
|----------------------------|--|-------------|
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Field type <eqpt::channelgroupid></eqpt::channelgroupid> | |
| | - the channel group identifier | |
| | Field type <eqpt::subchannelgroupid></eqpt::subchannelgroupid> | |
| | - the subchannel group identifier | |
| | Field type <eqpt::ng2ontid></eqpt::ng2ontid> | |
| | - the NG2 ONT identifier | |
| | Field type <gpon::iphostid></gpon::iphostid> | |
| | - iphost id | |
| | Field type <ng2::iphostid></ng2::iphostid> | |
| | - iphost id (ngpon2) | |

Table 41.46-2 "GPON ONT SIP Configuration Command" Command Parameters

| Parameter | Type | Description |
|------------------------|---|--|
| [no] proxyserv-prof | Parameter type: <gpon::uriprofilename> Format: (none <gpon:uriprofileptr> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon:uriprofileptr> - Index of the URI profile that contains the IP address of the server - range: [0100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.</gpon:uriprofileptr></asamprofilename></gpon:uriprofileptr></gpon::uriprofilename> | optional parameter with default value: "none" URI profile of the SIP proxy server for SIP signaling messages |
| [no] outproxyserv-prof | Parameter type: <gpon::uriprofilename> Format: (none <gpon:uriprofileptr> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon:uriprofileptr> - Index of the URI profile that contains the IP address of the server - range: [0100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.</gpon:uriprofileptr></asamprofilename></gpon:uriprofileptr></gpon::uriprofilename> | optional parameter with default value: "none" URI profile of the outbound SIP proxy server for SIP signaling messages |
| [no] primary-dns | Parameter type: <gpon::ipaddress> Format: - IPv4-address</gpon::ipaddress> | optional parameter with default value: "0.0.0.0" primary SIP DNS server ip address |

| Parameter | Type | Description |
|------------------------|--|-------------------------------------|
| [no] secondary-dns | Parameter type: <gpon::ipaddress></gpon::ipaddress> | optional parameter with default |
| • | Format: | value: "0.0.0.0" |
| | - IPv4-address | secondary SIP DNS server ip |
| | | address |
| [no] reg-expire-time | Parameter type: <gpon::regexpiretime></gpon::regexpiretime> | optional parameter with default |
| | Format: | value: "3600" |
| | - sip registration expiration time | SIP registration expiration time |
| | - unit: sec | |
| | - range: [086400] | |
| [no] re-reg-head-start | Parameter type: <gpon::reregheadstart></gpon::reregheadstart> | optional parameter with default |
| _ | Format: | value: "360" |
| | - Re-registration head start time | re-registration head start time |
| | - unit: sec | |
| | - range: [0600] | |
| [no] aor-host-prt-prof | Parameter type: <gpon::uriprofilename></gpon::uriprofilename> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile that contains the host |
| | < Gpon: UriProfilePtr> | or domain part of the SIP address |
| | name : <asamprofilename>)</asamprofilename> | of record |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon:uriprofileptr></gpon:uriprofileptr> | |
| | - Index of the URI profile that contains the IP address of the | |
| | server | |
| | - range: [0100] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] registrar-prof | Parameter type: <gpon::securiprof></gpon::securiprof> | optional parameter with default |
| | Format: | value: "none" |
| | (none | URI profile of the registrar server |
| | < Gpon::SecuriProfilePointer> | |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::securiprofilepointer></gpon::securiprofilepointer> | |
| | - profile index | |
| | - range: [050] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] soft-sw-vendor | Parameter type: <gpon::swvendor></gpon::swvendor> | optional parameter with default |
| | Format: | value: "" |
| | - name of the sip gateway softswitch vendor | name of the SIP gateway |
| | - range: [A-Z] | softswitch vendor |
| | - length: x<=4 | |
| [no] opt-tx-cntrl | Parameter type: <gpon::opticaltxcntrl></gpon::opticaltxcntrl> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | optional transmission control |
| | enable) | indicating whether the ONT is |
| | Possible values: | enabled/disabled to transmit |
| | - disable : disable optional transmission control | value options |
| | - enable : enable optional transmission control | |

| Parameter | Type | Description |
|-----------------|---|-------------------------------------|
| [no] uri-format | Parameter type: <gpon::uriformat></gpon::uriformat> | optional parameter with default |
| | Format: | value: "tel-uri" |
| | (tel-uri | URI format to specify the format |
| | sip-uri) | of the URI in outgoing SIP |
| | Possible values: | messages |
| | - tel-uri : tel uri format | |
| | - sip-uri : sip uri format | |
| [no] dscp | Parameter type: <gpon::sigdscp></gpon::sigdscp> | optional parameter with default |
| | Format: | value: "24" |
| | - dscp value | dscp setting value to use in the ip |
| | - range: [063] | header of outgoing SIP signaling |
| | | packets |
| [no] udp-port | Parameter type: <gpon::sipudpport></gpon::sipudpport> | optional parameter with default |
| | Format: | value: "5060" |
| | - udp port | The parameter is not visible |
| | - range: [50006000] | during modification. |
| | | specifies the udp port number to |
| | | be used for SIP signaling |
| | | messages |

Command Output

Table 41.46-3 "GPON ONT SIP Configuration Command" Display parameters

| Specific Information | | |
|------------------------|---|-------------------------------------|
| name | Type | Description |
| proxyserv-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the URI profile that |
| | - ignored printable string | contains the ip address of the SIP |
| | | proxy server for SIP signaling |
| | | messages. |
| | | This element is always shown. |
| outproxyserv-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the URI profile that |
| | - ignored printable string | contains the ip address of the |
| | | outbound SIP proxy server for |
| | | SIP signaling messages. |
| | | This element is always shown. |
| aor-host-prt-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the URI profile that |
| | - ignored printable string | contains the host or domain part |
| | | of the SIP address of record. |
| | | This element is always shown. |
| registrar-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the secure URI profile |
| | - ignored printable string | that contains the IP address of the |
| | | registrar server. |
| | | This element is always shown. |

41.47 Voice Ont SIP Agent PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of ONT SIP Agent monitoring.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont sip-agent (ont-index) [no pm-collect | pm-collect <Gpon::PmEnable>]

Command Parameters

Table 41.47-1 "Voice Ont SIP Agent PM Mode Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---|-------------|
| (ont-index) | Format: | ont index |
| | (ont : <eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <eqpt::ponid> / <eqpt::ontid> / <gpon::iphostid></gpon::iphostid></eqpt::ontid></eqpt::ponid> | |
| | ont:ng2 : <eqpt::channelgroupid> /</eqpt::channelgroupid> | |
| | <eqpt::subchannelgroupid> / <eqpt::ng2ontid> /</eqpt::ng2ontid></eqpt::subchannelgroupid> | |
| | <ng2::iphostid>)</ng2::iphostid> | |
| | Possible values: | |
| | - ont:ng2 : ngpon2 ont | |
| | - ont : ont | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Field type <eqpt::channelgroupid></eqpt::channelgroupid> | |
| | - the channel group identifier | |
| | Field type <eqpt::subchannelgroupid></eqpt::subchannelgroupid> | |
| | - the subchannel group identifier | |
| | Field type <eqpt::ng2ontid></eqpt::ng2ontid> | |
| | - the NG2 ONT identifier | |

| Resource Identifier | Type | Description |
|----------------------------|--|-------------|
| | Field type <gpon::iphostid></gpon::iphostid> | |
| | - iphost id | |
| | Field type <ng2::iphostid></ng2::iphostid> | |
| | - iphost id (ngpon2) | |

Table 41.47-2 "Voice Ont SIP Agent PM Mode Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------------|---|---------------------------------|
| [no] pm-collect | Parameter type: <gpon::pmenable></gpon::pmenable> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | performance mode state |
| | enable) | |
| | Possible values: | |
| | - disable : disable the collection | |
| | - enable : enable the collection | |

41.48 Voice Ont SIP Agent Call PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of ONT SIP Agent Call monitoring.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont sip-call (ont-index) [no pm-collect | pm-collect < Gpon::PmEnable>]

Command Parameters

Table 41.48-1 "Voice Ont SIP Agent Call PM Mode Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---|-------------|
| (ont-index) | Format: | ont index |
| | (ont : <eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <eqpt::ponid> / <eqpt::ontid> / <gpon::iphostid></gpon::iphostid></eqpt::ontid></eqpt::ponid> | |
| | ont:ng2 : <eqpt::channelgroupid> /</eqpt::channelgroupid> | |
| | <eqpt::subchannelgroupid> / <eqpt::ng2ontid> /</eqpt::ng2ontid></eqpt::subchannelgroupid> | |
| | <ng2::iphostid>)</ng2::iphostid> | |
| | Possible values: | |
| | - ont:ng2 : ngpon2 ont | |
| | - ont : ont | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Field type <eqpt::channelgroupid></eqpt::channelgroupid> | |
| | - the channel group identifier | |
| | Field type <eqpt::subchannelgroupid></eqpt::subchannelgroupid> | |
| | - the subchannel group identifier | |
| | Field type <eqpt::ng2ontid></eqpt::ng2ontid> | |

| Resource Identifier | Type | Description |
|----------------------------|--|-------------|
| | - the NG2 ONT identifier | |
| | Field type <gpon::iphostid></gpon::iphostid> | |
| | - iphost id | |
| | Field type <ng2::iphostid></ng2::iphostid> | |
| | - iphost id (ngpon2) | |

Table 41.48-2 "Voice Ont SIP Agent Call PM Mode Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------------|---|---------------------------------|
| [no] pm-collect | Parameter type: <gpon::pmenable></gpon::pmenable> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | performance mode state |
| | enable) | • |
| | Possible values: | |
| | - disable : disable the collection | |
| | - enable : enable the collection | |

41.49 Configure ont POT SIP

Command Description

This command edits a POTs port's SIP parameter for those line using SIP insted of MGC.

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont voice-sip-port (pots-index) [no user-aor | user-aor <Gpon::UserAddress>] [no display-name | display-name <Gpon::DisplayName>] [no val-scheme | val-scheme <Gpon::AuthSecValScheme>] [no user-name | no voice-mail-prof | password | password <Security::Password5>] [no realm | realm <Gpon::Realm>] [no voice-mail-prof | voice-mail-prof <Gpon::VoiceMailProfilePointer>] [no voice-mail-to | voice-mail-to | copon::VoiceMailTo>] [no ntwk-dp-prof | ntwk-dp-prof <Gpon::NetDialPlanProfilePointer>] [no app-serv-prof | app-serv-prof <Gpon::AppServProfilePointer>] [no robtimer | robtimer <Gpon::RobTimer>] [no robtimer | robtimer <Gpon::RobTimer>]

Command Parameters

Table 41.49-1 "Configure ont POT SIP" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|--|------------------------------------|
| (pots-index) | Format: | an ontpots access identifier index |
| | (<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <pre><eqpt::ponid> / <eqpt::ontid> / <gpon::ontslotid> /</gpon::ontslotid></eqpt::ontid></eqpt::ponid></pre> | |
| | <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup> | |
| | <ng2::ontid> / <gpon::ontslotid> /</gpon::ontslotid></ng2::ontid> | |
| | <gpon::ontpotsportid>)</gpon::ontpotsportid> | |
| | Possible values: | |
| | - ng2 : ngpon2 style identification | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Field type <ng2::channelgroup></ng2::channelgroup> | |
| | - channel group number | |

| Resource Identifier | Type | Description |
|---------------------|--|-------------|
| | Field type <ng2::subchannelgroup></ng2::subchannelgroup> | |
| | - subchannel group number | |
| | Field type <ng2::ontid></ng2::ontid> | |
| | - the ONT identifier | |
| | Field type <gpon::ontslotid></gpon::ontslotid> | |
| | - Gpon Ont Slot | |
| | - range: [114] | |
| | Field type <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | - Gpon Ont Pots Port | |
| | - range: [124] | |

Table 41.49-2 "Configure ont POT SIP" Command Parameters

| Parameter | Туре | Description |
|----------------------|---|---------------------------------|
| [no] user-aor | Parameter type: <gpon::useraddress></gpon::useraddress> | optional parameter with default |
| | Format: | value: "" |
| | - user identification | user address of record |
| | - length: x<=50 | |
| [no] display-name | Parameter type: <gpon::displayname></gpon::displayname> | optional parameter with default |
| | Format: | value: "" |
| | - customer id used to display name in outgoing sip message | customer ID user for display |
| | - length: x<=25 | name |
| [no] val-scheme | Parameter type: <gpon::authsecvalscheme></gpon::authsecvalscheme> | optional parameter with default |
| | Format: | value: "disabled" |
| | (disabled | validation scheme required for |
| | md5-digest | authentication |
| | basic-authentic) | |
| | Possible values: | |
| | - disabled : Validation disabled | |
| | - md5-digest : validate using md5 digest authentication | |
| | - basic-authentic : Validate using basic authentication | |
| [no] user-name | Parameter type: <gpon::authusername></gpon::authusername> | optional parameter with default |
| | Format: | value: "" |
| | - user name required for authentication | user name required for |
| | - length: x<=50 | authentication |
| [no] password | Parameter type: <security::password5></security::password5> | optional parameter with default |
| | Format: | value: "plain : " |
| | (prompt | password string hidden from |
| | plain : <security::plainpassword5>)</security::plainpassword5> | users |
| | Possible values: | |
| | - prompt : prompts the operator for a password | |
| | - plain : the password in plain text | |
| | Field type <security::plainpassword5></security::plainpassword5> | |
| | - authentication string | |
| | - length: x<=25 | |
| [no] realm | Parameter type: <gpon::realm></gpon::realm> | optional parameter with default |
| | Format: | value: "" |
| | - realm required for authentication | realm for authentication |
| | - length: x<=25 | |
| [no] voice-mail-prof | Parameter type: <gpon::voicemailprofilepointer></gpon::voicemailprofilepointer> | optional parameter with default |
| | Format: | value: 0L |
| | (none | voice mail profile contains sip |
| | <gpon::voicemailprofilepointer></gpon::voicemailprofilepointer> | voice-mail information |
| | name : <asamprofilename>)</asamprofilename> | |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::voicemailprofilepointer></gpon::voicemailprofilepointer> | |

| Parameter | Туре | Description |
|--------------------|---|--|
| | - profile index | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] voice-mail-to | Parameter type: <gpon::voicemailto></gpon::voicemailto> | optional parameter with default |
| | Format: | value: 3600L |
| | - voice mail subscription expiration time in seconds | voice mail subscription |
| | - unit: seconds | expiration time in seconds |
| | - range: [086400] | |
| [no] ntwk-dp-prof | Parameter type: <gpon::netdialplanprofilepointer></gpon::netdialplanprofilepointer> | optional parameter with default |
| | Format: | value: 0L |
| | (none | Network dial plan profile |
| | < Gpon::NetDialPlanProfilePointer> | contains network dial plan |
| | name : <asamprofilename>)</asamprofilename> | information |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::netdialplanprofilepointer></gpon::netdialplanprofilepointer> | |
| | - profile index | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| - | The currently allowed values can be shown with online-help. | |
| [no] app-serv-prof | Parameter type: <gpon::appservprofilepointer></gpon::appservprofilepointer> | optional parameter with default |
| | Format: | value: 0L |
| | (none | Application service profile that |
| | <gpon::appservprofilepointer></gpon::appservprofilepointer> | contains information related to |
| | name : <asamprofilename>)</asamprofilename> | calling features |
| | Possible values: | |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::appservprofilepointer></gpon::appservprofilepointer> | |
| | - profile index | |
| | - range: [020] | |
| | Data driven field type Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] ac-code-prof | Parameter type: <gpon::accesscodeprofilepointer></gpon::accesscodeprofilepointer> | optional parameter with default |
| [no] ac-code-prof | Format: | value: 0L |
| | (none | VOIP access code profile that |
| | <gpon::accesscodeprofilepointer></gpon::accesscodeprofilepointer> | contains information related to |
| | name : <asamprofilename>)</asamprofilename> | administrative feature |
| | Possible values: | administrative reature |
| | - none : no profile to associate | |
| | - name : profile name | |
| | Field type <gpon::accesscodeprofilepointer></gpon::accesscodeprofilepointer> | |
| | - profile index | |
| | - range: [020] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] rlstimer | Parameter type: <gpon::rlstimer></gpon::rlstimer> | optional parameter with default |
| [] | | F. W. P. P. W. |

| Parameter | Type | Description |
|---------------|---|-----------------------------------|
| | Format: | value: 10L |
| | - sip release timer | SIP release timer |
| | - unit: seconds | |
| | - range: [060] | |
| [no] rohtimer | Parameter type: <gpon::rohtimer></gpon::rohtimer> | optional parameter with default |
| | Format: | value: 15L |
| | - receiver off-hook timer | Receiver off-Hook timer that |
| | - unit: seconds | specifies how long in seconds the |
| | - range: [060] | line is in ROH condition |

Command Output

Table 41.49-3 "Configure ont POT SIP" Display parameters

| Specific Information | | |
|----------------------|---|-------------------------------|
| name | Type | Description |
| ntwk-dp-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the authentication |
| | - ignored printable string | security profile pointer |
| | | This element is always shown. |
| app-serv-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the authentication |
| | - ignored printable string | security profile pointer |
| | | This element is always shown. |
| ac-code-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the authentication |
| _ | - ignored printable string | security profile pointer |
| | | This element is always shown. |

41.50 Voice ONT MGC Configuration command

Command Description

This command creates the MEGACO configuration of the ONT

NOTE: Only one VoIP client can be supported in an ONT at this time

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont (no mgc-config (if-index)) | (mgc-config (if-index) pri-mgcuri-profid <Gpon::ReqSecureUriProfileName> sec-mgcuri-profid <Gpon::ReqSecureUriProfileName> [no protocol-ver | protocol-ver <Gpon::PrtclVer>] [no msg-format | msg-format <Gpon::MsgFormat>] [no max-retry-time | max-retry-time <Gpon::MaxRtryTime>] [no max-retries | max-retries <Gpon::MaxRetry>] [no status-delay-time | status-delay-time <Gpon::DelayTime>] base-termid <Gpon::TerminationId> [no sig-dscp | sig-dscp <Gpon::SigDscp>] [no udp-port | udp-port <Gpon::UdpPort>] [no sw-vendor | sw-vendor <Gpon::MgcVendorName>] [no cnf-msg-profid | cnf-msg-profid <Gpon::UriProfileName>])

Command Parameters

Table 41.50-1 "Voice ONT MGC Configuration command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|---|-----------------------|
| (if-index) | Format: | ifindex of iphost uni |
| | (<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <eqpt::ponid> / <eqpt::ontid> / 1</eqpt::ontid></eqpt::ponid> | |
| | ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup> | |
| | <ng2::ontid> / 1)</ng2::ontid> | |
| | Possible values: | |
| | - ng2 : ngpon2 style identification | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Possible values: | |
| | - 1 : Gpon voip Port | |
| | Field type <ng2::channelgroup></ng2::channelgroup> | |
| | - channel group number | |

| Resource Identifier | Type | Description |
|----------------------------|--|-------------|
| | Field type <ng2::subchannelgroup></ng2::subchannelgroup> | |
| | - subchannel group number | |
| | Field type <ng2::ontid></ng2::ontid> | |
| | - the ONT identifier | |
| | Possible values: | |
| | - 1 : Gpon voip Port | |

Table 41.50-2 "Voice ONT MGC Configuration command" Command Parameters

| Parameter | Type | Description |
|-------------------------|---|-----------------------------------|
| pri-mgcuri-profid | Parameter type: <gpon::reqsecureuriprofilename></gpon::reqsecureuriprofilename> | mandatory parameter |
| pri-ingeuri-profita | Format: | Uri profile that contains the ip |
| | (<gpon:securiprofptr></gpon:securiprofptr> | address of the primary media |
| | name : <asamprofilename>)</asamprofilename> | gateway controller |
| | Possible values: | gateway controller |
| | | |
| | - name : profile name | |
| | Field type <gpon:securiprofptr></gpon:securiprofptr> | |
| | - Index of the sec-uri profile that contains the IP address of | |
| | the server | |
| | - range: [150] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| sec-mgcuri-profid | Parameter type: <gpon::reqsecureuriprofilename></gpon::reqsecureuriprofilename> | mandatory parameter |
| | Format: | Uri profile that contains the ip |
| | (< Gpon: Sec UriProfPtr> | address of the secondary media |
| | name : <asamprofilename>)</asamprofilename> | gateway controller |
| | Possible values: | |
| | - name : profile name | |
| | Field type <gpon:securiprofptr></gpon:securiprofptr> | |
| | - Index of the sec-uri profile that contains the IP address of | |
| | the server | |
| | - range: [150] | |
| | Data driven field type | |
| | Possible values are depending on the actual configuration | |
| | and software. | |
| | The currently allowed values can be shown with online-help. | |
| [no] protocol-ver | Parameter type: <gpon::prtclver></gpon::prtclver> | optional parameter with default |
| f -3 F | Format: | value: 0L |
| | - Selects the version of MGC protocol signalling to be used | Selects the version of the MGC |
| | - range: [02] | signaling protocol to be used |
| [no] msg-format | Parameter type: <gpon::msgformat></gpon::msgformat> | optional parameter with default |
| [no] mag reriim. | Format: | value: 0L |
| | - Selects message format value | The parameter is not visible |
| | - range: [02] | during modification. |
| | range. [o2] | Specifies the message format |
| [no] max-retry-time | Parameter type: <gpon::maxrtrytime></gpon::maxrtrytime> | optional parameter with default |
| [no] max reay time | Format: | value: OL |
| | - Specifies the maximum retry time for MGC transaction | Specifies the maximum retry time |
| | - unit: sec | (in seconds) for MGC transaction |
| | - range: [060] | (in seconds) for Mee transaction |
| [no] max-retries | Parameter type: <gpon::maxretry></gpon::maxretry> | optional parameter with default |
| [110] max-redics | Format: | value: 0L |
| | | Specifies the maximum number |
| | - Specifies the maximum number of times a message is transmitted to the MGC | of times a message is transmitted |
| | | |
| In all status J.1. etc. | - range: [010] | to the MGC |
| [no] status-delay-time | Parameter type: <gpon::delaytime></gpon::delaytime> | optional parameter with default |

| Parameter | Type | Description |
|---------------------|---|--|
| | Format: - Service status delay time (in seconds) for changes in line service status - unit: sec - range: [060] | value: 0L Service status delay time (in seconds) for changes in line service status |
| base-termid | Parameter type: <gpon::terminationid> Format: - identifies the POTS port in H248 VoIP signalling messages.The first character must be alphabetic. The string 'ROOT' is not allowed range: [a-zA-Z0-9*/\$@.] - length: x<=25</gpon::terminationid> | mandatory parameter Base string for H248 physical termination Id |
| [no] sig-dscp | Parameter type: <gpon::sigdscp> Format: - dscp value - range: [063]</gpon::sigdscp> | optional parameter with default value: 24L DSCP value for use in outgoing signaling packets towards the Soft Switch |
| [no] udp-port | Parameter type: <gpon::udpport> Format: - Specifies the UDP port number to be used for MGC signaling messages - range: [20003000]</gpon::udpport> | optional parameter with default value: 2944L The parameter is not visible during modification. Specifies the UDP port number to be used for MGC signaling messages |
| [no] sw-vendor | Parameter type: <gpon::mgcvendorname> Format: - vendor id - 4 ASCII characters - range: [a-zA-Z0-9] - length: 4</gpon::mgcvendorname> | optional parameter with default value: "" Specifies the gateway soft switch Vendor |
| [no] cnf-msg-profid | Parameter type: <gpon::uriprofilename> Format: (none <gpon:uriprofileptr> name : <asamprofilename>) Possible values: - none : no profile to associate - name : profile name Field type <gpon:uriprofileptr> - Index of the URI profile that contains the IP address of the server - range: [0100] Data driven field type Possible values are depending on the actual configuration and software. The currently allowed values can be shown with online-help.</gpon:uriprofileptr></asamprofilename></gpon:uriprofileptr></gpon::uriprofilename> | optional parameter with default value: "none" Index or Name of the URI Profile that contains the Message Identifier string for H.248 messages |

Command Output

Table 41.50-3 "Voice ONT MGC Configuration command" Display parameters

| Specific Information | | |
|----------------------|---|-----------------------------------|
| name | Type | Description |
| pri-mgcuri-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the primary uri profile |
| | - ignored printable string | This element is only shown in |
| | | detail mode. |
| sec-mgcuri-prof-name | Parameter type: <gpon::ignoredprintablestring></gpon::ignoredprintablestring> | name of the secondary uri profile |
| | - ignored printable string | This element is only shown in |

| name | Type | Description |
|-----------------------|--|--|
| | | detail mode. |
| conf-mgcuri-prof-name | Parameter type: <gpon::ignoredprintablestring> - ignored printable string</gpon::ignoredprintablestring> | name of the H.248 message identifier uri profile This element is only shown in detail mode. |

41.51 Voice ONT MGC PM monitoring command

Command Description

This command sets the PM Mode of ONT MGC Agent monitoring

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont mgc-agent (voip-index) [no pm-collect | pm-collect <Gpon::PmEnable>]

Command Parameters

Table 41.51-1 "Voice ONT MGC PM monitoring command" Resource Parameters

| Resource Identifier | Type | Description |
|---------------------|---|-------------------------|
| (voip-index) | Format: | a unique voip ont index |
| | (<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | |
| | <eqpt::ponid> / <eqpt::ontid> / 1</eqpt::ontid></eqpt::ponid> | |
| | ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup> | |
| | <ng2::ontid> / 1)</ng2::ontid> | |
| | Possible values: | |
| | - ng2 : ngpon2 style identification | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Possible values: | |
| | - 1 : Gpon voip Port | |
| | Field type <ng2::channelgroup></ng2::channelgroup> | |
| | - channel group number | |
| | Field type <ng2::subchannelgroup></ng2::subchannelgroup> | |
| | - subchannel group number | |
| | Field type <ng2::ontid></ng2::ontid> | |
| | - the ONT identifier | |
| | Possible values: | |
| | - 1 : Gpon voip Port | |

Table 41.51-2 "Voice ONT MGC PM monitoring command" Command Parameters

| Parameter | Type | Description |
|-----------------|---|---------------------------------|
| [no] pm-collect | Parameter type: <gpon::pmenable></gpon::pmenable> | optional parameter with default |
| | Format: | value: "disable" |
| | (disable | This indicates whether MGC |
| | enable) | Performance Monitors should be |
| | Possible values: | collected for this MGC Config |
| | - disable : disable the collection | instance |
| | - enable : enable the collection | |

41.52 Voice Ont Pots Call PM Mode Configuration Command

Command Description

This command allows the operator to configure the PM Mode of ONT POTS Call monitoring

User Level

The command can be accessed by operators with sip,megaco privileges, and executed by operators with sip,megaco privileges.

Command Syntax

The command has the following syntax:

> configure voice ont pots-call (uni-idx) [no pm-collect | pm-collect <Gpon::OntPmCollect>]

Command Parameters

Table 41.52-1 "Voice Ont Pots Call PM Mode Configuration Command" Resource Parameters

| Resource Identifier | Type | Description |
|----------------------------|---|-------------------------------------|
| (uni-idx) | Format: | identification of the ont interface |
| | (<eqpt::rackid> / <eqpt::shelfid> / <eqpt::slotid> /</eqpt::slotid></eqpt::shelfid></eqpt::rackid> | index |
| | <eqpt::ponid> / <eqpt::ontid> / <gpon::ontslotid> /</gpon::ontslotid></eqpt::ontid></eqpt::ponid> | |
| | <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | ng2 : <ng2::channelgroup> / <ng2::subchannelgroup> /</ng2::subchannelgroup></ng2::channelgroup> | |
| | <ng2::ontid> / <gpon::ontslotid> /</gpon::ontslotid></ng2::ontid> | |
| | <gpon::ontpotsportid>)</gpon::ontpotsportid> | |
| | Possible values: | |
| | - ng2 : ngpon2 style identification | |
| | Field type <eqpt::rackid></eqpt::rackid> | |
| | - the rack number | |
| | Field type <eqpt::shelfid></eqpt::shelfid> | |
| | - the shelf number | |
| | Field type <eqpt::slotid></eqpt::slotid> | |
| | - the LT slot number | |
| | Field type <eqpt::ponid></eqpt::ponid> | |
| | - the PON identifier | |
| | Field type <eqpt::ontid></eqpt::ontid> | |
| | - the ONT identifier | |
| | Field type <ng2::channelgroup></ng2::channelgroup> | |
| | - channel group number | |
| | Field type <ng2::subchannelgroup></ng2::subchannelgroup> | |
| | - subchannel group number | |
| | Field type <ng2::ontid></ng2::ontid> | |
| | - the ONT identifier | |

| Resource Identifier | Type | Description |
|---------------------|--|-------------|
| | Field type <gpon::ontslotid></gpon::ontslotid> | |
| | - Gpon Ont Slot | |
| | - range: [114] | |
| | Field type <gpon::ontpotsportid></gpon::ontpotsportid> | |
| | - Gpon Ont Pots Port | |
| | - range: [124] | |

Table 41.52-2 "Voice Ont Pots Call PM Mode Configuration Command" Command Parameters

| Parameter | Type | Description |
|-----------------|---|---------------------------------|
| [no] pm-collect | Parameter type: <gpon::ontpmcollect></gpon::ontpmcollect> | optional parameter with default |
| | Format: | value: "disable" |
| | (enable | enable/disable pm mode of |
| | disable) | ont-pots call monitoring |
| | Possible values: | |
| | - enable : enable PM | |
| | - disable : disable PM | |