220- Trap Management Commands

220.1 Trap Management Command Tree

Description

This chapter gives an overview of nodes that are handled by "Trap Management Commands".

Command Tree

----admin
    ----trap
        ----manager
            - (address)
            - (reset-trap-buffer)

220.2 Trap Manager Management Command

Command Description

This command allows the operator to manage a trap manager.

User Level

The command can be accessed by operators with alarm privileges, and executed by operators with alarm privileges.

Command Syntax

The command has the following syntax:

> admin trap manager (address) [(reset-trap-buffer)]

Command Parameters

Table 220.2-1 "Trap Manager Management Command" Resource Parameters

Resource Identifier	Type	Description
(address)	Format: <Ip::V4Address> : <Trap::Port> Field type <Ip::V4Address> - IPv4-address Field type <Trap::Port> - trap port number - range: [1...65535]	the IP address of the manager

Table 220.2-2 "Trap Manager Management Command" Command Parameters

Parameter	Type	Description
(reset-trap-buffer)	Format: reset-trap-buffer Possible values: - reset-trap-buffer : reset the trap buffer	*optional parameter* reset the trap buffer