

/ Verify your installation

Check your PyAnsys Geometry version

```
from ansys.geometry.core import __version__
print(f"PyAnsys Geometry version: {__version__}")
```

PyAnsys Geometry version: 0.18.dev0

/ Sketching

There are two ways of creating 2D sketches in PyAnsys Geometry.

```
from ansys.geometry.core.sketch import Sketch
from ansys.geometry.core.math import Point2D
```

Functional-style sketching

```
sketch = Sketch()
```

```
(
    sketch
    .segment_to_point(Point2D([3, 3]), "Segment2")
    .segment_to_point(Point2D([3, 2]), "Segment3")
    .segment_to_point(Point2D([0, 0]), "Segment4")
)
```

You can visualize the sketch by calling the `plot` method.

```
sketch.plot()
```

Object-oriented sketching

```
sketch = Sketch()
```

```
sketch.triangle(
    Point2D([-10, 10]),
    Point2D([5, 6]),
    Point2D([-10, -10]),
)
```

/ Modeling

Launch a modeling session

```
from ansys.geometry.core import launch_modeler
modeler = launch_modeler()
print(modeler)
```

Ansys Geometry Modeler (0x7f89443002f0)

Ansys Geometry Modeler Client (0x7f8944300440)

Target: localhost:700

Connection: Healthy

Backend info:

Version: 27.1.0
Backend type: CORE_LINUX
Backend number: 20260916.1
API server number: 3365
CADIntegration: 27.1.0.13062143

By default, it will detect which modeling service is available on your system and launch it. If you have multiple modeling services installed, you can specify which one to use by passing the `mode` argument.

```
modeler = launch_modeler(mode='spaceclaim')
modeler = launch_modeler(mode='discovery')
modeler = launch_modeler(mode='geometry_service')
```

Connect to an existing modeler

```
from ansys.geometry.core import Modeler
modeler = Modeler()
print(modeler)
```

Create a design

```
design = modeler.create_design("MyDesign")
print(design)
```

ansys.geometry.core.designer.Design 0x7f8944301fd0

Name : MyDesign
Is active? : True
N Bodies : 0
N Components : 0
N Coordinate Systems : 0
N Named Selections : 0
N Materials : 0
N Beams : 0
N Beam Profiles : 0
N Datum Points : 0

N Datum Planes : 0
N Design Points : 0
N Design Curves : 0

Create a body by extruding a sketch

```
body = design.extrude_sketch("MyBody", sketch, 2)
print(body)
```

ansys.geometry.core.designer.Body 0x7f8942cc0ec0

Name : MyBody
Exists : True
Parent component : MyDesign
MasterBody : 0:22
Surface body : False
Color : #D6F7D1

Plot the design

```
design.plot()
```

Export the design to a file

```
scdocx_path = design.export_to_scdocx()
pmdb_path = design.export_to_pmdb()
para_txt_path = design.export_to_parasolid_text()
para_bin_path = design.export_to_parasolid_bin()
fmd_path = design.export_to_fmd()
disco_path = design.export_to_disco()
```

/ Extra: Product scripting

Ansys SpaceClaim and Ansys Discovery support product scripting, and so does the Ansys Geometry service. If you have a product script you want to run, you can use the `run_script_file` method available on the `Modeler` object. The `script_args` parameter is optional and they will be made available to the script inside a dictionary called `argsDict`.

```
result = modeler.run_script_file(
    file_path="path/to/script.py",
    script_args={"arg1": "value1", "arg2": "value2"},
)
```