

PyAnsys Units cheat sheet



Version: main

Defining a quantity using unit strings

```
from ansys.units import Quantity, UnitRegistry

meter = Quantity(value=1, units="m")
```

Defining a quantity using base dimensions

```
from ansys.units import Quantity, BaseDimensions, Dimensions

dims = BaseDimensions
dimensions = Dimensions({dims.LENGTH: 1, dims.TIME: 1})

acceleration = Quantity(value=3, dimensions=dimensions)

acceleration.value # 3.0
acceleration.units.name # "m s^-2"
```

Defining a quantity using UnitRegistry

```
from ansys.units import Quantity, UnitRegistry

ureg = UnitRegistry()
meter = Quantity(value=1, units=ureg.m)
```

Defining a quantity using NumPy array

```
from ansys.units import Quantity, UnitRegistry

length_array_quantity = Quantity(value=[1.0, 6.0, 7.0], units="m")
length_array_quantity[1] # Quantity (6.0, "m")

time = Quantity(value=2, units="s")

speed = length_array_quantity / time
speed # Quantity ([0.5 3. 3.5], "m s^-1")
```

Defining a quantity using the quantity table

```
from ansys.units import Quantity

torque = Quantity(5, quantity_table={"Torque": 1})

torque.value # 5.0
torque.units.name # "N m"
torque.units.si_units # "kg m^2 s^-2"
```

Arithmetic operations

```
from ansys.units import Quantity
import math

meter = Quantity(value=1, units="m")

m_ml = meter * 2 # (2.0, "m")
m_dv = meter / 2 # (0.5, "m")
m_sq = meter**2 # (1.0, "m^2")

meter = Quantity(value=1, units="m")
foot = Quantity(value=1, units="ft")

meter + foot # Quantity (1.3048, "m")
foot + meter # Quantity (4.2808398950131235, "ft")

deg = Quantity(90, "degree")
math.sin(deg) # 1.0
```

```
from ansys.units import UnitSystem

si = UnitSystem(system="SI")
si.LENGTH # "m"

cgs = UnitSystem(system="CGS")
cgs.LENGTH # "cm"

bt = UnitSystem(system="BT")
bt.LENGTH # "ft"
```

```
from ansys.units import BaseDimensions, UnitSystem, UnitRegistry

ureg = UnitRegistry()
dims = BaseDimensions

sys = UnitSystem(
    base_units={
        dims.MASS: ureg.slug,
        dims.LENGTH: ureg.ft,
        dims.TEMPERATURE: ureg.R,
        dims.TEMPERATURE_DIFFERENCE: ureg.delta_R,
        dims.CHEMICAL_AMOUNT: ureg.slugmol,
    }
)

sys.LENGTH
```

Convert quantity to other units

```
from ansys.units import Quantity

flbs = Quantity(1, "lb ft^-1 s^-1")
flbs.value # 1

pas = flbs.to("Pa s")
pas.value # 1.4881639435695542
pas.units.name # 'Pa s'
```

Convert units using unit systems

```
from ansys.units import Unit, UnitSystem

si = Unit("m s^-1")
bt = UnitSystem(system="BT")
si.convert(bt)
```

Temperature and temperature difference

```
from ansys.units import Quantity, UnitRegistry

ureg = UnitRegistry()

K = Quantity(value=280, units=ureg.K)
K2 = Quantity(value=295, units=ureg.K)
delta_K = Quantity(value=5, units=ureg.delta_K)

K2_sb_K = K2 - K # (15.0, "delta_K")
K_ad_delta_K = K + delta_K # (285.0, "K")
K2_sb_delta_K = K2 - delta_K # (290.0, "K")
delta_K_ad_delta_K = delta_K + delta_K # (10.0, "delta_K")
delta_K_sb_delta_K = delta_K - delta_K # (0.0, "delta_K")
```

Temperature values below absolute zero

```
from ansys.units import Quantity, UnitRegistry

ureg = UnitRegistry()

K = Quantity(value=-2, units=ureg.K) # (-2, delta_K)
C = Quantity(value=-2, units=ureg.C) # (-275, delta_C)
F = Quantity(value=-2, units=ureg.F) # (-500, delta_F)
R = Quantity(value=-2, units=ureg.R) # (-2, delta_R)
```

Angle as non-dimension

```
import ansys.units as pyunits

degree = pyunits.Quantity(1.0, "degree")
degree.is_dimensionless # True
degree + 1 # Quantity (58.29577951308232, "degree")
```

```
import os
os.environ["PYANSYS_UNITS_ANGLE_AS_DIMENSION"] = "1"
import ansys.units as pyunits

degree = pyunits.Quantity(1.0, "degree")
degree.is_dimensionless # False
degree + 1 # Not allowed
```

```
from ansys.units import Unit, UnitRegistry

ureg = UnitRegistry()
ureg.register_alias("angular_deg", "degree")
Unit("angular_deg") # resolves to "degree"
```

Quantity dimensions

```
from ansys.units.quantity_dimensions import QuantityDimensions

force = QuantityDimensions.FORCE
area = QuantityDimensions.AREA
pressure = QuantityDimensions.PRESSURE

pressure == force / area # True
```

```
from ansys.units import Unit
```

```
# <multiplier prefix>[unit]<^exponent>
accel = Unit("m s^-2") # base units with exponent
density = Unit("kg m^-3") # compound unit string
kpa = Unit("kPa") # multiplier prefix "k"
```

```
from ansys.units import UnitRegistry, get_si_value

ur = UnitRegistry(custom_units=[
    {"unit": "micron", "composition": "m", "factor": 1e-6},
    {"unit": "thou", "composition": "m", "factor": 2.54e-5},
])

q = ur.Quantity(1, "micron") # String-based lookup
get_si_value(q) # 1e-06
```

Plotting with Matplotlib

```
import matplotlib.pyplot as plt
from ansys.units import Quantity

x = Quantity([1, 2, 3], "m")
y = Quantity([4, 5, 6], "kg")
fig, ax = plt.subplots()
ax.plot(x, y)
plt.show()
```

```
from ansys.units import Unit, Quantity
```

```
# Built-in aliases resolve to canonical names
Unit("deg") # "degree"
Unit("rad") # "radian"
Unit("meter") # "m"
Unit("newton") # "N"
```

```
# Aliases work in quantities and compound strings
Quantity(90, "deg") # 90.0 degree
Unit("deg sec^-1") # "degree s^-1"
Quantity(180, "deg").to("rad") # ~3.14159 radian
```

```
from ansys.units import UnitRegistry
```

```
ur = UnitRegistry()
ur.register_unit(unit="Q", composition="N m", factor=1)
ur.Q == ur.J # True
```

```
# String-based lookup methods
unit = ur.get_unit("Q")
q = ur.Quantity(5, "Q")
```

Pandas integration

```
import pandas as pd

# Create unit-aware Series
distances = pd.Series([1.0, 2.0, 3.0], dtype="quantity[m]")

# Convert units
distances_cm = distances.units.to("cm")

# Unit-aware DataFrame
df = pd.DataFrame({
    "length": pd.Series([1.0, 2.0], dtype="quantity[m]"),
    "mass": pd.Series([1.0, 2.0], dtype="quantity[kg]")
})
```