


BTE13-010A: connection and programming map

Component side, oriented like IMG_7014: serial header LEFT, crystal and reset button RIGHT.

Read the actual silkscreen before soldering. Diagram is not a footprint or regulator-removal template.



OPERATING CONNECTIONS

VCC = protected battery; GND = OUT-; RAW = unused
A1 = LDR sense; 7 = LDR power; 9 = LED PWM
8 = status to Q2 2N3904; 2 = test button to GND
Regulator / power LED removed only after trace identification.

ISP CONNECTIONS / BOARD DISCONNECTED FROM BUILD

MOSI -> 11 MISO -> 12 SCK -> 13 RESET -> RST
Also connect target VCC and GND; use compatible voltage.
Configure actual internal 8 MHz clock and BOD 2.7 V.
A USB-to-serial adapter alone cannot perform this conversion.