


Integrity Instruments

P.O. Box 451 Pine River Minnesota 56474 USA Order Phone Fax Phone Tech Phone

800-450-2001 218-587-3414 218-587-3120


http://www.integrityusa.com



EXP-STA EXP-TRK

Digital I/O Mounting Boards

Integrity Instruments Expander Board User Manual



I/O Modules

The module inputs and outputs are connected to JS5. In the case of DC units polarity must be observed, and is shown above. There are many other modules which can be used, the only criteria being that the internal logic levels must be 5 vdc.

Fuses are 5 x 20 mm, 3.15 amp


The table below shows some of the manufacturers, and some of the applicable modules.

Module Color	Module type	Crouzet (Gordos)	Grayhill	Opto22	Potter & Brumfield	WRCAkron
WHITE	DC Input	IDC5	70-IDC5B	IDC5	IDC-5	1781-IB5S
RED	DC Output	ODC5	70-ODC5	ODC5	ODC-5	1781-OB5S
YELLOW	AC Input	IAC5	70-IAC5	IAC5	IAC-5	1781-IA5S
BLACK	AC Output	OAC5	70-OAC5	OAC5	OAC	1781-OA5S

Integrity Instruments Expander Board User Manual

Position Numbering

Board position and port/bit number in relation to I/O module position.



EXP-X BOARD #	I/O Module Number	I/O Port/Bit Number	I/O Module Port Pin#
	JS1	P2B0	Pin 1
1	JS2	P2B1	Pin 2
1	JS3	P2B2	Pin 3
	JS4	P2B3	Pin 4
	JS1	P2B4	Pin 5
2	JS2	P2B5	Pin 6
2	JS3	P2B6	Pin 7
	JS4	P2B7	Pin 8
	JS1	P1B0	Pin 14
3	JS2	P1B1	Pin 15
3	JS3	P1B2	Pin 16
	JS4	P1B3	Pin 17
	JS1	P1B4	Pin 18
1 1	JS2	P1B5	Pin 19
' '	JS3	P1B6	Pin 20
	JS4	P1B7	Pin 21

3

Operational Characteristics

The Integrity Instruments EXP-X boards mate up directly to our line of I/O data acquisition modules. The boards are designed to allow expansion for up to 16 digital I/O points. If you need more than the 4 I/O points just plug in another board. This can be done for up to 4 EXP-X boards. All 16 I/O points, plus voltage and ground are available at the male DB 25 connector on the first board. This is accomplished by data line rollover shown in the diagram below.

ALE D	B LEFT
PIN#	SIGNAL
V 1	P2 B0
N 2	P2 B1
N 3	P2 B2
N 4	P2 B3
N 5	P2 B4
N 6	P2 B5
N 7	P2 B6
N 8	P2 B7
N 14	P1 B0
N 15	P1 B1
N 16	P1 B2
N 17	P1 B3
N 18	P1 B4
N 19	P1 B5
N 20	P1 B6
N 21	P1 B7
N 24	+5V
N 22	+5V
N 25	GND
N 13	GND

Nomenclature

The boards are marked to show the specific port and bit number for each I/O point used with our data acquisition modules.

There are two ports, P1 and P2, and eight bits per port B0 to B7. The designation P2B3 is Port 2 Bit 3.

When all 4 boards are series connected, the **input end is board 1, then board 2, 3, and 4.** The marking on the board shows what port and bit number controls that I/O position on the board, depending on what board number it is in the connection series. See figures on page 3.


The left column in the diagram above shows the DB 25 pin number and its' relation to the specific I/O points on each board.

By using the Integrity Instruments DB25FTS adapter the expander board may be used with any I/O controller You need only to supply the unit with power and the proper signal lines for functionality.

MODELS: EXP-TRK------Track mount in Snaptrack[®] EXP-STA -----Standoffs 1/2 inch, hollow for 6/32 mounting screws

4

Expander Board Schematic





Integrity Instruments Expander Board User Manual

I/O Modules Specifications available from Integrity Instruments

PART NUMBER	FUNCTION	RANGE	TURN ON TIME	TURN OFF TIME
1781-IB5S	DC INPUT	3.3 to 32 VDC	.3 milli-seconds	.6 milli-seconds
1781-OB5S	DC OUTPUT	3 to 60 VDC 3A	.05 milli-seconds	.1 milli-seconds
1781-IA5S	AC INPUT	90 to 140 VAC	20 milli-seconds	30 milli-seconds
1781-OA5S	AC OUTPUT	12 to 140 VAC 3A	N/A	N/A


I/O Modules Internal Schematic and Exp Board Connections






PINNING

PIN 1	+ INPUT	+ OUTPUT		
PIN 2	- INPUT	- OUTPUT		
PIN 3	VCC	VCC		
PIN 4	TO MPU	TO MPU	- AS OUT	+ AS IN
PIN 5	GND	GND		





Digital & Analog I/O Port Specifications:

Digital I/O			
DB25 Pins	Description		
1	Port 2 Bit 0		
2	Port 2 Bit 1		
3	Port 2 Bit 2		
4	Port 2 Bit 3		
5	Port 2 Bit 4		
6	Port 2 Bit 5		
7	Port 2 Bit 6		
8	Port 2 Bit 7		
9			
10			
11			
12	+5Vdc		
13	GND		
14	Port 1 Bit 0		
15	Port 1 Bit 1		
16	Port 1 Bit 2		
17	Port 1 Bit 3		
18	Port 1 Bit 4		
19	Port 1 Bit 5		
20	Port 1 Bit 6		
21	Port 1 Bit 7		
22			
23			
24	+5Vdc		
25	GND		

NOTES

WARRANTY

Integrity Instruments warranties all products against defective workmanship and components for the life of the unit. Integrity Instruments agrees to repair or replace, at it's sole discretion, a defective product if returned to Integrity Instruments with proof of purchase. Products that have been mis-used, improperly applied, or subject to adverse operating conditions fall beyond the realm of defective workmanship and are not convered by this warranty.

Copyright \bigcirc 2000-2003, Integrity Instruments, Inc. All trademarks and/or registered trademarks are the property of their respective owners.

Revision: January 3, 2005 - v3.0