COLIVING MANAGEMENT

Your co-living journey begins here.

EASY MODE

SETUP SMART DOOR

SETUP STEP 5

SETUP TTLOCK

1. Go to company setting
2. Connect your own account



TTLOCK APPS

1. Go to Lock Setting





TTLOCK APPS

1. Remote Unlock=on
2. Privacy Lock=off
3. Firmware Update

Special Remark

- Don delete directly the password inside ttlock apps, it will not trigger platform
- Every password have own id, after you delete the system will crash



SMART DOOR

1. Add Lock
2. Sync will get all the lock & gateway from your ttlock apps
3. Save selected lock into system



COLIVING MANAGEMENT

Your co-living journey begins here.

FINISH

COMPLETE SETUP

HOW TO SETUP SMART DOOR