




3V3 -> 1.8V LDO 200mA








JTAG connector


## JTAG/UART to USB


































Auxillary connector






Line LED'S





## Pin function table

PIN	UART	JTAG	SPI	12C	SWD
ADBUS0	TXD	JTAG_TCK	SPI_SCK	 	SW_CLK
ADBUS1	RXD	JTAG_TDI	SPI_MOSI		SW_IO(o)
ADBUS2	RTS	JTAG_TDO	SPI_MISO		SW_IO(i)
ADBUS3	CTS	JTAG_TMS	SPI_CS		
BDBUS0	TXD	JTAG_TCK	SPI_SCK	I2C_SCL	
BDBUS1	RXD	JTAG_TDI	SPI_MOSI	I2C_SDA(o)	
BDBUS2	RTS	JTAG_TDO	SPI_MISO	I2C_SDA(i)	
BDBUS3	CTS	JTAG_TMS	SPI_CS		



MPSSE mode = JTAG/SPI, connector selected by JTAG\_VCC



