## USB-C




## 5V -> 3.3V LDO 400mA




## 3V3 -> 1.8V LDO 200mA




## Voltage selection




## Voltage indicator




## JTAG/UART to USB




## IFA buffer enable and direction




## IFB buffer enable and direction




## JTAG connector




## IFA voltage level translation




## IFB voltage level translation




## Auxillary connector




## Goldpin connector




## Pin function table

| PIN | UART | JTAG | SPI | I2C | SWD |
|---|---|---|---|---|---|
| ADBUS0 | TXD | JTAG_TCK | SPI_SCK | | SW_CLK |
| ADBUS1 | RXD | JTAG_TDI | SPI_MOSI | | SW_IO(o) |
| ADBUS2 | RTS | JTAG_TDO | SPI_MISO | | SW_IO(i) |
| ADBUS3 | CTS | JTAG_TMS | SPI_CS | | |
| | | | | | |
| BDBUS0 | TXD | JTAG_TCK | SPI_SCK | I2C_SCL | |
| BDBUS1 | RXD | JTAG_TDI | SPI_MOSI | I2C_SDA(o) | |
| BDBUS2 | RTS | JTAG_TDO | SPI_MISO | I2C_SDA(i) | |
| BDBUS3 | CTS | JTAG_TMS | SPI_CS | | |

***MPSSE mode = JTAG/SPI, connector selected by JTAG_VCC***

## Mode selector




## IFA I2C buffer w/ SDO+SDI switch




## Line LED'S




## IFA SWD mode switch




## SWD buffered mode switch





Antmicro Ltd.
www.antmicro.com


Sheet: /
File: debug-toolkit.kicad_sch

**Title: Debug Toolkit**

| Size: A2 | Date: 2022-08-03 | **Rev: 1.3.8** |
|---|---|---|
| KiCad E.D.A. eeschema 6.0.11+dfsg-1-bpo11+1 | | Id: 1/1 |

N1 Logo antmicro_logo
N2 Logo oshw_logo