This program implements a simple web server example using FreeRTOS and the LwIP TCP/IP stack with the PSE MSS MAC Ethernet driver. This can be used to exercise the driver on the HW Emulation platform with the Peripheral Daughter Board, Renode PolarFire SoC emulation or the FU540 based Aloe board.

The software has a fixed IP address of 172.16.0.3/255.255.255.0 Opening this address with a web-browser should display a simple web page.

The IP address can be change from within this file: \(/src/modules/config/lwip-2.0.0-wip/network_interface_settings.h \)

When targeting the Renode emulation then the messages on the UART show what extra steps are required for the bridge between the host and the emulation to work properly on the Linux host (no Windows support with SoftConsole 6.1).

When creating the bridge for the first time, it might display error: Could not set TUNSETIFF, error: 2 Renode is trying to probe the user's privileges, which should be safe to ignore. If the polkit and sudo are set to be passwordless then the bridge should be created correctly without any other user's interaction.

When targeting Renode, make sure that the IP settings are not overlapping with existing network on your host as the renode-tap0 requires to be own network.

When enabling Wireshark logger, some extra steps might be required to allow regular users to capture network traffic (read the materials listed below).

When targeting real HW then the IP network should match existing real network and just the IP address itself needs to be unique (join an existing network, but do not create conflicts).

Note: The example currently is not using the most up-to-date HAL release, the GEM driver required some changes to be made on top of HAL so it is not straight forward to port to the newest HAL. This will be addressed in the SoftConsole 6.2 release, however in the meantime use the bundled pse-blinky/pse-mustein-julia or firmware catalog examples use the most recent HAL.