# Range of Gain Ports Center Min Yaw Pitch Roll A106 A106 A106 A106

## 1. Clear all settings [servo & stick centering]

- Set Roll, Pitch & Yaw gain pots to zero. (CCW)
- Power on.
- Wait a few seconds.
- Power off.
- Restore gain pots.

# 2. ESC throttle calibration

- Set **Yaw** gain pot to zero. (CCW)
- Put throttle stick to full.
- Power on.
- LED flashes 3 times.
- Wait for motor signal (double bleep).
- Throttle to zero.
- Wait for motor confirm signal.
- Power off.
- Restore Yaw gain pot.

## 3. Stick Centering

Your current stick position can be center by following next steps except throttle.

- Set **Pitch** gain pot to zero. (CCW)
- Set Transmitter trims to center.
- Power on.
- LED flashes 3 times.
- Wait a few seconds.
- LED flashes 1 time.
- Power off.
- Restore Pitch gain pot.

### 4. Gyro(Servo) direction reversing

- Set Roll gain pot to zero.(CCW)
- Power on.
- LED flashes 3 times.
- To set Gyro Reverse, move Tx stick right/down or To normal it move stick left/up.
- Power off.
- Restore Roll gain pot.

# **5.** Setting Gyro gain

- Increase: Clockwise
- Decrease: Counterclockwise
- Initial Gyro gain pot value is 50%.
- Increase until it starts to oscillate rapidly, then back off until it is stable again.
- Set transmitter trims on take off.