


DIYDrones.com

Quick reference to update your MediaTek GPS Module...


1.-Inside the "Flash Tool" folder execute "PowerFlash.exe".

ll Firmware		7/28/2010 10:50 AM	File folder	
brom.dⅡ		3/3/2008 7:17 PM	Application extens	240 KB
brom.ini		12/21/2006 8:48 PM	Configuration sett	1 KB
MTK_AllInOne_DA_MT3329_v4.02.bin		7/8/2008 11:07 PM	PentaLogix Jobfile	14 KB
PowerFlash.exe		12/1/2009 3:12 PM	Application	1,382 KB
Powerflash.ini	Date created: 7	77/2010 9:41 AM	Configuration sett	2 KB
scat.txt	Size: 1.34 MB	5/9/2006 12:01 PM	Text Document	1 KE
Test_Log_2010.7.7.csv		7/7/2010 9:48 AM	CSV File	1 KE
Test_Log_2010.7.8.csv		7/8/2010 10:32 AM	CSV File	1 KB
Test_Log_2010.7.28.csv		7/28/2010 10:54 AM	CSV File	1 KB
Test_Log_2010.8.3.csv		8/3/2010 4:57 PM	CSV File	1 KB


2.-Go to Options>>Series and select "3329".




3.-Then go to "ComPort" and select the port connected to your GPS module.




4.-Go to "ComPort" again and set the "Update Baudrate" to "115200".




5.-Go to "File" and click on "Download Agent"




 $6.- Double\ click\ on\ "MTK_AllInOne_DA_MT3329xxxx.bin".$




7.-Now click on "ROM".




8.-Then go to folder "Firmware" and select the "firmware" you want to load, in this example there is only one file on the picture with the extension .bin:




9.-Then go to "Actions" and click "Connect", you should see the blue bars as indicated in the image:



10.-Then go to "Action" and Click on "Download"



11.-Then the system will start loading the firmware:



12.-Finally you should see a green donut indicating that the load was successful. You GPS is not updated.

