

Nikon Extension Bellows



INSTRUCTION MANUAL

NOMENCLATURE


Extension bellows

Bellows retaining clip

Connecting ring

Extension rail

Extension bellows mounting panel



Tripod head/rail connector locking knob

Bellows retaining screw



Extension bellows locking knob


End stop

CONTENTS

Foreword	3
Mounting the PB-6E	4
Focusing	5
Determining the reproduction ratio	6
Reproduction ratios	8
Specifications	11

FOREWORD


The Nikon Extension Bellows PB-6E can be connected to the Nikon Bellows Focusing Attachment PB-6 to increase the amount of extension up to 438mm. Its use permits the photographer to obtain higher magnification ratios than are possible with the bellows alone. When using both units in combination, please refer to the PB-6 instruction manual, too.



MOUNTING THE PB-6E

1. Unscrew the end-stop from the lens panel end of the PB-6 rail, disconnect the PB-6 bellows from the lens panel by loosening the bellows retaining screw, and take the lens panel completely off the rail.
2. Unscrew both end-stops from the PB-6E extension rail, loosen the locking knobs on the tripod head/rail connector, and slide it half-way off the end of the extension rail.
3. Slip the front end of the PB-6 rail into the tripod head/rail connector until the two rails meet in the center and the millimeter scale is continuous. Then tighten both locking knobs to prevent the rails from pulling apart.
4. Now connect the front of the PB-6 bellows to the back of the PB-6E mounting panel.
5. Slip the PB-6 lens panel onto the front end of the PB-6E extension rail and tighten the locking knob. Then connect the PB-6E extension bellows to the lens panel. If you want to mount the lens in the reverse position, you must reverse the lens panel on the rail. Then, connect the bellows to the front rim of the lens.
6. Finally screw the end-stops into the front of the PB-6E extension rail.
7. Don't forget to put the two extra end-stops away for safekeeping.

Note: When the PB-6/PB-6E assembly is in use, the PB-6's tripod head may be left on its rail or removed, since its function is replaced by the tripod head/rail connector of the PB-6E.




FOCUSING

With the PB-6E attached to the PB-6, reproduction ratios are almost always larger than 1X. Because the subject appears dark in the finder, the photographer may need to illuminate the subject for focusing.

Focusing can be done by moving either the lens panel, the camera panel or the subject. (The focusing ring of the lens should be turned to infinity.) To determine the size of the subject field, reproduction ratio, bellows extension and working distance (i.e., the distance between the subject plane in focus and the lens barrel), please refer to the reproduction ratio tables on page 8~10.

distance between the subject plane in focus and the front of the lens barrel), please refer to the reproduction ratio tables on page 8~10.

When the PB-6/PB-6E assembly is mounted on a tripod or a repro-copy outfit such as the accessory Nikon PF-2, PF-3 or PF-4, it is recommended to move the assembly itself for focusing after first determining the bellows' extension that will give you the desired reproduction ratio.



DETERMINING THE REPRODUCTION RATIO

To find the reproduction ratio by measuring the bellows extension (lens in the normal position)

The scale on the upper part of the PB-6E extension rail forms a continuation of the scale of the PB-6 when the two units are connected. Thus, the amount of the bellows extension is shown on the scale of the PB-6E rail. Where "X" is the value given on the scale, and "f" is the focal length of the lens used, the reproduction ratio (M) is equal to $\frac{X}{f}$

Example: When the Micro-Nikkor 55mm f/2.8 is used, and the X value on the scale is given as 385, the reproduction ratio is as follows:

$$M = \frac{385}{55} = 7$$

When the lens panel and the camera panel are both at intermediate positions on the rail, read off the numerical values on each side. Then find the difference of the two values and subtract 22mm from the result. This gives the bellows extension value.

Example: When the difference is 232mm and the focal length of the lens is 105mm, the reproduction ratio is as follows:

$$M = \frac{(232 - 22)}{105} = \frac{210}{105} = 2$$

Note: It should be remembered that these values are only correct if the lens in use is set at infinity; settings other than infinity will result in additional extension, which has to be

added to the value given on the scale in order to determine the true bellows extension.

To find the reproduction ratio in the Nikon F3's viewfinder (lens in any position)

Place the scale in the same place as the subject and parallel with the longer side of the viewfinder. The left end of the scale (marked "0") should be continuous with the left-hand side of the viewfinder (or the top side, if the camera is placed vertically). Look through the viewfinder, and read off the length of the area which is in sharp focus. The reproduction ratio M is as follows:

$$M = \frac{36}{\text{the length of the area read off}} \\ (\text{along the long side of the viewfinder})$$


Example: When 18mm is read off as the length of the area in sharp focus, then:

$$M = \frac{36}{18} = 2$$

When using Nikon cameras other than the F, F2 or F3, the value computed in the above equation must be multiplied by 0.9 because of the difference in viewfinder coverage.

Important!

It should be remembered that when photographing at high magnification using the extension bellows, the slightest vibration will result in a blurred image. Always use a sturdy tripod and cable shutter release. Proper illumination is also indispensable for satisfactory results.



Scale



Lengthwise reading (mm)	1.5	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
Reproduction ratio	24X	18	12	9	7.2	6	5.1	4.5	4	3.6	3.3	3	2.8	2.6	2.4	2.3	2.1	2	1.9	1.8	1.7	1.6	1.5	1.4	1.3	1.2					

Lengthwise reading (mm)	32	33	34	35	36	37	38~42	43~48	49~55	56~65	66~80	81~102	103~144	145~240	241~380						
Reproduction ratio	1.1X		1		0.9		0.8		0.7		0.6		0.5		0.4		0.3		0.2		0.1

REPRODUCTION RATIOS

Lens	Mounting position	Subject field	∞	360	180	144	108	72	36	18	12	9	7.2	6	5.1	4.5	4	3.6	3.3	3	2.6	2.3	2	1.8	1.6	1.5		
		∞	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X		
		Reproduction ratio	1/∞	1/6X	1/5X	1/4X	1/3X	1/2X	1X	2X	3X	4X	5X	6X	7X	8X	9X	10X	11X	12X	14X	16X	18X	20X	22X	24X		
20mm f/2.8	Reverse	Extension																									(22.3×)	
		Working distance																										
20mm f/3.5	Reverse	Extension																										(22.2×)
		Working distance																										
24mm f/2.8 f/2	Reverse	Extension																										(18.4×)
		Working distance																										
28mm f/3.5 f/2.8 f/2 f/3.5 PC	Normal	Extension																										
		Working distance																										
	Reverse	Extension																										(15.7×)
		Working distance																										
Series E 28mm f/2.8	Normal	Extension																										
		Working distance																										
35mm f/2 f/1.4	Reverse	Extension																										
		Working distance																										
35mm f/2.8 f/2.8 PC Series E 35mm f/2.5	Normal	Extension																										(12.2×)
		Working distance																										0.1
	Reverse	Extension																										(12.3×)
		Working distance																										
50mm f/1.8 f/2 f/1.4, f/1.2 f/1.8 AF Series E 50mm f/1.8	Normal	Extension																										(8.5×)
		Working distance																										
	Reverse	Extension																										(8.4×)
		Working distance																										
f/2.8 Micro 55mm f/3.5 Micro f/1.2	Normal	Extension																										(8.0×)
		Working distance																										
	Reverse	Extension																										(7.6×)
		Working distance																										

Lens		Mounting position	Subject field	∞	360	180	144	108	72	36	18	12	9	7.2	6	5.1	4.5	4	3.6	3.3	3	2.6	2.3	2	1.8	1.6	1.5									
				∞	240	120	96	72	48	24	12	8	6	4.8	4	3.4	3	2.7	2.4	2.2	2	1.7	1.5	1.3	1.2	1.1	1									
				1/∞×	1/10×	1/5×	1/4×	1/3×	1/2×	1×	2×	3×	4×	5×	6×	7×	8×	9×	10×	11×	12×	14×	16×	18×	20×	22×	24×									
58mm f/1.2 Noct	Normal	Extension									48	116	174	208	232	290	348	406	438																	
		Working distance									(1/1.2×)	●	●	●	●	●	●	●	●	(7.6×)																
	Reverse	Extension									74	32.7	23	19.9	18.2	15.3	13.4	12	11.4																	
		Working distance									(1.4×)	●	●	●	●	●	●	●	●	(7.4×)																
85mm f/2 f/1.4	Normal	Extension									48	85	170	208	255	340	438																			
		Working distance									(1/1.8×)	●	●	●	●	●	●	●	●	(5.2×)																
	Reverse	Extension									90	103	146	208	316	401	438																			
		Working distance									(1/3.0×)	●	●	●	●	●	●	●	●	(4.4×)																
Series E 100mm f/2.8	Normal	Extension									48	50	100	200	208	300	400	438																		
		Working distance									(1/2.1×)	●	●	●	●	●	●	●	●	(4.4×)																
	Reverse	Extension									106	116	126	131	139	156	208	306	406	438																
		Working distance									●	●	●	●	●	●	●	●	●	(3.3×)																
105mm f/2.8 Micro	at ∞	Normal	Extension								48	53	105	208	315	420	438																			
		Working distance									(1/2.2×)	●	●	●	●	●	●	●	●	(4.2×)																
	Reverse	Extension									137	148	158	163	172	190	208	242	347	438																
		Working distance									●	●	●	●	●	●	●	●	●	(2.9×)																
105mm f/4 Micro f/2.5 f/1.8	Normal	Extension									1084	559	452	349	244	189	139	86	70	1																
		Working distance									(1.1×)	●	●	●	●	●	●	●	●	●	(5.8×)															
	Reverse	Extension									153	160	168	172	179	193	208	234	317	399	438															
		Working distance									(1/7.5×)	●	●	●	●	●	●	●	●	(3.5×)																
135mm f/3.5 f/2.8 f/2 Series E 135mm f/2.8	Normal	Extension									48	105	208	315	438																					
		Working distance									300	133	142	151	168	208	221	326	438																	
	Reverse	Extension									(1/6.1×)	●	●	●	●	●	●	●	●	(3.1×)																
		Working distance									670	450	350	240	150	140	86	68																		
180mm f/2.8 ED f/2.8	Normal	Extension									180	194	208	214	225	248	315	438																		
		Working distance									●	●	●	●	●	●	●	●	●	(1.9×)																
	Reverse	Extension									1400	680	570	440	300	170	100																			
		Working distance									●	●	●	●	●	●	●	●	●	(1.9×)																

REPRODUCTION RATIOS—continued

Lens	Mounting position	Subject field	(mm)																						
			∞	360	180	144	108	72	36	18	12	9	7.2	6	5.1	4.5	4	3.6	3.3	3	2.6	2.3	2	1.8	1.6
Reproduction ratio	∞	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
200mm f/4	Normal	Extension							48	67	100	208	400	438											
		Working distance							(1/4.2×)																
	Reverse	Extension																							
		Working distance	395	415	435	438			1200	920	720	520	420	420											
200mm f/4 IF Micro	Normal	Extension							48	50	67	100	200	208	400	438									
		Working distance							(1/4.2×)																
	Reverse	Extension																							
		Working distance	782	302	322	332	349	382	438	980	957	754	557	357	349	257	248								

= With PB-6 alone.

= With PB-6 and PB-6E together.

Working distance: Distance between the subject plane in focus and the front edge of the lens barrel; with the lens mounted in reverse, the distance is between the subject and the rear edge of the lens barrel.

Notes: 1) Reproduction ratios are those obtained at infinity.

- 2) If more than one lens is included in each lens column (i.e., 24mm f/2.8 and f/2), the reproduction ratios apply only to the first lens (i.e., 24mm f/2.8).
- 3) The 180mm f/2.8, 180mm f/2.8 ED, 135mm f/2, 85mm f/1.4 and 28mm f/3.5 PC lenses cannot be used in the reversed position because of the larger size of their attachments. To mount the Nikkor 20mm f/2.8 or 105mm f/1.8 in the reversed position, use the optional Nikon Macro Adapter Ring BR-5.
- 4) For close-up and macrophotography, the following lenses are especially recommended: 55mm f/2.8 Micro, 105mm f/2.8 Micro, 200mm f/4 IF Micro, 50mm f/1.8, etc.

SPECIFICATIONS

Bellows extension: With PB-6:

48mm ~ 208mm

With PB-6 and PB-6E:

83mm ~ 438mm

Reproduction ratio: With PB-6 and 50mm f/1.8:

1/1.1 ~ 4X (lens in normal position)

1.1~3.9X (lens in reverse position)

With PB-6, PB-6E and 50mm f/1.8:

1.6X ~ 8.5X (lens in normal position)

2.1X ~ 8.4X (lens in reverse position)

Composition: Extension rail, extension bellows and tripod head/rail connector

Dimensions: 82mm(W) x 155mm(H) x 230mm(L)

Weight: Approx. 800g

No reproduction in any form of this manual, in
whole or in part (except for brief quotation in critical
articles or reviews), may be made without written
authorization from NIKON CORPORATION.

Nikon

NIKON CORPORATION

FUJI BLDG., 2-3, MARUNOUCHI 3-CHOME, CHIYODA-KU, TOKYO 100, JAPAN
PHONE: 81-3-3214-5311 **TELEX:** NIKON J22601 **FAX:** 81-3-3201-5856