Host Dashboard

Host Dashboard

Invocation

- Navigate to this page by clicking the hostname under the Managed Hosts tab on the Home page.
- Also invoked by using the "Search a host" search bar on the main menu bar.

Overview

 The Host Dashboard is a dynamic view. It refreshes every 10 seconds to display up-to-date information.

General

Display the host connection information.

Software Packages

Display the software packages of the host.

Scheduled Installations

 Display all the scheduled installations. When an installation is executing, a runner icon is displayed next to the scheduled installation.

Install/Software Inventory History

Display both the install and software inventory history.

Action

- Schedule an Install.
- Delete All Scheduled Installs.
- Delete All Failed Installs.
- Retrieve the Latest Software.
- Edit Host.

Host Dashboard

ill Host: ASR9K-PE1-R0

Region Cisco Telecom
West Coast

Platform ASR9K

Software 5.1.3


Host or IP 172.28.98.2


Username cisco

Connection telnet

Created By root


Last Successful Retrieval: 12h 13m 56s ago





Install History





Software Inventory History



