Date:		Mapping to DIM100	pinout with Adapter card		HSEC Pinout:
12-Mar-2020		E	280025		2.15
From With Illand	DIM!	•	280023	DIMi	From With Hall
Exp Kit lbl	DIM pin			DIM pin 51	Exp Kit lbl
	2			52	
	3	12V	12V	53	
	4	-	-	54	
	5	-	-	55	
-	6			56	
ВО	7	A11/C0/CMP1/TESTANA0	A0/C15/ADCINCAL/CMP3P	57	A0
	8			58	
B1		A12/C1/TESTANA1/CMP2/CMP4P	A1/CMP1P	59	A1
	10			60	
B2	11	C4/A14/CMP3P	A2/C9/CMP1P/CMP3	61	A2
	12	as to upon		62	
В3	13 14	C6/CMP3P	A3/C5/VDAC/CMP3	63 64	A3
B4		A15/C7/CMP1	A4/C14/CMP2P/CMP4	65	A4
54	16		A4/C14/CMPZP/CMP4 All VREFHIS *	66	
B5	17	C8/A9/CMP4P/CMP2P	A5/C2/CMP3	67	A5
58	18	-	-		59
В6	19	A10/C10/CMP2	A6/CMP1P	69	A6
60	20	GPIO-35/TDI	-	70	61
В7		A8/C11/CMP2P/CMP4P#	A7/C3/CMP4	71	A7
62	22	-	-	72	63
00	22	GPIO-00	GPIO-01	72	01
00 02	23 24	GPIO-00 GPIO-02	GPIO-01 GPIO-03	73 74	01 03
04	25	GPIO-04	GPIO-05	75	05
06	26	GPIO-06	GPIO-07	76	07
	27		5V	77	
08	28	GPIO-08	GPIO-09	78	09
10	29	GPIO-10	GPIO-11 @		11
48		GPIO-12 @	GPIO-13 @	80	49
84	31	GPIO-14 GPIO-42	GPIO-15	81	85
86 12	32	GPIO-42 GPIO-39	5V	82 83	13
15	34	-		84	14
24	35	GPIO-24 ** #	GPIO-25 # @		25
26	36	GPIO-26 # @	GPIO-27 # @	86	27
	37		5V	87	
16	38	GPIO-16	GPIO-17		17
18	39	GPIO-18/X2 ##	GPIO-19/X1 ##		19
20 22	40 41	GPIO-40 GPIO-22	GPIO-41 GPIO-23	90 91	21 23
87	41	GPIO-22 GPIO-37/TDO	GPIO-23	91	23
28	43	GPIO-28 @@	GPIO-29 @@	93	29
30	44	GPIO-30	GPIO-31	94	31
32		GPIO-32**	GPIO-33		33
34	46	GPIO-34	5V	96	
	47		GPIO-35/TDI	97	
		TCK	GPIO-37/TDO	98	
	49 50	TMS	-	99 100	
	30			100	
* Resistors may b	e altered to	o connect this HSEC pin to the MCU's VREFHI inputs			
** Boot mode pin		, Print			
		of two HSEC pins via switch			
## GPIO can only					
		eader and can be disconnected by desoldering resistors.			
@@ Can be conn	ected to PC	terminal via switch			
1					