Date:		Mapping to DIM100 pinout with Adapter card				HSE(Pinout
30-Jul-2019	F280025					2.1
			1 20002			
Exp Kit lbl	DIM pin				DIM pin 51	Exp Kit lbl
	2				52	
	3	12V		12V	53	
	4	-		-	54	
	5	-		-	55	
	6				56	
	_					
ВО		A11/C0/CMP1/TESTANA0		A0/C15/ADCINCAL/CMP3P		A0
B1	8 9	A12/C1/TESTANA1/CMP2/CMP4P		A1/CMP1P	58 59	A1
DI	10	A12/CI/TESTANAI/CIVIF2/CIVIF4F		A1/CIVIF1F	60	AI
B2	11	C4/A14/CMP3P		A2/C9/CMP1P/CMP3		A2
	12			, 25, 2 21 / 61111 5	62	
В3	13	C6/CMP3P		A3/C5/VDAC/CMP3		A3
	14				64	
B4	15	A15/C7/CMP1		A4/C14/CMP2P/CMP4	65	A4
	16	-		All VREFHIs *	66	
B5	17	C8/A9/CMP4P/CMP2P		A5/C2/CMP3		A5
58	18	-		<u> </u>	68	59
B6	19	A10/C10/CMP2		A6/CMP1P		A6
60	20	GPIO-35/TDI		A7/C2/CADA	70	61
B7 62	21	A8/C11/CMP2P/CMP4P #		A7/C3/CMP4	71 72	A7 63
62	22	-		-	72	03
00	23	GPIO-00		GPIO-01	73	01
02	24	GPIO-02		GPIO-03		03
04	25	GPIO-04		GPIO-05		05
06	26	GPIO-06		GPIO-07	76	07
	27			5V	77	
08	28	GPIO-08		GPIO-09	78	09
10	29	GPIO-10		GPIO-11 @	79	11
48	30	GPIO-12 @		GPIO-13 @	80	49
84		GPIO-14		GPIO-15	81	85
86	32	GPIO-42	_	5V	82	
12	33	GPIO-39	_		83	13
15 24	34 35	- GPIO-24 ** #		GPIO-25 # @	84 85	14 25
24	36	GPIO-26 # @		GPIO-25 # @ GPIO-27 # @	86	27
20	37			51 10-27 # @	87	
16	38	GPIO-16		GPIO-17	88	17
18	39	GPIO-18/X2 ##		GPIO-19/X1 ##		19
20	40	GPIO-40		GPIO-41	90	21
22	41	GPIO-22		GPIO-23		23
87	42	GPIO-37/TDO		5V	92	
28	43	GPIO-28 @@		GPIO-29 @@		29
30	44	GPIO-30		GPIO-31		31
32		GPIO-32**		GPIO-33		33
34	46 47	GPIO-34		GPIO-35/TDI	96 97	
	48	TCK		GPIO-33/TDI		
		TMS		Gi 10-37/100	99	
	50				100	
		o connect this HSEC pin to the MCU's VREFHI inputs				
** Boot mode pin						
		of two HSEC pins via switch				
## GPIO can only						
		eader and can be disconnected by desoldering resisto	ors.			
(@(@ Can be conn	ected to PC	terminal via switch				