

दक्षिण मध्य रेलवे से आरंभ होने वाली कोचिंग गाड़ियों में ब्रेक-यान उपस्कर (सनि 4.19.4)

➤ **ब्रेक-यान उपस्कर लोड करना :**

- ब्रेक यान उपस्कर को प्राथमिक रखरखाव स्टेशन के प्लेटफॉर्म पर दोनों एसएलआर (अर्थात्, आगे और पीछे के एसएलआर) में लोड किया जाएगा, या कुछ गाड़ियों में तीन एसएलआर (अर्थात्, आगे, बीच और पीछे के एसएलआर) को अलमारी/कैबिनेट के अंदर लोड किया जाएगा, जिसे वन-टाइम लॉक (ओटीएल) के साथ लॉक किया जाएगा और सेइंजी/कइंजी-सवारी व मालडिब्बा और उप सेइंजी द्वारा संयुक्त रूप से सील किया जाएगा.
- ईएमयू/एमईएमयू के मामले में, ब्रेक यान उपस्कर मोटर कोच के लो टेंशन कम्पार्टमेंट में लोड किए जाएँगे. डीईएमयू/डीएचएमयू के मामले में, ब्रेक यान उपस्कर लोड करने के लिए ड्राइविंग ट्रेलर कैब में उपलब्ध स्थान का उपयोग किया जाएगा.
- सभी दो/तीन एसएलआर की जांच गंतव्य स्टेशन के सेइंजी/कइंजी- सवारी व मालडिब्बा और उप स्टेशन अधीक्षक द्वारा संयुक्त रूप से प्लेटफॉर्म पर वापसी दिशा में की जाएगी.
- मद के सामने उल्लिखित निम्नलिखित प्रभारी, एसएलआर में उपलब्ध समर्पित कैबिनेट में कार्यशील स्थिति में बीवी उपस्करों की प्रारंभिक लोडिंग की व्यवस्था करेंगे. उप स्टेशन अधीक्षक को प्लेटफॉर्म पर दो/तीन एसएलआर में लोडिंग का समन्वय करना होगा.

	मदें	नग	द्वारा रखरखाव / आपूर्ति
ए	पोर्टेबल नियंत्रण टेलीफोन 2/4 तार प्रकार आवश्यकतानुसार	1सेट	सेइंजी/कइंजी-टेली
बी	पोर्टेबल गाड़ी प्रकाश उपस्कर	1 सेट	सेइंजी/कइंजी-टीएल
सी	अग्निशामक यंत्र (डीसीपी प्रकार)	2 नग	सेइंजी/कइंजी-सवमाडि
डी	लकड़ी के वेडज्स / स्किड्स	2 नग	सेइंजी/कइंजी- सवमाडि
ई	अच्छी स्थिति में स्ट्रेचर	1 नग	उप स्टेशन अधीक्षक
एफ	उपयुक्त हुक के साथ रस्सी की सीढ़ियाँ	2 नग (न्यूनतम)	कइंजी (सवमा)

- बी.वी. उपस्करों की लोडिंग पूरी हो जाने के बाद, सेइंजी./कइंजी.-सवमाडि. ओटीएल उपलब्ध करायेगा तथा उसे रेक्सिन पाउच से ढकेगा, आवश्यक टेप/कॉर्ड से बांधेगा तथा सील कर देगा.
- गाड़ी के आरंभिक स्टेशन के सेइंजी./कइंजी.-सवमाडि. को गार्ड द्वारा आवश्यकतानुसार उपयोग के लिए कैबिनेट में एक अतिरिक्त ओटीएल को अनलॉक स्थिति में रखना होगा.
- आरंभिक लोडिंग और सीलिंग के बाद, प्लेटफॉर्म पर सेइंजी./कइंजी.-सवमाडि. द्वारा प्रत्येक ट्रिप पर आने वाले और जाने वाले रैकों की निरंतर निगरानी की जाएगी और एसएलआर में उपलब्ध बीवी उपस्करों का रिकॉर्ड रखा जाएगा.

➤ **एसएलआर के भीतर विवरणों की पेंटिंग और सुरक्षा:**

- जिस कैबिनेट में बी.वी. उपस्कर लोड किए गए हैं, उस पर पेंटिंग की जाएगी/स्टिकर लगाया जाएगा, जिसमें एसएलआर संख्या, सीरियल नंबर के साथ बी.वी. उपस्कर का विवरण और परीक्षण की निर्धारित तारीख अंकित होगी
- ओटीएल के उपयोग के संबंध में गार्डों को दिए जाने वाले अनुदेशों को भी चित्रित किया जाना चाहिए या स्टिकर के रूप में चिपकाया जाना चाहिए.
- बी.वी. उपस्कर युक्त कैबिनेट को ओटीएल के उपयोग के साथ लॉकिंग की सुविधा के लिए क्लैम्पिंग/लॉकिंग व्यवस्था प्रदान की जाएगी.
- बी.वी. उपस्करों की उपलब्धता देखने के लिए वायर मेश/वेल्ड मेश भी उपलब्ध कराई जानी चाहिए ताकि बी.वी. उपकरण सौंपने/लेने के समय कैबिनेट का दरवाज़ा खोले बिना ही सुविधा हो. कैबिनेट के अंदर आवश्यक प्रकाश व्यवस्था और कैबिनेट के बाहर नियंत्रण स्विच उपलब्ध कराए जाने चाहिए. नए आईसीएफ एसएलआर में कैबिनेट के लिए मजबूत कांच की खिड़कियाँ लगाई गई हैं.

➤ **बी.वी. उपस्कर की अधिप्राप्ति.**

संबंधित विभागों के सेइंजी/कइंजी तथा रैक के प्राथमिक रखरखाव स्टेशन पर उप स्टेशन अधीक्षक के पास आवश्यक संख्या में बीवी उपस्कर होने चाहिए तथा उस स्टेशन पर प्राथमिक रूप से अनुरक्षित सभी रैकों के सभी एसएलआर में प्रारंभिक प्रावधान के लिए 10% अतिरिक्त होना चाहिए.

➤ **बी.वी. उपस्कर का कार्यभार सौंपना एवं लेना:**

- आरंभिक स्टेशन के उप स्टेशन अधीक्षक/टीएनसी, इस प्रयोजन के लिए विशेष रूप से बनाए गए रजिस्टर में बीवी उपस्कर/सील की अक्षुण्णता और उपलब्धता दर्ज करेंगे. उन्हें वाहन मार्गदर्शन (वीजी) के अलावा रजिस्टर में गार्ड की पावती भी प्राप्त करनी होगी..

- (ii) आने वाले और जाने वाले दोनों गार्डों को वीजी और रफ जर्नल बुक में प्रविष्टियां करनी होंगी, तथा सील और ओटीएल की अक्षुण्णता के बारे में स्वीकार करना होगा।

➤ **ओटीएल एवं बीवी उपस्करों का प्रतिस्थापन:**

- (i) सील गायब होने या ओटीएल टूटने होने या बीवी उपस्कर गायब होने के मामले में, गाड़ी का गार्ड स्टेशन के स्टेशन मास्टर को एक संदेश देगा, जिसकी एक प्रति गाड़ी के आरंभिक स्टेशन के स्टेशन मास्टर को भी भेजी जाएगी, जिसमें गाड़ी नंबर, एसएलआर नंबर, गायब बीवी उपस्कर क्रम संख्या, तारीख, स्थान आदि का उल्लेख होगा।
- (ii) इसके बाद, आरंभिक स्टेशन का स्टेशन मास्टर संबंधित सेइंजी/कइंजी को सामान/सामानों को वापस लेने के लिए सलाह देगा।
- (iii) संबंधित सेइंजी/कइंजी को परीक्षण के बाद बीवी उपस्कर को प्रतिस्थापित/पुनर्प्राप्त करना चाहिए।

➤ **बी.वी. उपस्कर के प्रतिस्थापन/परीक्षण की निर्धारित तारीख:**

- (i) अग्निशामक यंत्र: इन्हें वर्ष में एक बार बदला जाएगा। प्रत्येक अग्निशामक यंत्र पर निर्धारित तारीख अंकित की जाएगी ताकि आसानी से पहचाना जा सके और आवश्यकतानुसार बदला जा सके।
- (ii) पोर्टेबल टेलीफोन: 2/4 तार वाले टेलीफोन का परीक्षण छह महीने में एक बार सेइंजी./कइंजी टेली द्वारा किया जाएगा। निर्धारित तारीख दर्शाने वाला स्टीकर चिपकाया जाना चाहिए (उदाहरणार्थ, निर्धारित तारीख - 6 नवम्बर)।
- (iii) गार्डों को साइन ऑन करते समय पीटी सेट जारी करने तथा साइन ऑफ करते समय वापस लेने की प्रथा जारी रहेगी।
- (iv) पोर्टेबल गाड़ी लाइटनिंग उपस्कर: प्रत्येक बॉक्स के कवर पर और ईएल बॉक्स के अंदर आसानी से पहचान के लिए क्रमिक संख्या अंकित होनी चाहिए। ईएल बॉक्स की सामग्री का परीक्षण सेइंजी./कइंजी.-टीएल द्वारा छह महीने में एक बार किया जाएगा और अगली नियत तारीख स्टिकर पर लिखी जानी चाहिए।

➤ **यातायात के कारण संरचना में किसी भी एसएलआर को मार्ग में अलग नहीं किया जाएगा।**

➤ **गार्ड के कर्तव्य:**

- (i) गाड़ी के गार्ड को गाड़ी रवाना होने से पहले यह सुनिश्चित करना होगा कि बी.वी. उपस्कर सही ढंग से उपलब्ध है, ओ.टी.एल. लॉक स्थिति में है तथा सील लगी हुई है। जब सील टूटी हो, लेकिन ओटीएल बरकरार हो, तो गार्ड, रेक्सीन कवर और सील उपलब्ध कराने के लिए आरंभिक स्टेशन के स्टेशन मास्टर को सूचित करेगा।
- (ii) दुर्घटना/आपात स्थिति के दौरान उपयोग के लिए गाड़ी के गार्ड द्वारा बी.वी. उपस्कर युक्त कैबिनेट सील को तोड़ा जाएगा।
- (iii) उपस्कर के उपयोग के बाद, गार्ड, आरंभिक स्टेशन के सेइंजी/कइंजी - सवमाडि और उप स्टेशन अधीक्षक को एक संदेश देगा जिसमें उपयोग की तारीख, समय और स्थान का उल्लेख होगा, ताकि आवश्यकता पड़ने पर उपस्कर को पुनः प्राप्त करने में सुविधा हो।
- (iv) वह रास्ते में इसकी अक्षुण्णता की भी जांच करेगा।
- (v) जब भी आपात स्थिति में कैबिनेट/अलमारी खोली जाती है, तो वह लिखित संदेश के माध्यम से उप-स्टेशन अधीक्षक को इसकी सूचना देगा। वह वीजी और रफ जर्नल बुक पर यह टिप्पणी करेगा कि उपस्कर कहाँ से निकाला गया था; वह उपस्कर को अतिरिक्त ओटीएल के साथ लॉक कर देगा।
- (vi) वह रेक्सीन पाउच और सील उपलब्ध कराने के लिए आरंभिक स्टेशन के उप स्टेशन अधीक्षक को भी संदेश देगा।
- (vii) वह गंतव्य स्टेशन पर वीजी/रफ जर्नल बुक में ओटीएल और सील की अक्षुण्णता के बारे में सेइंजी/कइंजी-सवमाडि के उप-स्टेशन अधीक्षक से पावती प्राप्त करेगा।

मेमू/ईएमयू/डेमू/डीएचएमयू गाड़ियों में ब्रेक यान उपस्कर :

➤ **ब्रेक यान उपस्कर Brake-van equipment :**

निम्नलिखित ब्रेक यान उपस्कर कार्यशील अवस्था में मेमू/ईएमयू शेड द्वारा मेमू/ईएमयू के प्रत्येक मोटर कोच के निम्न दाब डिब्बे में और प्राथमिक रखरखाव के लिए उत्तरदायी डीएसएल शेड द्वारा डेमू/डीएचएमयू के प्रत्येक ड्राइविंग पावर यान में उपलब्ध स्थान में लोड किए जाएंगे। शेड के प्रभारी यह सुनिश्चित करने के लिए उत्तरदायी हैं कि निर्धारित उपस्कर कार्यशील अवस्था में लोड किए जाएँ।

1	स्ट्रेचर — एक
2	अग्निशामक यंत्र — दो
3	वेडज्स — दो

अस्वीकरण:

इस फ़ाईलीफ में इस विषय पर उल्लिखित उपर्युक्त सामग्री विभिन्न मैनुअल, रेलवे बोर्ड के पत्रों और अन्य पत्रों का अंश है। इसे मूल पत्र और समय-समय पर जारी किए गए अन्य मैनुअल/पत्रों के साथ पढ़ा जाना चाहिए तथा यह किसी भी तरह से उनका अधिकरण नहीं कर सकती है।

संरक्षा संगठन

दक्षिण मध्य रेलवे

SOUTH CENTRAL RAILWAY

Safety.387/Fly Leaf/12/2025

Fly Leaf No. 12 / 2025

Attention..... All Concerned

BRAKE-VAN EQUIPMENT IN COACHING TRAINS ORIGINATING IN SOUTH CENTRAL RAILWAY. (SR 4.19.4)

➤ **Loading of Brake-van Equipment:**

- (i) The BV Equipment would be loaded at the platform of the primary maintenance station in both SLRs (i.e., Front and Rear SLR), or in some trains three SLRs (i.e., Front, Centre and Rear SLRs) inside a cupboard / cabinet which shall be locked with One-Time Lock (OTL) and sealed jointly by the SE/JE-C&W and Dy. SS.
- (ii) In case of EMU / MEMU, the brake van equipment shall be loaded in Low Tension Compartment in the Motor Coach. In case of DEMU / DHMU, the space available in Driving Trailer Cab shall be utilized for loading the brake van equipment.
- (iii) All two / three SLRs shall be checked in the return direction at the platform jointly by the SE / JE - C&W and Dy. SS of destination station.
- (iv) The following in-charges mentioned against item shall arrange for initial loading of BV Equipment in working condition in the dedicated cabinet provided in the SLR. Dy. SS should co-ordinate loading in two / three SLRs on the platform.

	Items	No.	Maintained / Supplied by
a	PortableControlTelephone2/4wire type as required.	1 set	SE/JE-Tele
b	Portable Train lighting equipment	1 set	SE/JE-TL
c	Fire extinguisher (DCP type)	2 Nos.	SE/JE-C&W
d	Wooden Wedges / Skids	2 Nos.	SE/JE-C&W
e	Stretcher in good condition	1 No.	Dy. SS
f	Rope ladders with suitable hooks (AS-18)	2 No. (Minimum)	JE(C&W)

- (v) After full complement of BV equipment is loaded, SE / JE - C&W shall provide OTL and cover it with Rexene pouch, tie with necessary tape /cord and seal the same.
- (vi) The SE / JE - C&W of train-originating station shall also keep one spare OTL in unlocked condition in the cabinet for use by the Guard enroute, whenever required.
- (vii) After initial loading and sealing is done, SLRs, shall be continuously monitored on each and every trip both outgoing and incoming rakes by SE / JE - C&W at the Platform and maintain record of the BV Equipment available in the SLRs.

➤ **Painting of details inside SLRs and securing:**

- (i) On the cabinet containing the BV Equipment are loaded, painting / sticker shall be provided, indicating SLR No., details of BV Equipment with serial number and due date of testing.
- (ii) Instructions to Guards on usage of OTL should also be painted or pasted in the form of sticker.

- (iii) Cabinet containing BV Equipment shall be provided with clamping / locking arrangement to facilitate locking with the use of the OTL.
- (iv) Wire mesh / weld mesh shall also to be provided to see the availability of BV Equipment, to facilitate at the time of handing over / taking over the BV Equipment without having to open the cabinet door. Necessary lighting arrangements inside the cabinet with control switch outside the cabinet shall be provided. New ICF SLRs are turned out with toughened glass windows for the cabinet.

➤ **Procurement of BV Equipment.**

The SEs / JEs of concerned Departments and Dy. SS at the primary maintenance station of the rake shall be in possession of the required number of BV Equipment + 10% extra for initial provision in all SLRs of all the rakes primarily maintained at that station.

➤ **Handing over & Taking over charge of BV Equipment:**

- (i) Dy. SS / TNC of the originating station shall record the intactness and the availability of the BV Equipment / seal in the register specially maintained for this purpose. They shall obtain acknowledgement of the Guard in the register apart from Vehicle Guidance (VG).
- (ii) Both the incoming and outgoing Guards shall make entries in the VG and the Rough Journal Book, and acknowledge about the intactness of seal and OTL.

➤ **Replacement of OTL & BV Equipment:**

- (i) In case of seal missing or OTL broken or BV Equipment missing, the Guard of the train shall give a message to the Station Master of the station with a copy to the Station Master of the train originating station indicating the train number, SLR number, missing BV Equipment serial numbers, along with date, location etc.
- (ii) The Station Master of the originating station in turn shall advise the concerned SEs / JEs for recouping the item/s.
- (iii) Concerning SE / JE should replace / recoup BV Equipment after testing.

➤ **Due date for replacement / testing of BV Equipment:**

- (i) Fire-Extinguishers: Replacement shall be done once in a year. Due date shall be stencilled on each fire-extinguisher for easy identification and replacement as and when required.
- (ii) Portable Telephone: The 2/4 wire telephone will be tested once in six months by SE/JE-Tele. The sticker indicating the due date should be pasted (eg., Due – Nov.06).
- (iii) The practice of issuing PT sets to Guards at the time of signing ON and collecting back while signing OFF will continue.
- (iv) Portable Train Lightning Equipment: Each box be serially numbered on the cover and inside the EL Box for easy identification. Contents of the EL Box shall be tested once in six months by the SE/JE-TL and the next due date should be written on the sticker.

➤ **No SLR in the formation shall be detached en-route on Traffic account.**

➤ **Duties of Guard:**

- (i) The Guard of the train shall ensure before departure of the train that the BV Equipment is correctly available, OTL is in locked condition and the seal is put on. When the seal is broken, but OTL is intact, the Guard shall advise the Station Master of the originating Station for providing rexine cover and seal.
- (ii) The cabinet seal containing the BV Equipment shall be broken by the Guard of the train for use during accidents / emergencies.
- (iii) After usage of the equipment, the Guard shall give a message to the SE / JE – C&W and the Dy. SS of the originating station indicating date, time and place of usage so as to facilitate recouplement of equipment if required.
- (iv) He shall also check for its intactness en-route.
- (v) Whenever, cabinet / cupboard is opened in emergency, he shall intimate the same to the Dy. SS under a written message. He shall pass a remark on the VG and Rough Journal Book as to where the equipment was taken out; he shall lock the equipment with the spare OTL.
- (vi) He shall also give a message to the Dy. SS of the originating station for providing the rexene pouch and seal.
- (vii) He shall obtain the acknowledgement of the Dy. SS of SE / JE-C&W in the VG / Rough Journal Book at the destination station about the intactness of OTL and seal.

Brake van equipment in MEMU / EMU / DEMU / DHMU trains :

➤ **Brake van equipment :**

The following brake van equipment in working condition shall be loaded in low tension compartment in each motor coach of MEMU / EMU by the MEMU / EMU shed and, in the space, available in each Driving Power car of DEMU / DHMU by DSL sheds responsible for primary maintenance. In-charges of the sheds are responsible for ensuring the loading of the stipulated equipment in working condition.

1	Stretcher – one
2	Fire extinguishers – two
3	Wedges – two

Disclaimer :

The above content mentioned on the subject in this FLY Leaf is an extract from different manuals, RB's letters and other letters. The same to be read in conjunction with the original letter & other manuals / letters issued from time to time and in no way can supersede them.

SAFETY ORGANISATION

SOUTH CENTRAL RAILWAY