KOM3712 Control Systems DesignSpring 2020

Design via State Space Methods – 2 of 4: *Observers*

Dr. Şeref Naci Engin

Yildiz Technical University

Faculty of Electrical & Electronics

Control and Automation Engineering Dept.

Davutpaşa Campus

Esenler, Istanbul, Turkey 34320

e-mail: nengin@yildiz.edu.tr

https://avesis.yildiz.edu.tr/nengin/

T: +90 212 383 59 43

F: +90 212 383 59 59

Office: A-203

Textbooks followed mostly for the Design in the State Space are,

- Modern Control Engineering (5th ed.), Katsuhiko Ogata, Chap. 9
- Control Systems Engineering (7th ed.), Norman S. Nise, Chap. 12

Observers: Introduction


- Requirements for state feedback controller design:
 - ✓ Controllability
 - ✓ Entire state vector availability
- Unavailable state variables should be estimable, otherwise, state feedback control implementation is impossible
- Challenges to state variable sensing/measurement:
 - Sensor accuracy: may deteriorate over time
 - Measurement cost: may be too high for very large systems
 - Availability: some states may be unmeasurable


Introduction, cont'd...

- Controller design relies upon access to the state variables for feedback through adjustable gains (remember: u = -Kx).
- This access can be provided by hardware. For example, gyros can measure position and velocity on a space vehicle or UAV.
- Sometimes it is impractical to use this hardware for reasons of cost, accuracy, or availability.
- For example, in powered flight of space vehicles, inertial measuring units (IMU) can be used to calculate the acceleration.
- However, their alignment deteriorates with time; thus, other means of measuring acceleration may be desirable.
- In other applications, some of the state variables may not be available at all, or it is too costly to measure them or send them to the controller.
- If the state variables are not available because of system configuration or cost, it is possible to estimate the states.
- Estimated states, rather than actual states, are then fed to the controller.

Introduction, cont.'s...

- Observer/estimator: a subsystem for estimating the unmeasurable state variables
- The observer model is normally based on the plant model





Observer Canonical Form (OCF) for Observers!

- Observer design (like state feedback controller design) is a pole-placement problem
- Observer design is simplified if system is represented in Observer Canonical Form (OCF):

$$\frac{Y(s)}{U(s)} = \frac{b_0 s^n + b_1 s^{n-1} + b_2 s^{n-2} + \dots + b_{n-1} s + b_n}{s^n + a_1 s^{n-1} + a_2 s^{n-2} + \dots + a_{n-1} s + a_n}$$

$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \\ \vdots \\ \vdots \\ \dot{x}_n \end{bmatrix} = \begin{bmatrix} 0 & 0 & \cdots & 0 & -a_n \\ 1 & 0 & \cdots & 0 & -a_{n-1} \\ \vdots & \vdots & \ddots & \ddots & \vdots \\ \vdots & \ddots & \ddots & \ddots & \vdots \\ 0 & 0 & \cdots & 1 & -a_1 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \\ \vdots \\ x_n \end{bmatrix} + \begin{bmatrix} b_n - a_n b_0 \\ b_{n-1} - a_{n-1} b_0 \\ \vdots \\ b_1 - a_1 b_0 \end{bmatrix} u$$

$$y = \begin{bmatrix} 0 & 0 & \cdots & 0 & 1 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \\ \vdots \\ x_{n-1} \\ x_n \end{bmatrix} + b_0 u$$
An alternative OCF is placing the negative coefficients of a 's in reverse order with respect to the above OCF in the first column.

order with respect to the above OCF in the first column.

Observer – more on its structure

- Observer is designed to have much faster (say, 5 times or more) transient response than that of controlled loop
- This is achieved by placing observer poles farther to the left of the s-plane than the control loop's closedloop poles
- Observer design is a trade-off between speed of response and need for noise rejection
- It may be necessary to design several observer gain matrices, then evaluate the system performance for each of them

Observer model


Plant model:

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}u \qquad (1)$$
$$y = \mathbf{C}\mathbf{x}$$

Closed-loop observer model:

$$\dot{\hat{\mathbf{x}}} = \mathbf{A}\hat{\mathbf{x}} + \mathbf{B}u + \mathbf{L}(y - \hat{y}) \quad (4)$$

$$\hat{\mathbf{v}} = \mathbf{C}\hat{\mathbf{x}}$$



B

State vector error estimation model (subtract (4) from (1)):

$$(\dot{\mathbf{x}} - \dot{\hat{\mathbf{x}}}) = \mathbf{A}(\mathbf{x} - \hat{\mathbf{x}}) - \mathbf{L}(y - \hat{y})$$
 (5a)

$$y - \hat{y} = \mathbf{C}(\mathbf{x} - \hat{\mathbf{x}}) \tag{5b}$$

Substitute (5b) into (5a):

$$(\dot{\mathbf{x}} - \dot{\hat{\mathbf{x}}}) = \mathbf{A}(\mathbf{x} - \hat{\mathbf{x}}) - \mathbf{LC}(\mathbf{x} - \hat{\mathbf{x}})$$
 \rightarrow $(\dot{\mathbf{x}} - \dot{\hat{\mathbf{x}}}) = (\mathbf{A} - \mathbf{LC})(\mathbf{x} - \hat{\mathbf{x}})$

A

L

Let $\mathbf{x} - \hat{\mathbf{x}} = \mathbf{e}_x$

$$\dot{\boldsymbol{e}}_{x} = (\mathbf{A} - \mathbf{LC})\boldsymbol{e}_{x}$$

$$y - \hat{y} = \mathbf{C}\boldsymbol{e}_{x}$$
(6)

In fact, the estimated model has the same dynamics ((4)):

Estimated

output,

Closed-loop observer

Plant

output,

Estimated error

output

$$\dot{\hat{\mathbf{x}}} = (\mathbf{A} - \mathbf{LC})\hat{\mathbf{x}} + \mathbf{B}u + \mathbf{L}y$$

Observer model, cont.'s

$$\dot{e}_x = (\mathbf{A} - \mathbf{LC})e_x$$
 (6) \rightarrow State estimation error dynamics

- If eigenvalues of (6) are all stable, estimated state vector converges to actual state vector
- Moreover, the dynamics of (6) can be shaped by means of the proper design of L
- Eigenvalues of *error dynamical system* are determined from:

$$\det[s\mathbf{I} - (\mathbf{A} - \mathbf{LC})] = 0 \tag{7}$$

Observer design problem:

- 1. Choose the observer eigenvalues to ensure stable and fast error dynamic response
- 2. Determine the value of L accordingly

Observer model - caution:

$$\dot{e}_{x} = (\mathbf{A} - \mathbf{LC})e_{x}$$
 (6) \rightarrow State estimation error dynamics

Observer design problem – caution!

- 1. The system model was assumed to be exact. Hence the matrices **A**, **B** and **C**, representing the physical system are used in the derivation of (6). This cannot be true.
- 2. Also, disturbances on the physical system have been ignored. A more accurate state space model of the plant is,

$$\dot{\mathbf{x}}(t) = \mathbf{A}\mathbf{x}(t) + \mathbf{B}u(t) + \mathbf{B}_w w(t)$$

$$y(t) = \mathbf{C}\mathbf{x}(t) + v(t)$$
(7)

where, w(t) is a vector of the disturbance inputs and v(t) represents the sensor errors. If this model is considered the error dynamics (6) become,

$$\dot{\boldsymbol{e}}_{x} = (\mathbf{A} - \mathbf{LC})\boldsymbol{e}_{x} + \mathbf{B}_{w}\boldsymbol{w}(t) - \mathbf{L}\boldsymbol{v}(t)$$

We see that errors will not die out over time, even the modeling inaccuracies are ignored.

Observer design: System in OCF

(1)
$$\mathbf{A} - \mathbf{LC} = \begin{bmatrix} -a_{n-1} & 1 & 0 & 0 & \cdots & 0 \\ -a_{n-2} & 0 & 1 & 0 & \cdots & 0 \\ \vdots & \vdots & \vdots & \vdots & \vdots & \vdots \\ -a_1 & 0 & 0 & 0 & \cdots & 1 \\ -a_0 & 0 & 0 & 0 & \cdots & 0 \end{bmatrix} - \begin{bmatrix} l_1 \\ l_2 \\ \vdots \\ l_{n-1} \\ l_n \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & 0 & \cdots & 0 \end{bmatrix}$$

$$= \begin{bmatrix} -(a_{n-1} + l_1) & 1 & 0 & 0 & \cdots & 0 \\ -(a_{n-2} + l_2) & 0 & 1 & 0 & \cdots & 0 \\ \vdots & \vdots & \vdots & \vdots & \vdots & \vdots \\ -(a_1 + l_{n-1}) & 0 & 0 & 0 & \cdots & 1 \\ -(a_0 + l_n) & 0 & 0 & 0 & \cdots & 0 \end{bmatrix}$$

(2) Closed-loop observer characteristic equation:

$$\det[s\mathbf{I} - (\mathbf{A} - \mathbf{LC})] = s^n + (a_{n-1} + l_1)s^{n-1} + (a_{n-2} + l_2)s^{n-2} + \cdots + (a_1 + l_{n-1})s + (a_0 + l_n) = 0$$

(3) Desired closed-loop characteristic equation:

$$\Delta_{CL-\text{desired}} = s^n + d_{n-1}s^{n-1} + d_{n-2}s^{n-2} + \dots + d_1s + d_0 = 0$$

(3) Observer Gain Vector L is found by matching the coefficients of (2) and (3),

$$l_i = d_{n-i} - a_{n-i}$$
 $i = 1, 2, ..., n$

Observer design example: OCF

Observer Design for Observer Canonical Form

PROBLEM: Design an observer for the plant

$$G(s) = \frac{(s+4)}{(s+1)(s+2)(s+5)} = \frac{s+4}{s^3 + 8s^2 + 17s + 10}$$

which is represented in observer canonical form. The observer will respond 10 times faster than the controlled loop designed in Example 12.4.

(1) System in OCF:

$$A = \begin{bmatrix} 0 & 0 & -10 \\ 1 & 0 & -17 \\ 0 & 1 & -8 \end{bmatrix}, B = \begin{bmatrix} 4 \\ 1 \\ 0 \end{bmatrix}, C = \begin{bmatrix} 0 & 0 & 1 \end{bmatrix}, D = 0$$

$$A - LC = \begin{bmatrix} 0 & 0 & -10 \\ 1 & 0 & -17 \\ 0 & 1 & -8 \end{bmatrix} - \begin{bmatrix} l_1 \\ l_2 \\ l_3 \end{bmatrix} \begin{bmatrix} 0 & 0 & 1 \end{bmatrix}$$

$$= \begin{bmatrix} 0 & 0 & -10 \\ 1 & 0 & -17 \\ 0 & 1 & -8 \end{bmatrix} - \begin{bmatrix} 0 & 0 & l_1 \\ 0 & 0 & l_2 \\ 0 & 0 & l_3 \end{bmatrix} = \begin{bmatrix} 0 & 0 & -(10 + l_1) \\ 1 & 0 & -(17 + l_2) \\ 0 & 1 & -(8 + l_3) \end{bmatrix}$$

(2) Closed-loop observer characteristic equation:

$$\Delta_{CL} = s^3 + (8 + l_3)s^2 + (17 + l_2)s + 10 + l_1 = 0 \dots (8)$$

Observer design example: OCF, cont.'s...

Observer Design for Observer Canonical Form

PROBLEM: Design an observer for the plant

$$G(s) = \frac{(s+4)}{(s+1)(s+2)(s+5)} = \frac{s+4}{s^3 + 8s^2 + 17s + 10}$$

which is represented in observer canonical form. The observer will respond 10 times faster than the controlled loop designed in Example 12.4.

Design a state-variable feedback controller to yield a 20.8% overshoot and a settling time of 4 seconds for the plant...

(3) Desired observer closed-loop characteristic equation:

Observer should respond 10 times faster than controlled loop

Closed-loop control system dominant poles:

$$p_{1,2}$$
 sys = $-1 \pm j2$

Observer dominant poles:

$$p_{1,2_obs} = -10 \pm j20$$

Third observer pole chosen to be <u>10 times</u> the <u>real component</u> of the <u>dominant</u> closed-loop <u>observer poles</u>

$$p_{3 \ obs} = -100$$

$$\Delta_{CL}$$
 des = $s^3 + 120s^2 + 2500s + 50000$...(9)

Observer design example: OCF, cont.'s...

Observer Design for Observer Canonical Form

PROBLEM: Design an observer for the plant

$$G(s) = \frac{(s+4)}{(s+1)(s+2)(s+5)} = \frac{s+4}{s^3 + 8s^2 + 17s + 10}$$

which is represented in observer canonical form. The observer will respond 10 times faster than the controlled loop designed in Example 12.4.

$$\Delta_{CL} = s^3 + (8 + l_3)s^2 + (17 + l_2)s + 10 + l_1 = 0 \dots (8)$$

$$\Delta_{CL_des} = s^3 + 120s^2 + 2500s + 50000 \dots (9)$$

(4) Determine L:

$$L = \begin{bmatrix} l_1 \\ l_2 \\ l_3 \end{bmatrix} = \begin{bmatrix} 49990 \\ 2483 \\ 112 \end{bmatrix}$$

Observability

- Observability is a property of a dynamical system that determines whether it is <u>possible to estimate the</u> <u>system's state vector</u> or not
- The observer estimates the state vector based on the measured output and the control input
- Thus a state variable can be estimated only if it directly affects the output
- When a system is in <u>Diagonal Form</u>, it is easy to see the direct effect of each state variable on the output

Observability, cont.'s...

- <u>Definition</u>: a system is **observable** if the initial state, $x(t_o)$, can always be determined, given the input u(t), and the output y(t), measured over a finite interval $[t_0, t_1]$.
- Otherwise, the system is not observable.
- Plant model: $\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}u$ $y = \mathbf{C}\mathbf{x}$
- Observability matrix:

$$\bullet \quad \mathbf{O} = \begin{bmatrix} \mathbf{C} \\ \mathbf{C}\mathbf{A} \\ \mathbf{C}\mathbf{A}^2 \\ \vdots \\ \mathbf{C}\mathbf{A}^{\mathbf{n}-1} \end{bmatrix}$$

System is observable only if the observability matrix is of full rank

Observer design: system not in OCF

- For a system not in Observer Canonical Form, handcomputation of the observer gain matrix tends to be cumbersome and tedious (for higher-order systems)
- Two design methods for systems not in OCF
 - 1. Transformation of system to **OCF**
 - 2. Direct coefficient matching of closed-loop characteristic equations

Observer design: system not in **OCF**Transformation to OCF (*if possible*)

System not in OCF:

$$\dot{\mathbf{z}} = \mathbf{A}\mathbf{z} + \mathbf{B}u$$
; $y = \mathbf{C}\mathbf{z}$

System transformed to OCF

$$\dot{\mathbf{x}} = \mathbf{P}^{-1}\mathbf{A}\mathbf{P}\mathbf{x} + \mathbf{P}^{-1}\mathbf{B}u; \ y = \mathbf{C}\mathbf{P}\mathbf{x}$$

Observability matrices of systems in OCF and non-OCF:

$$P = O_z^{-1}O_x$$
 \rightarrow Transformation matrix

Observer gain matrix:

0,

$$L_z = PL_x$$

Observability Example: Transformation to OCF

PROBLEM: Design an observer for the plant

$$G(s) = \frac{1}{(s+1)(s+2)(s+5)}$$

represented in cascade form. The closed-loop performance of the observer is governed by the characteristic polynomial used in Example 12.5: $s^3 + 120s^2 + 2500s + 50,000$.

System in cascade form:

$$\dot{\mathbf{z}} = \mathbf{A}\mathbf{z} + \mathbf{B}u = \begin{bmatrix} -5 & 1 & 0 \\ 0 & -2 & 1 \\ 0 & 0 & -1 \end{bmatrix} \mathbf{z} + \begin{bmatrix} 0 \\ 0 \\ 1 \end{bmatrix} u$$

$$y = \mathbf{C}\mathbf{z} = \begin{bmatrix} 1 & 0 & 0 \end{bmatrix} \mathbf{z}$$

- (1) Determine O_z
- (2) Determine **OCF** representation of system
- (3) Determine O_x
- (4) Determine L_x
- (5) Determine P
- (6) Determine L_z

Observability Example: Direct coefficient matching

PROBLEM: A time-scaled model for the body's blood glucose level is shown in Eq. (12.105). The output is the deviation in glucose concentration from its mean value in mg/100 ml, and the input is the intravenous glucose injection rate in g/kg/hr (*Milhorn*, 1966).

$$G(s) = \frac{407(s+0.916)}{(s+1.27)(s+2.69)}$$

Design an observer for the phase variables with a transient response described by $\zeta = 0.7$ and $\omega_n = 100$.

- (1) Derive phase-variable state space representation
- (2) Derive det[sI A + LC]
- (3) Derive desired observer closed-loop characteristic equation
- (4) Compare results of (2) and (3) to determine L