

SmartLamp X1 - User Manual

1. Getting Started

Plug the lamp into a standard outlet and hold the power button for 3 seconds. The ring light will blink blue when ready to pair.

2. Pairing

Open the SmartLamp app and tap 'Add Device'. Follow the on-screen steps.

Troubleshooting

Lamp does not turn on: check the outlet and the power cable.

Blinking red light: firmware update failed; hold power for 10 seconds to reset.

Cannot pair: make sure your phone is on a 2.4 GHz Wi-Fi network.

Specifications

Power: 9W LED

Brightness: 800 lumens

Color temperature: 2700K - 6500K

Connectivity: Wi-Fi 2.4 GHz, Bluetooth 5.0