ADDENDUM DriveRight VSS Installation for Ford F-250 Trucks

Product # 8155VF & 8160VF

This addendum describes how to install the DriveRight VSS on Ford F-250 Trucks. Use these instructions in conjunction with the "DriveRight VSS Installation Guide."

Installation

- The F-250 cable should be used only on Ford F-250 trucks.
- Do not install the F-250 cable on the F-150 or other cars and trucks unless it is recommended by Davis Instruments Technical Support.
- Because the F-250 cable was designed specifically for the F-250 model truck, you are not required to set any DIP switches.
- For installation, follow the instructions contained in the DriveRight VSS Installation Guide but ignore any references to the dip switch.

Technical Support

If you are experiencing problems with your DriveRight VSS, first be sure to check all cable connections. If you are unable to solve the problem, please call Davis Technical Support. We'll be glad to help. Most questions can be answered while you're on the phone. You can also email us for support, or visit our website. Sorry, we are unable to accept collect calls.

Note: Please do not return items to the factory for repair without prior authorization.

(510) 732-7814 for Technical Support, Monday – Friday, 7:00 a.m. – 5:30 p.m. Pacific Time.

(510) 670-0589 Fax Customer Service or Tech Support.

www.davisnet.com Download copies of user manuals from the "Support" page. Watch for FAQs and other updates. Subscribe to the e-newsletter.

 ${\bf support@davisnet.com}\ E{\rm -mail}\ your\ technical\ support\ questions.$