


DriveRight®



VSS Installation Guide



Product Number: 8155VSS, 8155VF, 8160VSS, 8160VF

Davis Instruments Part Number: 7395-062 DriveRight^{*} VSS Installation Guide

Rev. D Manual (7/18/01)

© Davis Instruments Corp. 2001. All rights reserved.

This product complies with the essential protection requirements of the EC EMC Directive 89/336/EC.


DriveRight is a registered trademark of Davis Instruments Corp. Velcro is a trademark of Velcro Industries, Manchester NH.

INTRODUCTION

The following instructions explain how to complete a DriveRight VSS (Vehicle Speed Sensor) installation. VSS installation is only possible on the DriveRight Trip 500AL.

COMPONENTS

The DriveRight Trip 500AL (VSS Input) should come with all of the materials shown below. Please make sure you have all listed components before proceeding with the installation.



Tools and Materials Needed

The installation requires some or all of the following tools and materials. Please make sure you have all necessary items before proceeding with the installation.

	Medium Phillips Screwdriver
	Crimping Tool
	Pliers
	Electric Drill with 2.5 mm (7/64") Drill Bit
	Fuse Tap
П	Multimeter

INSTALLATION

The instructions contained in the following sections provide guidelines for installation of the Trip 500AL.

Planning the Installation


The installation is similar to installing a vehicle stereo or vehicle alarm. The DriveRight requires three electrical inputs; +12 V, vehicle ground, and your vehicle's VSS signal. The steps required to install the DriveRight are:

- 1. Determine where to mount the DriveRight display.
- 2. Locate and tap your VSS wire.
- 3. Locate and tap power (+12V from battery) and ground.
- 4. Connect the harness cable to the 3 main tap wires.
- 5. Choose the correct switch settings.
- 6. Mount the DriveRight in the vehicle.
- 7. Connect the DriveRight and go for a test drive.

WARNING: Installing the DriveRight can be hazardous to both the installer and your vehicle's electrical system if not done by an experienced professional. This manual assumes you are aware of the inherent dangers of working in and around a vehicle and have a working understanding of electricity.

Wiring Diagram

The diagram below provides an overall picture of the Trip 500AL VSS installation.



Step 1: Determine Where to Mount the Driveright Display

Knowing where you are going to mount the DriveRight display can help you make wiring decisions later on. For example, if your DriveRight is near the fuse box it will be convenient to get +12V using a fuse tap connector. However, if your DriveRight display is on the other side of the vehicle it may be easier to find a lamp circuit. If the position of the display is not critical, you may wish to move to the next step, and decide where to mount it after you've tapped the three main electrical connections (+12V, Ground, VSS).

NOTE: If you need ideas about where the display might be mounted, look at "Step 6: Mount the DriveRight Display in the Vehicle" on page 9.

Step 2: Locate and tap your VSS wire

The location of the VSS wire for a given make and model of vehicle can be found in the Vehicle Technical Information Guide for Cruise Control book. This book is made available to authorized DriveRight installers.

If you can not obtain a copy of this book, the information is available on the World Wide Web at www.rostra.com. Go to that Web address and click on "Rostra VSS & Tach Information System". Enter the full year and manufacturer of the vehicle. The information will specify a "location number" indicating where the wire can be found, and it will specify the wire color.

NOTE: The web site "www.rostra.com' is owned and operated by Rostra Precision Instruments. Rostra does not provide support for the DriveRight product. If you have trouble finding the VSS wire, please contact Davis Instruments Technical Support at 510-732-7814.


NOTE: Some base model vehicles with manual transmission and no cruise control may not have the VSS module installed. Also, vehicles manufactured before 1992 may not have the VSS signal. Consult the service department at your vehicle dealership if you are having trouble. If your vehicle has a cable driven speedometer, it may be possible for you to purchase a VSS pulse converter that can be installed to provide the VSS pulse. Otherwise, you will be required to install the Trip 500 AL which uses the drive shaft-mounted reed switch sensor.

Use the inline splice to make the connection to the VSS wire as shown below. Select red or blue T-Tap disconnect to fit your VSS wire.

Step 3: Locate and tap power (+12V) and ground


The DriveRight requires a constant +12 volts and has a negligible drain on the vehicle battery (8 ma). You can obtain the +12V from several different places. Generally, you can easily obtain +12V from the fuse box using a fuse tap connector (not supplied) or using the supplied in-line splice connectors to tap into a KNOWN circuit that does not involve safety related equipment (headlights, tail lights, air bag, etc.). Possible candidate wires include those from the cigarette lighter, dome light, glove compartment light, clock, tail gate light, or other convenience functions.

After locating +12V, connect it to the red +12V wire (the one with the fuse holder) using the in-line splice as shown below. Do not install the fuse into the fuse holder until instructed to do so in step 4.



If you are getting +12V from your fuse box, use a fuse tap connector appropriate for your vehicle.

A ground can be made by inserting the spade terminal under the head of a screw threaded into the vehicle chassis and then crimping the spade terminal onto the black ground wire, as shown below. Check that the screw is actually grounded using a multimeter before making the connection.




Step 4: Connect the Harness Cable to the 3 Main Tap Wires

Use the butt splice to connect the VSS in-line circuit input wires to your three main tap wires (+12V, Ground, VSS) by matching the wire colors. Red is used for +12V, black for the ground wire, and white for the VSS wire. Make sure the wiring harness extends to where you can plug the DriveRight display into it. Once the harness cable is connected, install the fuse into the fuse holder in the red (+12V) tap wire.

Step 5: Choose the Correct Dip Switch Settings


Because not all VSS signals are the same, you may need to change the default dip switch setting on the VSS in-line circuit. As a technical note, the switches have following functions. Switch 1 is required if your VSS signal is a square wave which does not go to ground. Switch 2 AC couples the signal in and is used for sine wave VSS signals. Switch 3 improves the sensitivity of the AC coupled signals. Switch 4 turns on the LED test circuit.

NOTE: No dip switch settings are required for the Ford F-250 truck harness cable supplied with DriveRight Trip500AL VSS #8155VF and DriveRight VSS Installation/Mounting Kit #8160VF. The Ford F-250 cable is for use on F-250 trucks only. Do not use the F-250 cable on other cars or trucks unless instructed to do so by Davis Instruments.



Use this flow chart to determine the optimum dip switch setting.


NOTE: You will need to test drive the vehicle and observe the green test LED which is enabled using switch 4. 0 (zero) means the switch is off and 1 means the switch is on. The DriveRIght unit must be plugged in for the LED to indicate.




Step 6: Mount the DriveRight Display in the Vehicle


The following illustrations show possible mounting options for the display.

TOP OF DASHBOARD (Horizontal Surfaces)




FACE OF DASHBOARD (Vertical Surfaces)






Step 7: Connect the DriveRight Display and Go for a Test Drive

Insert the battery into the DriveRight as shown below.



Connect the harness cable to the DriveRight display cable as shown below. It is important to hold the DriveRight display cable as shown below (on the cable, not the sheath) in order to achieve a secure connection. The cables should "click" into place when a secure connection is made.



Once plugged in, the display should "wake-up" into the Current Readings screen. If the display screen remains blank, make sure the battery is in the unit. If it is, try pressing MODE. If the screen remains blank after pressing MODE, press both the MODE and PLUS simultaneously. If it remains blank after that, check both the +12V and ground connections.


Go for a test drive and check that the DriveRight matches the speedometer. If it is not close at all, do not be discouraged since it may be uncalibrated. Consult the calibration section of the Trip 500AL User's Guide for the Trip 500AL for instructions on calibrating the unit. If after calibrating the unit it still does not register speed correctly, move on to the trouble-shooting section.

It is also possible that the unit may alarm unexpectedly during an initial test drive, which can be caused by incorrect calibration along with the alarm being set or just by the login alarm being set. Enter a Driver ID code on the unit to silence the second case. If this does not work, you need to turn the alarm off. Consult the Trip 500AL's User's Guide for specific instructions on entering a Driver ID code or turning an alarm off.

NOTE: Remember to turn off the Test LED once the DriveRight is installed.

APPENDIX 1: TROUBLESHOOTING

If your speed is not regsitering correctly, consult the following check list to help you identify the cause of the problem.



enable the test circuit). The following other methods can be used to see if you have the correct wire. In order of preference:

- ☐ Use a portable oscilloscope and verify the square wave or sine wave VSS signal.

 Watch the signal frequency change with speed.
- ☐ Using a multimeter to measure the frequency of the VSS pulse. Usually, the PPM (pulses per mile) of the VSS signal is known. At 40 km/hr (25 mph) the following frequencies should be:

2000 PPM : 14 hz

4000 PPM: 28 hz 5000 PPM: 35 hz

8000 PPM : 56 hz

- ☐ A voltmeter can be used on square wave signals to verify the 2 DC levels when the vehicle is moved. Note, in most cases the vehicle must be running and driven slowly to detect this change.
- ☐ Check with your local vehicle dealership to make sure the vehicle make and model is equipped with a complete VSS signal.

APPENDIX 2: VSS COMPATIBILITY

The DriveRight can work with many different VSS signals provided the switch settings of the VSS in-line circuit are set correctly. However, if the signal does not meet the specifications below it may not work.

- □ Maximum VSS frequency at 25 mph is 1 khz (144,000 PPM).
- Minimum peak to peak amplitude at 5 mph is 1 volt.
- ☐ Maximum peak to peak amplitude is 25 volts.
- ☐ Input Impedance of VSS inline-circuit is 22k.

Technical Support

If you are experiencing problems with your DriveRight VSS, first be sure to check all cable connections. If you are unable to solve the problem, please call Davis Technical Support. We'll be glad to help. Most questions can be answered while you're on the phone. You can also email us for support, or visit our website. Sorry, we are unable to accept collect calls.

NOTE: Please do not return items to the factory for repair without prior authorization.

(510) 732-7814 for Technical Support, Monday – Friday, 7:00 a.m. – 5:30 p.m. Pacific Time.

(510) 670-0589 Fax Customer Service or Tech Support. www.davisnet.com Download copies of user manuals from the "Support" page. Watch for FAQs and other updates. Subscribe to the e-newsletter.

support@davisnet.com E-mail your technical support questions.



3465 Diablo Avenue, Hayward, CA 94545-2778 510-732-9229 • Fax: 510-732-9188 E-mail: info@davisnet.com • www.davisnet.com