

1 2 3 4 5 6

A

A

B

B


C

C

D

D

1




Sheet: /midi/
File: midi.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 3/9

1 2 3 4 5 6



A

A

B

B


C

C

D

D

FFC connection to backpack eurorack-pmod






Sheet: /pmod_audio/
File: pmod_audio.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 5/9

+/- 12V Eurorack PWR**+5V buck pre-regulator****+3.3V SMPS**

Sheet: /power/
File: power.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 6/9

A

B


C

A

B

C

Digital Video Interface / GPDI



Sheet: /gpdi/
File: gpdi.kicad_sch

Title:

Size: A4 Date
KiCad E.D.A. 9.0.6

Rev:
Id: 6/9

A

A

B


B

C

C

D

D



Sheet: /encoder/
File: encoder.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 7/9

A

A

B


B

C

C

D

D




Sheet: /led_driver/
File: led_driver.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 8/9

Programmable (Device / Host / Dual-role) USB C



Sheet: /usbc/
File: usbc.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6

Rev:
Id: 9/9