

4.3.

add x5, x18, x10

Mo	op	fn:	funct7	rs2	rs1	funct3	rd	opcode
			0000000	01010	10010	000	00101	0110011
= 0x00A922B3								

lw x6, 16(x5)

Mo	op	fn:	imm[11:0]	rs1	funct3	rd	opcode
			000000010000	00101	010	00110	0000011
= 0x0102A303							

slli x7, x6, 2

Mo	op	fn:	funct7	shamt	rs1	funct3	rd	opcode
			0000000	00010	00110	001	00111	0010011
= 0x00231393								

sw x7, 4(x5)

Mo	op	fn:	imm[11:5]	rs2	rs1	funct3	imm[4:0]	opcode
			0000000	00111	00101	010	00100	0100011
= 0x0072A223								