CS122A: Intermediate Embedded and Real Time Operating Systems

Jeffrey McDaniel

University of California, Riverside


► A **control system** is an embedded system that regulates the behavior of a physical device


- A control system is an embedded system that regulates the behavior of a physical device
- ▶ It attempts to match a system value to a desired value

- ► A **control system** is an embedded system that regulates the behavior of a physical device
- ▶ It attempts to match a system value to a desired value
- Cruise control and water heaters are common examples


- ► A **control system** is an embedded system that regulates the behavior of a physical device
- ▶ It attempts to match a system value to a desired value
- ► Cruise control and water heaters are common examples
- ► The **plant** is the device being controlled

- ► A **control system** is an embedded system that regulates the behavior of a physical device
- ▶ It attempts to match a system value to a desired value
- Cruise control and water heaters are common examples
- ▶ The **plant** is the device being controlled
- ▶ The **controller** takes feedback and controls the plant







► The plant (water tank) outputs the actual value (actual water temperature) which is the value to be regulated




- ► The plant (water tank) outputs the actual value (actual water temperature) which is the value to be regulated
- ▶ This actual value is used as **feedback** to the controller




- ► The plant (water tank) outputs the actual value (actual water temperature) which is the value to be regulated
- ▶ This actual value is used as **feedback** to the controller
- The controller uses the actuator input (flame) to alter the output



- ► The plant (water tank) outputs the actual value (actual water temperature) which is the value to be regulated
- ▶ This actual value is used as **feedback** to the controller
- ► The controller uses the actuator input (flame) to alter the output
- ► The controller also has a desired output value (desired water temperature) as input



► The **error** is the difference between the desired and actual value (*desired - actual*)



- ► The **error** is the difference between the desired and actual value (*desired actual*)
- ► The job of the controller is to reduce this error to zero by altering the actuator input based on the feedback


- Actuator (gas valve): 8 bit value (0-200) (B)
- ▶ Desired temperature: 4 bit value (0-100°C/ 10) (A3:0)
- ► Actual temperature: 4 bit value (0-100°C/ 10) (A7:4)

```
#define Actuator B
unsigned char Desired(){
    return (A & OxOF);
}
unsigned char Actual(){
    return (A & OxFO) >> 4;
}
signed char Error;
```

- Actuator (gas valve): 8 bit value (0-200) (B)
- ▶ Desired temperature: 4 bit value (0-100°C/ 10) (A3:0)
- ► Actual temperature: 4 bit value (0-100°C/ 10) (A7:4)

```
#define Actuator B
unsigned char Desired(){
   return (A & OxOF);
}
unsigned char Actual(){
   return (A & OxFO) >> 4;
}
Error=Desired()-Actual()
signed char Error;
Actuator=???
```

- ► Actuator (gas valve): 8 bit value (0-200) (B)
- ▶ Desired temperature: 4 bit value (0-100°C/10) (A3:0)
- ► Actual temperature: 4 bit value (0-100°C/ 10) (A7:4)




- ► Actuator (gas valve): 8 bit value (0-200) (B)
- ▶ Desired temperature: 4 bit value (0-100°C/10) (A3:0)
- Actual temperature: 4 bit value (0-100°C/ 10) (A7:4)


```
Actuator=0 Ctrl Heat()
```

```
unsigned char Heat(){
  if (Desired() < Actual()) {
    Actuator = 200;
  }
}</pre>
```


On-off control is the simplest method




- On-off control is the simplest method
- ► Turn on actuator if Desired() < Actual()




- On-off control is the simplest method
- Turn on actuator if
 Desired() < Actual()</pre>
- Actual may overshoot desired



- On-off control is the simplest method
- ► Turn on actuator if Desired() < Actual()
- Actual may overshoot desired
- ► Turning off actuator lowers the actual temperature



- On-off control is the simplest method
- Turn on actuator if
 Desired() < Actual()</pre>
- Actual may overshoot desired
- ► Turning off actuator lowers the actual temperature
- Actual temperature will oscillate around desired temperature




► The time it takes to bring the lower actual value to the desired value is the **rise time**

- ► The time it takes to bring the lower actual value to the desired value is the **rise time**
- ► Too slow a rise time is not desirable, but overshooting is also not desirable

- The time it takes to bring the lower actual value to the desired value is the rise time
- ► Too slow a rise time is not desirable, but overshooting is also not desirable
- Oscillation is also not desirable, although it is inevitable


- The time it takes to bring the lower actual value to the desired value is the rise time
- ► Too slow a rise time is not desirable, but overshooting is also not desirable
- ▶ Oscillation is also not desirable, although it is inevitable
- ➤ A system with oscillation amplitude increasing over time is said to be unstable

Proportional Control



 Overshoot needs to be avoided, rise time needs to be quick, and oscillation needs to be minimized


Proportional Control



- Overshoot needs to be avoided, rise time needs to be quick, and oscillation needs to be minimized
- In a proportional controller the actuator (flame) is set proportionally to the error.

$$Actuator = Kp * Error$$

Proportional Control




- Overshoot needs to be avoided, rise time needs to be quick, and oscillation needs to be minimized
- In a proportional controller the actuator (flame) is set proportionally to the error.


Actuator = Kp * Error

Actuator is reduced as actual approaches desired value


▶ Proportional control does not take into account the *rate of change* of the output value.

- Proportional control does not take into account the rate of change of the output value.
- Problems of overshoot, oscillation, and slow rise time can be overcome even further using a Proportional-Derivative (PD) controller






$$Actuator = K_p * Error - K_d * Deriv$$




$$Actuator = K_p * Error - K_d * Deriv$$

$$f(x) = e^x + log_{10x^2} + x^2$$



Actuator =
$$K_p * Error - K_d * Deriv$$

 $f(x) = e^x + log_{10^{x^2}} + x^2$
 $Deriv = f'(x) = ?$



$$Actuator = K_p * Error - K_d * Deriv$$

$$Deriv = Actual - Actual Prev$$

► Control systems can suffer from **steady-state error** where the actual output value never reaches the desired value

- ► Control systems can suffer from **steady-state error** where the actual output value never reaches the desired value
- ► Steady-state error can be approximated using the sum of past error values

- ► Control systems can suffer from **steady-state error** where the actual output value never reaches the desired value
- Steady-state error can be approximated using the sum of past error values
- ► This sum can be computed as the area under the curve, or the plots integral

- Control systems can suffer from steady-state error where the actual output value never reaches the desired value
- Steady-state error can be approximated using the sum of past error values
- This sum can be computed as the area under the curve, or the plots integral

$$Actuator = K_p * Error + K_i * Integ - K_d * Deriv$$

With $K_i \ll K_p$ typically

- Control systems can suffer from steady-state error where the actual output value never reaches the desired value
- Steady-state error can be approximated using the sum of past error values
- This sum can be computed as the area under the curve, or the plots integral

$$Actuator = K_p * Error + K_i * Integ - K_d * Deriv$$

With $K_i \ll K_p$ typically

 Limits must be set on these values based on the actuator abilities

- Control systems can suffer from steady-state error where the actual output value never reaches the desired value
- Steady-state error can be approximated using the sum of past error values
- This sum can be computed as the area under the curve, or the plots integral

$$Actuator = K_p * Error + K_i * Integ - K_d * Deriv$$

With $K_i \ll K_p$ typically

- Limits must be set on these values based on the actuator abilities
- These values are typically calculated using floating point numbers, which are computationally intensive, integer approximations can sometimes be acceptable