

Vantage Instruments

Model VX-220 Operating Manual

Document VI-DOC-4417

Revision 2 - issued February 2026

This manual describes the installation, routine operation and field calibration of the bench analyser. Read the safety notices in section 1 before connecting the instrument to a supply.

1. Installation and Bench Preparation

Where a measurement fell outside of the agreed tolerance band, the deviation is listed together with the corrective action taken to close it and the date on which it was signed off.

Reviewers are asked to confirm that the values reproduced here match the records held by the originating department before the report is filed with the registry.

The retention schedule that applies to the supporting evidence is unchanged, and the material remains available to the auditors on written request for the duration of the term.

Nothing set out in this section is intended to vary the terms of the master agreement, all of which continue to apply to the parties in full.

2. Routine Operation

Reviewers are asked to confirm that the values reproduced here match the records held by the originating department before the report is filed with the registry.

The retention schedule that applies to the supporting evidence is unchanged, and the material remains available to the auditors on written request for the duration of the term.

Nothing set out in this section is intended to vary the terms of the master agreement, all of which continue to apply to the parties in full.

Questions about the content of this page should be directed to the document owner named on the cover sheet, who will route them to the responsible team.

3. Field Calibration

The retention schedule that applies to the supporting evidence is unchanged, and the material remains available to the auditors on written request for the duration of the term.

Nothing set out in this section is intended to vary the terms of the master agreement, all of which continue to apply to the parties in full.

Questions about the content of this page should be directed to the document owner named on the cover sheet, who will route them to the responsible team.

The figures quoted in this section were reconciled against the operational ledger at the close of the reporting period, and none of them carry an outstanding exception.

Tighten the manifold clamp to 3.2 Nm using a calibrated torque driver, then repeat the leak check before the instrument is returned to service.