## **PROGRAM** READ MACRO X MOV DX, OFFSET X MOV AH,3FH INT 21H **ENDM** DISPLAY MACRO X MOV DX, OFFSET X MOV AH,09H INT 21H **ENDM** .MODEL SMALL .STACK .DATA MSG1 DB 0AH,0DH,"ENTER THE STRING:\$" MSG2 DB 0AH,0DH,"ENTER THE CHARACTER TO BE REPLACED: \$" MSG3 DB 0AH,0DH,"ENTER THE CHARACTER TO BE REPLACED WITH: \$" MSG4 DB 0AH,0DH," NEW STRING IS: \$" STR1 DB 100 DUP("\$") .CODE START: MOV AX,@DATA MOV DS,AX DISPLAY MSG1 **READ STR1 DISPLAY MSG2** MOV AH,01H INT 21H MOV BL,AL **DISPLAY MSG3** MOV AH,01H INT 21H

MOV CL,AL MOV SI,00H

```
L0:
      CMP STR1[SI],'$'
      JE L3
L1:
      CMP STR1[SI],BL
      JE L2
      INC SI
      JMP L0
L2:
      MOV STR1[SI],CL
      INC SI
      JMP L0
L3:
      DISPLAY MSG1
      DISPLAY STR1
      MOV AH,4CH
      INT 21H
```

## **OUTPUT**

**ENTER THE STRING: AMMU** 

**END START** 

ENTER THE CHARACTER TO BE REPLACED: M

ENTER THE CHARACTER TO BE REPLACED WITH: P

**NEW STRING IS: APPU**