NAME

sane-lexmark - SANE backend for Lexmark X1100/X1200 Series scanners

DESCRIPTION

The **sane-lexmark** library implements a SANE (Scanner Access Now Easy) backend that provides access to the scanner part of Lexmark X1100/X1200 AIOs. This backend should be considered **beta-quality** software!

The scanners that should work with this backend are:

	Vendor	Model	status
-	Lexmark	x74	good
	Lexmark	X1110	untested
	Lexmark	X1140	untested
	Lexmark	X1150	good
	Lexmark	X1170	good
	Lexmark	X1180	good
	Lexmark	X1185	complete
	Lexmark	X12xx	good in USB1.1,
			not fully tested in $USB2.0$
	Dell	A920	good

The options the backend supports can either be selected through command line options to programs like **scanimage**(1) or through GUI elements in **xscanimage**(1) or **xsane**(1).

If you notice any strange behavior, please report to the backend maintainer or to the SANE mailing list.

Valid command line options and their syntax can be listed by using

scanimage --help -d lexmark:usb:<usb port>

Scan Mode Options

--mode

selects the basic mode of operation of the scanner. Valid choices are *Color*, *Gr ay* and *Lineart*. The default mode is *Color*. The *Lineart* mode is black and white only (1 bit). *Gr ay* mode will produce 256 levels of gray (8 bits). *Color* mode allo ws for over 16 million different colors produced from 24 bits of color information.

--resolution

selects the resolution for a scan. The horizontal and vertical resolutions are set by the value of this option. The scanner is capable of the following resolutions for the specified option value:

Value	Hor. Resolution	Vert. Resolution
75	75dpi	75dpi
150	150dpi	150dpi
300	300dpi	300dpi
600	600dpi	600dpi
1200	600dpi	1200dpi (only for X11xx models with 'B2' sensor

--preview

requests a preview scan. The resolution used for that scan is 75 dpi and the scan area and the scan mode are as specified through their options, or the default if not specified. The default value for preview mode is "no".

12 Jul 2008 1

--threshold

selects the minimum-brightness to get a white point. The threshold is only used with Lineart mode scans. It is specified as a percentage in the range 0..100% (in steps of 1). The default value of the threshold option is 50.

CONFIGURATION FILE

The configuration file /etc/sane.d/lexmark.conf contains only the usb device id (eg usb 0x043d 0x007c).

FILES

/usr/lib/x86_64-linux-gnu/sane/libsane-lexmark.a

The static library implementing this backend.

/usr/lib/x86_64-linux-gnu/sane/libsane-lexmark.so

The shared library implementing this backend (present on systems that support dynamic loading).

ENVIRONMENT

SANE_DEBUG_LEXMARK

If the library was compiled with debug support enabled, this environment variable controls the debug level for this backend. E.g., a value of 255 requests all debug output to be printed. Smaller levels reduce verbosity.

SANE_DEBUG_LEXMARK_LOW

Provides debug output for low level Lexmark functions.

LIMITATIONS

The windows TWAIN driver has many more options than this SANE backend. However they are only software adjustments. This backend only implements what the scanner can support. For instance, shading correction (vertical stripes due to sensor variation across its width) is done in software. Head park position is also detected by software. The data compression isn't supported for the X1200 series on USB 1.1, leading to slow scans.

BUGS

No bugs currently known.

SEE ALSO

```
sane-scsi(5), scanimage(1), xscanimage(1), xsane(1), sane(7)
```

AUTHOR

The backend was originally written by Fred Odendaal.

http://ca.geocities.com/freshshelf@rogers.com/

The new version is currently developed by Stéphane Voltz.

http://stef.dev.free.fr/sane/lexmark

X74 support was written by Torsten Houwaart

<ToHo@gmx.de>

12 Jul 2008 2

CREDITS

Many thanks go to:

Julien Furgerot who lent me a Dell A920. Robert Price, Dani Ele and Dalai Felinto for the time they spent recording USB activity and testing the experimental version.

12 Jul 2008 3