# **NAME**

usb\_printerid - prints the ID of the printer on a USB port

### **SYNOPSIS**

usb\_printerid [options] /dev/usb/lpNNN

### **DESCRIPTION**

**usb\_printerid** prints the identification of the printer on a USB port using the ioctl control **LPIOC\_GET\_DEVICE\_ID**.

#### **EXAMPLES**

Print the USB info before and after downloading the firmware.

```
# usb_printerid /dev/usb/lp0
GET_DEVICE_ID string:
MFG:Hewlett-Packard;MDL:HP LaserJet 1020;CMD:ACL;CLS:PRINTER;\
DES:HP LaserJet 1020;

# cp /lib/firmware/hp/sihp1020.dl /dev/usb/lp0

# usb_printerid /dev/usb/lp0
GET_DEVICE_ID string:
MFG:Hewlett-Packard;MDL:HP LaserJet 1020;CMD:ACL;CLS:PRINTER;\
DES:HP LaserJet 1020;FWVER:20050309;
```

#### **FILES**

/usr/bin/usb\_printerid, /lib/firmware/hp/\*

### **SEE ALSO**

arm2hpdl(1)

# **AUTHOR**

Rick Richardson < rick.richardson@comcast.net> http://foo2zjs.rkkda.com/